

FIRMA	MODEL	Typ / Opis	CHASSIS	Chassis Model
Panasonic	chassis AC1 PCB	TV	AC1	
Panasonic	chassis ALPHA-2 PCB on	TV	ALPHA-2	
Panasonic	chassis ALPHA-4 PCB on	TV	ALPHA-4	
Panasonic	chassis EURO-1 PCB only	TV	EURO-1	
Panasonic	chassis EURO-2 PCB onl	TV	EURO-2	
Panasonic	chassis EURO-2L PCB or	TV	EURO-2L	
Panasonic	chassis EURO-2M PCB o	TV	EURO-2M	
Panasonic	chassis EURO-2S PCB o	TV	EURO-2S	
Panasonic	chassis EURO-3 PCB onl	TV	EURO-3	
Panasonic	chassis EURO-3H PCB o	TV	EURO-3H	
Panasonic	chassis EURO-3HW PCB	TV	EURO-3HW	
Panasonic	chassis EURO-3HWS PCI	TV	EURO-3HWS	
Panasonic	chassis EURO-3W PCB c	TV	EURO-3W	
Panasonic	chassis EURO-4 PCB onl	TV	EURO-4	
Panasonic	chassis EURO-5 PCB onl	TV	EURO-5	
Panasonic	chassis Z5 PCB only	TV	Z5	
Panasonic	chassis Z7 PCB only	TV	Z7	
Panasonic	chassis Z8 PCB only	TV	Z8	
Panasonic	TC-14B3R	TV	Z375	
Panasonic	TC-14K1R	TV	Z7	
Panasonic	TC-14R1	TV	Z3	
Panasonic	TC-14R1L	TV	Z3	
Panasonic	TC-14S1R	TV	Z5	
Panasonic	TC-14S1R/B/BH	TV	Z5	
Panasonic	TC-14S2R	TV	Z5	
Panasonic	TC-14S3M	TV	Z7	
Panasonic	TC-14S3MC	TV	Z7	
Panasonic	TC-14S3R	TV	Z7	
Panasonic	TC-14S3R/W	TV	Z7	
Panasonic	TC-14S3RC	TV	Z7	
Panasonic	TC-14S3RF	TV	Z7	
Panasonic	TC-14S3RL	TV	Z7	
Panasonic	TC-14S3RP	TV	Z7	
Panasonic	TC-14S4RC	TV	Z7	
Panasonic	TC-14S4RF	TV	Z7	
Panasonic	TC-14S4RL	TV	Z7	
Panasonic	TC-14S4RP	TV	Z7	
Panasonic	TC-15M2R	TV	Z4	
Panasonic	TC-15M2T	TV	Z4	
Panasonic	TC-21K1R	TV	Z7	
Panasonic	TC-21M2R	TV	Z4	
Panasonic	TC-21M2T	TV	Z4	
Panasonic	TC-21S1M	TV	Z5	
Panasonic	TC-21S1R	TV	Z5	
Panasonic	TC-21S1R/B/BH/BN	TV	Z5	
Panasonic	TC-21S3M	TV	Z7	
Panasonic	TC-21S3MC	TV	Z7	
Panasonic	TC-21S3R	TV	Z7	
Panasonic	TC-21S3RC	TV	Z7	
Panasonic	TC-21S3RF	TV	Z7	
Panasonic	TC-21S3RL	TV	Z7	
Panasonic	TC-21S3RP	TV	Z7	
Panasonic	TC-21S4RC	TV	Z7	
Panasonic	TC-21S4RF	TV	Z7	
Panasonic	TC-21S4RL	TV	Z7	

Panasonic	TC-21S4RP	TV	Z7
Panasonic	TC-42P1	TV	GP2D
Panasonic	TC-42P1F	TV	GP2D
Panasonic	TX-14B3T	TV	Z375
Panasonic	TX-14C3T/S	TV	Z7
Panasonic	TX-14C3T/Y	TV	Z7
Panasonic	TX-14K1T	TV	Z7
Panasonic	TX-14K2T	TV	Z7
Panasonic	TX-14S1T	TV	Z5
Panasonic	TX-14S1T/B/BH	TV	Z5
Panasonic	TX-14S2T	TV	Z5
Panasonic	TX-14S3T	TV	Z7
Panasonic	TX-14S3T/W	TV	Z7
Panasonic	TX-14S3TC	TV	Z7
Panasonic	TX-14S3TF	TV	Z7
Panasonic	TX-14S3TL	TV	Z7
Panasonic	TX-14S3TP	TV	Z7
Panasonic	TX-14S4TC	TV	Z7
Panasonic	TX-14S4TF	TV	Z7
Panasonic	TX-14S4TL	TV	Z7
Panasonic	TX-14S4TP	TV	Z7
Panasonic	TX-21AD2	TV	EURO-2S
Panasonic	TX-21AD2/M	TV	EURO-2
Panasonic	TX-21AD2DP	TV	EURO-2L
Panasonic	TX-21AD2DP/M	TV	EURO-2
Panasonic	TX-21AD2F	TV	EURO-2
Panasonic	TX-21AD3C	TV	EURO-2
Panasonic	TX-21AD3F	TV	EURO-2
Panasonic	TX-21CK1	TV	Z8
Panasonic	TX-21K1T	TV	Z7
Panasonic	TX-21K2T	TV	Z7
Panasonic	TX-21MD1	TV	EURO-2L
Panasonic	TX-21MD1C/P	TV	EURO-2L
Panasonic	TX-21MD1E	TV	EURO-2L
Panasonic	TX-21MD1F	TV	EURO-2L
Panasonic	TX-21MD1L	TV	EURO-2L
Panasonic	TX-21MD3	TV	EURO-2M
Panasonic	TX-21MD3C	TV	EURO-2M
Panasonic	TX-21MD3E	TV	EURO-2M
Panasonic	TX-21MD3F	TV	EURO-2M
Panasonic	TX-21MD3P	TV	EURO-2M
Panasonic	TX-21MD4	TV	EURO-4
Panasonic	TX-21MD4C	TV	EURO-4
Panasonic	TX-21MD4F	TV	EURO-4
Panasonic	TX-21MD4L	TV	EURO-4
Panasonic	TX-21MD4P	TV	EURO-4
Panasonic	TX-21S1T	TV	Z5
Panasonic	TX-21S1T/B/BH/BN	TV	Z5
Panasonic	TX-21S3T	TV	Z7
Panasonic	TX-21S3TC	TV	Z7
Panasonic	TX-21S3TF	TV	Z7
Panasonic	TX-21S3TL	TV	Z7
Panasonic	TX-21S3TP	TV	Z7
Panasonic	TX-21S4TC	TV	Z7
Panasonic	TX-21S4TF	TV	Z7
Panasonic	TX-21S4TL	TV	Z7

Panasonic	TX-21S4TP	TV	Z7
Panasonic	TX-21V2	TV	ALPHA-4
Panasonic	TX-24W1	TV	ALPHA-2W
Panasonic	TX-25A2X	TV	ALPHA-3
Panasonic	TX-25A3	TV	EURO-1
Panasonic	TX-25AD1	TV	EURO-2S
Panasonic	TX-25AD1D	TV	EURO-2
Panasonic	TX-25AD1DP	TV	EURO-2S
Panasonic	TX-25AD1E	TV	EURO-2S
Panasonic	TX-25AD1F	TV	EURO-2
Panasonic	TX-25AD2	TV	EURO-2S
Panasonic	TX-25AD2C	TV	EURO-2
Panasonic	TX-25AD2DP	TV	EURO-2S
Panasonic	TX-25AD2P	TV	EURO-2S
Panasonic	TX-25AD2P	TV	EURO-2S
Panasonic	TX-25AD50F	TV	EURO-3H
Panasonic	TX-25AD50F/P	TV	EURO-3H
Panasonic	TX-25AD50F/S	TV	EURO-3
Panasonic	TX-25AD70C	TV	EURO-3H
Panasonic	TX-25AD70F	TV	EURO-3H
Panasonic	TX-25AD70F/P	TV	EURO-3H
Panasonic	TX-25AD90F	TV	EURO-5
Panasonic	TX-25EX4F	TV	EURO-4
Panasonic	TX-25G1	TV	ALPHA-2W
Panasonic	TX-25LD4C	TV	EURO-4
Panasonic	TX-25LD4DP	TV	EURO-4
Panasonic	TX-25LD4F	TV	EURO-4
Panasonic	TX-25LD4P	TV	EURO-4
Panasonic	TX-25LD90P	TV	EURO-5
Panasonic	TX-25LDM4F	TV	EURO-4
Panasonic	TX-25MD1	TV	EURO-2L
Panasonic	TX-25MD1E	TV	EURO-2L
Panasonic	TX-25MD1F	TV	EURO-2L
Panasonic	TX-25MD1L	TV	EURO-2L
Panasonic	TX-25MD1P	TV	EURO-2L
Panasonic	TX-25MD3	TV	EURO-2M
Panasonic	TX-25MD3C	TV	EURO-2M
Panasonic	TX-25MD3E	TV	EURO-2M
Panasonic	TX-25MD3F	TV	EURO-2M
Panasonic	TX-25MD3P	TV	EURO-2M
Panasonic	TX-25MD4	TV	EURO-4
Panasonic	TX-25MD4C	TV	EURO-4
Panasonic	TX-25MD4F	TV	EURO-4
Panasonic	TX-25MD4L	TV	EURO-4
Panasonic	TX-25MD4P	TV	EURO-4
Panasonic	TX-25MD5E	TV	EURO-2L
Panasonic	TX-25MDT3F	TV	EURO-2M
Panasonic	TX-25MDT4F	TV	EURO-4
Panasonic	TX-25MDX3E	TV	EURO-2M
Panasonic	TX-25SL1F	TV	EURO-4
Panasonic	TX-25X1	TV	ALPHA-4
Panasonic	TX-25X1DP	TV	ALPHA-4
Panasonic	TX-25XD1C	TV	EURO-2S
Panasonic	TX-25XD1E	TV	EURO-2S
Panasonic	TX-25XD1F	TV	EURO-2S
Panasonic	TX-25XD3C	TV	EURO-2M

Panasonic	TX-25XD3E	TV	EURO-2M
Panasonic	TX-25XD3F	TV	EURO-2M
Panasonic	TX-25XD3P	TV	EURO-2M
Panasonic	TX-25XD4/A	TV	EURO-4
Panasonic	TX-25XD4C	TV	EURO-4
Panasonic	TX-25XD4F	TV	EURO-4
Panasonic	TX-25XD4P/A	TV	EURO-4
Panasonic	TX-25XD60C	TV	EURO-3H
Panasonic	TX-25XD60F	TV	EURO-3H
Panasonic	TX-25XD60P	TV	EURO-3H
Panasonic	TX-25XD60S	TV	EURO-3H
Panasonic	TX-25XD90F/A/B	TV	EURO-5
Panasonic	TX-25XD90P/A/B	TV	EURO-5
Panasonic	TX-25XDP3	TV	EURO-2M
Panasonic	TX-25XDP3L	TV	EURO-2M
Panasonic	TX-28A2X	TV	ALPHA-3
Panasonic	TX-28DT2	TV	EURO-4D
Panasonic	TX-28EX1F	TV	EURO-4
Panasonic	TX-28EX4F	TV	EURO-4
Panasonic	TX-28G1	TV	ALPHA-2W
Panasonic	TX-28LD1	TV	EURO-2
Panasonic	TX-28LD1C	TV	EURO-2
Panasonic	TX-28LD1E	TV	EURO-2L
Panasonic	TX-28LD1F	TV	EURO-2
Panasonic	TX-28LD1P	TV	EURO-2
Panasonic	TX-28LD2P	TV	EURO-2M
Panasonic	TX-28LD4C	TV	EURO-4
Panasonic	TX-28LD4DP	TV	EURO-4
Panasonic	TX-28LD4DPL	TV	EURO-4
Panasonic	TX-28LD4F	TV	EURO-4
Panasonic	TX-28LD4P	TV	EURO-4
Panasonic	TX-28LD5E	TV	EURO-2L
Panasonic	TX-28LD7C	TV	EURO-2L
Panasonic	TX-28LDM4F	TV	EURO-4
Panasonic	TX-28LDP4F	TV	EURO-4
Panasonic	TX-28MD3	TV	EURO-2M
Panasonic	TX-28MD3C	TV	EURO-2M
Panasonic	TX-28MD3E	TV	EURO-2M
Panasonic	TX-28MD3F	TV	EURO-2M
Panasonic	TX-28MD3P	TV	EURO-2M
Panasonic	TX-28MD4	TV	EURO-4
Panasonic	TX-28MD4C	TV	EURO-4
Panasonic	TX-28MD4F	TV	EURO-4
Panasonic	TX-28MD4L	TV	EURO-4
Panasonic	TX-28MD4P	TV	EURO-4
Panasonic	TX-28MDT3F	TV	EURO-2M
Panasonic	TX-28MDT4F	TV	EURO-4
Panasonic	TX-28MDX3E	TV	EURO-2M
Panasonic	TX-28PK10	TV	EURO-5L
Panasonic	TX-28SL10F	TV	EURO-5
Panasonic	TX-28SL1F	TV	EURO-4
Panasonic	TX-28W1	TV	ALPHA-2W
Panasonic	TX-28X1	TV	ALPHA-4
Panasonic	TX-28X1DP	TV	ALPHA-4
Panasonic	TX-28XD1C	TV	EURO-2S
Panasonic	TX-28XD1E	TV	EURO-2S

Panasonic	TX-28XD1F	TV	EURO-2S
Panasonic	TX-28XD3	TV	EURO-2M
Panasonic	TX-28XD3C	TV	EURO-2M
Panasonic	TX-28XD3E	TV	EURO-2M
Panasonic	TX-28XD3F	TV	EURO-2M
Panasonic	TX-28XD3L	TV	EURO-2M
Panasonic	TX-28XD3P	TV	EURO-2M
Panasonic	TX-28XD4/A	TV	EURO-4
Panasonic	TX-28XD4C	TV	EURO-4
Panasonic	TX-28XD4F	TV	EURO-4
Panasonic	TX-28XD4P/A	TV	EURO-4
Panasonic	TX-28XD60C	TV	EURO-3H
Panasonic	TX-28XD60F	TV	EURO-3H
Panasonic	TX-28XD60P	TV	EURO-3H
Panasonic	TX-28XD60S	TV	EURO-3H
Panasonic	TX-28XD6C	TV	EURO-2S
Panasonic	TX-28XD70C	TV	EURO-3H
Panasonic	TX-28XD70F	TV	EURO-3H
Panasonic	TX-28XD7C	TV	EURO-2M
Panasonic	TX-28XD90F/A/B	TV	EURO-5
Panasonic	TX-28XD90P/A/B	TV	EURO-5
Panasonic	TX-28XDP1C	TV	EURO-2S
Panasonic	TX-28XDP1F	TV	EURO-2S
Panasonic	TX-28XDP3	TV	EURO-2M
Panasonic	TX-28XDP3L	TV	EURO-2M
Panasonic	TX-29A3	TV	EURO-1
Panasonic	TX-29AD1	TV	EURO-2S
Panasonic	TX-29AD1D	TV	EURO-2
Panasonic	TX-29AD1DP	TV	EURO-2S
Panasonic	TX-29AD1E	TV	EURO-2S
Panasonic	TX-29AD1F	TV	EURO-2
Panasonic	TX-29AD2	TV	EURO-2S
Panasonic	TX-29AD2/M	TV	EURO-2S
Panasonic	TX-29AD2C	TV	EURO-2
Panasonic	TX-29AD2DP	TV	EURO-2S
Panasonic	TX-29AD2DP/M	TV	EURO-2S
Panasonic	TX-29AD2P	TV	EURO-2S
Panasonic	TX-29AD3F	TV	EURO-2S
Panasonic	TX-29AD3P	TV	EURO-2S
Panasonic	TX-29AD50F	TV	EURO-3H
Panasonic	TX-29AD50F/P	TV	EURO-3H
Panasonic	TX-29AD50F/S	TV	EURO-3
Panasonic	TX-29AD70C	TV	EURO-3H
Panasonic	TX-29AD70DP	TV	EURO-3H
Panasonic	TX-29AD70F	TV	EURO-3H
Panasonic	TX-29AD70F/P	TV	EURO-3H
Panasonic	TX-29AD90F	TV	EURO-5
Panasonic	TX-29AK10P	TV	EURO-5
Panasonic	TX-29LD90P	TV	EURO-5
Panasonic	TX-32DT2	TV	EURO-4D
Panasonic	TX-32PF10	TV	EURO-5
Panasonic	TX-32PF10F	TV	EURO-5
Panasonic	TX-33AK10	TV	EURO-5
Panasonic	TX-36PF10	TV	EURO-5
Panasonic	TX-36PF10F	TV	EURO-5
Panasonic	TX-G10	TV	AC1

Panasonic	TX-G10/C	TV	AC1
Panasonic	TX-W28D2DP	TV	EURO-3HW
Panasonic	TX-W28D2DP	TV	EURO-3HW
Panasonic	TX-W28D2F	TV	EURO-3HW
Panasonic	TX-W28D2F/P	TV	EURO-3HW
Panasonic	TX-W28D3F	TV	EURO-3HW
Panasonic	TX-W28D3F/P	TV	EURO-3HW
Panasonic	TX-W28D4F	TV	EURO-5
Panasonic	TX-W28D5F	TV	EURO-5
Panasonic	TX-W28D5F/P	TV	EURO-5
Panasonic	TX-W28LD90F	TV	EURO-5
Panasonic	TX-W28R3	TV	EURO-3W
Panasonic	TX-W28R3DP	TV	EURO-3W
Panasonic	TX-W28R3F/L	TV	EURO-3W
Panasonic	TX-W28R4	TV	EURO-4
Panasonic	TX-W28R4DP	TV	EURO-4
Panasonic	TX-W28R4F	TV	EURO-4
Panasonic	TX-W28R4L	TV	EURO-4
Panasonic	TX-W32D2	TV	EURO-3HW
Panasonic	TX-W32D20	TV	EURO-3HW
Panasonic	TX-W32D2DP	TV	EURO-3HW
Panasonic	TX-W32D2DP	TV	EURO-3HW
Panasonic	TX-W32D2F	TV	EURO-3HW
Panasonic	TX-W32D2F/P	TV	EURO-3HW
Panasonic	TX-W32D3DP	TV	EURO-3HW
Panasonic	TX-W32D3DP/L	TV	EURO-3HW
Panasonic	TX-W32D3F	TV	EURO-3HW
Panasonic	TX-W32D3F/P	TV	EURO-3HW
Panasonic	TX-W32D4DP	TV	EURO-5
Panasonic	TX-W32D4F	TV	EURO-5
Panasonic	TX-W32D5DPF	TV	EURO-5
Panasonic	TX-W32D5F	TV	EURO-5
Panasonic	TX-W32D5F/P	TV	EURO-5
Panasonic	TX-W32LD90F	TV	EURO-5
Panasonic	TX-W32R4	TV	EURO-4
Panasonic	TX-W32R4DP	TV	EURO-4
Panasonic	TX-W36D3DP	TV	EURO-3HWS
Panasonic	TX-W36D3DP/L	TV	EURO-3HWS

☐ CheckBox1

**echanizm**











box1