



Yc DISPLAY BOARD 033 075 35




CONTROL UNIT




Nc KEYBOARD
NAPPAINLEVY
033 075 42

Yc DISPLAY BOARD
NAYTTOLEVY
033 075 28




Fc DISPLAY DRIVER MODULE
NAYTON OHJAUSMODULI
033 075 73
033 075 80


Jc RC-RECEIVER
KS-VAST OTIN



033064-19 033065-12



PICTURE IF




TYPES 113 • 114
MODELS 1131 • 1141 • 1132 • 1142
2131 • 2141 • 2132 • 2142
THS MODELS F261 • F262 • F281 • F282

Схема для
свободного
распространения!
НЕ ПРОДАВАТЬ,
УЗНАЮ-ВЫЕБУ!

033064-19


033065-12


FREQUENCY SYNTHESIZER



PICTURE IF

VOLTAGE REGULATOR





R A D I O I O N





Схема для
свободного
распространения!
НЕ ПРОДАВАТЬ,
УЗНАЮ-ВЫЕБУ!








SIGNAL UNIT

033 064-1₉

033 065-1₂

RADIOLOM






KEX MATRIX

Tryckknappssats FK "Bred" 80404396


FK 03021³²³~~822~~ = K9519



- VID** = VIDEO SIG
- MUTE** = SOUND M
- SAND** = SANDCAS
- BCL** = BEAM CU
- T** = SWITCHING (ACTIVE P
- DIS ENA** = DISPLAY
- DATA** = SERIAL D
- RC** = REMOTE C
- RES** = RESERVE
- AUX** = AUDIO MO
- CL** = SERIAL C
- OIRT LED** = OPTIONAL
- BLINK** = DISPLAY
- HUE** = HUE CONT

033057-02

POWER SUPPLY-/DEFLECTION UNIT



POWER SUPPLY/
2000 FST
DEFLECTION UNIT

033 057 02

Amplifier	Gain control
Voltage regulator	Oscilloscope
Schmitt trigger	Master