

MAKE	MODEL	CHASSIS/EQUIVALENT	COMMENTS	COMMENTS	COMMENTS	COMMENTS			
Aiwa	TV14MT11		2004, F90-F110						
Aiwa	TV21MT11		2004, F165						
Aiwa	TVF21TS1U	Sony BX1 chassis	2003, F199	remote RMZ5200					
Aiwa	TVSE1430K	Daewoo CP385							
Aiwa	TVSE2130K	Daewoo CP385							
Aiwa	VX14MW1U	CP082S (Daewoo CP082)	2003						
Aiwa	VX21MW1U	CP082S (Daewoo CP082)	2003						
Aiwa	VXD1420K	combi Orion chassis, deck OVD-6S	PCB marked TM9423A, video VM9171B	Micro OEC0085B, option codes	LOPTR Q406 2SD2599				
Aiwa	VXD1450K	combi Orion chassis, deck OVD-7							
Aiwa	VXD2120K	combi Orion chassis, deck OVD-6S	PCB marked TM9450A, video VM9171B	Micro OEC0085B, option codes in EEPROM address 100H					
Aiwa	VXD2121K	combi Orion chassis, deck OVD-7	PCB marked TMA523A, video VMA239A	Micro OEC0113B					
Aiwa	VXD2150K	combi Orion chassis, deck OVD-7	PCB marked TMA523A, video VMA239A	Micro OEC0113B					
Aiwa	VXF121K	combi Orion chassis, deck OVD-6S	PCB marked TMX477A, video VMX199A	Micro OEC0096A					
Aiwa	VXG140K	combi Orion chassis, deck OVD-5	PCB marked TM7379, video VM7125	Micro OEC6044D					
Aiwa	VXG142K	combi Orion chassis, deck OVD-5A	PCB marked TM7379B, video VM7125	Micro OEC6044D					
Aiwa	VXG143K	combi Orion chassis, deck OVD-6	PCB marked TM9423A, video VM9162D	Micro OEC0078C, option codes EEPROM address 100H					
Aiwa	VXG143KAL (has "A" circled)	combi Orion chassis, deck OVD-6S	PCB marked TMX473A, video VMX193B	Micro OEC0093B					
Aiwa	VXG145K	combi Orion chassis, deck OVD-7	main PCB VMA230A , PSU PCB VPA150A	Micro OEC0107B, option codes EEPROM address 0B4h (0B4->0B4h)					
Aiwa	VXT1410K	combi Orion chassis, deck OVD-4A		Micro OEC6018					
Aiwa	VXT1420K	combi Orion chassis, deck OVD-4A	PCB marked TM4316, video VM4079	Micro OEC6025A					
Aiwa	VXT145K	combi Orion chassis, deck OVD-5	PCB marked TM8395A, video VM7125D	Micro OEC6044D					
Aiwa	VXT147K	combi Orion chassis, deck OVD-5A	PCB marked TM8395B, video VM7125	Micro OEC6044D	PSU IC501 STRF6653				
Aiwa	VXT1480K	combi Orion chassis, deck OVD-5	PCB marked TM7379A, video VM7125A	Micro OEC6044A					
Aiwa	VXT149K	combi Orion chassis, deck OVD-6	PCB marked TM9423A, video VM9162D	Micro OEC0078C, option codes EEPROM address 100H					
Aiwa	VXT149KAL (has "A" circled)	combi Orion chassis, deck OVD-6S	PCB marked TMX473A, video VMX193B	Micro OEC0093B					
Aiwa	VXT2010K	combi, deck TN5900	1992						
Akai	CT1417	Onwa							
Akai	CT2115UK	Samsung P58SC							
Akai	CT2125	Samsung P58SC							
Akai	CT2137	Akai CT2157							
Akai	CT2157	Akai CT2137							
Akai	CT2158	Sanyo E4-A21							
Akai	CT2159U	Onwa							
Akai	CT2161	Stereo plus							
Akai	CT2162UNT	Onwa							
Akai	CT2185	Sanyo A5-A21							
Akai	CT2565	Stereo plus							
Akai	CT2567	Stereo plus	Goodmans 285DPL						
Akai	CT2570	Compact D2	ITT						
Akai	CT2579N	Nokia Compact D-E							
Akai	CT2585N	Eurostereo2							
Akai	CT2820	Compact D2	ITT						
Akai	CT2862UNT	Onwa K9228							
Akai	CT2865	Stereo plus							
Akai	CT2867	Stereo plus							
Akai	CT2870N	Nokia Compact D2-E							
Akai	CT2879N	Nokia Compac D-E							
Akai	CT2885N	Eurostereo2							
Akai	MP237H1 (MP2 37 H1)	Mono Plus 2 (MP2)	=TV1420UK						
Akai	MZ82R1	Nokia/Salora/Luxor MZ-chassis							
Akai	SN63B6	Stereo Plus-2, same as TV2551TN	Nokia TV2881T						
Akai	SN71B6	Stereo Plus-2, same as TV2851TN	Nokia TV2881T						
Akai	SW72B2	Stereo Plus-2, same as TV2881T	Nokia TV2881T						
Akai	TV2551TN	Stereo Plus-2 (SN/SW chassis)	Nokia TV2881T						
Akai	TV2835T	Schneider TV9.7							
Akai	TV2851TN	Stereo Plus-2 (SN/SW chassis)	Nokia TV2881T						
Akai	TV2852TN	Stereo Plus-2 (SN/SW chassis)	Nokia TV2881T						
Akai	TV2881T	Stereo Plus-2 (SN/SW chassis)	Nokia TV2881T						
Akai	TV2891T	Nokia/Salora/Luxor MZ-chassis							
Akai	TV3291T	Nokia/Salora/Luxor MZ-chassis							
Akai	WSP28NTFSFDGB	PT92 +DVD							
Akai	WSP32NTFSFDGB(S)	PT92 +DVD							
Akai	TV1420UK ( TV1420TUK )	Mono Plus 2 (MP2)	remote RCN622						
Akai	TV1421(T)	Mono Plus 2 (MP2)							
Akai	TV2020(T)UK	Mono Plus 2 (MP2)							
Akai	TV2021(T)	Mono Plus 2 (MP2)							
Akai	TV2120(T)	Mono Plus 2 (MP2)							
Akai	TV2121(T)	Mono Plus 2 (MP2)							
Akashi	1450	Eltron EC142							
Akura	ATPTV028FT	PT92 ??							
Akura	ATPTV028WSS	PT92							
Akura	AVTV028WSS	PT92 or 11AK19Pro							
Akura	CX10	Boots CTV10R	Alba CTV10						
Akura	CX10	Nikkai Baby 10	Tourer						
Akura	CX10	Osaki P10R	Thorn P10R						
Akura	CX10	Samsung C1210R							
Akura	CX12	Thorn P14BT							
Akura	CX1400T	CX26							
Akura	CX1400T	Minoka MK 1495T							
Akura	CX18	Thorn P146R							
Akura	CX24								
Akura	CX25								
Akura	CX26	Digital Chassis							
Akura	CX30								
Akura	CX32	Thorn CT51R							
Akura	CX33	Thorn CT51T							
Akura	CX35								
Akura	CX4	Osaki P142	Thorn P142						
Alba	CS1919	Rank A823							
Alba	CTV10	Nikkai Baby 10							
Alba	CTV100	Matsui 1436	Bush 2004						
Alba	CTV1400	Harwood HTV3604R							
Alba	CTV14R	Nikkai TLG14R							
Alba	CTV3309	11AK20M-6	1999-	AK20 prod.code 10000107					
Alba	CTV3359	11AK20M-6	1999-	AK20 prod.code: 10000813	remote 930				
Alba	CTV3409	11AK08-13/14 or 11AK20M-3	11AK20 after 1999	AK20 prod.code 10000112					
Alba	CTV3410	Bush 2007 2033T 2167NTX 2169NTX							
Alba	CTV3411	Orion chassis	PCB marked TMX466B	LOPTR Q401 2SD2599	remote 076R0DG040				
Alba	CTV3418	11AK20M-6	1999, remote 930	AK20 prod.code 10000114					
Alba	CTV3418BLK	11AK36	remote 1940						
Alba	CTV3419SIL	11AK36	remote 1940						
Alba	CTV3451TXT	Orion chassis	PCB marked TMA504A	Micro OECF001A					
Alba	CTV3455	CTV841							
Alba	CTV3458	Bush 2007 2033T 2167NTX 2169NTX							
Alba	CTV3459	11AK08 or 11AK20M-6	11AK20 after 1999	AK20 prod.code 10000113					
Alba	CTV3469	11AK20 or 11AK36	chassis depends on the year						
Alba	CTV3481	Orion chassis	Micro PCJ195C30ECF009A (OECF009A)	Remote 076N0GE030					
Alba	CTV4805	Matsui 1455	Onwa						
Alba	CTV4808	11AK19E3							
Alba	CTV4809	11AK10(older) or 11AK19-5, 11AK19-8A, 11AK19E3 (after 1997)		AK19 prod.code: 10000233					
Alba	CTV4851	11AK19							
Alba	CTV4855	Onwa							
Alba	CTV4856	11AK10							
Alba	CTV4858SIL	11AK19E3 or 11AK30(2002-2003)	chassis depends on the year	11AK30 - 10014185					
Alba	CTV4859	11AK19-8A	1999-	AK19 prod.code: 10000234					
Alba	CTV4861SIL	Beko 12.7 chassis, PCB marked G70.190-10							
Alba	CTV4886	NEW ONWA (Bush 2060NTX)	1997	Micro C69609Y, PSU IC STRS6309					
Alba	CTV4889	11AK10-15, 11AK19-8A	AK19 after 1999	AK19 prod.code: 10000971					
Alba	CTV501	Onwa							
Alba	CTV5105SIL	Beko 12.7 chassis, PCB marked G70.190-03	2003, F100	LOPTx 058.013-TR7, 1142.1816, 003071095, equiv. HR8484, FBT40962					
Alba	CTV5109SIL	11AK30-2, 11AK30A4	2002-2003	AK30 prod.code: 10014183					
Alba	CTV5165SIL	Beko 12.7 chassis							
Alba	CTV5984	11AK19E3							
Alba	CTV6682	11AK12							
Alba	CTV6682A	11AK19							
Alba	CTV6688	11AK19 or 11AK37-8	11AK37 after 2002						
Alba	CTV701	Onwa							
Alba	CTV703	Alba CTV703 CTV704T CTV713	Bush 2020T 2021 2021T	Hinari HIT51T					
Alba	CTV704	Indiana 100	NEI						
Alba	CTV704T	Alba CTV703 CTV704T CTV713	Bush 2020T 2021 2021T	Hinari HIT51T					
Alba	CTV711	Indiana 100							
Alba	CTV712	Indiana 100	NEI						
Alba	CTV713	Alba CTV703 CTV704T CTV713	Bush 2020T 2021 2021T	Hinari HIT51T					
Alba	CTV741	Indiana 100	NEI						
Alba	CTV742	Indiana 100	NEI						
Alba	CTV743	C-43 (Bush 2914)							
Alba	CTV744	Indiana 100	NEI						
Alba	CTV747	Orion 14A chassis							

Alba	CTV748	Orion 14A chassis	PCB marked TM0157M, Micro OEC8034	Scan coils YS-60275K					
Alba	CTV752	Indiana 200	NEI						
Alba	CTV840	Onwa	also Bush 1402, Hinary HIT140RC	Goodmans 1404, 1404A					
Alba	CTV841	also Bush 1452T, Goodmans 147TT							
Alba	CTV841	Bush 2114							
Alba	PTV9C	Goodmans Q9001							
Alba	PTV9C	Samsung BT110							
Alba	T1114	Ferguson 3840							
Alba	T14	Bush 2007 2033T 2167NTX 2169NTX							
Alba	VTV10	Orion chassis (Bush BTV10)							
Amstrad	CTV1400	(new) = Crown CTF14R							
Amstrad	CTV1401	Orion 14PS	Saisho CT1400/Matsui 1410						
Amstrad	CTV1409	Orion 14PR	Saisho CT14R						
Amstrad	CTV1409	Triumph CTV8208							
Amstrad	CTV1410	Orion 14LR chassis	Alba CTV840						
Amstrad	CTV1600	Triumph CTV8205							
Amstrad	CTV20T	similar to CTV1400							
Amstrad	CTV2110	Onwa							
Amstrad	CTV280	Bush 2857							
Amstrad	CTV3014F	PT11 chassis							
Amstrad	CTV3021N	PT11 chassis	1998	Micro CTV352/V1.4					
Amstrad	CTV3021NF	SM1 chassis	1998	Micro CTV352/V1.4					
Amstrad	CTV3028N	SM1 chassis		Micro CTV352/V1.4					
Amstrad	CTV3121N	PT11 chassis							
Amstrad	CTV3128N	SM2 chassis							
Amstrad	CTV3228NF	SM2 chassis	1999						
Amstrad	CTV3321NF	PT92 chassis							
Amstrad	STV20		with sat Rx						
Amstrad	TVR1	Funai							
Amstrad	TVR2	Funai							
Amstrad	TVR3	Funai							
Amstrad	WSTV7328N	11AK19P							
Argaro	1401	Fidelity ZX2000							
Autovox	CTR2282GB	Series 1							
Autovox	CTR2283GB	Series 1							
Autovox	CTR2682GB	Series 1							
Autovox	CTR2683GB	Series 1							
B & O	3000	20AX							
B & O	3140	MX3000							
B & O	3141	MX3000							
B & O	3142	MX3000							
B & O	3143	MX3000							
B & O	3144	MX3000							
B & O	3145	MX3000							
B & O	3146	MX3000							
B & O	3147	MX3000							
B & O	3263	Made 1989							
B & O	3300	20AX							
B & O	3502	20AX							
B & O	3602	20AX							
B & O	3702	20AX							
B & O	3703	LX2800							
B & O	3705	LX2800							
B & O	3707	LX2800							
B & O	3712	LX2800							
B & O	3713	LX2800							
B & O	3714	LX2800							
B & O	3715	LX2800							
B & O	3718	LX2800							
B & O	3720	LX2800							
B & O	3741	LX2500							
B & O	3742	LX2500							
B & O	3743	LX2500							
B & O	3745	LX2500							
B & O	3747	LX2500							
B & O	3752	LX2500							
B & O	3753	LX2500							
B & O	3754	LX2500							
B & O	3755	LX2500							
B & O	3758	LX2500							
B & O	3760	LX2500							
B & O	3800	20AX							
B & O	3802	20AX							
B & O	3900	20AX							
B & O	3923	LX4500							
B & O	4002	20AX							
B & O	4402	20AX							
B & O	5000	39XX							
B & O	5102	77XX							
B & O	6000	39XX							
B & O	6002	20AX							
B & O	7702	7XX							
B & O	8102	71XX							
B & O	9000	33XX							
B & O	311x	MX2000							
B & O	7433	7702							
B & O	L2500	37XX							
B & O	L2502	38XX							
B & O	L2800	37XX							
B & O	L2802	38XX							
B & O	LX2500	37XX							
B & O	LX2502	38XX							
B & O	LX2800	37XX							
B & O	LX2802	38XX							
B & O	M20	31XX							
B & O	MX1500	78XX							
B & O	MX2000	31XX							
B & O	MX3000	314X							
B & O	MX5500	326X							
Baird	8170	Ferguson TX90							
Baird	8171	Ferguson TX90							
Baird	8233	Ferguson TX10							
Baird	RR5188	Tatung 1790							
Baird	RR5190	Sanyo E4-A21							
Baird	RR5191N	ICC7							
Baird	RR5988	Tatung 180							
Baird	RR5990	Sanyo E4-A25							
Baird	RR5991N	ICC5 IMC							
Baird	RR6890N	Sanyo ED1-2B							
Baird	RR6891	ICC5 IMC							
Beko	10214	10.2 (AT2)							
Beko	11214T	10.2 (AT2)							
Beko	11221T	10.2 (AT2)							
Beko	11225(T)	10.2 (AT2)							
Beko	12220(T) (NX)	10.2 (AT2)							
Beko	14212T( R )	12.1							
Beko	14213T( R )	12.1							
Beko	14242-8TDS	12.8							
Beko	14242T( R )	12.4	PCB marked A99.190-16						
Beko	14272TDS	12.7	2003 £70, 2004 £65	PCB marked G70.190-03					
Beko	15225 (T) (NX)	10.2 (AT2)							
Beko	15325(NX)(T)	10.3 (AT3)							
Beko	16228 (T) (NX)	10.2 (AT2)							
Beko	16328(NX)	10.3 (AT3)							
Beko	17125(NX)(T)	11.1							
Beko	17325(T)( R )	10.3 (AT3)							
Beko	18221 (T) (NX)	10.2 (AT2)							
Beko	19221	10.2 (AT2)							
Beko	19321(NX)(T)	10.3 (AT3)							
Beko	19421(T)	10.4 (AT4)							
Beko	20120NX	11.1							
Beko	20212R( T)	12.1							
Beko	20242-8R	12.8							
Beko	20242T ( R )	12.4							
Beko	20272TDS	12.7	PCB marked G70.190-03						
Beko	20320(NX)(T)	10.3 (AT3)							
Beko	20420(T)	10.4 (AT4)							
Beko	21211T	12.1							
Beko	21241T(RD)	12.4							

[illegible]

	Bush	2034T	11AK19 or 11AK30(2002-2003)		11AK30 - 1001482						
	Bush	2037TSIL	11AK30A4	2002-2003	1001484						
	Bush	2038TSIL	Beko 12.7		PCB marked G70.190-10						
	Bush	2052	Kong Wah K-91151T	Alba CTV841	Matsui 2074	Goldstar CIS4441					
	Bush	2052T	Onwa								
	Bush	2057	Bush 2059	Bush 2157	Bush 2159						
	Bush	2059	see Bush 2057								
	Bush	2060NTX	NEW ONWA	similar to Alba CTV4886							
	Bush	2063NTX	11AK10-8								
	Bush	2063NTX/A	11AK10-15		AK10 prod.code: 1000257						
	Bush	2067NTX	PT9601 (Goodmans GTV211)								
	Bush	2068NTX	11AK10-17								
	Bush	2071NTX	11AK19-8A, 11AK19E3(2000), 11AK19P5(2002)	1999-2002	AK19 prod.code: 10000229						
	Bush	2077NTXSIL	11AK30-2 (2002),11AK30A4 (2002-2003),11AK30	2002-2004							
	Bush	2102	Onwa								
	Bush	2114	11AK01	Kong Wah K-91151T, Alba CTV841	Matsui 2074	Goldstar CIS4441					
	Bush	2131TSIL	11AK19P4, 11AK19P5		AK19 prod.code: 10006073						
	Bush	2134TSIL	11AK30	£130							
	Bush	2136TSIL	Beko								
	Bush	2137TSIL	11AK30	2002-2003, £149.99	prod.code: 10015421						
	Bush	2138TSIL	Beko 12.7	2003, £149.99	PCB marked G70.190-6	Micro SDA5535-A062					
	Bush	2151(TX)	Indiana 100								
	Bush	2152	Kong Wah K-91151T	Alba CTV841	Matsui 2074	Goldstar CIS4441					
	Bush	2152T	Onwa								
	Bush	2157	see Bush 2057								
	Bush	2159	see Bush 2057								
	Bush	2160NTX	Grundig G1000								
	Bush	2164NTX	11AK19-8A, 11AK19B-1	1999-	AK19 prod.code: 10000364	Micro SDA5255-A059(11AK19-xx), SDA5255-A073(11AK19-8A), SDA5255-A045(11AK19-8A)					
	Bush	2167NTX	2007 2033T 2167NTX 2169NTX	Alba CTV3458							
	Bush	2169NTX	2007 2033T 2167NTX 2169NTX	Alba CTV3458							
	Bush	2171NTX	11AK19-8A	1999-	AK19 prod.code: 10000363						
	Bush	2171NTXSIL	11AK19P5		AK19 prod.code: 10006101						
	Bush	2177NTXSIL	11AK30-2(2002),11AK30A4(2002-2003),11AK30	2002-2004							
	Bush	2214	Osume CTV1474R	Alba CTV841							
	Bush	2321	11AK01	Kong Wah K-91151T, Alba CTV841	Matsui 2074	Goldstar CIS4441					
	Bush	2420 (2420 Mk I)	chassis C600								
	Bush	2514T	Indiana 100								
	Bush	2515T	Indiana 100								
	Bush	2520TX	Indiana 100		Turkish						
	Bush	2521TX	Indiana 100		Turkish						
	Bush	2534TSIL	11AK19P5		prod.code: 10014200						
	Bush	2541(TX)	Indiana 100								
	Bush	2550NTX	Schneider TV4	Serv. Mode: see Bush 2850NTX							
	Bush	2550NTX/A	Schneider TV8								
	Bush	2568NTX	11AK19-08								
	Bush	2571NTX	11AK19-8A, 11AK19E3	1998-2000	AK19 prod.code: 10001134, 100006102						
	Bush	2574NTXSIL	11AK19P4, 11AK19P5	2001-2002	AK19 prod.code: 10009365						
	Bush	2714	11AK03								
	Bush	2720	11AK03								
	Bush	2721	11AK03								
	Bush	2768NTSIL	SM2								
	Bush	2814T	11AK03								
	Bush	2820T	11AK03								
	Bush	2821T	11AK03								
	Bush	2850NTX	Schneider TV4	Serv. mode: press RED and BLUE on R/C together then within 5 sec press P- and V+ together on TV. If you do not have original remote, use any Philips RC5 remote							
	Bush	2850NTX/A	Schneider TV8								
	Bush	2855WD	Schneider TV4								
	Bush	2857NTX	Harwood HTV9425RTN	Amstrad CTV280							
	Bush	2863NTX	11AK12								
	Bush	2863NTX/A	11AK19-8A								
	Bush	2866NTX	SM1 Stereo								
	Bush	2866NTXSMS2	SM2								
	Bush	2867NTX	11AK12 or 11AK19								
	Bush	2868NTX	11AK19-5, 11AK19-8A	1999-	AK19 prod.code: 10000518						
	Bush	2870VPL	11AK19-8A								
	Bush	2871NTX	11AK19-8A, 11AK19E3 (from March2000), 11AK19P5 (from Apr2002)		AK19 prod.code: 10000517, 10006103						
	Bush	2872NTX	11AK19E3								
	Bush	2874NTX	11AK19E3								
	Bush	2874NTXSIL	11AK37-6	2002							
	Bush	2878NTX	PT92	2001							
	Bush	2877NTXSIL	11AK19P4, 11AK19P5 or 11AK37-8	2001-2002(11AK19), 2003(11AK37)	AK19 prod.code: 10009515						
	Bush	2879	C43 (Alba CTV-743)								
	Bush	28ZKA	4400 chassis								
	Bush	28ZKF	4400 chassis								
	Bush	2914	C43 (Alba CTV-743)								
	Bush	2920T	Alba CTV703 CTV704T CTV713	Hinari HIT51T							
	Bush	2921	Alba CTV703 CTV704T CTV713	Hinari HIT51T							
	Bush	2921T	Alba CTV703 CTV704T CTV713	Hinari HIT51T							
	Bush	3114	Orion 14EBS	Saisho CT149X	(TVS 89-90 P231)						
	Bush	3114A/AS	Orion 14LR chassis	Matsui 1466, Hinary HIT140RC							
	Bush	3114AT		Osaki 3114AT							
	Bush	3370VPL	11AK19								
	Bush	3463NTX	4400 chassis	around £700-£800							
	Bush	3472NTX (34BKD)	4400 chassis								
	Bush	6690D	11AK19B1 +digibox		AK19 prod.code: 10003064						
	Bush	6693D	11AK33J4 +digibox	2003 £349, 2004 £299	10019795						
	Bush	7690D	11AK19B1 +digibox								
	Bush	7693D	11AK33J4 +digibox	2003, 2004 £399	10019794						
	Bush	AC6465	Rank T23A								
	Bush	BC6004	Murphy MC6124	Murphy 6425							
	Bush	BC6268	T22A	BC6238	BC6468						
	Bush	BC7100	Saba chassis								
	Bush	BC7200	T24E	Murphy MC7240							
	Bush	BC7300	T26A								
	Bush	BT14	chassis TV14	Bush BTV140T							
	Bush	BTV10	Orion chassis (Alba VTV10)								
	Bush	BTV140T		Bush BTV14							
	Bush	BTV16	similar to BTV20	Serv.mode: MENU-MUTE-PAUSE-MUTE							
	Bush	BTV17	Orion chassis, deck OVD-6; same as Goodman	PCB marked TM9423A, video VM9162A	Micro OEC0078A, option codes	PSU IC STRF6707					
	Bush	BTV17/OVD7	Orion chassis, deck OVD-7			PSU IC STRG6653					
	Bush	BTV17SIL/OVD7	Orion chassis, deck OVD-7	PCB marked VMA230A							
	Bush	BTV170TBLK	Orion chassis	PCB marked TM9423A		PSU IC STRF6707					
	Bush	BTV17A	similar to BTV17	PCB marked VMX193G	Micro OEC0093	PSU IC STRF6707					
	Bush	BTV180TSI		2004 £99							
	Bush	BTV183DVD	TVV/CR/DVD	2003, £249; 2004 £199							
	Bush	BTV18SIL	Orion chassis, deck OVD-7, 2003 £99	PSU PCB VPA150A							
	Bush	BTV18SIL/A	Orion chassis, deck OVD-7	PCB marked VMB290A	Micro OEC0133A						
	Bush	BTV20	similar to BTV16	Serv.mode: MENU-MUTE-PAUSE-MUTE							
	Bush	BTV213DVD	TVV/CR/DVD	2003, £329							
	Bush	CTV1400	Harwood HTV3604R								
	Bush	DVD142RC	11AK46-1 +DVD	Serv.mode: INSTALL-4-7-2-5	remote						
	Bush	DVD142TV	11AK46-1, 11AK46-5 +DVD	2003, £170	remote						
	Bush	DVD143TVFTNT1	PT90 +DVD		remote 631020001381						
	Bush	DVD144RC		2004, £99							
	Bush	DVD145TV		2003, £140							
	Bush	DVD660TV	PT90 +DVD		remote 631020001381						
	Bush	DVD660TVSIL/A	PT92 +DVD								
	Bush	IBX260	INTERNET Box double scart	2001	Vestel prod.code: 10009407						
	Bush	ITV2100	Beko 14.1								
	Bush	ITV2112	Beko 12.4 with Internet access	Micro SDA555x (SB7640-03/TXT), video N	serv.mode: MENU, then 7.5,9.2.						
	Bush	ITV2800	Beko 14.1 with Internet	PCB 7SZ 190-14, remote KWR2020	Micro SAA5563PS/M3, jungle TDA8843, sound MSP3410D						
	Bush	ITV6600	Beko 14.1	PCB 7SZ 190-17							
	Bush	ITV8401	11AK20S with Internet access								
	Bush	M1400	Fidelity ZX3000 Mk2								
	Bush	M1500	Fidelity ZX3000 Mk2								
	Bush	M20T01	Fidelity ZX4000								
	Bush	M22T01	Fidelity ZX4000								
	Bush	RF6682VPL	Beko 14.1 or 14.2	2001(14.1); 2002(14.2)	14.1 - PCB marked 7SZ.190-18; 14.2 - PCB marked S99.190-04, S99.190-07						
	Bush	RF7682VPL	Beko 14.1 or 14.2	14.2 - PCB marked S99.190-07							
	Bush	WS5673SIL (10016197)	11AK37-10, 11AK37-11		AK37 prod.code: 10016197						
	Bush	WS5676SIL	11AK37								
	Bush	WS5680		2004, £180							
	Bush	WS6667 (28ZKA)	4400 chassis								
	Bush	WS6668SIL (28ZKV)	4400 chassis	PCB marked B-4411							
	Bush	WS6671 (10004932)	11AK19P4, 11AK19P5	in 11AK19P4 Micro is 19V1.OFT-A14	AK19 prod.code: 10004932						
	Bush	WS6671SIL (10006104)	11AK19P4, 11AK19P5		AK19 prod.code: 10006104						
	Bush	WS6671SIL (10014467)	11AK37-8		AK37 prod.code: 10014467						
	Bush	WS6672	PT92								
	Bush	WS6673	11AK19P5								





Decca	DN1253	120 Chassis							
Decca	DN1256	120/125 Chassis							
Decca	DN1259	120/130 Chassis							
Decca	DN1451	140 Chassis							
Decca	DN1471	140 Chassis							
Decca	DN1651A	160 Chassis							
Decca	DN1670	160 Chassis							
Decca	DN1671	160 Chassis							
Decca	DN1672	160 Chassis							
Decca	DN1674	160 Chassis							
Decca	DN8452	140 Chassis							
Decca	DN8472	140 Chassis							
Decca	DN8652	165 Chassis							
Decca	DN8951	190 Chassis		Boots C1411/2	Matsui 1424				
Decca	DN8951	190 Chassis							
Decca	DN8955	190 Chassis							
Decca	DN9256	120/125 Chassis							
Decca	DN9257	120/125 Chassis							
Decca	DN9259	120/130 Chassis							
Decca	DP1257	120/130 Chassis							
Decca	DP1453	140 Chassis							
Decca	DP1473	140 Chassis							
Decca	DP1653/A	160 Chassis							
Decca	DP1673	160 Chassis							
Decca	DP8454	140 Chassis							
Decca	DP8474	140 Chassis							
Decca	DP9257	120/130 Chassis							
Decca	DP9454	140 Chassis							
Decca	DT1253	120 Chassis							
Decca	DT1257	120/125 Chassis							
Decca	DT1260	120 Chassis							
Decca	DT1263	120 Chassis							
Decca	DT1455	140 Chassis							
Decca	DT1475	140 Chassis							
Decca	DT1655	160 Chassis							
Decca	DT1675	160 Chassis							
Decca	DT8456	140 Chassis							
Decca	DT8459	140 Chassis							
Decca	DT8466	145A Chassis							
Decca	DT8476	145A Chassis							
Decca	DT8496	145A Chassis							
Decca	DT9253	120 Chassis							
Decca	DT9255	120/125 Chassis							
Decca	DT9260	120/125 Chassis							
Decca	DT9456	140 Chassis							
Decca	DT9459	140 Chassis							
Decca	DT9466	145A Chassis							
Decca	DT9476	145A Chassis							
Decca	DT9496	145A Chassis							
Decca	DT9497	140 Chassis							
Decca	DT9770	190/195 Chassis							
Decca	DT9772	171 Chassis							
Decca	DU8670M	165 Chassis							
Decca	DU8688	165 Chassis							
Decca	DV1254	120 Chassis							
Decca	DV1351	130 Chassis							
Decca	DV1353	130 Chassis							
Decca	DV1360	130 Chassis							
Decca	DV1361	130 Chassis							
Decca	DV1457	140 Chassis							
Decca	DV1462	140 Chassis							
Decca	DV1475	140 Chassis							
Decca	DV1477	140 Chassis							
Decca	DV1657	160 Chassis							
Decca	DV1677	160 Chassis							
Decca	DV8458	140 Chassis							
Decca	DV8460	140 Chassis							
Decca	DV8468	145A Chassis							
Decca	DV8478	147 Chassis							
Decca	DV8498	145A Chassis							
Decca	DV8554	150 Chassis							
Decca	DV9101	111 Chassis							
Decca	DV9151	111 Chassis							
Decca	DV9254	120 Chassis							
Decca	DV9351	130 Chassis							
Decca	DV9352	130 Chassis							
Decca	DV9357	131 Chassis							
Decca	DV9458	140 Chassis							
Decca	DV9460	140 Chassis							
Decca	DV9468	145A Chassis							
Decca	DV9498	145A Chassis							
Decca	DV9499	140 Chassis							
Decca	DV9551	150 Chassis							
Decca	DV9758	170/180 Chassis							
Decca	DYS9893C	180 Chassis							
Decca	DZ1352	130 Chassis							
Decca	DZ1362	130 Chassis							
Decca	DZ9152	111 Chassis							
Decca	DZ9352	130 Chassis							
Decca	DZ9354	130 Chassis							
Decca	DZ9358	120/130 Chassis							
Decca	DZ9362	130 Chassis							
Decca	DZ9555	150 Chassis							
Decca	PT9255	120/125 Chassis							
Decca	PV9352	130 Chassis							
Decca	PZ9354	130 Chassis							
Decca		10	Bradford						
Decca		30	Bradford						
Decca		70							
Decca		80	Granada C20SD1 / C20TD1						
Decca		90							
Decca		100							
Decca		110							
Decca		120							
Decca		125							
Decca		130							
Decca		140							
Decca		141							
Decca		145							
Decca		150							
Decca		160			Tatung TV9448				
Decca		161	GEC C1410		Tashiko 16E891				
Decca		162							
Decca		165	GEC C2000						
Decca		166							
Decca		170	Proline 360TT		Tatung TUV9731/4				
Decca		180	Proline NV2400/NV2700		Tatung TYS9824				
Decca		185							
Decca		A Series							
Decca		B Series							
Decca		C Series	Tatung DU6C22						
Decca		C Series	Tatung TU2C52						
Decca		C Series	Tatung VU2CEO						
Dynatron	267475SK	Philips K40							
Etron	EC142	Akashi 1450							
Expert	2061	Hitachi CPT2051							
Ferguson	14C1	TX90							
Ferguson	14C2	TX90							
Ferguson	14C9	TX90							
Ferguson	14D1	TX85							
Ferguson	14D2	TX85/90							
Ferguson	14J1	TX85							
Ferguson	14J2	TX85/90							
Ferguson	14J9	TX85							
Ferguson	14K1	TX85							
Ferguson	14K2	TX85							
Ferguson	14K9	TX85							
Ferguson	14L1	TX86							
Ferguson	14L2	TX86							

Ferguson	14L9	TX86							
Ferguson	14M1	TX86							
Ferguson	14M2	TX89							
Ferguson	14M9	TX86							
Ferguson	16A1	TX90							
Ferguson	16A2	TX90							
Ferguson	16A3	TX90							
Ferguson	16H2	TX99							
Ferguson	16H3	TX99							
Ferguson	170	TX9							
Ferguson	171	TX9							
Ferguson	1764	9700							
Ferguson	1765	9700							
Ferguson	1785	TX10							
Ferguson	1791	9700							
Ferguson	1796	9750							
Ferguson	1799	9700							
Ferguson	190	TX9							
Ferguson	200	TX90							
Ferguson	2000	TX90							
Ferguson	20A1	TX100							
Ferguson	20A2	TX100							
Ferguson	20A3	TX100							
Ferguson	20A4	TX100							
Ferguson	20C2	TX100							
Ferguson	20C3	TX100							
Ferguson	20C4	TX100							
Ferguson	20E1	TX90							
Ferguson	20E2	TX90							
Ferguson	20G1	TX100							
Ferguson	20G2	TX100							
Ferguson	20G3	TX100							
Ferguson	20H1	TX100							
Ferguson	20H2	TX100							
Ferguson	20H3	TX100							
Ferguson	20K2	TX95							
Ferguson	20K3	TX95							
Ferguson	22B1	TX100							
Ferguson	22B2	TX100							
Ferguson	22B3	TX100							
Ferguson	22B4	TX100							
Ferguson	22B5	TX10							
Ferguson	22D1	TX100							
Ferguson	22D2	TX100							
Ferguson	22D3	TX100							
Ferguson	22D4	TX100							
Ferguson	22G1	TX100							
Ferguson	22G2	TX100							
Ferguson	22G3	TX100							
Ferguson	22H1	TX100							
Ferguson	22H2	TX100							
Ferguson	22H3	TX100							
Ferguson	232	TX10							
Ferguson	2323	TX100							
Ferguson	233	TX10							
Ferguson	2343	TX100							
Ferguson	2353	TX100							
Ferguson	2403	TX10							
Ferguson	2422	TX100							
Ferguson	2423	TX100							
Ferguson	2452	TX100							
Ferguson	2453	TX100							
Ferguson	2463	TX100							
Ferguson	262	TX9							
Ferguson	26D1	TX100							
Ferguson	26D2	TX100							
Ferguson	26D3	TX100							
Ferguson	26G2	TX100							
Ferguson	26G3	TX100							
Ferguson	26H1	TX100							
Ferguson	26H2	TX100							
Ferguson	26H3	TX100							
Ferguson	271	TX9							
Ferguson	273	TX9							
Ferguson	282	TX10							
Ferguson	283	TX10							
Ferguson	2841	1690							
Ferguson	289	TX10							
Ferguson	311	TX10							
Ferguson	3170	TX9							
Ferguson	3171	TX9							
Ferguson	3190	TX9							
Ferguson	3232	TX10							
Ferguson	3233	TX10							
Ferguson	3262	TX9							
Ferguson	3271	TX9							
Ferguson	3272	TX9							
Ferguson	3273	TX9							
Ferguson	3282	TX10							
Ferguson	3283	TX10							
Ferguson	3289	TX10							
Ferguson	32WS650D	ICC19							
Ferguson	3311	TX10							
Ferguson	3579	TX571							
Ferguson	36040	TX9							
Ferguson	36140	TX90							
Ferguson	36141	TX90							
Ferguson	36152	TX9							
Ferguson	36310	TX90							
Ferguson	36311	TX90							
Ferguson	36351	TX9							
Ferguson	36H2	TX99							
Ferguson	36H3	TX99							
Ferguson	36K2	TX89							
Ferguson	36K3	TX99/89							
Ferguson	37003	TX9							
Ferguson	37003	TX9							
Ferguson	37023	TX9							
Ferguson	37023	TX9							
Ferguson	37041	TX9							
Ferguson	37041	TX9							
Ferguson	37051	TX10							
Ferguson	37060	TX10							
Ferguson	37060	TX10							
Ferguson	37063	TX10							
Ferguson	37063	TX10							
Ferguson	37081	TX9							
Ferguson	37081	TX9							
Ferguson	37090	TX9							
Ferguson	37090	TX9							
Ferguson	37093	TX9							
Ferguson	37093	TX9							
Ferguson	37100	TX9							
Ferguson	37100	TX9							
Ferguson	37101	TX9							
Ferguson	37101	TX9							
Ferguson	37103	TX9							
Ferguson	37140	TX90							
Ferguson	37141	TX90							
Ferguson	37147	TX90							
Ferguson	37149	TX90							
Ferguson	37311	TX10							
Ferguson	3734	9600							
Ferguson	37340	TX10							
Ferguson	37340	TX10							
Ferguson	37341	TX10							
Ferguson	37341	TX10							
Ferguson	37350	TX9							
Ferguson	37350	TX9							



Ferguson	37351	TX9							
Ferguson	37351	TX9							
Ferguson	37353	TX9							
Ferguson	37353	TX9							
Ferguson	3736	9600							
Ferguson	37360	TX9							
Ferguson	37360	TX9							
Ferguson	37361	TX9							
Ferguson	37361	TX9							
Ferguson	37363	TX10							
Ferguson	37363	TX9							
Ferguson	3737	9600							
Ferguson	37370	TX10							
Ferguson	37370	TX10							
Ferguson	37371	TX10							
Ferguson	37373	TX10							
Ferguson	37373	TX10							
Ferguson	3743	9600							
Ferguson	37430	TX10							
Ferguson	3745	9800							
Ferguson	37460	TX10							
Ferguson	37463	TX10							
Ferguson	37463	TX10							
Ferguson	3747	9600							
Ferguson	3749	9800							
Ferguson	37493	TX9							
Ferguson	37493	TX9							
Ferguson	3752	9800							
Ferguson	3755	TX9							
Ferguson	3755	TX9							
Ferguson	37559	TX9							
Ferguson	3756	TX9							
Ferguson	3756	TX9							
Ferguson	3757	9900							
Ferguson	3758	9900							
Ferguson	3759	9600							
Ferguson	3760	TX9							
Ferguson	3760	TX9							
Ferguson	37600	TX9							
Ferguson	3762	9600							
Ferguson	3763	9600							
Ferguson	3764	9600							
Ferguson	3765	TX10							
Ferguson	3765	TX10							
Ferguson	37650	TX10							
Ferguson	37650	TX10							
Ferguson	3766	TX10							
Ferguson	3767	TX10							
Ferguson	3767	TX10							
Ferguson	3768	TX9							
Ferguson	3768	TX9							
Ferguson	3769	TX9							
Ferguson	3769	TX9							
Ferguson	3776	9600							
Ferguson	3780	TX9							
Ferguson	3780	TX9							
Ferguson	37800	TX9							
Ferguson	37800	TX9							
Ferguson	37801	TX9							
Ferguson	37801	TX9							
Ferguson	3781	TX9							
Ferguson	3781	TX9							
Ferguson	3782	9650							
Ferguson	3784	9602							
Ferguson	3785	TX10							
Ferguson	3785	TX10							
Ferguson	37850	TX10							
Ferguson	37850	TX10							
Ferguson	3786	TX10							
Ferguson	3787	NORD-FV1							
Ferguson	3787	Nordmende 8180 chassis (1978)	Nordmende 4230						
Ferguson	3788	TX10							
Ferguson	3788	TX10							
Ferguson	3789	9653							
Ferguson	3790	TX9							
Ferguson	3790	TX9							
Ferguson	3791	TX10							
Ferguson	3791	TX10							
Ferguson	3792	TX9							
Ferguson	3792	TX9							
Ferguson	3793	9653							
Ferguson	3794	TX10							
Ferguson	3795	TX10							
Ferguson	3795	TX10							
Ferguson	37953	TX10							
Ferguson	37953	TX10							
Ferguson	3796	TX10							
Ferguson	3796	TX10							
Ferguson	37963	TX10							
Ferguson	37963	TX10							
Ferguson	38000	1696							
Ferguson	38010	1696							
Ferguson	38020	1790-1791							
Ferguson	38030	1790							
Ferguson	38050	1790							
Ferguson	3838	1613							
Ferguson	3839	1613							
Ferguson	3840	1690-1691	Alba T1114						
Ferguson	3845	1690-1691							
Ferguson	3847	1690-1691							
Ferguson	3848	1690-1691							
Ferguson	3850	1615							
Ferguson	38500	1615							
Ferguson	3852	1615							
Ferguson	38520	1615							
Ferguson	3853	1694							
Ferguson	3854	1694							
Ferguson	3857	1694							
Ferguson	3858	1694							
Ferguson	3870	1697							
Ferguson	3871	1697							
Ferguson	38710	1697							
Ferguson	3C02	TX571							
Ferguson	3MC01	TX90							
Ferguson	3MC05	TX90							
Ferguson	40MK10	TX90E							
Ferguson	40MPR45	TX90E							
Ferguson	41H2	TX99							
Ferguson	41H3	TX99							
Ferguson	41K3	TX98							
Ferguson	41P3	IKC2							
Ferguson	4838	1612							
Ferguson	5170	TX9							
Ferguson	5171	TX9							
Ferguson	5190	TX9							
Ferguson	51A0	TX100							
Ferguson	51A1	TX100							
Ferguson	51A2	TX100							
Ferguson	51A3	TX100							
Ferguson	51A4	TX100							
Ferguson	51A5	TX100							
Ferguson	51A8	TX100							
Ferguson	51D1	TX100							
Ferguson	51G2	TX100							
Ferguson	51G3	TX100							
Ferguson	51H2	TX99							
Ferguson	51H3	TX100							
Ferguson	51H4	TX100							
Ferguson	51H5	TX100							

Ferguson	51H8	TX100							
Ferguson	51J7	TX99							
Ferguson	51J8	TX99							
Ferguson	51K2	TX99							
Ferguson	51K3	TX99							
Ferguson	51K4	ICC5							
Ferguson	51K5	ICC5							
Ferguson	51K7	ICC5							
Ferguson	51L3	ICC5							
Ferguson	51L5Q	ICC5	Nicam						
Ferguson	51L7	ICC5							
Ferguson	51P7	TX98							
Ferguson	51Q7	TX98							
Ferguson	5232	TX10							
Ferguson	5233	TX10							
Ferguson	5262	TX9							
Ferguson	5271	TX9							
Ferguson	5272	TX9							
Ferguson	5273	TX9							
Ferguson	5281	TX10							
Ferguson	5282	TX10							
Ferguson	5283	TX10							
Ferguson	5289	TX10							
Ferguson	5311	TX10							
Ferguson	59B1	TX100							
Ferguson	59B2	TX100							
Ferguson	59B3	TX100							
Ferguson	59B4	TX100							
Ferguson	59B5	TX100							
Ferguson	59B8	TX100							
Ferguson	59D2	TX100							
Ferguson	59D3	TX100							
Ferguson	59G2	TX100							
Ferguson	59G3	TX100							
Ferguson	59H2	TX100							
Ferguson	59H3	TX100							
Ferguson	59H4	TX100							
Ferguson	59H5	TX100							
Ferguson	59J7	TX100							
Ferguson	59K4	ICC5							
Ferguson	59K5	ICC5							
Ferguson	59K7	ICC5							
Ferguson	59L5	ICC5							
Ferguson	59L7	ICC5							
Ferguson	59M2	ICC5							
Ferguson	59M5	ICC5							
Ferguson	59P7	ICC5							
Ferguson	59P7A	ICC5							
Ferguson	6003	TX10							
Ferguson	6004	TX10							
Ferguson	6012	TX10							
Ferguson	6013	TX10							
Ferguson	6019	TX10							
Ferguson	6021	TX9							
Ferguson	6023	TX9							
Ferguson	6031	TX9							
Ferguson	6053	TX9							
Ferguson	6070	TX9							
Ferguson	6071	TX9							
Ferguson	6076	TX9							
Ferguson	6083	TX10							
Ferguson	6093	TX9							
Ferguson	6103	TX10							
Ferguson	6116	TX9							
Ferguson	6121	TX9							
Ferguson	6144	TX10							
Ferguson	6170	TX90							
Ferguson	6171	TX90							
Ferguson	6175	TX90							
Ferguson	6213	TX9							
Ferguson	6245	TX10							
Ferguson	626R	TX807							
Ferguson	6603	TX10							
Ferguson	66B2	TX100							
Ferguson	66B3	TX100							
Ferguson	66B5	TX100							
Ferguson	66B8	TX100							
Ferguson	66H2	TX100							
Ferguson	66H3	TX100							
Ferguson	66H4	TX100							
Ferguson	66H5	TX100							
Ferguson	66K4	ICC5							
Ferguson	66M3	ICC5	1993						
Ferguson	6735	9600							
Ferguson	6745	9800							
Ferguson	6749	9800							
Ferguson	6770	9900							
Ferguson	6771	TX9							
Ferguson	6775	9600							
Ferguson	6830	1612							
Ferguson	6838	1613							
Ferguson	6839	1613							
Ferguson	6840	1690							
Ferguson	6850	1615							
Ferguson	6852	1615							
Ferguson	68K4	ICC5							
Ferguson	68K4BQ	ICC5							
Ferguson	68M5	ICC5							
Ferguson	7170	TX9							
Ferguson	7171	TX9							
Ferguson	7190	TX9							
Ferguson	7232	TX10							
Ferguson	7233	TX10							
Ferguson	7262	TX9							
Ferguson	7271	TX9							
Ferguson	7272	TX9							
Ferguson	7273	TX9							
Ferguson	7281	TX10							
Ferguson	7282	TX10							
Ferguson	7283	TX10							
Ferguson	7289	TX10							
Ferguson	7311	TX10							
Ferguson	7741	TX100							
Ferguson	7742	TX100							
Ferguson	7841	TX100							
Ferguson	7842	TX100							
Ferguson	78M5	ICC5							
Ferguson	8143	TX10							
Ferguson	8170	TX9							
Ferguson	8171	TX9							
Ferguson	8190	TX9							
Ferguson	8203	TX10							
Ferguson	8232	TX10							
Ferguson	8233	TX10							
Ferguson	8243	TX9							
Ferguson	8262	TX9							
Ferguson	8271	TX9							
Ferguson	8272	TX9							
Ferguson	8273	TX9							
Ferguson	8281	TX10							
Ferguson	8282	TX10							
Ferguson	8283	TX10							
Ferguson	8289	TX10							
Ferguson	8311	TX10							
Ferguson	8787	NORDMENDE FV1							
Ferguson	A10R	TX80							
Ferguson	A14R	TX90E							
Ferguson	A36F	IKC2							
Ferguson	A36F	TX80							

Ferguson	A36R	TX80							
Ferguson	A51EAL	TX100							
Ferguson	A51F	ICC2							
Ferguson	A51N	ICC7							
Ferguson	A59EAK	TX100							
Ferguson	A59EAS	TX100							
Ferguson	A59F	ICC7							
Ferguson	A59N	ICC7/8							
Ferguson	A68N	ICC7							
Ferguson	AXF51	TX100							
Ferguson	B14C	TX90E							
Ferguson	B14R	TX90E							
Ferguson	B39F	TX90E							
Ferguson	B49F	TX90E							
Ferguson	B51F	ICC7							
Ferguson	B51NX	ICC8							
Ferguson	B59F	ICC7							
Ferguson	B59N	ICC8							
Ferguson	B59NX	ICC8							
Ferguson	B68N	ICC8							
Ferguson	B68NX	ICC8							
Ferguson	B78NT/X	ICC5							
Ferguson	C14C	TX90E							
Ferguson	C15012R	Samsung P68 chassis							
Ferguson	C2152	TX100							
Ferguson	C2153	TX100							
Ferguson	C3615UT	Eurocombo2							
Ferguson	C39F	TX90E							
Ferguson	C49F	TX90E							
Ferguson	C51F	ICC8							
Ferguson	C51N	ICC8							
Ferguson	C51ND	ICC7							
Ferguson	C51NX	ICC8							
Ferguson	C59NX	ICC8							
Ferguson	C68F	ICC7							
Ferguson	C68NX	ICC8							
Ferguson	D14R	TX805							
Ferguson	D51N	ICC9							
Ferguson	D51ND	ICC9	NICAM						
Ferguson	D51NDD	ICC9							
Ferguson	D59F	ICC9	Mono sound						
Ferguson	D59N	ICC9	NICAM						
Ferguson	D68N	ICC9	NICAM						
Ferguson	D78N	ICC9	NICAM						
Ferguson	DSF68NX	IDC2							
Ferguson	F16/17	ICC7?							
Ferguson	FG14CB12V	CP-310 (Daewoo)	Goodmans TVC1400 TVC14VP	Daewoo DVT1484D					
Ferguson	FG20CB12V	CP-310 (Daewoo)	Goodmans TVC1400 TVC14VP	Daewoo DVT1484D					
Ferguson	FTV28WN1	11AK37	2004 £250						
Ferguson	M3610U	TX807							
Ferguson	M3615UT	TX807							
Ferguson	M3673GC(T)	TX91G							
Ferguson	M51131RH	TX807C							
Ferguson	M5115UT	TX807							
Ferguson	M5515UT	TX807							
Ferguson	M5518U	ICC17							
Ferguson	M5519U	TX91G							
Ferguson	M5520U	TX91G							
Ferguson	M5573GF	TX91G							
Ferguson	M6322U	ICC17							
Ferguson	M6373GH	TX92F							
Ferguson	M7017U	TX807CS							
Ferguson	M7022U	ICC17							
Ferguson	M7073GH	TX92F							
Ferguson	M8122U	ICC17							
Ferguson	M8123U	ICC17							
Ferguson	M8421U	ICC17							
Ferguson	M8422U	ICC17							
Ferguson	MC01	TX90	Receiver/Monitor						
Ferguson	MC05	TX90	Receiver/Monitor						
Ferguson	MC09	TX85							
Ferguson	MC09	TX90							
Ferguson	RR5191N	ICC7							
Ferguson	S59N	ICC9	NICAM+						
Ferguson	S68N	ICC9	NICAM+						
Ferguson	S7971	TX100							
Ferguson	S7981	TX100							
Ferguson	T10R	TX90	Mains/Batt portable 10"						
Ferguson	T14R	TX805							
Ferguson	T14T	TX91							
Ferguson	T25DPL	ICC9							
Ferguson	T28DPL	ICC9							
Ferguson	T49F	TX91							
Ferguson	T5173GF	TX91G							
Ferguson	T51F	TX91							
Ferguson	T59F	TX92	Thompson Digital Chassis						
Ferguson	T59FB	TX92F							
Ferguson	T59N	TX92							
Ferguson	T59NB	TX92F							
Ferguson	T68N	TX92							
Ferguson	T7021U	ICC17							
Ferguson	T7025UD	ICC17							
Ferguson	T78DPL	ICC9							
Ferguson	T78N	TX92							
Ferguson	T94N	ICC9							
Ferguson	TB6013C	TX10							
Ferguson	TB6023	TX9							
Ferguson	TB6213	TX9							
Ferguson	U2001	TX100							
Ferguson	U2201	TX100							
Ferguson	V51NB	TX91G							
Ferguson	W70201S	ICC17							
Ferguson	W7022U	ICC17							
Ferguson	W7023U	ICC17							
Ferguson	WF70401G	ICC20	(Telefunken chassis 446X)						
Ferguson	X51FB	TX91G							
Fidelity	1482	ZX2000							
Fidelity	AVS1600	ZX3000							
Fidelity	AVS2000	ZX3000							
Fidelity	C14M06/R06	ZX1415	Brittania B14M11						
Fidelity	C14M07	Solarvox 140 chassis	Nikkai TLG88						
Fidelity	C14M08	Solarvox 141 chassis	Nikkai TLG99						
Fidelity	C14R08	ZX4000							
Fidelity	C14T01	ZX5000							
Fidelity	C20R03	ZX4222							
Fidelity	C20T03	ZX4223							
Fidelity	C20T04	ZX5000 (Digital)	Saisho/Matsui CM260T						
Fidelity	C51T01	ZX5000							
Fidelity	CM14	ZX3000							
Fidelity	CTM14	ZX3000 Mk2							
Fidelity	CTM1400	ZX3000 Mk2							
Fidelity	CTM2000	ZX3000							
Fidelity	CTM2001	ZX3000							
Fidelity	CTM2002	ZX3000							
Fidelity	CTM2003R/T	ZX3000							
Fidelity	CTM2003TX	ZX4200							
Fidelity	CTM200TX	ZX4200							
Fidelity	CTV14	ZX2000							
Fidelity	CTV14 Mk2	ZX3000	Triumph CTV8209						
Fidelity	CTV140	ZX2000							
Fidelity	CTV1404	ZX1411	Murphy M14R01						
Fidelity	CTV1404R	ZX4000							
Fidelity	CTV1404S	ZX4000							
Fidelity	CTV1405	ZX3000							
Fidelity	CTV1405S	ZX4000							
Fidelity	CTV140R	ZX4010							
Fidelity	CTV14R	ZX2000							
Fidelity	CTV14S	ZX2000/3000							
Fidelity	CTV20	ZX4120							

Fidelity	CTV2001	ZX3000							
Fidelity	CTV2020	ZX3000							
Fidelity	CTV2022	ZX3000 Mk2							
Fidelity	CTV2024	ZX3000/2000							
Fidelity	CTV2026	ZX3000							
Fidelity	CTV20R	ZX3000/2000							
Fidelity	CTV20T	ZX3000							
Fidelity	CTV2201	ZX3000							
Fidelity	CTV2201S	ZX4230							
Fidelity	CTV2201T	ZX4231							
Fidelity	CTV2210	ZX3000							
Fidelity	CTV2224	ZX3000							
Fidelity	CTV2226	ZX3000							
Fidelity	CTV22R	ZX3000							
Fidelity	CTV22T	ZX3000							
Fidelity	WSTV7028NF	11AK19-8A							
Fidelity	WSTV7028NF	11AK19-8A							
Finlandia	A. Model numbers:-	E.G. C59CZ7 C=colour; 59=crt size;	C=year of manuf.; Z=Finlandia	7= version (higher the vers.	the more features)				
Finlandia	AZ			Salora J	Ipsalo 2				
Finlandia	BZ			Salora J	Ipsalo 2				
Finlandia	CZ			Salora K	Ipsalo 3				
Finlandia	DZ	Salora 15L37/20L30 etc		Salora L	Ipsalo 3				
Finlandia	EZ	Tashiko 51E941/942	Hitachi CPT2658	Salora K	Ipsalo 3				
Finlandia	FZ		Nokia	Salora M	Digital				
Finlandia	GZ		Hitachi CS2852TA	Salora M	Digital				
Finlandia	HZ		Nokia	Salora M	Digital				
Finlandia	JZ			Salora N					
Finlandia	NZ								
Finlandia	PZ								
Finlandia	SZ	Salora 1F3		Salora F					
Finlandia	TZ			Salora F					
Finlandia	VZ			Salora F					
Finlandia	XZ	Salora 1G3/1G5		Salora G/H	Ipsalo 1/2				
Finlandia	YZ			Salora J	Ipsalo 2				
Finlandia		Salora 1H4		Salora H	Ipsalo 2				
Finlandia		Salora 21/25/28M87	Hitachi CPT6608	Salora M	Digital				
Finlandia		Salora 22J40	Hitachi CPT2050/2250	Salora J	Ipsalo 2				
Finlandia		Salora 22K30 etc	Hitachi CPT2188/2568 etc	Salora K	Ipsalo 3				
Finlandia		Salora 24K7H / 22K37	Hitachi CPT2488	Salora K	Ipsalo 3				
Finlandia			Hitachi CPT2625	Salora J	Ipsalo 2				
Finlandia			Hitachi CPT2060/2260/2660	Salora J	Ipsalo 2				
Finlandia			Hitachi C15-P108	Salora L	Ipsalo 3				
Finlandia			Hitachi C17-P118	Salora L	Ipsalo 3				
Finlandia			Hitachi CPT1556	Salora L	Ipsalo 3				
Finlandia			Hitachi CPT2656	Salora K	Ipsalo 3				
Finlandia			Hitachi C28-P759						
Finlandia			Hitachi CPT2888	Salora K	Ipsalo 3				
Finlux	1013	160							
Finlux	1014	145							
Finlux	1014M	145 chassis Tatung							
Finlux	1015	165							
Finlux	1016	160							
Finlux	10B28	3000							
Finlux	10B35	3000							
Finlux	1101	165							
Finlux	1111	1000 Mono							
Finlux	1119	1000 Mono							
Finlux	1122	1000 Mono							
Finlux	1131	1000 Mono							
Finlux	1141	1000 Mono							
Finlux	1406	1000 Stereo							
Finlux	1412	1000 Stereo							
Finlux	1418	1000 Stereo							
Finlux	1422	1000 Stereo							
Finlux	14A1TX	Mono Plus 2 (MP2)							
Finlux	1622	3000							
Finlux	1632	1000 Stereo							
Finlux	1642	1000 Mono							
Finlux	2015	170							
Finlux	21A17	5000							
Finlux	21E17.	5000							
Finlux	21F12	5000							
Finlux	21S20	5100							
Finlux	21S22	5100							
Finlux	21S34	5000							
Finlux	21S38	5000							
Finlux	2472	2000							
Finlux	2482	2000							
Finlux	25C28	5000							
Finlux	25F14	5000							
Finlux	25K10	5000							
Finlux	25K30	5000							
Finlux	25S22	5100							
Finlux	25S24	5000							
Finlux	25S34	5000							
Finlux	25S38	5000							
Finlux	25S52	5000							
Finlux	2633	2000 Stereo							
Finlux	26E12.	5000							
Finlux	26E17.	5000							
Finlux	2872	2000							
Finlux	2882	2000							
Finlux	28C26	5100							
Finlux	28E17.	5000							
Finlux	28F12	5000							
Finlux	28K10	5000							
Finlux	28K30	5000							
Finlux	28S22	5100							
Finlux	28S24	5000							
Finlux	28S34	5000							
Finlux	28S38	5000							
Finlux	28W25	Eurodigi							
Finlux	3021F	3000							
Finlux	3024F	3000							
Finlux	3024F	3000							
Finlux	3028F	3000							
Finlux	3029	3000							
Finlux	3029V	3000							
Finlux	3029V	3000							
Finlux	32A21	3800							
Finlux	32W25	Eurodigi							
Finlux	32W35	Eurodigi							
Finlux	34A21	3600							
Finlux	34F12	3600							
Finlux	3621	3600							
Finlux	3624	3600							
Finlux	3628	3600							
Finlux	3720	CBT-9508							
Finlux	3815	C-8500							
Finlux	3821	8500							
Finlux	5021	C-8500							
Finlux	5021A65	5000							
Finlux	5021F12	5000							
Finlux	5025(S) 25524	5000							
Finlux	5025E17	5000							
Finlux	5025F12	5000							
Finlux	5025K10	5000							
Finlux	5025M14	5000							
Finlux	5025N65	5000							
Finlux	5028E17	5000							
Finlux	5028F12	5000							
Finlux	5028K10	5000							
Finlux	5028M14	5000							
Finlux	5028N65	5000							
Finlux	5029A65	5000							
Finlux	50F21	3600							
Finlux	50F25	3000							
Finlux	50F28	3000							
Finlux	50V29	3000							







Granada	C14HS5	Sanyo CBP3011							
Granada	C14HS5	Sanyo CBP3012							
Granada	C14HT2	JVC 1480							
Granada	C14HV2	Sharp C1421HBK							
Granada	C14HY2	Pye 37KV1242							
Granada	C14HY2	Sharp C1431HBK							
Granada	C14JS2	Sanyo CBP3012							
Granada	C14KS2	Sanyo CBP3015							
Granada	C14KS2	Sanyo CBP3018							
Granada	C14KS3	Sanyo CBP3024							
Granada	C14KX2	Toshiba 1400R							
Granada	C14LP3	Philips 1221B							
Granada	C14LX2	Toshiba 1400R							
Granada	C14LZ2	Nokia Mono Plus							
Granada	C14LZ3	Nokia OEM							
Granada	C14MN2	Panasonic TC14S1R							
Granada	C14MP2	Philips 14PT1277							
Granada	C14MY3	Sharp VT3700							
Granada	C14MZ2	Nokia OEM							
Granada	C14NN2	Panasonic TC14S1R							
Granada	C14NN4	Panasonic TX14S1T							
Granada	C14NP2	Philips 14136B							
Granada	C14NP4	Philips 14136B							
Granada	C14NS2	Sanyo EC2-A14							
Granada	C14NX4	Toshiba 1510RT							
Granada	C14PN4	Panasonic TX14S2T							
Granada	C14PP2	Philips 14PT1332							
Granada	C14PP3	Philips 14PV162							
Granada	C14PS2	Sanyo 14M1							
Granada	C14RN2	Panasonic TC14B3R							
Granada	C14RN2	Panasonic TX14B3T							
Granada	C14RP3	Philips 14PV172							
Granada	C16ER3	Panasonic TC1665							
Granada	C16ER3	Panasonic TC1675							
Granada	C16ES1	Sanyo CPi4144							
Granada	C16ES2	Sanyo CPi4144							
Granada	C16ES3	Sanyo CPi4144							
Granada	C16ES4	Sanyo CPi4144							
Granada	C16EV1	Nordmende 3636							
Granada	C16EV3	Decca 8485							
Granada	C16EV3	Ferguson 16A21							
Granada	C16EV3	Panasonic 8454							
Granada	C16EV5	Ferguson 16A3							
Granada	C17EV7	Seleco 17466							
Granada	C20AA4	GEC C2087H	Hitachi NP83CQ						
Granada	C20BY4	Rediffusion Mk 4A							
Granada	C20CD4	Tatung 145X							
Granada	C20DS4	Sanyo CPT3141							
Granada	C20EC3	Sanyo CTP6143							
Granada	C20ED1	Decca DN1672							
Granada	C20ED1	Decca DT1455							
Granada	C20ED1	Decca DT1655							
Granada	C20EK1	ITT 3307							
Granada	C20EK3	ITT CT3327							
Granada	C20EK5	ITT CT3327T							
Granada	C20ET3	Ferguson 2042							
Granada	C20ET3	Ferguson 20H2							
Granada	C20ET4	Ferguson 20E2H							
Granada	C20ET5	Ferguson 20A3T							
Granada	C20ET5	Ferguson 20C3H							
Granada	C20EV1	B&O M20							
Granada	C20EV2	Mitsubishi CT2033							
Granada	C20EV3	Sanyo CTP6144							
Granada	C20EV4	Ferguson 20A2T							
Granada	C20EV4	Ferguson 20E1H							
Granada	C20EV4	Mitsubishi CT120A2							
Granada	C20EV5	Mitsubishi CT2078							
Granada	C20EX3	Mitsubishi CT2040							
Granada	C20EX6	Fidelity 20T0							
Granada	C20EX6	Fidelity C20T04							
Granada	C20EY5	Pye 51KT2366							
Granada	C20RP3	Philips 20PV164							
Granada	C20RY1/2/3	Rediffusion Mk3							
Granada	C20TY1/2/3/5	Rediffusion Mk3							
Granada	C20VA1	GEC C2026H							
Granada	C20WY1/2/3/5	Rediffusion Mk4							
Granada	C20XA1	GEC C2067H	Hitachi NP81CQ						
Granada	C22AA4	GEC C2287H	Hitachi NP83CQ						
Granada	C22BY4	Rediffusion Mk 4A							
Granada	C22CD4	Tatung 145X							
Granada	C22DS4	Sanyo CPT3141							
Granada	C22ET3	Toshiba 222R5							
Granada	C22ET4	Ferguson 22D2H							
Granada	C22EV1	Pye 56EK2610							
Granada	C22EV5	Hitachi 2278							
Granada	C22EV5	Pye 56EK2615							
Granada	C22EV5	Sony 2217							
Granada	C22EV7	Nordmende 5432							
Granada	C22RY1/2/3	Rediffusion Mk3							
Granada	C22TY1/2/3/5	Rediffusion Mk3							
Granada	C22VA1	GEC C2236H							
Granada	C22VA3	GEC C2260H							
Granada	C22WY1/2/3/5	Rediffusion Mk4							
Granada	C22XA1	GEC C2267H	Hitachi NP81CQ						
Granada	C22XA5	GEC C2269H	Hitachi NP81CQ						
Granada	C24EV7	Seleco 24497							
Granada	C26BY4	Rediffusion Mk 4A							
Granada	C26BZ7	Salora J							
Granada	C26DS4	Sanyo CPT3141							
Granada	C26EK1	ITT 3715							
Granada	C26ES3	Sony 2762							
Granada	C26ES5	Hitachi 2658							
Granada	C26ET3	Ferguson 26D2H							
Granada	C26ET5	Ferguson 26D3H							
Granada	C26ET5	Ferguson 26D3H							
Granada	C26ET6	Toshiba 261T							
Granada	C26EV3	Mitsubishi CT2627							
Granada	C26RY1/2/3	Rediffusion Mk3							
Granada	C26TY1/2/3/5	Rediffusion Mk3							
Granada	C26WY1/2/3/5	Rediffusion Mk4							
Granada	C27EK7	ITT 3888							
Granada	C27EK8	ITT 888							
Granada	C27EK9	ITT 888							
Granada	C36EA3	GEC C1502							
Granada	C36EA4	GEC C1503							
Granada	C36EP1	Philips 15CE1010							
Granada	C36EP3	Philips 15CE1210							
Granada	C36EP4	Philips							
Granada	C36FD6	Tatung							
Granada	C36FY5	Pye 38KE1185							
Granada	C36GP5	Philips 15CE1518							
Granada	C36GP6	Philips 15GR2530							
Granada	C36GX2	Toshiba 155R9BZ							
Granada	C36HP6	Philips 15GR2530							
Granada	C36HX2	Toshiba 156R9BT							
Granada	C36JP6	Philips 2331							
Granada	C36JS2	Sanyo DeGraaf							
Granada	C37JK7	Panasonic HTZ							
Granada	C41EB4	Sanyo 1747							
Granada	C41EP4	Philips 17CE1230							
Granada	C41EP5	Philips 17CE1530							
Granada	C41EP6	Philips 17CE1538							
Granada	C41EV7	Seleco? (Sharp?) 1746							
Granada	C41EY5	Pye 43KT2196							
Granada	C41FK5	Panasonic TX1786							
Granada	C41FP2	Philips 17CE1230							
Granada	C41FS3	Sanyo CBP1748							
Granada	C41FS5	Sanyo CBP1740							
Granada	C41FS6	Sanyo CBP1748							



[illegible]

[illegible]

Granada	C59NN7	Panasonic TX25AD1DP																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																															
---------	--------	---------------------	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--







[illegible]

Hitachi	CPT1482	NP84C2								
Hitachi	CPT1483	NP84C2								
Hitachi	CPT1484	NP84C2								
Hitachi	CPT1497	NP84C2								
Hitachi	CPT1499	NP84C2								
Hitachi	CPT1556	Salora L								
Hitachi	CPT1557	Salora L								
Hitachi	CPT1558	Luxor 18036549								
Hitachi	CPT1624	NP82CQ								
Hitachi	CPT1626	NP82CQ								
Hitachi	CPT1644	NP84CQ								
Hitachi	CPT1646	NP84CQ								
Hitachi	CPT1646R	NP84CQ								
Hitachi	CPT1657	NP8C								
Hitachi	CPT1674	NP84CQ/4								
Hitachi	CPT1676	NP84CQ/4								
Hitachi	CPT2016	NP81CQ/2								
Hitachi	CPT2024	NP82CQ	GEC C2086							
Hitachi	CPT2026	NP83CQ								
Hitachi	CPT2028	NP83CQ								
Hitachi	CPT2036	NP83CQ	GEC 2090 / C2295							
Hitachi	CPT2038	NP83CQ								
Hitachi	CPT2044	NP83CQ/2	GEC2294H							
Hitachi	CPT2046	NP83CQ/2	GEC2294H							
Hitachi	CPT2048	NP83CQ/2								
Hitachi	CPT2050	Salora J 22J40								
Hitachi	CPT2051	NP80/CR	Expert 2061							
Hitachi	CPT2055	NP80C								
Hitachi	CPT2060	Salora J								
Hitachi	CPT2066	NP85CQ/2								
Hitachi	CPT2068	NP85CQ/2								
Hitachi	CPT2071	NP80/CR								
Hitachi	CPT2074	NP83CQ/2								
Hitachi	CPT2076	NP83CQ/2								
Hitachi	CPT2078	NP83CQ/2								
Hitachi	CPT2091	NP83CQ								
Hitachi	CPT2118	G6P								
Hitachi	CPT2128	G7P/2								
Hitachi	CPT2138	G7PS/2								
Hitachi	CPT2158	NP85CQ/2								
Hitachi	CPT2174	G6P								
Hitachi	CPT2176	G6P	GEC C2095 / C2200 / C2295							
Hitachi	CPT2178	G6P								
Hitachi	CPT2188	Salora K								
Hitachi	CPT2196	G8Q/P								
Hitachi	CPT2198	G8Q/P								
Hitachi	CPT2210	NP81CQ/2								
Hitachi	CPT2216	NP81CQ/2								
Hitachi	CPT2218	NP81CQ/2								
Hitachi	CPT2224	NP81CQ/2	GEC C2085 / C2285 / C2288							
Hitachi	CPT2226	NP81CQ/2	GEC C2286							
Hitachi	CPT2228	NP83CQ/2								
Hitachi	CPT2234	NP83CQ	GEC 2288H	GEC2089H						
Hitachi	CPT2236	NP83CQ								
Hitachi	CPT2238	NP83CQ								
Hitachi	CPT2244	NP83CQ/2	GEC2294H							
Hitachi	CPT2246	NP83CQ/2	GEC2294H							
Hitachi	CPT2248	NP83CQ/2								
Hitachi	CPT2250	Salora J								
Hitachi	CPT2260	Salora J	IPSALO-2							
Hitachi	CPT2274	NP83CQ/2								
Hitachi	CPT2276	NP83CQ/2								
Hitachi	CPT2278	NP83CQ/2								
Hitachi	CPT2476	G6P								
Hitachi	CPT2478	G6P								
Hitachi	CPT2488	Salora K								
Hitachi	CPT2508	G7P MK2								
Hitachi	CPT2524	G7P/2								
Hitachi	CPT2528	G7P								
Hitachi	CPT2538	G7P MK2								
Hitachi	CPT2550	Salora J								
Hitachi	CPT2568	NP86UQ/2								
Hitachi	CPT2578	G8Q/P								
Hitachi	CPT2596	G8Q/P								
Hitachi	CPT2598	G8Q/P								
Hitachi	CPT2598A	G8Q								
Hitachi	CPT2625	Sakora J								
Hitachi	CPT2626	NP83CQ								
Hitachi	CPT2650	Salora J								
Hitachi	CPT2656	Salora L								
Hitachi	CPT2658	Salora L								
Hitachi	CPT2660	Salora J	IPSALO-2							
Hitachi	CPT2808	G7P-MK2								
Hitachi	CPT2888	Salora K								
Hitachi	CPT3308	G8P								
Hitachi	CPT5908	Salora M								
Hitachi	CPT6608	Salora M								
Hitachi	CPY2055	NP80C								
Hitachi	CRP143	NP6C								
Hitachi	CRP146	PAL4								
Hitachi	CRP147	PAL4								
Hitachi	CRP148	PAL4								
Hitachi	CTP202	PAL4								
Hitachi	CTP203	NP6C								
Hitachi	CTP205	PAL4								
Hitachi	CTP206	PAL4								
Hitachi	CTP208	NP8CQ								
Hitachi	CTP209	PAL4								
Hitachi	CTP213	NP6C								
Hitachi	CTP215	NP6C								
Hitachi	CTP216	NP6C								
Hitachi	CTP217	NP6C								
Hitachi	CTP230	NP8C								
Hitachi	CWP132	NP6C								
Hitachi	CWP300	NP8CQ								
Hitachi	D36WF840N	D8 (A8 plus digibox but without feature box)	2001							
Hitachi	GIRD3000	USAT001								
Hitachi	GRD100	OMNI								
Hitachi	P26	SJ								
Hitachi	P27	SX								
Hitachi	P27FM	SX								
Hitachi	P32	SV								
Huanyu	37C2	similar to Hitachi NP82CQ								
ITT	1530HS	EUROMONO 1	HOTEL							
ITT	1730HS	EUROMONO 1	HOTEL							
ITT	2130HS	EUROMONO 1	HOTEL							
ITT	3578UK	COMPACT D								
ITT	3598UK	COMPACT D								
ITT	3878UK	COMPACT D								
ITT	3888UK	COMPACT D								
ITT	3988MS	DIGI B 110								
ITT	848C	COMPACT B								
ITT	Compact B Mk2	CT3425 / CT3437	CT3548	FX3448						
ITT	Compact D2 FST	ST25TX								
ITT	Core 110'	5520 / 6320 /7140								
ITT	Core 2	CP3128								
ITT	CP2212	CVC1110/12								
ITT	CP2342	CVC1110/12 PICO 1A								
ITT	CP2352	CVC1110/12 PICO 1A								
ITT	CP3104	PICO S								
ITT	CP3104/16	PICO S/2								
ITT	CP3106	MONOPRINT A								
ITT	CP3120	ZX4200								
ITT	CP3125/T	PICO S/2-3								
ITT	CP3128	MONOPRINT B								
ITT	CP3128	CORE 2 90DEG								
ITT	CP3200	PICO 1A								
ITT	CP3204	PICO S/22222-3								
ITT	CP3210	PICO A FS								



ITT	CP3225	PICO S+S/2							
ITT	CP3225/1	PICO S/3							
ITT	CP3228	MONOPRINT B							
ITT	CT2500	CVC1175							
ITT	CT2500/2	PICO 1ST/2							
ITT	CT2512	CVC1200							
ITT	CT2512/2	MINI 2 90DEG FS							
ITT	CT2600	CVC1210/15	MINI 2 110DEG STD						
ITT	CT2601	COMPACT 80R DST							
ITT	CT2612	CVC1210/15							
ITT	CT2612/2	MINI 2 110DEG FS							
ITT	CT2613	COMPACT 80R 110DEG							
ITT	CT2700	MINI 2 110DEG STD							
ITT	CT2701	COMPACT 80R DST							
ITT	CT2712	CVC1200	MINI 2 110DEG FS						
ITT	CT2713	COMPACT 80R							
ITT	CT3306	MONOPRINT A							
ITT	CT3307	MONOPRINT A							
ITT	CT3314M	MONOPRINT A							
ITT	CT3315	PICO S-S3							
ITT	CT3325	PICOS2-S3							
ITT	CT3326	MONOPRINT B							
ITT	CT3327	MONOPRINT B							
ITT	CT3414M	80R 110DEG							
ITT	CT3415	80R 110DEG							
ITT	CT3425	80R 110DEG							
ITT	CT3426	COMPACT B							
ITT	CT3435	COMPACT 80R 90DEG							
ITT	CT3436	COMPACT 80R 90DEG							
ITT	CT3437	COMPACT B							
ITT	CT3446	DIGI 3 90DEG							
ITT	CT3448	COMPACT B100DEG							
ITT	CT3535	80R 110DEG							
ITT	CT3537	COMPACT B 110DEG FST							
ITT	CT3548	COMPACT B2 110DEG FST							
ITT	CT3548	COMPACTB							
ITT	CT3548UK	COMPACTB							
ITT	CT3578	COMPACTD							
ITT	CT3598	COMPACTD							
ITT	CT3715	COMPACT 80R							
ITT	CT3724	COMPACT 80R 110DEG							
ITT	CT3724	MONO PLUS							
ITT	CT3835	COMPACT 80R 110DEG FST							
ITT	CT3837	COMPACT B 110DEG							
ITT	CT3878	COMPACTD							
ITT	CT3888	COMPACTD							
ITT	CT4030	CORE 90 FST							
ITT	CT4532	EUROMONO 1/ 2 90 DEG							
ITT	CT5110	CORE 2							
ITT	CT5111	CORE 2 90DEG							
ITT	CT5520	CORE 2 110DEG							
ITT	CT5521	CORE 2 90DEG							
ITT	CT5523	EUROMONO 1/2 90DEG							
ITT	CT6332	EUROMONO 1/2 110DEG							
ITT	CVC1100	Granada YK1							
ITT	CVC1102								
ITT	CVC1110	Granada AK1							
ITT	CVC1112								
ITT	CVC1120								
ITT	CVC1150								
ITT	CVC1175	Solarvox 20S09	CT2500/2						
ITT	CVC1200	Solarvox 20T19							
ITT	CVC1200								
ITT	CVC1202	CT2512							
ITT	CVC1203								
ITT	CVC1204								
ITT	CVC1210	CT2600 / 2700							
ITT	CVC1212								
ITT	CVC1215		TX2612						
ITT	CVC1217								
ITT	CVC20								
ITT	CVC21								
ITT	CVC25								
ITT	CVC30		TX791						
ITT	CVC32								
ITT	CVC40	CP340							
ITT	CVC45								
ITT	CVC5								
ITT	CVC7								
ITT	CVC800								
ITT	CVC801	Granada XK1/5	CP0211/1						
ITT	CVC802	CT1511/2							
ITT	CVC803	CT0500/2							
ITT	CVC820	Granada WK1/5							
ITT	CVC823	CT600/1				ITT80-90°			
ITT	CVC824	CT3701/3732	CT/TX3432/3732			ITT80-90°/110°			
ITT	CVC825		ITT 3732						
ITT	CVC830		ITT80-110°						
ITT	CVC9								
ITT	Digi 3	ST3876/3896	ST3576						
ITT	Digivision 6362	Eurostereo 1							
ITT	Digivision 6382	Eurostereo 1							
ITT	Digivision 7162	Eurostereo 1							
ITT	Digivision 7182	Eurostereo 1							
ITT	EuroMono2		FX5532						
ITT	EuroStereo		2BF110NN						
ITT	FS9R	FS10R							
ITT	FX3448	Compact B							
ITT	FX3448UK	Compact B							
ITT	FX3548	Compact B							
ITT	FX3548UK	Compact B							
ITT	FX3724	MONO PLUS							
ITT	FX4030	CORE 2 90DEG							
ITT	FX4530	CORE 2 90DEG							
ITT	FX4532	EUROMONO 1/2 90DEG							
ITT	FX5124	MONOPLUS							
ITT	FX5520	CORE 2 110DEG							
ITT	FX5521	CORE 2 90DEG							
ITT	FX5524	MONO PLUS							
ITT	FX5530	CORE 2 90DEG							
ITT	FX5532	EUROMONO 1/2 90DEG							
ITT	FX6320	CORE 2 110DEG							
ITT	FX6330	CORE 2 110DEG							
ITT	FX6332	EUROMONO 1/ 2 110DEG							
ITT	MC3896	DIGI 3 110DEG							
ITT	Mini 2 ST2/2					TX3325			
ITT	Monoprint A	CT3306	CP3106						
ITT	Monoprint B	CT3327	CT3326			TX3326			
ITT	Monoprint B					TX3126			
ITT	Pico 1A	Granada 14AK1							
ITT	Pico S/2								
ITT	Pico S/3	CT2500	TX2612			CP3106			
ITT	Pico S/3	Solarvox 16R19	Solarvox 20S19			CT23304	KB Aristocrat A632S		
ITT	Pico S/3	Tashiko 14F681	Solarvox 14R19			CT3315/1	CP3125		
ITT	SAT7190	M80							
ITT	SFN3578	COMPACT D-2							
ITT	SFN3878	COMPACT D-2							
ITT	SFN5363	EUROSTEREO 1							
ITT	SFN5515	5000							
ITT	SFN5552	EUROSTEREO 1							
ITT	SFN5553	EUROSTEREO 2 B-F							
ITT	SFN5575	STEREO PLUS							
ITT	SFN5581	COMPACT D/E							
ITT	SFN6315	5000							
ITT	SFN6355	STEREO PLUS							
ITT	SFN6361	COMPACT DE							
ITT	SFN6363	EUROSTEREO 1							
ITT	SFN6364	EUROSTEREO 2 B-F							
ITT	SFN6365	STEREO PLUS							

[illegible]





Logik	4294	TX100							
Logik	4298	TX10							
Logik	20A1	TX100							
Logik	20E1	TX90							
Logik	4298	TX100							
Logik	M125	KC							
Luxor	3361	L1 Chassis							
Luxor	3392	Mono Plus 2 (MP2)							
Luxor	3654	L1 Chassis							
Luxor	3711	B-2 Chassis							
Luxor	3781	180 Chassis	B-1 Chassis						
Luxor	4211	B-2 Chassis							
Luxor	4723	Nokia 3723							
Luxor	4743	Nokia 3743							
Luxor	4751	A-1 CHASSIS							
Luxor	4781	B-1 CHASSIS							
Luxor	4783	Nokia 3783							
Luxor	4791	B-2 CHASSIS							
Luxor	4854	L-1 CHASSIS							
Luxor	4874	L-2 CHASSIS							
Luxor	5111	BC Chassis	B-2 Chassis						
Luxor	5114	BC Chassis	B-2 Chassis						
Luxor	5134	B3-1 Chassis	SX9 Chassis						
Luxor	5141	SX9 Chassis							
Luxor	5151	A1 Chassis							
Luxor	5191	B2 Chassis							
Luxor	5192	Mono Plus 2 (MP2)							
Luxor	5355	SX9 Chassis							
Luxor	5564	L-2 CHASSIS							
Luxor	5566	K1							
Luxor	5592	Mono Plus 2 (MP2)							
Luxor	5601	BC Chassis	B-2 Chassis						
Luxor	5608	BC Chassis	B-2 Chassis						
Luxor	5609	B-2 Chassis							
Luxor	5619	SX9 Chassis							
Luxor	5634	SX9 Chassis							
Luxor	5636	SX9 Chassis							
Luxor	5639	SX9 Chassis							
Luxor	5644	SX9 Chassis							
Luxor	5661	A-1 CHASSIS							
Luxor	5664	A-1 CHASSIS							
Luxor	5681	B-1 CHASSIS							
Luxor	5691	B-2 Chassis							
Luxor	5698	B-2 Chassis							
Luxor	6355	SX9 Chassis							
Luxor	6368	K-1 Chassis							
Luxor	6385	M Chassis	Salora						
Luxor	6387	L-2 CHASSIS							
Luxor	6615	A-2 CHASSIS							
Luxor	6656	SX9 Chassis							
Luxor	6661	A-1 CHASSIS							
Luxor	6663	A-1 CHASSIS							
Luxor	6664	A-1 CHASSIS							
Luxor	6709	B-2 Chassis							
Luxor	6711	B-2 Chassis							
Luxor	6711	BC Chassis							
Luxor	6714	A-2 CHASSIS							
Luxor	6718	B-2 Chassis							
Luxor	6718	BC Chassis							
Luxor	6719	A-2 CHASSIS							
Luxor	6734	SX9 Chassis							
Luxor	6736	SX9 Chassis							
Luxor	6739	SX9 Chassis							
Luxor	6741	SX9 Chassis							
Luxor	6781	A-1 CHASSIS							
Luxor	6791	B-2 Chassis							
Luxor	6798	B-2 Chassis							
Luxor	7064	L-2 CHASSIS							
Luxor	7068	K-1 Chassis							
Luxor	7075	M Chassis	Salora						
Luxor	7078	M-1 CHASSIS							
Luxor	7085	M Chassis	Salora						
Luxor	7128	EURODIGI 16:9							
Luxor	8228	EURODIGI 16:9							
Luxor	8289	Nokia/Salora/Luxor MZ-chassis							
Luxor	9128	EURODIGI 16:9							
Luxor	18056449	SX9 Chassis							
Luxor	18067349	SX9 Chassis							
Luxor	17L67	L2 Chassis							
Luxor	FS71U1	FEATURE STEREO (FS Chassis)							
Matsui	1091X	Goodmans Compact-100							
Matsui	1400 IRE	11AK36A8	2003-2004	AK36 prod.code: 10023024					
Matsui	1402								
Matsui	1403								
Matsui	1407	orion chassis	PCB marked TM7384A	serv.mode: set volume to minimum, press VOL- on TV and '9' on R/C, navigate using Ch+/Ch-, adjust using Vol+/Vol-, to					
Matsui	1407RS	same chassis to 2107N	serv.mode: see Matsui 1407						
Matsui	1408R	Orion chassis	PCB TM9414A, TM9414B; Micro OEC6053	Remote 076R0BR060					
Matsui	1408T	Orion TV134TX	PCB marked TM9414B, Micro OEC6053A	Remote 07660BQ150					
Matsui	1409R	Orion chassis, serv.mode see 1407	PCB marked TMX466A	076R0DG020	scan coils XY-14016AL2 E157951 fail very often				
Matsui	1409T	Orion chassis, serv.mode see 1407	PCB marked TMX466A	076R0DG010	scan coils XY-14016AL2 E157951 fail very often				
Matsui	140R	=140R Orion chassis	PCB marked TM6362						
Matsui	140T	=140T Orion chassis	PCB marked TM6362						
Matsui	1410	Amstrad CTV1401	Saisho CT1400						
Matsui	1410	Saisho CT142R	ORION 14PS(B)						
Matsui	1410R	Orion CTN BB							
Matsui	1410T	Orion CTN BB							
Matsui	1414R		there is no elec.service mode, but there is child lock, volume lock and tuning lock						
Matsui	1420	Orion 14DS	Saisho CT141						
Matsui	1420A	Saisho CT141X							
Matsui	1420B								
Matsui	1420T	Orion chassis, serv.mode see 1407	2002/2003 £70, 2004 £60	PCB TMA504A, Micro OECF00	INIT 01 -> EEPROM 03H, INIT 02 ->04H and so on				
Matsui	1420TSIL(B)	Orion chassis, serv.mode see 1407	2004	PCB TMB557A, Micro PCM195C30ECF009B (OECF009B)					
Matsui	1421T Silver		2004 £60						
Matsui	1422								
Matsui	1424	TATUNG 190/195							
Matsui	1430								
Matsui	1430A								
Matsui	1434	Tatung 190							
Matsui	1435	Orion 14A chassis	PCB marked TM0176B						
Matsui	1435B	Orion chassis	PCB marked TM0176C						
Matsui	1436	Bush 2004	Alba CTV100						
Matsui	1436XA								
Matsui	1440	Orion 14DR	Saisho CT142R						
Matsui	1440A	Saisho CT142RX							
Matsui	1450	Binatone 01/9014	Boots CTV1414R						
Matsui	1450	Matsui 1455							
Matsui	1450	Saisho CT147R	HINARI CT4	Dansai CTV1477					
Matsui	1455	Alba CTV4805	Onwa						
Matsui	1460	1660 2060							
Matsui	1465								
Matsui	1466	ORION 14LR							
Matsui	1476	Orion chassis	PCB marked TM0280A	LOPTr Q401 2SD2089 LOPTx FCM-14B007A					
Matsui	1480	Saisho CT149							
Matsui	1480A	Orion 14DT	Saisho CT149X						
Matsui	1480B								
Matsui	1481								
Matsui	1481B	Orion 14AT	PCB marked TM0157						
Matsui	1482								
Matsui	1496(T) ( R )	Matsui 2096, CHASSIS SR1	Crown CRP2196NT						
Matsui	1498	Onwa							
Matsui	1408R	see 1408R (letter "O" = zero)							
Matsui	14R1	Grundig G1000							
Matsui	14T1	Grundig G1000	GT1402						
Matsui	14TR50	Tatung F chassis							
Matsui	14TVDVR1	TV/DVD/VCR Combi	2004 £199						
Matsui	14V1	G1000	GT1401						
Matsui	14V1R	GrundigCUC7301	P37-071						
Matsui	14V1T	GrundigCUC7301	P37-731						
Matsui	14V2R	CUC7303							



Mitsubishi	CT15MS1TX	EE2							
Mitsubishi	CT180								
Mitsubishi	CT188								
Mitsubishi	CT1902								
Mitsubishi	CT1905								
Mitsubishi	CT2023								
Mitsubishi	CT2027								
Mitsubishi	CT2027								
Mitsubishi	CT2101								
Mitsubishi	CT2117								
Mitsubishi	CT2124	Euro 4 Chassis							
Mitsubishi	CT2125								
Mitsubishi	CT2131	Euro 4 Chassis							
Mitsubishi	CT2132	Euro 4 Chassis							
Mitsubishi	CT2141	Euro 4 Chassis							
Mitsubishi	CT2142	Euro 4 Chassis							
Mitsubishi	CT2144	Euro 4 Chassis							
Mitsubishi	CT2145	Euro 6 Chassis							
Mitsubishi	CT2145BM	Euro 6 Chassis							
Mitsubishi	CT2146	Euro 6 Chassis							
Mitsubishi	CT2146TX	Euro 6 Chassis	EURO 4						
Mitsubishi	CT2153	Euro 4Z Chassis							
Mitsubishi	CT2154	Euro 4 Chassis							
Mitsubishi	CT2155	Euro 4Z Chassis							
Mitsubishi	CT21A2STX(LST)	Euro 12 Chassis							
Mitsubishi	CT21A3STX	Euro 12 Chassis							
Mitsubishi	CT21A5STX	Euro 14FS							
Mitsubishi	CT21AV1B	EE3							
Mitsubishi	CT21M1	Euro 10 Chassis							
Mitsubishi	CT21M1BM	Euro 10 Chassis							
Mitsubishi	CT21M1LM	Euro 10 Chassis							
Mitsubishi	CT21M2	Euro 14							
Mitsubishi	CT21M3	Euro 14							
Mitsubishi	CT21M5B(T)	EE4							
Mitsubishi	CT2206								
Mitsubishi	CT2217								
Mitsubishi	CT2223								
Mitsubishi	CT2224								
Mitsubishi	CT2227								
Mitsubishi	CT2230								
Mitsubishi	CT2517	Euro 1 Chassis							
Mitsubishi	CT2525	Euro 10 Chassis							
Mitsubishi	CT2528	Finlux 9000							
Mitsubishi	CT2531	Euro 4 Chassis							
Mitsubishi	CT2532	Euro 4 Chassis							
Mitsubishi	CT2533								
Mitsubishi	CT2534	Euro 4 Chassis							
Mitsubishi	CT2545	Euro 4 Chassis							
Mitsubishi	CT2553	Euro 4Z Chassis							
Mitsubishi	CT2554								
Mitsubishi	CT2555	Euro 4Z Chassis							
Mitsubishi	CT25A2STX(LST)	Euro 12 Chassis							
Mitsubishi	CT25A3STX	Euro 12 Chassis							
Mitsubishi	CT25A4STX(LST)	Euro 12 Chassis							
Mitsubishi	CT25A5STX	Euro 14FS							
Mitsubishi	CT25A6STX	Euro 12 Chassis							
Mitsubishi	CT25AV1B	EE3							
Mitsubishi	CT25AV1BDS	EE3 Chassis	TV/Sat Rx						
Mitsubishi	CT25B2STX	Euro 11 Chassis							
Mitsubishi	CT25B3ST	B3							
Mitsubishi	CT25M1	M1 Chassis Euro 10 Chassis							
Mitsubishi	CT25M2TX	Euro 14							
Mitsubishi	CT25M3TX	Euro 14							
Mitsubishi	CT25M5BT	EE4							
Mitsubishi	CT28AV1B	EE3							
Mitsubishi	CT28BW2B	EE3 Chassis							
Mitsubishi	CT28BW2BD	EE3W							
Mitsubishi	CT2964	Euro 4Z Chassis							
Mitsubishi	CT2965	Euro 8F Chassis	PSU similar to Euro 10						
Mitsubishi	CT29A4ST	Euro 12 Chassis							
Mitsubishi	CT29A6ST	Euro 12 Chassis							
Mitsubishi	CT29AT5								
Mitsubishi	CT29B2STX	Euro 11 Chassis							
Mitsubishi	CT29B3ST	B3							
Mitsubishi	CT29B4ST	B4							
Mitsubishi	CT29BV1(BD)	EE3W							
Mitsubishi	CT32BW1B	W1							
Mitsubishi	CT32CW1BD	EW1							
Mitsubishi	CT33B3ST	B3							
Mitsubishi	CT33C1STX(TX)								
Mitsubishi	CT37C1STX(TX)								
Mitsubishi	CT37C2STX	E9							
Murphy	3510T	Goodmans FST51TT							
Murphy	CTV 3510	Murphy CTV 3540T							
Murphy	CTV3500	Cathay/Osaki P22G	Phase PH20567				Susumu FX14S/FX1400R		
Murphy	CTV3540T	Goodmans FST51TT							
Murphy	M14R01	Fidelity ZX4000	Fidelity CTV1404R						
Murphy	M1500	Fidelity ZX4000							
Murphy	M22S01	Fidelity ZX4200							
Murphy	M22S01	Fidelity ZX4200							
Murphy	M22T01	Fidelity ZX4000							
Murphy	MC6124	Bush BC6004							
Naiko	N1088	Goodmans Compact-110							
Naiko	N2810DVD	PT92 +DVD	2003/2004 Safeways F299						
Naiko	N2811W	PT92							
Naiko	N2818W	PT92							
Naiko	N2850W	PT92	2003/2004						
Naiko	N2866	PT90A +DVD							
Naiko	N2897	F16							
Naiko	N3211W	PT92							
Naiko	N3280W	PT90	2003/2004						
Narita	DVTV2	TV+DVD Profile PT90C chassis							
NEC	PF32W01	Daewoo SC132 chassis	=Daewoo model DSC3261H						
NEI	1288	Mono							
NEI	1451R/TX	Indiana 100 Chassis	Bush						
NEI	1461R	Indiana 100 Chassis	Bush						
NEI	1481R	Indiana 100 Chassis	Similar to NEI2031						
NEI	1482	Indiana 100 Chassis	Bush						
NEI	14FRE								
NEI	14SRE		Sunkyong						
NEI	1551TX	Indiana 100 Chassis	Bush						
NEI	1581TX	Indiana 100 Chassis	Bush						
NEI	1601								
NEI	2031R/TX	Indiana 100 Chassis							
NEI	2041R	Indiana 200 Chassis	Bush						
NEI	2047(TX)	Indiana 200 Chassis							
NEI	2051R/TX	Indiana 200 Chassis	Bush						
NEI	2052R	Indiana 200 Chassis	Bush						
NEI	2131R	Indiana 100 Chassis	Bush						
NEI	2147(TX)	Indiana 200 Chassis							
NEI	2151R/TX	Indiana 200 Chassis	Bush						
NEI	2152R	Indiana 200 Chassis							
NEI	2181R	Indiana 200 Chassis	Bush						
NEI	2591FTXN	CE25							
NEI	2891FTXN	CE25							
NEI	5544	11AK03 Chassis							
NEI	ART701	Evelux E5 (use remote to bring out of stby)	Evelux = Elektronika Velenje in Slovenia						
NEI	C25F1FXN	CE25							
NEI	C28F1FXN	CE25							
NEI	CTV61	Indiana 100 Chassis							
NEI	E14D1X	Evelux E5							
NEI	E14TX	Evelux E5							
NEI	E20C1X	Evelux E5							
NEI	E2591TFXN	CE25							
NEI	E25G1TFXN	Evelux E5							
NEI	E28G1TFXN	Evelux E5							
NEI	NE3743TX	11AK08							
NEI	NE5147	11AK03 Chassis							
NEI	NE5155NT	11AK10							





Nokia	SFN7174	Eurostereo 2 B-F							
Nokia	SFN7186	FEATURE STEREO (FS Chassis)							
Nokia	SFN7296	FEATURE STEREO PLUS							
Nokia	SFN8296	FEATURE STEREO PLUS							
Nokia	SP55A1.5554	STEREO PLUS							
Nokia	SP63D1.6355UK	STEREO PLUS							
Nokia	SP71D1	STEREO PLUS							
Nokia	SP71L1	STEREO PLUS	Akai CT2867						
Nokia	ST51A1	MONOPLUS							
Nokia	ST51D2	MONOPLUS							
Nordmende	1434PI	F10							
Nordmende	1444	F10							
Nordmende	2112	F10							
Nordmende	2513A	F8							
Nordmende	3434	F10							
Nordmende	3601		Ferguson 3787						
Nordmende	3602	F8							
Nordmende	3604	F14							
Nordmende	4230	FV I	Ferguson 3787						
Nordmende	4231		Ferguson 3787						
Nordmende	5038	F15/16							
Nordmende	5205	F15/16							
Nordmende	5432	F11							
Nordmende	6559	F15							
Nordmende	7000	F15							
Nordmende	778535A	F5 TT							
Nordmende	8180		Ferguson 3787						
Nordmende	9572D	F5 TT							
Nordmende	982512H	F10							
Nordmende	982514/H	F10							
Nordmende	982515/H	F10							
Nordmende	F11B	Ferguson ICC3							
Nordmende	F15	Ferguson ICC5	Telefunken 617						
Nordmende	F18	Ferguson ICC5	Telefunken 617						
Nordmende	F17/F18	Ferguson ICC5	Telefunken 518/618/B/A						
Nordmende	F19	Ferguson IKC2							
Nordmende	F19/F20	Ferguson IKC2	Telefunken 418/A						
Nordmende	F20	Ferguson IKC2							
Nordmende	F22	Ferguson TX80	Telefunken 318A						
Nordmende	F23	ICC8-S	Telefunken 418						
Nordmende	F23-11	ICC7-S	Telefunken 418B-ST						
Nordmende	F24	ICC8-M	Telefunken 418C						
Nordmende	F24-11	ICC7-M	Telefunken 418B						
Nordmende	Futura 55	chassis F18							
Oceanic	B294SAT	Eurodigi 16:9							
Okishi	N2818W	PT92							
Onimax	2818	TV9.3 Multi (Schneider)	Micro IC901 ST92R195B0/EPF	LOPTx 1372.0031, =HR8409					
Onwa	K9228	Akai CT2862UNT							
Orion	14AT	Matsui 1481B							
Orion	14DR	Matsui 1440	Saisho CT142R						
Orion	14DS	Matsui 1420	Saisho CT141						
Orion	14DT	Matsui 1480A	Saisho CT149X						
Orion	14LR	Matsui 1466							
Orion	14PR	Amstrad CTV1409	Saisho CT14R	Triumph CTV8208					
Orion	14PS	Amstrad CTV1401	Matsui 1410	Saisho CT1400					
Orion	16BR	Matsui 1640	Saisho CT162R						
Orion	18PS	Matsui 1810	Saisho CT1800						
Orion	20LS	Logik 690	Saisho CT204						
Orion	20LT	Logik 698	Saisho CT208						
Orion	286KB	4300	PCB marked B-4101						
Orion	28ZKM TV28F44	4400							
Orion	28ZKN TV28F44	4400							
Orion	3850	Bush 4400 chassis							
Orion	C1500	combi Orion chassis	PSU PCB VPA150A, main PCB VMA230A	Micro OEC0107					
Orion	CTV144	Saisho CX14R	Triumph CTV8212						
Orion	CTV164	Saisho CX16R	Triumph CTV8312						
Orion	T28F44	4400							
Orion	TV134TX	Matsui 1408T		Remote 07660BQ160					
Orion	TV2844W	4400 chassis							
Orion	TV400TX	chassis CTT-H AA							
Orion	TV4400NTX	4400 chassis							
Orion	TV450TX ( TV450R )	CTN AA chassis							
Orion	TV700BR	CTN AA chassis							
Orion	TV700SLTX	CTN BB chassis							
Orion	TV800TX	CTN AA chassis							
Osaki	3214S	Orion 14A chassis							
Osaki	Ci5013T	Samsung Ci5052XT							
Osaki	CTV14	Jackson Mk2	Triumph CTV8209						
Osaki	P10	Nikkai Baby 10 etc							
Osaki	P140	Philips GR1-AX	Philips 14GR1021						
Osaki	P142	Akura CX4							
Osaki	P145	Philips GR1-AX							
Osaki	P20G	Murphy CTV3500							
Osaki	P20H	Hinari CT4							
Osaki	P60G	Hitachi NP8CQ							
Osume	CTV1474R	Bush 2214							
Osume	CTV1484R	Solarvox 141	Nikkai TLG99	Harwood HTV9014R					
Osume	CTV1486T	Nikkai TLG100T							
Pacific	PDVTV14-100	Orion chassis	Micro 195C6PC00ECF011A (OECF011A)						
Pacific	PTV2701T	Schneider chassis TV9							
Pacific	PTV3604	CTS AA	Micro SAA5541PS/M5/0330						
Pacific	PTV3605	Beko 12.8	PCB marked G80.190-02	LOPTx 003071094 (058.413-TR5), equiv. FBT41041					
Pacific	PTV3606	Orion chassis	PCB marked TMB557A						
Pacific	PTV5102	CTS AA		serv.: select prog 75, press OSD key (+) on R/C and MENU on TV together for 10 sec, green S will appear in lower left c					
Pacific	PTV7001T	E9 chassis (Evelux, made in Slovenia)	Micro SDA5255-B001						
Pacific	PTV7002	E9 chassis (Evelux, made in Slovenia)							
Pacific	PTV7003	E9 chassis (Evelux, made in Slovenia)	Micro SDA5255-B002						
Panasonic	1665	Z1							
Panasonic	21V2	Alpha 4							
Panasonic	25A3	Euro 1							
Panasonic	25X1DP	Alpha 4							
Panasonic	28X1	Alpha 4H							
Panasonic	28X1DP	Alpha 4							
Panasonic	CT20S	U4 Chassis							
Panasonic	CT22S	U4W Chassis							
Panasonic	TC1302	M6							
Panasonic	TC1303	M6							
Panasonic	TC1404	M11							
Panasonic	TC1405	M11							
Panasonic	TC1406	M11							
Panasonic	TC1407	M12							
Panasonic	TC1408	M12							
Panasonic	TC1460	Z1							
Panasonic	TC1465	Z1							
Panasonic	TC1470	Z1							
Panasonic	TC1475	Z1							
Panasonic	TC1480	Z3							
Panasonic	TC1485T	Z3	1990						
Panasonic	TC14B3R	Z375 (DAEWOO CP375)							
Panasonic	TC14B4R(/B)	Z185 (Daewoo CP185)							
Panasonic	TC14JR1	Z7							
Panasonic	TC14K1R	Z7							
Panasonic	TC14L3R	MX1A							
Panasonic	TC14S1M	Z5							
Panasonic	TC14S1R/B	Z5		remote TNQ8E0460					
Panasonic	TC14S1R/BH	Z5		remote TNQ8E0461					
Panasonic	TC14S2R	Z5		remote TNQ8E0460					
Panasonic	TC14S3R(/W)	Z7		remote TNQ8E0460					
Panasonic	TC14S3RC	Z7	nonUK Pal B/G						
Panasonic	TC14S4RL	Z7		remote TNQ8E0460					
Panasonic	TC15M1	Z4							
Panasonic	TC15M1M	Z4							
Panasonic	TC15M1R	Z4							
Panasonic	TC15M1T	Z4							
Panasonic	TC15M2	Z4							
Panasonic	TC15M2R	Z4		remote TNQ8E0448					
Panasonic	TC15MIR	Z1							
Panasonic	TC1601	M11							
Panasonic	TC1602	M11							

Panasonic	TC1831	U4							
Panasonic	TC1832	U4							
Panasonic	TC1833	U4							
Panasonic	TC1835	U4							
Panasonic	TC1837	U4							
Panasonic	TC1841	U4							
Panasonic	TC1651	U5							
Panasonic	TC1665	Z1							
Panasonic	TC1675	Z1							
Panasonic	TC1752	U5							
Panasonic	TC1785	Z3							
Panasonic	TC1786	Z3							
Panasonic	TC1802	M11							
Panasonic	TC1802U	M7							
Panasonic	TC1803	M7							
Panasonic	TC1807	M9							
Panasonic	TC1808	M11							
Panasonic	TC1810	M11							
Panasonic	TC1830	M12							
Panasonic	TC1832	M12							
Panasonic	TC200	M11							
Panasonic	TC2000	U3							
Panasonic	TC2002	U1							
Panasonic	TC2006	M7							
Panasonic	TC201	M9	M11						
Panasonic	TC2011	U3W							
Panasonic	TC202	M11							
Panasonic	TC202	PIX-M9							
Panasonic	TC2020	M11							
Panasonic	TC2024	U3W							
Panasonic	TC202G	PIX-M9							
Panasonic	TC2030	M12							
Panasonic	TC2031	U4W							
Panasonic	TC2033	U4							
Panasonic	TC2035	M11							
Panasonic	TC204	M9							
Panasonic	TC2043	U4W							
Panasonic	TC2051	U5							
Panasonic	TC2055	M11							
Panasonic	TC2056	M11							
Panasonic	TC2061	U5							
Panasonic	TC2076	M11							
Panasonic	TC208	U3							
Panasonic	TC2086	M11							
Panasonic	TC210	M11							
Panasonic	TC211	M12							
Panasonic	TC2110	U5N							
Panasonic	TC2112	U5							
Panasonic	TC212	M11							
Panasonic	TC214	M11							
Panasonic	TC215	M12							
Panasonic	TC216	M11							
Panasonic	TC2160	U5N							
Panasonic	TC217	M11							
Panasonic	TC2175	Z1							
Panasonic	TC218	M11							
Panasonic	TC2185	Z3							
Panasonic	TC2195	Z3T							
Panasonic	TC21K1R	Z7							
Panasonic	TC21L3R	MX1A							
Panasonic	TC21M	Z4							
Panasonic	TC21M1R	Z4							
Panasonic	TC21M2R	Z4			remote TNQ8E0447				
Panasonic	TC21R	ALPHA2							
Panasonic	TC21R1	ALPHA2							
Panasonic	TC21S1	Z5			remote TNQ8E0461				
Panasonic	TC21S3	Z7							
Panasonic	TC21S4RL	Z7			remote TNQ8E0460				
Panasonic	TC220	M11							
Panasonic	TC2201	U1	PIU-S1C						
Panasonic	TC2202	U1							
Panasonic	TC2203	U1							
Panasonic	TC2204	U1							
Panasonic	TC2205	U2							
Panasonic	TC2206	U1/U4							
Panasonic	TC2207	U2							
Panasonic	TC2208	U2							
Panasonic	TC2209	U3							
Panasonic	TC221	U3							
Panasonic	TC2210NS	M11							
Panasonic	TC2210SP	M8							
Panasonic	TC2210VR	M12							
Panasonic	TC2211	U3W							
Panasonic	TC2213	U3W							
Panasonic	TC2216	U3W							
Panasonic	TC222	M11							
Panasonic	TC2220	M11							
Panasonic	TC2221	U3							
Panasonic	TC2223	U3							
Panasonic	TC2225	U3							
Panasonic	TC2226	U3							
Panasonic	TC2229	U3							
Panasonic	TC223	M12							
Panasonic	TC2231	M7							
Panasonic	TC2232	U4W							
Panasonic	TC2233	U4W							
Panasonic	TC2234	U4							
Panasonic	TC2235	M11							
Panasonic	TC2235UR	U4							
Panasonic	TC2239	U4							
Panasonic	TC224	M11							
Panasonic	TC2240	U4							
Panasonic	TC2243	U4							
Panasonic	TC225	U3							
Panasonic	TC2251	M8							
Panasonic	TC2253	U5							
Panasonic	TC2255	M11							
Panasonic	TC2256	M11							
Panasonic	TC2263	U5							
Panasonic	TC2271	M8							
Panasonic	TC2276	M11							
Panasonic	TC2283	U2 / U3							
Panasonic	TC2291	U2							
Panasonic	TC2292	U2							
Panasonic	TC2293	U2							
Panasonic	TC230	M12							
Panasonic	TC232	M12							
Panasonic	TC233	M12							
Panasonic	TC234	M12							
Panasonic	TC235	M12							
Panasonic	TC2461	U5							
Panasonic	TC2475	ALPHA1W							
Panasonic	TC24R1	ALPHA2							
Panasonic	TC26	M11							
Panasonic	TC2600	M8							
Panasonic	TC2603	M11							
Panasonic	TC261	M8							
Panasonic	TC2610	M11							
Panasonic	TC262	M7	PIUS1						
Panasonic	TC2620	M11							
Panasonic	TC2622	U3W							
Panasonic	TC2629	U3							
Panasonic	TC262G	M11							
Panasonic	TC262GA	PIUS1							
Panasonic	TC262SPM	M9							
Panasonic	TC2630	M12							
Panasonic	TC2633	U4							
Panasonic	TC2634	U4							
Panasonic	TC2635	M11							

[illegible]



Panasonic	TX32PG30	EURO7		remote EUR511212A					
Panasonic	TX32PG50	EURO7		remote EUR511224					
Panasonic	TX32PH40	EURO7P	2002	remote EUR511224					
Panasonic	TX32PK1	EURO4		remote EUR511210					
Panasonic	TX32PK2	EURO4		remote EUR511210					
Panasonic	TX32PK20	EURO5		remote EUR511211					
Panasonic	TX32PK25	EURO4H 100Hz		remote EUR511211					
Panasonic	TX32PK3	EURO4		remote EUR511210					
Panasonic	TX32PL1	EURO4		remote EUR511210					
Panasonic	TX32PL10	EURO4H 100Hz	around £900	remote EUR511211					
Panasonic	TX32PL4	EURO4		remote EUR511210					
Panasonic	TX32PS1	EURO10	2003	remote EUR511320					
Panasonic	TX32PS5	EURO10							
Panasonic	TX3300	U4							
Panasonic	TX3370GR	ALPHA1							
Panasonic	TX33A1	ALPHA2W							
Panasonic	TX33A1G	ALPHA2							
Panasonic	TX33A2	ALPHA3							
Panasonic	TX33AK10	EURO5		remote EUR511211					
Panasonic	TX36DT35	EURO8	2002	remote EUR511241					
Panasonic	TX36PB50(N)	EURO7		remote EUR511224					
Panasonic	TX36PD30	GP1 , 100Hz							
Panasonic	TX36PF10	EURO5		remote EUR511220					
Panasonic	TX36PG50	EURO7		remote EUR511224					
Panasonic	TX36PL30	EURO7		remote EUR511212A					
Panasonic	TX37A2	ALPHA3							
Panasonic	TX37A2G	ALPHA3							
Panasonic	TX47PT11(projector)	EURO5VP		remote EUR511220					
Panasonic	TX47PT10 (projector)	EURO7VP							
Panasonic	TX5500	U5							
Panasonic	TXC21	U4							
Panasonic	TXC22	U5							
Panasonic	TXC71	ALPHA1W							
Panasonic	TXC74	ALPHA1W							
Panasonic	TXC78	ALPHA1W							
Panasonic	TXC84	ALPHA2							
Panasonic	TXC88	ALPHA2							
Panasonic	TXG10	AC1 Multisystem							
Panasonic	TXW28D1F	E2100	nonUK						
Panasonic	TXW28D2	EURO3HW							
Panasonic	TXW28D5F/P	EURO5							
Panasonic	TXW28R3	EURO3W							
Panasonic	TXW28R4(DP)	EURO4		remote EUR511210					
Panasonic	TXW32D2	EURO3HW							
Panasonic	TXW32D3DP/L	EURO3HW							
Panasonic	TXW32D4DP	EURO5		remote EUR511211					
Panasonic	TXW32D5F/P	EURO5							
Panasonic	TXW32R4(DP)	EURO4		remote EUR511210					
Panasonic	TXW36D3DP/L	EURO3HWS							
Panasonic	TYSU1	ALPHA1							
Panasonic	TYSU2	ALPHA1							
Panasonic	TYSU3	ALPHA1							
Perdio	CT2005	Indiana 100	Bush						
Perdio	P1408	Indiana 100	Bush						
Perdio	P1480	Indiana 100	Bush						
Perdio	P2004	Indiana 100	Bush						
Perdio	P2005	Indiana 100	Bush						
Perdio	P2101	Indiana 100	Bush						
Perdio	P2102	Indiana 100	Bush						
Phase	PH20567	Murphy CTV3500							
Philips	797	K12							
Philips	912	TX							
Philips	928	KT3							
Philips	934	KT3							
Philips	10CX1120	Pye 25KX1201							
Philips	1201	K30							
Philips	1205	K30							
Philips	1234	K30							
Philips	1250	K30							
Philips	12B611	T8	1976						
Philips	12B710	TX	1982						
Philips	12B711	TX	1982						
Philips	12B912	TX	1982						
Philips	12B915	TX	1982						
Philips	12TX1501	TX1	1982						
Philips	12TX2301	TX2	1982						
Philips	12TX2460	TX2	1982						
Philips	12TX2501	TX2	1982						
Philips	12TX2502	TX2	1982						
Philips	12TX3201	TX3	1984						
Philips	12TX3303	TX3	1984						
Philips	12TX3501	TX3	1984						
Philips	12TX3502	TX3	1984						
Philips	14B614	T8	1976						
Philips	14C825	KT2	1977						
Philips	14C925	KT3	1979						
Philips	14CE1200	CP90	1988						
Philips	14CE1201	CP90	1987						
Philips	14CE1210	CP90							
Philips	14CE1500	CP90	1988						
Philips	14CF1014	CF1	1985						
Philips	14CF1114	CF1	1985						
Philips	14CN2201	NC3-CR	1988						
Philips	14CN3001	NC3	1987						
Philips	14CT2006	CTX-S	1982						
Philips	14CT2007	CTX-E	1984						
Philips	14CT2201	CTX-E							
Philips	14CT2206	CTX-E	1983						
Philips	14CT3005	KT3	1980						
Philips	14CT3205	KT3	1980						
Philips	14CT3605	KT3	1984						
Philips	14CT3606	KT3							
Philips	14CT3607	KT3							
Philips	14CT4206	KT4 SYSTEM 4	1983						
Philips	14GR1021	GR1-AX	1989						
Philips	14GR1212	GR1-AX							
Philips	14GR1220	GR1-AX	1990						
Philips	14GR1221	GR1-AX	1990						
Philips	14GR1227/05B	GR1-AX	1992						
Philips	14GR2520	G90AE	1989						
Philips	14PT121A	GR1-AX	1993						
Philips	14PT1332/05	L6.1AA	1996						
Philips	14PT1342	L6.1	1996-2000						
Philips	14PT1356/05	L01.2E AA	2002						
Philips	14PT135A	ANUBIS A	1994						
Philips	14PT135B	AA5	1995						
Philips	14PT1532	L6.1	1996-1998						
Philips	14PT1553/05	L6.1	1998						
Philips	14PT1556/05	L01.2E AA	2002, 2004 £80	RCLE011					
Philips	14PT155A	ANUBIS A	1993						
Philips	14PT155B	AA5	1995						
Philips	14PT156A	ANUBIS A	1994						
Philips	14PT156B	AA5-AB	1994-1996						
Philips	14PT2002/05	L01.2E	2002						
Philips	14PT2665/05	L9.2E AA	2000-2001						
Philips	14PT2666/05	L01.2E		RCLE014					
Philips	14PT3685/05	L9.3E	2000-2001						
Philips	14PT6107/05D	TDVD1.1E	2002						
Philips	14PV110	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV111/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14PV112/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14PV120/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV125/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV135/07	Funai MK12 deck	2004	similar 14PV135 14PV235 14PV385					
Philips	14PV182/05	MONO98 chassis							
Philips	14PV202	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV203/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14PV210	Delta 99, Turbo drive deck	1999						
Philips	14PV220	Epsilon 2001 , Turbo drive deck	2001						

Philips	14PV225/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV227	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV235/07	Funai MK12 deck	2004	similar 14PV135 14PV235 14PV385					
Philips	14PV284/05(S)	MONO98 chassis							
Philips	14PV320	Delta 99, Turbo drive deck	1999						
Philips	14PV325	Delta 99, Turbo drive deck	1999						
Philips	14PV327	Delta 99, Turbo drive deck	1999						
Philips	14PV340	Delta 99, Turbo drive deck	1999						
Philips	14PV345	Delta 99, Turbo drive deck	1999						
Philips	14PV350	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV354	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV358	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV360/07	Funai MK11 deck		similar 14PV360 14PV365					
Philips	14PV365/07	Funai MK11 deck		similar 14PV360 14PV365					
Philips	14PV374/07	Funai MK12 deck	2003						
Philips	14PV375/07	Funai MK12 deck	2003						
Philips	14PV385/07	Funai MK12 deck	2004	similar 14PV135 14PV235 14PV385					
Philips	14PV415/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14PV422/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV425/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV460/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14TVCR24	COMBI							
Philips	14TX1504	TX-14	1982						
Philips	14TX2504	TX2	1982						
Philips	14TX3504	TX3	1984						
Philips	14TX3540	TX3							
Philips	15AA3332	ANUBIS A	1991						
Philips	15CE1010	CP90	1987						
Philips	15CE1210	CP90	1987						
Philips	15CE1510	CP90	1987						
Philips	15CE1518	CP90	1988						
Philips	15CT2309	CTX-E	1985						
Philips	15GR2330	G90AE	1989						
Philips	15GR2331	G90AE	1991						
Philips	15GR2530	G90AE	1989						
Philips	16C927	KT3	1979						
Philips	16C928	KT3	1979						
Philips	16CT2016	CTX-E	1982						
Philips	16CT2216	CTX-E	1983						
Philips	16CT3015	KT3	1980						
Philips	16CT3215	KT3	1980						
Philips	16CT3715	KT3	1981						
Philips	16CT4418	KT4 SYSTEM 4	1983						
Philips	16CT4616	KT4 SYSTEM 4	1983						
Philips	16CT4718	KT4 SYSTEM 4	1983						
Philips	17B920/15X	E2	1983						
Philips	17CE1230	CP90	1987						
Philips	17CE1530	CP90	1987						
Philips	17CE1538	CP90	1988						
Philips	17CE1630	CP90	1987						
Philips	17CT2319	CTX-E	1985						
Philips	17CT2619	CTX-E	1985						
Philips	17GR2340	G90AE	1989						
Philips	17GR2341	G90AE	1991						
Philips	17GR2540	G90AE	1989						
Philips	17HT1340	ANUBIS B	1993						
Philips	17HT1540	ANUBIS B	1993						
Philips	17HT1549	ANUBIS B	1993						
Philips	17HT3252	A7H.1	1998						
Philips	17HT3302	A7H.1	1998						
Philips	17PT1563/05	L7.2E AA	1998						
Philips	17PT1565	L9.2E	2000						
Philips	17PT156B	AA5-AB	1995						
Philips	17PT166A	ANUBIS A AC	1994						
Philips	20C933	KT3	1979						
Philips	20C934	KT3	1980						
Philips	20CT2028	CTX-E	1983						
Philips	20CT2035	CTX-E	1985						
Philips	20CT2036	CTX-E	1982						
Philips	20CT2235	CTX-E	1986						
Philips	20CT2236	CTX-E	1984						
Philips	20CT2635	CTX-E	1986						
Philips	20CT2636	CTX-E	1985						
Philips	20CT3027	KT3	1984						
Philips	20CT3227	KT3	1981						
Philips	20CT3723	KT3	1984						
Philips	20CT3726	KT3	1982						
Philips	20CT4428	KT4 SYSTEM 4	1983						
Philips	20CT4626	KT4 SYSTEM 4	1983						
Philips	20CT4636	KT4 SYSTEM 4	1984						
Philips	20CT4728	KT4 SYSTEM 4	1983						
Philips	20PT1552	L6.1	1996						
Philips	20PV184/05	MONO98 chassis							
Philips	20PV220	Delta 99, Turbo drive deck	1999						
Philips	20PV230	Epsilon 2001 , Turbo drive deck	2001						
Philips	21AA3350	ANUBIS A	1991						
Philips	21AA3356	ANUBIS A	1992/1993						
Philips	21AA3557	ANUBIS A	1992/1993						
Philips	21AB3556	ANUBIS B	1992						
Philips	21CE1051	CP90	1987						
Philips	21CE1059	CP90	1987						
Philips	21CE1250	CP90	1987						
Philips	21CE1251	CP90	1987						
Philips	21CE1259	CP90	1987						
Philips	21CE1550	CP90	1987						
Philips	21CE1551	CP90	1987						
Philips	21CE1557	CP90	1988						
Philips	21CE1558	CP90	1988						
Philips	21CE1559	CP90	1987						
Philips	21CE2340	2A	1986						
Philips	21CE2640	2A	1986						
Philips	21CE4550	2B	1986						
Philips	21CE4559	2B	1987						
Philips	21CE5554	2B	1988						
Philips	21CE7550	3A	1987						
Philips	21CE7650	3A	1987						
Philips	21CT4829	KT4 SYSTEM 4	1985						
Philips	21GR1251	GR1-AX	1990						
Philips	21GR2150	G90AE	1989						
Philips	21GR2350	G90AE	1989						
Philips	21GR2550	G90AE	1989						
Philips	21GR2552	G90AE	1989						
Philips	21GR2554	G90AE	1991						
Philips	21GR2752	G90B	1989						
Philips	21GR9752	G90B	1991						
Philips	21HT1350	ANUBIS B	1995						
Philips	21HT1550	ANUBIS B	1993						
Philips	21HT1559	ANUBIS B	1993						
Philips	21HT5403/05Z	L9H.2E AA	2000						
Philips	21PT136B	AA5-AB	1995						
Philips	21PT1532	L6.1AA	1996						
Philips	21PT1653/05	L6.2 AA	1998						
Philips	21PT165A	ANUBIS A AC	1993-1994						
Philips	21PT165B	AA5-AB	1996						
Philips	21PT1663/05	L7.2E AA	1998						
Philips	21PT1664	L9.2E	2000						
Philips	21PT166B	AA5-AB	1995-1997						
Philips	21PT2665/05	L9.2E AA	2000						
Philips	21PT44416/05	L01.2E	2002						
Philips	21PT4424/05	L7.2E AA	1998						
Philips	21PT442B/05	MD1.1E	1995-1996						
Philips	21PT442B/05B	MD1.2E	1997						
Philips	21PT4456	L9.2	2000						
Philips	21PT4457/05	L01.2E	2001						
Philips	21PT4475	L9.2E	2000-2001						
Philips	21PT4494	L6.3	1998						
Philips	21PT522A/05	GR2.2	1993						
Philips	21PT522B/05(/25)	GR2.4	1994-1995						
Philips	21PT5321/05	GR2.4	1995						

Philips	21PT5322/05	MD1.2E	1996						
Philips	21PT5324/05R	A8.0E	1998						
Philips	21PT532A/05	GR2.2	1993						
Philips	21PT532B/05/(25)	GR2.4	1994-1995						
Philips	21PT5407/05	L01.1E	2001, Multistandard B/G, D/K, I						
Philips	21PT5457/05	L01.2E AA	2002, Multistandard B/G, D/K, I						
Philips	21PT5505/05	L9.1E AB	2000-2001						
Philips	21PT5507/05	L01.1E AB	2002						
Philips	21PT5606/05	L01.1E AB	2002						
Philips	21PT6807/05	L01.1E AB	2002						
Philips	21PV210	Delta 99, Turbo drive deck	1999						
Philips	21PV288/05	MONO98 chassis							
Philips	21PV320	Delta 99, Turbo drive deck	1999						
Philips	21PV340	Epsilon 2001 , Turbo drive deck	2001						
Philips	21PV375/07	Funai MK12 deck	2003						
Philips	21PV385/07	Funai MK12 deck	2004						
Philips	21PV548	Epsilon 2001 , Turbo drive deck	2001						
Philips	21PV620/05	STEREO98 chassis							
Philips	21PV688/05	STEREO98 chassis							
Philips	21PV715/07	Delta 2000 chassis	2000						
Philips	21PV908 (combi)	Delta 2000 chassis	2000						
Philips	21ST1730	GR2.1	1991						
Philips	21ST2730	GR2.2	1992						
Philips	21ST2731	GR2.2	1992						
Philips	2206	CTX							
Philips	2216	CTX							
Philips	2226	CTX							
Philips	22AV3500	CP90							
Philips	22CE2060	2A							
Philips	22CE2081	2A	1986						
Philips	22CE2065	2A	1986						
Philips	22CE2281	2A	1986						
Philips	22CE2287	2A	1986						
Philips	22CE2681	2A	1986						
Philips	22CE2665	2A	1986						
Philips	22CE2667	2A	1986						
Philips	22CS1002	K30	1980						
Philips	22CS1201	K30	1980						
Philips	22CS1205	K30							
Philips	22CS1234	K30	1982						
Philips	22CS3040	K35	1983						
Philips	22CS3245	K35	1982						
Philips	22CS3745	K35	1983						
Philips	22CS3761	K35	1982						
Philips	22CS3850	K35	1982						
Philips	22CS3880	K35							
Philips	22CS4360	K40 SYSTEM 4	1983						
Philips	22CS4860	K40 SYSTEM 4	1984						
Philips	22CS4861	K40 SYSTEM 4	1985						
Philips	22CS5240	K40 SYSTEM 4	1984						
Philips	22CS5350	K40 SYSTEM 4	1984						
Philips	22CS5735	K40 SYSTEM 4	1985						
Philips	22CS5740	K40 SYSTEM 4	1984						
Philips	22CS5744	K40 SYSTEM 4	1984						
Philips	22CS5748	K40 SYSTEM 4	1985						
Philips	22CS5750	K40 SYSTEM 4	1984						
Philips	22CS5751	K40 SYSTEM 4	1985						
Philips	22CT2226	CTX-E							
Philips	23BC2001	TC2	1982						
Philips	24CE2370	2A	1986						
Philips	24CE2670	2A	1986						
Philips	24CE3270	CP110	1987						
Philips	24CE3271	CP110	1987						
Philips	24CE3570	CP110	1987						
Philips	24CE3578	CP110	1988						
Philips	24CE3588	CP110	1988						
Philips	24CE4570	2B	1986						
Philips	24CE4579	2B	1987						
Philips	24CE7570	3A	1987						
Philips	24PW6005	A10E	2000-2001						
Philips	24PW6006/05	L01.1E	2001-2002 around £285						
Philips	24PW6322	MD1.2E	1997						
Philips	24PW6324/05R	A8.0E	1999						
Philips	24PW6407	L01.1E	2002-2003 around £375						
Philips	25CE5574	2B	1988						
Philips	25CE6270	CP110	1989						
Philips	25CE6570	CP110	1989						
Philips	25GR5560	G110	1989						
Philips	25GR5762	G110	1990						
Philips	25GR5763	G110	1990						
Philips	25GR5764	G110	1990						
Philips	25GR6771	G111-S	1990						
Philips	25GR9762	G110	1989						
Philips	25GR9763	G110	1990						
Philips	25GR9768	G110	1990						
Philips	25HT5403/05Z	L9H.2E AA	2001						
Philips	25ML8300	FL1.7	1992						
Philips	25ML8500	FL1.6	1992						
Philips	25MN1550/05	GR2.1	1991						
Philips	25MN1550/25	GR2.2	1992						
Philips	25PT4101/05	AA5-AB	1995-1996						
Philips	25PT4103/05	L6.2AA	1997-1998						
Philips	25PT410A	GR2.1	1993						
Philips	25PT4423	L6.2	1997-1998						
Philips	25PT4456/25	L9.1E	2000						
Philips	25PT4457/05	L01.1E AA	2001-2002	RCLE014					
Philips	25PT4475	L9.1E	2000						
Philips	25PT4494/05	L6.3	1998						
Philips	25PT4501	MD1.1E	1995-1996						
Philips	25PT4521	MD1.1E	1995						
Philips	25PT4523	MD1.2E	1996-1997						
Philips	25PT482A/05	GR2.2 AA	1993-1994						
Philips	25PT5324/05R	A8.0E	1998						
Philips	25PT532A/05	GR2.2	1993						
Philips	25PT532B/05	GR2.4	1994						
Philips	25PT6322/05	MD1.2E	1997						
Philips	25PT632A/05	GR2.4	1995						
Philips	25PV720	Delta 99, Turbo drive deck	1999						
Philips	25ST1724	GR2.1	1991						
Philips	25ST1760/25	GR2.1	1991						
Philips	25ST1761/25	GR2.1	1991						
Philips	25ST2760	GR2.2	1992						
Philips	25ST2761	GR2.2	1992						
Philips	26C797	K12	1979						
Philips	26CE2080	2A	1985						
Philips	26CE2081	2A	1986						
Philips	26CE2281	2A	1986						
Philips	26CE2581	2A	1986						
Philips	26CP2601	K12	1980						
Philips	26CS1009	K30	1980						
Philips	26CS1205	K30	1981						
Philips	26CS1250	K30	1982						
Philips	26CS3070	K35	1983						
Philips	26CS3275	K35	1982						
Philips	26CS3775	K35	1983						
Philips	26CS3880	K35	1982						
Philips	26CS3890	K35	1983						
Philips	26CS3895	K35	1983						
Philips	26CS4880	K40 SYSTEM 4	1983						
Philips	26CS4895	K40 SYSTEM 4	1984						
Philips	26CS5770	K40 SYSTEM 4	1984						
Philips	26CS5774	K40 SYSTEM 4	1984						
Philips	26CS5793	K40 SYSTEM 4	1985						
Philips	27CE2390	2A	1986						
Philips	27CE2690	2A	1986						
Philips	27CE3290	CP110	1987						
Philips	27CE3590	CP110	1987						
Philips	27CE3598	CP110	1988						
Philips	27CE4895	2B	1987						











[illegible]





[illegible]





Sharp	86GF64H	DA50W	2000						
Sharp	86GS62H	GA10 50Hz	2001						
Sharp	70FW53E	DA50W 50Hz	2002						
Sharp	70GS64S	DA100 (nonUK model)							
Sharp	76DW18H	CW100	1999						
Sharp	76EF19H	DA100W , 100Hz, not Dolby, only NICAM	1999						
Sharp	76EF20H	DA100W , 100Hz, Dolby sound	1999						
Sharp	76FW53H	DA100 50Hz chassis (aka DA50W)	1999/2000						
Sharp	76FW54H	DA100 50Hz	1999/2000						
Sharp	76GF63H	DA50W							
Sharp	76GF64H	DA50W	2000						
Sharp	81GF66E	DA100W							
Sharp	C1407	no chassis type							
Sharp	C1410HW	4PS							
Sharp	C1411H	4PSR1							
Sharp	C1412								
Sharp	C1415	no chassis type							
Sharp	C1420H	7PS							
Sharp	C1421H	7PSR1							
Sharp	C1430	8PS							
Sharp	C1431H	8PSR							
Sharp	C1480	TAP-812							
Sharp	C1491	Rediffusion Mk5							
Sharp	C1493								
Sharp	C1495								
Sharp	C1871								
Sharp	C1891								
Sharp	C2002								
Sharp	C2072								
Sharp	C2092								
Sharp	C2095								
Sharp	C3703H	7PS							
Sharp	C3703HBK	7PS							
Sharp	C3704	8PS							
Sharp	C3705	4PSR1							
Sharp	C3705H	4PS							
Sharp	C3706H	14B							
Sharp	C3709	7PS							
Sharp	C3710H	8PSR							
Sharp	C3720H	14A							
Sharp	C3730H	14B							
Sharp	CV2121H	7PSR1							
Sharp	CV2123H	7PSR1							
Sharp	CV2131	8PSR							
Sharp	CV2133H	8PSR							
Sharp	CV3707	5P-SR1							
Sharp	CV3707H	5PS							
Sharp	CV3709H	7PS							
Sharp	CV3730								
Sharp	CV3745	14B							
Sharp	CV4833	14B							
Sharp	CV5407	5PS							
Sharp	DV1512	Euro DS1							
Sharp	DV1600	no chassis type							
Sharp	DV1620								
Sharp	DV2120	4PSR2							
Sharp	DV2121	4PS							
Sharp	DV3750H	S3B							
Sharp	DV3751H	S3B							
Sharp	DV3760H	4BSA							
Sharp	DV3761H	4BSC							
Sharp	DV3770H	4BSA							
Sharp	DV4205	4PS							
Sharp	DV5101H	EURO-DS							
Sharp	DV5103H	EURO-DS							
Sharp	DV5105H	DECO-4							
Sharp	DV5107H	DECO-5							
Sharp	DV51083H	D3000							
Sharp	DV5131H	S3B							
Sharp	DV5132H	DECO-5							
Sharp	DV5135H	DECO-5							
Sharp	DV5150H	S3B							
Sharp	DV5161H	4BSA							
Sharp	DV5165H	4BSB							
Sharp	DV5180H	4BSB							
Sharp	DV5903H	D3000							
Sharp	DV59083H	D3000							
Sharp	DV5932H	BCTV-A							
Sharp	DV5935H	BCTV-A							
Sharp	DV5937H	BCTV-A							
Sharp	DV5940H	4BSC							
Sharp	DV6603H	D3000							
Sharp	DV66083H	D3000							
Sharp	DV6632H	4BSC							
Sharp	DV6635H	BCTV-A							
Sharp	DV6640H	4BSC							
Sharp	SV2189	8PLS							
Sharp	SV257	NC-7							
Sharp	SV2588	8PLS							
Sharp	SV2588H	8PLS							
Sharp	SV2589	8PLS							
Sharp	SV2589H	8PLS							
Sharp	SV287	NC-7							
Sharp	SV2888	8PLS							
Sharp	SV2888H7	8PLS							
Sharp	SV2889	8PLS							
Sharp	SV3320	8PLP1							
Sharp	VT3700	VP1	TV/VCR						
Sharp	VT3705	VP1	TV/VCR						
Skantic	3781	180							
Skantic	5111	BC							
Skantic	5114	BC							
Skantic	5601	BC							
Skantic	5608	BC							
Skantic	6711	BC							
Skantic	6718	BC							
Skantic	18051919	B2							
Solarvox	142TT								
Solarvox	14R19	CVC1110/12							
Solarvox	14S09	CVC1110/12							
Solarvox	14S19	ITT PICO S/2							
Solarvox	16R19	ITT PICO S/2	CVC1110/12						
Solarvox	20R09	ITT MINI 2 ST2/2							
Solarvox	20S09	ITT CVC1175							
Solarvox	20S19	ITT PICO S/2							
Solarvox	20T09	ITT CVC1200/1							
Solarvox	20T19	ITT MINI2							
Solarvox	22R09	ITT CVC1215							
Solarvox	22S09	ITT CVC1200/1	CVC1210/15						
Solarvox	22S19	ITT COMPACT 80/R							
Solarvox	22T09	ITT CVC1215							
Solarvox	22T09TX	ITT CVC1210							
Solarvox	26R09	ITT CVC1212/17							
Solarvox	26SR09	ITT CVC1212/17							
Solarvox	26ST09	ITT CVC1212/17							
Solarvox	26T09	ITT CVC1212/17							
Solarvox	CML14	Hinari CT4 / 5	Nikkai TLG0909						
Solarvox	CML14RC	Nikkai TLG0101							
Sony	CKV2760		TV/MONITOR						
Sony	FDL390		1991						
Sony	KD28DL10U	FE2D, 50Hz, Dolby Surround	2003, RM933,£430						
Sony	KD28DL11U	FE2D	2004, RM949						
Sony	KD28DX200U	AE6D	2004, RM933						
Sony	KD28DX40U	FE2D	2001, RM933, around £540						
Sony	KD28DX50U	FE2D	2003, RM933						
Sony	KD28DX51U	FE2D	2004, RM949						
Sony	KD32DX100U	AE6D	2001, RM933						
Sony	KD32DX150U	AE6D	2003, RM933						
Sony	KD32DX200U	AE6D	2004, RM933						

[illegible]

Sony	KV24LS36U	FE2	2001, RM932, around £410						
Sony	KV24WS1U	BE5B	1995, RM837						
Sony	KV24WS2U	BE3D	1996, RM862						
Sony	KV24WX1U	BE3D	1996, RM839, A board	part number A-1632-538-A					
Sony	KV2511	AE1							
Sony	KV2521U	AE1							
Sony	KV2562	AE2							
Sony	KV25F1U	BE3D	1996, RM862, A board 1-659-826-14	part number A-1632-398-A					
Sony	KV25F2U	BE3D	1996, RM862						
Sony	KV25F3U	BE3D	1997, RM862, A board 1-659-826-14	part number A-1632-608-A					
Sony	KV25FX20U	FE1A							
Sony	KV25FX30	FE2	nonUK						
Sony	KV25K1U	AE4	1996, RM862						
Sony	KV25K5U	FE1	1998, RM883, RM887						
Sony	KV25T1U	BE3B	1996, RM837, A board	part number A-1632-407-A					
Sony	KV25T2U	FE1	1998, RM883						
Sony	KV25X1U	BE3D	1996, RM839, A board	part number A-1632-400-A					
Sony	KV25X5U	FE1	1999, RM883						
Sony	KV2704		1980						
Sony	KV2705	QE1	1982, RM615						
Sony	KV2706	QE1	1982, RM615						
Sony	KV2715UB	YE2							
Sony	KV2752UB	PE3 (chassis depends on year)	1983, RM632						
Sony	KV2752UB	RX (chassis depends on year)	1985, RM632						
Sony	KV2756UB	PE3 (chassis depends on year)	1983, RM632						
Sony	KV2756UB	RX (chassis depends on year)	1985, RM632						
Sony	KV2762UB	PE3 (chassis depends on year)	1984, RM632						
Sony	KV2762UB	RX (chassis depends on year)	1985, RM632						
Sony	KV2764EC	PE3	RM635						
Sony	KV2766UB	PE3 (chassis depends on year)	1984, RM632						
Sony	KV2766UB	RX (chassis depends on year)	1985, RM632						
Sony	KV27VX	VX							
Sony	KV27XRTU	SX	1986, RM661						
Sony	KV27XRU	SX	1986, RM661						
Sony	KV28CL10U	FE 2, 50Hz	2003, RM946, £360						
Sony	KV28CS70U	AE6B	2004, RM932						
Sony	KV28DS20U	BE3E	1999, RM888, A board 1-673-314-12	part number A-1632-854-A					
Sony	KV28DS60U	GE1A	1999, RM891						
Sony	KV28DS65U	GE1A	2001, RM892						
Sony	KV28DX20U	BE3E	1999, RM888, A board 1-673-314-12	part number A-1632-852-A					
Sony	KV28DX30U	BE3E	2000, RM888, A board 1-673-314-13	part number A-1632-909-A					
Sony	KV28EW20U	FE2	2002, RM887						
Sony	KV28FC60Z	AE5	1999, RM892						
Sony	KV28FD1E	GE1 (nonUK model but has UK sound)	1997, RM864						
Sony	KV28FQ70U	AE6B, 100Hz, virtual surround sound	2003, RM938, £540-£700						
Sony	KV28FQ75U	AE5A	2000, RM893						
Sony	KV28FQ86	AE6BA (nonUK)	2004, RM945						
Sony	KV28FS20U	BE3E	1999, RM887, A board 1-673-314-12	part number A-1632-881-A					
Sony	KV28FX20U	BE3E	1999, RM887, A board 0-673-313-03	part number A-1632-850-A					
Sony	KV28FX60U	AE5	1999, RM891						
Sony	KV28FX65U	AE5	2000, RM887						
Sony	KV28FX66U	AE6B	2002, RM937						
Sony	KV28FX68U	AE6B, 100Hz	2003, RM932, around £500						
Sony	KV28HX15U	FE2	2004, RM947						
Sony	KV28LS35U	FE2	2001, RM932						
Sony	KV28LS36U	FE2W, 50Hz	2003, RM932, (2003 around £599; 2004 around £400)						
Sony	KV28LS60U	AE6B	2002, RM932						
Sony	KV28WF1U	BE3D	1997, RM839, A board 1-659-826-15	part number A-1632-676-A					
Sony	KV28WS1U	BE3B	1995, RM837						
Sony	KV28WS2U	BE3D	1996, RM862, A board 1-659-826-17	part number A-1632-515-A					
Sony	KV28WS3U	AE3 100Hz	1995, RM838						
Sony	KV28WX1U	BE3D	1996, RM839, A board	part number A-1632-501-A					
Sony	KV2922U	AE1C and SCC-E23B-A							
Sony	KV29CL10U	FE2	2003, RM946						
Sony	KV29F1U	BE3D	1996, RM862, A board 1-659-826-14	part number A-1632-398-A					
Sony	KV29F2U	BE3D	1996, RM862, A board 1-659-826-12	part number A-1632-438-A					
Sony	KV29F3U	BE3D	1997, RM862, A board 1-659-826-14	part number A-1632-398-A					
Sony	KV29FC20	FE1A	nonUK						
Sony	KV29FQ76	AE6A	nonUK, RM938						
Sony	KV29FS60U	AE5	1998, RM891						
Sony	KV29FS70U	AE5/AE5A							
Sony	KV29FX11U	BE3D	1998, RM886, A board 1-659-826-16	part number A-1632-781-A					
Sony	KV29FX20U	FE1A	1999, RM887						
Sony	KV29FX30	FE2	nonUK						
Sony	KV29FX66	AE6B	2001, nonUK, RM934						
Sony	KV29K1U	AE4	1996, RM862						
Sony	KV29K5U	FE1	1998, RM883						
Sony	KV29LS30	FE2	2002, RM887						
Sony	KV29LS35	FE2	2002, nonUK, RM932						
Sony	KV29LS60	AE6B	nonUK, RM932						
Sony	KV29X1U	BE3D	1996, RM839, A board	part number A-1632-400-A					
Sony	KV29X2	AE3							
Sony	KV29X5U	FE1	1998, RM883						
Sony	KV32CS70U	AE6B	2004, RM932						
Sony	KV32DS20U	BE3E	1999, RM888, A board 1-673-314-12	part number A-1632-854-A					
Sony	KV32DS60U	GE1A	1999, RM891						
Sony	KV32DS65U	GE1A	2001, RM892						
Sony	KV32DX20U	BE3E	1999, RM888, A board 1-673-314-12	part number A-1632-852-A					
Sony	KV32DX30U	BE3E (LOPTx 145330841, SM incorrect)	2000, RM888, A board 1-673-314-13	part number A-1632-909-A					
Sony	KV32FC60Z	AE5	1999, RM892						
Sony	KV32FD1E	GE1 (nonUK model but has UK sound)	1997, RM864						
Sony	KV32FQ70U	AE6B, 100Hz	2003, RM938, £650-£900						
Sony	KV32FQ75U	AE5A	2000, RM893						
Sony	KV32FQ80U	AE6A	2002, RM936						
Sony	KV32FQ86U	AE6BA	2004, RM945, £700-£800						
Sony	KV32FS60	AE5 nonUK	1998, RM891						
Sony	KV32FX20U	BE3E	1999, RM887, A board 0-673-313-03	part number A-1632-850-A					
Sony	KV32FX60U	AE5	1999, RM891						
Sony	KV32FX65U	AE5	2000, RM887						
Sony	KV32FX66U	AE6B	2002, RM937						
Sony	KV32FX68U(S)	AE6B	2003, RM932, around £600						
Sony	KV32HX15U	FE2	2004, RM947						
Sony	KV32LS35U	FE2	2001, RM932						
Sony	KV32LS36U	FE2W, 50Hz	2003, RM932						
Sony	KV32LS60U	AE6B	2002, RM932						
Sony	KV32WF1U	BE3D	1997, RM839, A board 1-659-826-15	part number A-1632-676-A					
Sony	KV32WS2U	BE3D	1998, RM862, A board 1-659-826-17	part number A-1632-515-A					
Sony	KV32WS3U	AE3 100Hz	1995, RM838						
Sony	KV32WS4U	AE4	1996, RM862						
Sony	KV32WX2U	AE4	1996, RM862						
Sony	KV32WX4U	AE4	1996, RM862						
Sony	KV34WX2U	AE4	1996, RM862						
Sony	KV36FQ80	AE6A	2002, RM936						
Sony	KV36FS70U(S)	AE5A	2000, RM892, Multistandard 1, B/G, D/K						
Sony	KV36FS76U	AE6A, 100Hz	2002, RM938, £1270						
Sony	KV36HQ100		2004, £1500						
Sony	KVA2112	AE1C	1991, RM816						
Sony	KVA2122U	AE1C	1992, RM816						
Sony	KVA2123	AE1C							
Sony	KVA2131	AE2A							
Sony	KVA2132U	AE2A	1993, RM831						
Sony	KVA2133	AE2A							
Sony	KVA2511	AE1C							
Sony	KVA2512	AE1C	1991, RM816						
Sony	KVA2513	AE1C							
Sony	KVA2522	AE1C	1992, RM816						
Sony	KVA2523	AE1C							
Sony	KVA2532	AE2A	1993, RM831						
Sony	KVA2533	AE2A							
Sony	KVA2542	AE2B	1994, RM831						
Sony	KVA2912	AE1C	1991, RM816						
Sony	KVA2913	AE1C							
Sony	KVA2922	AE1C	1992, RM816						
Sony	KVA2923	AE1C							
Sony	KVA2932	AE2A	1993, RM831						
Sony	KVA2933	AE2A							
Sony	KVA2942U	AE2B	1994, RM831						
Sony	KVA3412	DE2	1991, RM816						
Sony	KVA3413	DE2							

Sony	KVB2512U	AE2	1993, RM830						
Sony	KVB2513	AE2							
Sony	KVB2515	AE2							
Sony	KVB252	AE2B							
Sony	KVB2912U	AE2	1993, RM830						
Sony	KVB2913	AE2							
Sony	KVB2915	AE2							
Sony	KVB292	AE2B							
Sony	KVC2121	AE1C							
Sony	KVC2122	AE1C	1991, RM816						
Sony	KVC2123	AE1C							
Sony	KVC2163	AE1C							
Sony	KVC2521	AE1B							
Sony	KVC2522	AE1C	1991, RM816						
Sony	KVC2523	AE1B							
Sony	KVC2531	AE1B							
Sony	KVC2533	AE1B							
Sony	KVC2561	AE1C							
Sony	KVC2563	AE1C							
Sony	KVC2573	AE1C							
Sony	KVC27	AE1							
Sony	KVC2721	AE1							
Sony	KVC2911	AE1							
Sony	KVC2921	AE1B							
Sony	KVC2923	AE1B							
Sony	KVC2931	AE1B							
Sony	KVC2933	AE1B							
Sony	KVC2951	AE1C							
Sony	KVC2953	AE1C							
Sony	KVC2963	AE1C							
Sony	KVC2973	AE1C							
Sony	KVD2511	AE1A							
Sony	KVD2512	AE1A	1990, RM689						
Sony	KVD2911	AE1A							
Sony	KVD2912	AE1A	1990, RM689						
Sony	KVD2921	AE1A							
Sony	KVD3411	DE1							
Sony	KVD3412	DE1	1989, RM685						
Sony	KVD3431	DE2							
Sony	KVD3432	DE2	1991, RM811						
Sony	KVD3433	DE2							
Sony	KVDX21	AE1							
Sony	KVDX2112	AE1	1989, RM670						
Sony	KVDX21TU	AE1	1989, RM670						
Sony	KVDX271TU	AE1	1989, RM670						
Sony	KVDX27T	AE1							
Sony	KVDX27TU	AE1	1989, RM670						
Sony	KVE2511	AE1A							
Sony	KVE2512U	AE1A	1990, RM689						
Sony	KVE2521	AE1C							
Sony	KVE2522	AE1C	1991, RM817						
Sony	KVE2523	AE1C							
Sony	KVE2532	AE2	1992, RM830						
Sony	KVE254	AE2A							
Sony	KVE2542	AE2A	1993, RM831						
Sony	KVE2543	AE-2A							
Sony	KVE255	AE2B							
Sony	KVE2911	AE1A							
Sony	KVE2912U	AE1A	1990, RM689						
Sony	KVE2921	AE1C							
Sony	KVE2922U	AE1C	1991, RM817						
Sony	KVE2923	AE1C							
Sony	KVE2925	AE1C	1991, RM813						
Sony	KVE2932	AE2	1992, RM830						
Sony	KVE2933	AE2A							
Sony	KVE294	AE2A							
Sony	KVE2942U	AE2A	1993, RM831						
Sony	KVE2943	AE2A							
Sony	KVE295	AE2B							
Sony	KVE296	AE2F							
Sony	KVE2963	AE2A							
Sony	KVE3433	AE2							
Sony	KVFX2921	CE1							
Sony	KVFX2923	CE1							
Sony	KVFX29TU	FX	1989, RM682						
Sony	KVG2515U	AE2B	1994, RM831, TV/SAT RX						
Sony	KVG2915U	AE2B	1994, RM831, TV/SAT RX						
Sony	KVH1510	BE1							
Sony	KVH1513	BE1							
Sony	KVH2513	AE1C							
Sony	KVM1100	EE1A							
Sony	KVM1120	EE1A	1993, RM828						
Sony	KVM1400U	BE2A	1993, RM841						
Sony	KVM1401U	BE2A	1993, RM841						
Sony	KVM1410U	BE2A	1992, RM694						
Sony	KVM1411U	BE2A	1992, RM694						
Sony	KVM1420U	BE2A	1991, RM694						
Sony	KVM1421U	BE2A	1991, RM694						
Sony	KVM1430	BE2A							
Sony	KVM1431	BE2A							
Sony	KVM1440U	BE4	1995, RM836						
Sony	KVM1441U	BE4	1995, RM836						
Sony	KVM14M1U	BE4							
Sony	KVM14TU	BE1	1989, RM657						
Sony	KVM14U	BE1	1989, RM658						
Sony	KVM1620U	BE2A	1991, RM694						
Sony	KVM1621U	BE2A	1991, RM694						
Sony	KVM16TU	BE1	1989, RM657						
Sony	KVM16U	BE1	1989, RM658						
Sony	KVM1920	BE2A							
Sony	KVM1921U	BE2A	1992, RM694						
Sony	KVM19TU	BE1	1989, RM657						
Sony	KVM2100D	BE2A							
Sony	KVM2101U	BE2A	1993, RM841						
Sony	KVM2120U	BE1	1990, RM670						
Sony	KVM2121U	BE1							
Sony	KVM2130	BE1	1991, RM670						
Sony	KVM2131	BE1	1991, RM670						
Sony	KVM2140U	BE2A	1991, RM820						
Sony	KVM2141U	BE2A	1991, RM820						
Sony	KVM2150U	BE2A	1992, RM826						
Sony	KVM2151	BE2A	1992, RM826						
Sony	KVM2170U	BE4A	1995, RM836						
Sony	KVM2171U	BE4A	1995, RM836						
Sony	KVM21TU	AE1							
Sony	KVM21U	AE1	1989, RM670						
Sony	KVM21XMU	AE-1							
Sony	KVM2511	AE1	1989, RM670						
Sony	KVM2521	AE1C	1991, RM816						
Sony	KVM2531	AE1C	1992, RM816						
Sony	KVM2541	BE3B	1994, RM833						
Sony	KVP14U	BE1	1989						
Sony	KVS2911	AE1							
Sony	KVS2912	AE2	1992, RM832						
Sony	KVS2922	AE2A	1993, RM842						
Sony	KVS2942	AE2F	1994, RM831						
Sony	KVS2943	AE2F							
Sony	KVS2952U	AE3 100Hz	1995, RM831						
Sony	KVS3411	AE2							
Sony	KVS3412U	AE2	1993, RM832						
Sony	KVS3412U	AE2A	1994, RM842						
Sony	KVS3413E	AE2							
Sony	KVS3432U	AE2B	1994, RM831						
Sony	KVV1410	BC2	1994, RM846						
Sony	KVV1430	TE1	1995, RMY963						
Sony	KVW281	AE2F							
Sony	KVW2812U	AE2F 100Hz	1994, RM842						
Sony	KVW3212U	AE2F 100Hz	1995, RM842						
Sony	KVX21	AE1							

[illegible]





Thomson	32WR101	ITC008	2004, 50Hz, 16:9	RC111TA1G						
Thomson	32WR25UG	ICC17		MB100						
Thomson	32WS23U	ICC17	2003, 50Hz							
Thomson	32WS650D	ICC19								
Thomson	32WS83KP	ICC19								
Thomson	32WS95UF	Plasma	50Hz							
Thomson	32WT45US	ICC20 +DVD	100Hz	RCV400						
Thomson	32WX211S	ICC17	50Hz	RCT2100S						
Thomson	32WX35US	ICC17	50Hz	RCT4170						
Thomson	32WX401T	ICC20	2003, 100Hz, Stereo Nicam	RC111TA1G						
Thomson	32WX411T(S)	ICC20	100Hz	RCT2100S						
Thomson	32WX610S	ICC21	100Hz	RCT4130S						
Thomson	32WX65US	ICC19								
Thomson	32WZ413S	ETC210	2003, 100Hz, Dolby Surround	RCT311TAM1						
Thomson	32WZ611S	ICC21	100Hz	RCT4130S						
Thomson	32WZ841W	ICC21	100Hz	RCT4157W						
Thomson	33MS24UG(EG)	ICC17	2003, 50Hz	RCT2100S						
Thomson	34DC430	ETC210	2004, 100Hz, 4:3	RCT311TAM1						
Thomson	34DF220	ITC008	2004, 50Hz, 4:3	RCT311TM1G						
Thomson	36MK48CRU	TX91								
Thomson	36WT611T(S)	ICC21 +DVD	100Hz	RCV400						
Thomson	36WX87UT(US)	ICC21	100Hz	RCT4157S						
Thomson	37MG73J	ICC9		RCT3002						
Thomson	37MH44E	ICC19-IM	100Hz	RCT4130						
Thomson	37PB220S4U	Plasma	2004, 100Hz	RCS615TCLM1						
Thomson	40JW611S	ICC21	100Hz	RCT4130S						
Thomson	40KW413	ETC210	2004, 100Hz, 16:9	RCT311TAM1						
Thomson	40KW611S	ICC21	100Hz	RCT2100S						
Thomson	40KW613S	ITC222	2003, 100Hz, Dolby, Multistandard	RCT311TAM1						
Thomson	40TW611S	ICC21 +DVD	100Hz	RCV400						
Thomson	42JH67E	ICC21	100Hz	RCT4130S						
Thomson	42JH68US(E)	ICC21	100Hz	RCT2100S						
Thomson	42KH413S	ETC210	2003, 100Hz High Focus	RCT311TAM1						
Thomson	42PB120B4	Plasma	2004	RCS615TCLM1						
Thomson	42PB220S4U	Plasma	2004	RCS615TCLM1						
Thomson	42PM03LF	Plasma	2003, 50/60Hz progressive	TBD						
Thomson	42WB02SU	Plasma	2003, 50/60Hz progressive	RCT4157S						
Thomson	42WM02LU	Plasma	2003, 50/60Hz progressive	RCT120TA						
Thomson	42WM02ST	Plasma	2003, 50/60Hz progressive	RCT4157S						
Thomson	42WM03LU	Plasma	2003, 50/60Hz progressive	RCT120TA						
Thomson	42WM03ST	Plasma	2003, 50/60Hz progressive	RCT4157S						
Thomson	42WM04ST	Plasma	2004	RCT4157S						
Thomson	42WP94U(E)	Plasma	2003	RCT4147						
Thomson	42WS94UF	Plasma	2003	RCT4147						
Thomson	42WS95UF	Plasma	50Hz	RCT4147						
Thomson	44CW413	ETC210 (Projection TV)	2004	RCT615TDM1						
Thomson	44DLP541	DLP	2003, 300Hz progressive scan	RCS615THLM1						
Thomson	44DLY645	ITC250 (DLP)	2004,	RCS615TCLM1						
Thomson	44JW611S	ICC21	100Hz	RCT4130S						
Thomson	44JW611S2	ICC21	100Hz	RCT311TAM1						
Thomson	44JW613S	ITC222	2004, 100Hz, 16:9	RCT615TDM1						
Thomson	44JW643S	ITC222	2003, 100Hz, Dolby, Multistandard	RCS615TCLM						
Thomson	44RW65US	ICC19-MM	100Hz	RCT4130S						
Thomson	44RW67US	ICC21	100Hz	RCT4130S						
Thomson	44TW611S	ICC21 +DVD	100Hz	RCT4130S						
Thomson	46JH67E	ICC21	100Hz	RCT4130S						
Thomson	46JH68E(US)(U)	ICC21	2003, 100Hz	RCT2100S						
Thomson	46KH413S	ETC210	2003, 100Hz High Focus	RCT311TAM1						
Thomson	50DLY645	ITC250 projection	2004, progressive scan, 16:9	RCS615TCLM1						
Thomson	50DSZ645	ITC250 (DLP)	2004	RCS615TCLM1						
Thomson	50WB03PU	Plasma	2003, 50/60Hz progressive	RC4157S						
Thomson	50WS94UF	Plasma	50Hz	RCT4147						
Thomson	50WS95UF	Plasma	2003, 50Hz	RCT4147						
Thomson	52BW613	ITC222	2004	RCT615TDM1						
Thomson	52JW641S	ICC21	2003, 100Hz	RCT4157S						
Thomson	52JW643S	ITC222	2003, 100Hz, Dolby, Multistandard	RCS615TCLM						
Thomson	52RW611S	ICC21	100Hz	RCT4130S						
Thomson	52RW87E(US)(ES)	ICC21	100Hz	RCT4157S						
Thomson	61DLY64E	ITC250	2004	RCS615TCLM1						
Thomson	61DSZ645	ITC250	2004	RCS615TCLM1						
Thomson	61JW643S	ITC222	2004, 100Hz, Dolby, Multistandard	RCS615TCLM						
Thomson	61TW611S	ICC21 +DVD	2003, 100Hz	RCV456						
Thomson	72MK89DU	ICC11		RCT1702						
Thomson	Digital2	EUTVD2001 TV+DVD	50Hz	RCV300						
Thomson	HTM14117	TX807C	2003, 50Hz	HRC102						
Thomson	HTM20117	TX807C	2003, 50Hz	RCT100						
Thomson	HTM21117	TX807C	2003, 50Hz	RCT100						
Thomson	M5115UT	TX807								
Thomson	RP52UK	ICC9								
Thomson	Smooth2	TX807C	50Hz	RCT102						
Thomson	Style2	TX807C	50Hz							
Thomson	Sugar2	TX807C	2003, 50Hz	RCT315						
Thomson	Tekno2	Combo 99 Mono	50Hz	RCV100S						
Thomson	Xinox	TX807C	50Hz	RCT315						
Thomson	Xinox2	TX807C	50Hz	RCT315						
Thorn	3788	Ferguson TX10								
Thorn	37140	Ferguson TX90								
Thorn	38020	Thorn 1790								
Thorn	38030	Thorn 1790								
Thorn	CT5122T	Tatung D								
Thorn	CT514TN	Daewoo CP365								
Thorn	P1465R	Decca 190								
Thorn	P1470R	GR1-AX								
Thorn	P1480R	Daewoo DMQ1454								
Thorn	P1482T	Tatung D								
Toshiba	1480	C80								
Toshiba	2563									
Toshiba	1400TBT		1991							
Toshiba	1400TBZ									
Toshiba	140E4B		1984							
Toshiba	140R3B									
Toshiba	140R4B									
Toshiba	141E3B									
Toshiba	143R4BR									
Toshiba	144ORB	C4								
Toshiba	1440TB	C4								
Toshiba	1450TB	C4ER								
Toshiba	145E7B									
Toshiba	145R7B									
Toshiba	14N21B2	Orion chassis, 2002	PCB marked TMC571A	Micro OECF012A	remote RC-GX010					
Toshiba	14N21BS 14N21BB	Orion chassis, 2002 around £100	PCB marked TMB537A	Micro OECF005A		Serv. Mode: Vol- on set and "9" on R/c for >2 sec				
Toshiba	14N21IS	Orion chassis, 2003	PCB marked TMB537A	Micro OECF005A	remote RC-FK01A					
Toshiba	14R01B	Samsung KS1A	Samsung C114R01B2							
Toshiba	14R01F	Samsung KS1A								
Toshiba	14T01B	Samsung KS1A	Samsung C114T01B2							
Toshiba	14T01D	Samsung KS1A								
Toshiba	14T01I	Samsung KS1A								
Toshiba	14T01N	Samsung KS1A								
Toshiba	150R6B									
Toshiba	1510RB									
Toshiba	1510TBT		1991							
Toshiba	155R8B									
Toshiba	155R9B									
Toshiba	156R9B									
Toshiba	159X4Y		Multi std portable							
Toshiba	15V11B	Orion chassis, 2002	PCB marked TMA531A or TMA531C (on ne	Micro OECF004A	remote SBKM00032A					
Toshiba	15V31B	Orion chassis, 2002	PCB marked TMC572B	Micro OECF012A	remote RC-GX010					
Toshiba	1720RB									
Toshiba	1721TB	C4								
Toshiba	1722TB	C4ER								
Toshiba	1752TB									
Toshiba	175R9B		1988							
Toshiba	175T9B									
Toshiba	199R4B									
Toshiba	201T4B									
Toshiba	202R5B									
Toshiba	202T5B									
Toshiba	2100RBT									
Toshiba	2100TBT		1990							





Toshiba	34AX9	FIDS	2001, multistandard I, B/G, D/K							
Toshiba	36ZP18P	C00S	2001							
Toshiba	3787DB	C8SS	1999, around £930-£1,400 depending on the year							
Toshiba	38VL14	F0LP								
Toshiba	40PW8DB	C8SS								
Toshiba	40PW8DG	C8SS								
Toshiba	40WH08B	C00P	1999							
Toshiba	42PW23P	C01P	2002							
Toshiba	42PW33P	C03P	2003							
Toshiba	42WH18B	C01P	2001							
Toshiba	42WT29B	C01P	2002			CT-90079				
Toshiba	43PJ93B	C9SS								
Toshiba	46WH08B	C00P	2000							
Toshiba	48PJ6DB	C5SS projection								
Toshiba	50PJ98B	C9SS								
Toshiba	50WH18B	C01P	2001							
Toshiba	50WT29B	C01P	2002			CT-90079				
Toshiba	55PJ6DB	C5SS projection								
Toshiba	56PW8DB	C8SS								
Toshiba	56PW8DG	C8SS								
Toshiba	56WH08B	C00P								
Toshiba	57WT29B	C02P (same as 50WT29B on C01P)	2002			CT-90079				
Toshiba	61PJ98B	C9SS								
Toshiba	67Z24B	Z13B (same as 28Z13B)	2002							
Toshiba	67Z27B	C00S	£499							
Toshiba	82Z27B	C00S (same as 32Z17B)	2002			CT-90043				
Toshiba	C169S	RANK-T24								
Toshiba	C208S	RANK-T24								
Toshiba	C2090	RANK-T24								
Toshiba	C2095B	Bush T24								
Toshiba	C222S	RANK-T24								
Toshiba	C222B	RANK-T24								
Toshiba	C2290	RANK-T24								
Toshiba	C2295B1	RANK-T24								
Toshiba	C262S	RANK-T24								
Toshiba	C2625B1	RANK-T24								
Toshiba	VTD1420	Orion chassis TV+DVD, 2004 £150	TV PCB TMC574A, DVD VMC316A	Micro OECF011A	remote					
Toshiba	VTD1431	Orion chassis TV+DVD, 2004 £145	TV PCB TMC574A, DVD BMD004A	Micro OECF017A						
Toshiba	VTD1551	Orion chassis TV+DVD, 2004 £190	TV PCB CMD006A, DVD DMD008A	Micro OECF017A						
Toshiba	VTD2020	Orion chassis TV+DVD, 2004 £230	TV PCB TMC574A, DVD VMC316A	Micro OECF011A	remote					
Toshiba	VTD2031	Orion chassis TV+DVD, 2004 £190	TV PCB TMC574A, DVD BMD004A	Micro OECF017A						
Toshiba	VTV1400	Orion chassis, OVD-7 deck	main PCB VMA240A, PSU VPA153A	Micro OEC0107B, option codes	remote VT1400					
Toshiba	VTV1400S	Orion chassis, OVD-7 deck	main PCB VMA240A, PSU VPA153A	Micro OEC0107B, option codes	remote VT1400					
Toshiba	VTV1401	SCV11F (Samsung)								
Toshiba	VTV1402B	Orion chassis, OVD-6S deck	TV PCB TMX473A, video VMX193A	Micro OEC0093A, option codes	EEPROM address 0F0h					
Toshiba	VTV1402S	Orion chassis, OVD-6S deck	TV PCB TMX473A, video VMX193A	Micro OEC0093A, option codes	EEPROM address 0F0h					
Toshiba	VTV1403B	Orion chassis, OVD-7 deck	main PCB VMA240A, PSU VPA153A	Micro OEC0107B, option codes	remote VT1403					
Toshiba	VTV1403S	Orion chassis, OVD-7 deck	main PCB VMA240A, PSU VPA153A	Micro OEC0107B, option codes	remote TOT201N09090					
Toshiba	VTV1415	Orion chassis, OVD-7 deck, 2004 £130	main PCB VMB291A, PSU VPA153A	Micro OEC0133A	remote VT1400					
Toshiba	VTV1416	Orion chassis, OVD-7 deck, 2004 £120	main PCB VMB291A, PSU VPA153A	Micro OEC0133A						
Toshiba	VTV1434	Orion chassis, OVD-7 deck	TV PCB TMB536A, video VMB254A	Micro OEC0113B	remote VT1403					
Toshiba	VTV1435	Orion chassis, OVD-7 deck	main PCB VMB291A, PSU VPA153A	Micro OEC0133A	remote VT1403					
Toshiba	VTV1436	Orion chassis, OVD-7 deck, 2004	main PCB VMB291A, PSU VPA153A	Micro OEC0133A						
Toshiba	VTV1455	Orion chassis, OVD-7 deck	TV PCB TMB536A, video VMC295A	Micro OEC0113B	remote					
Toshiba	VTV1534	Orion chassis, OVD-7 deck	TV PCB TMB536A, video VMB254A	Micro OEC0113B	remote VT1534					
Toshiba	VTV1555	Orion chassis, OVD-7 deck	TV PCB TMB536A, video VMB254A	Micro OEC0113B	remote VT1534					
Toshiba	VTV2034	Orion chassis, OVD-7 deck	TV PCB TMB536A, video VMB254A	Micro OEC0113B	remote VT1403					
Toshiba	VTV2055	Orion chassis, OVD-7 deck	TV PCB TMB536A, video VMC295A	Micro OEC0113B	remote					
Toshiba	VTV2056	Orion chassis, OVD-7 deck, 2004	TV PCB TMB536A, video VMC295A	Micro OEC0113B						
Toshiba	VTV2133	Orion chassis, OVD-6S deck	TV PCB TMX477A, video VMX199B	Micro OEC0096B	remote VT2133					
Toshiba	VTV2134	Orion chassis, OVD-7 deck	TV PCB TMB536A, video VMB254A	Micro OEC0113B	remote VT2134					
Toshiba	VTV2175	Orion chassis, OVD-7 deck	TV PCB TMB536A, video VMC295A	Micro OEC0113B	remote					
Toshiba	VTV21FL3	Orion chassis, OVD-6S deck (nonUK PAL B/G, CT)	TV PCB TMA515A, video VMA223A	Micro OEC0103B	remote VT21FL3					
Toshiba	VTW2185	Orion chassis, TV+DVD+VCR(OVD-7 deck)	TV PCB TMC568A, DVD VMB283B, video	Micro OEC0136A	remote TOT202N73010					
Toshiba	VTW2186	Orion chassis, TV+DVD+VCR(OVD-7 deck), 2001	TV PCB TMC568A, DVD BMD005A, video	Micro OEC0136B						
Triumph	CTV820S	Amstrad CTV1600								
Triumph	CTV820B	Amstrad CTV1409	Saisho CT14R							
Triumph	CTV820B	Jackson Mk 2	Osaki CTV14							
Triumph	CTV8212	Orion CTV144	Saisho CX14R							
Triumph	CTV8312	Orion CTV164	Saisho CX16R							
Triumph	TC1670	Hitachi NP8CQ								
Tyne Professio	7287/9	Beko 10.3 chassis								
Ultra	2001	Ferguson TX90								
Ultra	2201	Ferguson TX100								
Ultra	6771	Ferguson TX9								
Waltham	W14BLK		2004 £50 from Currys							
Watson	FA2801TS	11AK19P5								
Watson	FA3201TS	11AK19P4	2001-2002			AK19 prod.code: 10008630	remote 3040 (part 30011943)			
Watson	FA3629	11AK20M-6	1999-			AK20 prod.code: 10001418	remote 930			
Watson	FA3629 (silver)	11AK20M-6	1999-			AK20 prod.code: 10000721				
Watson	FA5139	11AK19-8A, 11AK19P4	1999-2001			AK19 prod.code: 10000896	remote 2040			
Watson	FA5160	11AK19P								
Watson	FA5161T	11AK30								
Watson	FA5471	SM1 stereo								
Watson	FA7039	11AK19-8A	1999-			AK19 prod.code: 10001207				
Watson	FA7040	11AK19E3								
Wharfedale	32PF1	11AK33								
Wharfedale	350	PT11								
Wharfedale	550	Amstrad CTV3128								
Wharfedale	550S (=CTV550S)	PT92	LOPTx 1352.5037 or 40348A-09 (HR8553, FBT40725)							
Wharfedale	850	PT92	LOPTx 1352.5037 or 40348A-09 (HR8553, FBT40725)							
Wharfedale	850S	chassis E9 (Elektronika Velenje (Evelux))	LOPTx 1372.9005 (HR8529, FBT40862)				Serv.mode: press TV, i, STOP withing 5 sec from switching set on. To exit press STOP.			
Wharfedale	890	PT92								
Wharfedale	CTV550S (=550S)	PT92	LOPTx 1352.5037 or 40348A-09 (HR8553, FBT40725)							
Wharfedale	CTV850	chassis E9 (Elektronika Velenje (Evelux))	LOPTx 1372.9005 (HR8529, FBT40862)	Micro SDA5255-B001(EV E9 7R	Serv.mode: press TV, i, STOP withing 5 sec from switching set on. To exit press STOP.					
Wharfedale	M10	PT92	LOPTx 4033749 (HR8545, FBT40784)							
Wharfedale	M8	PT92								
Wharfedale	T2101	PT92								
Wharfedale	T2102S	PT92								
Wharfedale	T2801	PT92								
Wharfedale	T2802S	PT92								
Wharfedale	T2811WS	PT92								
York	B52T	PT92 (14" set)								
York	X5 Junior	PT92								
Zanussi	16ZB312	BS665								
Zanussi	16ZT505	BS465								
Zanussi	16ZT506	BS565								
Zanussi	20ZA374	BS665								
Zanussi	20ZA374-16B	BS700								
Zanussi	20ZT505	BS465								
Zanussi	20ZT506	BS565								
Zanussi	20ZT509	BS500								
Zanussi	22ZA374	BS665								
Zanussi	22ZA377	BS665								
Zanussi	22ZA577	BS665								
Zanussi	22ZC454	BS665								
Zanussi	22ZT505	BS400								
Zanussi	22ZT506	BS500								
Zanussi	22ZT507	BS400								
Zanussi	22ZT616	BS500								
Zanussi	22ZT905	BS400								
Zanussi	22ZT906	BS500								
Zanussi	22ZT907	BS400								
Zanussi	26ZA374	BS665								
Zanussi	26ZT905	BS400								
Zanussi	26ZT906	BS500								