

MODEL_NUMB CTG_CTG_CDESCRIPTIO

01AJ3180/99	1041Clock radio
01AW7391/99	1041Radio cassette recorders - mono
01AW7501/99	1041Radio cassette recorders - mono
01AW7791/99	1041Radio cassette recorders - mono
01D7180/99	1041Radio cassette recorders - mono
01D8279/99	1041Radio cassette recorders - mono
01D8479/99	1041Radio cassette recorders - mono
01VR6448/99	1021Leader
02AJ1310/99	1041Clock radio
02AJ1310/99W	1041Clock radio
02AJ1320/99	1041Clock radio
02AJ1330/99	1041Clock radio
02AJ1380/99	1041Clock radio
02AK721/99	1049
02AL325/99	1041Radio + Cassette
02AL360/99	1041Radio cassette recorders - mono
02AL460/99	1041Radio cassette recorders - mono
02AL560/99	1041Radio cassette recorders - mono
02AQ2000/99	1041Radio cassette recorders - mono
02AQ2200/99	1041Radio cassette recorders - mono
02AQ6501/99	1041Radio + Cassette
02AQ6502/99	1041Radio + Cassette
02AQ6536/99	1041Radio + Cassette
02AS125/99	1041Clock radio
02AS128/99	1041Clock radio
02AS129/99	1041Clock radio
02AS130/99	1041Clock radio
02AS140/99	1041Clock radio
02AS300/99	1049
02AS305/99	1049
02AS305T/99	1049
02AS305TT/99	1049
02AS340/99	1049
02AS345II/99	1049
02AW3000/99	1041Radio cassette recorders - mono
02AZ8025/99	1042Single deck
02AZ8305/99	1041Radio cassette recorders - mono
02AZ8325/99	1042Single deck
02D1000/99	1041Radio cassette recorders - mono
02D1100/99	1041Radio cassette recorders - mono
02ECR38/99	1041Clock radio

CHS_CHASSI DATE_INTRSEGMENT_DE DESCRIPTI2

1.12.1992	CLOCKRADIO
1.03.1992	RADIO MONO + STEREO
1.05.1992	RADIO MONO + STEREO
1.03.1992	RADIO MONO + STEREO
1.03.1992	RADIO MONO + STEREO
1.10.1992	RADIO MONO + STEREO
1.10.1992	RADIO MONO + STEREO
1.03.1992	VCR
1.07.1992	CLOCKRADIO
1.02.1994	CLOCKRADIO
1.07.1992	CLOCKRADIO
1.10.1992	CLOCKRADIO
1.10.1993	CLOCKRADIO
1.08.1993	MIDISYSTEMS
1.03.1992	PERSONAL STEREO
1.05.1992	RADIO MONO + STEREO
1.03.1992	RADIO MONO + STEREO
1.05.1992	RADIO MONO + STEREO
1.07.1992	RADIO MONO + STEREO
1.09.1992	RADIO MONO + STEREO
1.10.1993	PERSONAL STEREO
1.09.1993	PERSONAL STEREO
1.08.1993	PERSONAL STEREO
1.06.1992	CLOCKRADIO
1.03.1992	CLOCKRADIO
1.03.1992	CLOCKRADIO
1.03.1992	CLOCKRADIO
1.03.1992	CLOCKRADIO
1.09.1993	MIDISYSTEMS
1.08.1993	MIDISYSTEMS
1.02.1994	MIDISYSTEMS
1.12.1994	MIDISYSTEMS
1.12.1994	MIDISYSTEMS
1.12.1994	MIDISYSTEMS
1.03.1993	RADIO MONO + STEREO
1.09.1993	RADIORECORDERS + CD
1.09.1992	RADIO MONO + STEREO
1.09.1993	RADIORECORDERS + CD
1.03.1993	RADIO MONO + STEREO
1.08.1993	RADIO MONO + STEREO
1.05.1994	CLOCKRADIO

02ECR39/99	1041Clock radio	1.03.1994	CLOCKRADIO
02FW19/99	1049Mini systems	1.10.1993	MINISYSTEMS
02FWC35/99	1049Mini systems	1.09.1992	MINISYSTEMS
02LX1000/99	1049	1.05.1994	MIDISYSTEMS
02LX1250/99	1049	1.03.1994	MIDISYSTEMS
02LX1450/99	1049	1.03.1994	MIDISYSTEMS
02LX1500/99	1049	1.03.1994	MIDISYSTEMS
02LX1750/99	1049	1.03.1994	MIDISYSTEMS
02LX1800/99	1049	1.03.1994	MIDISYSTEMS
02LX1900/99	1049	1.03.1994	MIDISYSTEMS
02LX2500/99	1049	1.06.1994	MIDISYSTEMS
02LX3000/99	1049	1.04.1994	MIDISYSTEMS
06AK601/99	1049	1.03.1992	MIDISYSTEMS
06AK603/99	1049	1.03.1992	MIDISYSTEMS
06AK630/99	1049	1.02.1993	MIDISYSTEMS
06AS125/99	1049	1.04.1994	MIDISYSTEMS
06AS205/99	1049	1.03.1993	MIDISYSTEMS
06AS325/99	1049	1.10.1994	MIDISYSTEMS
06AS405/99	1049	1.02.1993	MIDISYSTEMS
06AS425/99	1049	1.10.1994	MIDISYSTEMS
06AS440/99	1049	1.10.1994	MIDISYSTEMS
06AS450/99	1049	1.10.1995	MIDISYSTEMS
06AS465/99	1049	1.09.1997	MIDISYSTEMS
06AS560/99	1049	1.10.1996	MIDISYSTEMS
06AS565/99	1049	1.10.1996	MIDISYSTEMS
06AS575/99	1049	1.05.1998	MIDISYSTEMS
06AS660C/99	1049	1.06.1996	MIDISYSTEMS
06AS665C/99	1049	1.03.1997	MIDISYSTEMS
06AS667C/99	1049	1.01.1998	MIDISYSTEMS
06AS675C/99	1049	1.09.1997	MIDISYSTEMS
06AS680C/99	1049	1.10.1998	MIDISYSTEMS
06AS765C/99	1049	1.03.1997	MIDISYSTEMS
06AS785C/99	1049	1.11.1997	MIDISYSTEMS
06AS800C/99	1049	1.09.1998	MIDISYSTEMS
06AS9300/99	1049	1.03.1992	MIDISYSTEMS
06AS9400/99	1049	1.03.1992	MIDISYSTEMS
06CD163/99	1049CD	1.10.1994	CD PLAYERS
06CD164/99	1049	1.04.1993	MIDISYSTEMS
06CD165/99	1049CD	1.10.1994	CD PLAYERS
06CDC265/99	1049CD Video	1.08.1995	CDC / CDV
06DR180/99	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
06DR280/99	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO

06DR440/99	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
06FB100/99	1058	1.03.1992	SPEAKER BOXES
06FB300/99	1058	1.03.1992	SPEAKER BOXES
06FB400/99	1058	1.03.1992	SPEAKER BOXES
06FB560/99	1058		SPEAKER BOXES
06FB664/99	1058	1.03.1992	SPEAKER BOXES
06FB672/99	1058		SPEAKER BOXES
06FR732/99	1049Receivers	1.03.1997	RECEIVERS
06FR752/99	1049Receivers	1.03.1997	RECEIVERS
06FW26/99	1049Mini systems	1.08.1994	MINISYSTEMS
06FW316C/99	1049Mini systems	1.08.1998	MINISYSTEMS
06FW330/99	1049Mini systems	1.10.1995	MINISYSTEMS
06FW332/99	1049Mini systems	1.03.1997	MINISYSTEMS
06FW339C/99	1049Mini systems	1.08.1998	MINISYSTEMS
06FW352C/99	1049Mini systems	1.03.1997	MINISYSTEMS
06FW356C/99	1049Mini systems	1.09.1998	MINISYSTEMS
06FW360C/99	1049Mini systems	1.01.1996	MINISYSTEMS
06FW395C/99	1049Mini systems	1.04.1997	MINISYSTEMS
06FW46/99	1049Mini systems	1.11.1994	MINISYSTEMS
06FW56/99	1049Mini systems	1.08.1995	MINISYSTEMS
06FW630/99	1049Mini systems	1.05.1996	MINISYSTEMS
06FW650C/99	1049Mini systems	1.03.1996	MINISYSTEMS
06FW670P/99	1049Mini systems	1.03.1997	MINISYSTEMS
06FW750C/99	1049Mini systems	1.10.1997	MINISYSTEMS
06FW790P/99	1049Mini systems	1.11.1997	MINISYSTEMS
06FW850C/99	1049Mini systems	1.07.1998	MINISYSTEMS
100U1591/19G	2012PAL/SECAM terminal	1.01.1997	SATELLITE
100U1601/19B	2012PAL/SECAM terminal	1.09.1997	SATELLITE
110S2601/00G	2012PAL/SECAM terminal	1.04.1996	SATELLITE
110S2601/16G	2012PAL/SECAM terminal	1.12.1999	SATELLITE
110U1601/19G	2012PAL/SECAM terminal	1.06.1998	SATELLITE
110U1601/20G	2012PAL/SECAM terminal	1.02.1999	SATELLITE
110U2801/00M	2012PAL/SECAM terminal	1.11.1996	SATELLITE
111S2601/00G	2012PAL/SECAM terminal	1.01.1997	SATELLITE
111U2601/00B	2012PAL/SECAM terminal	1.03.1997	SATELLITE
111U2801/00B	2012PAL/SECAM terminal	1.02.1997	SATELLITE
111U2801/00G	2012PAL/SECAM terminal	1.02.1997	SATELLITE
112U2601/00B	2012PAL/SECAM terminal	1.04.1997	SATELLITE
112U2801/00B	2012PAL/SECAM terminal	1.04.1997	SATELLITE
112U2801/00G	2012PAL/SECAM terminal	1.06.1997	SATELLITE
113U2601/00B	2012PAL/SECAM terminal	1.10.1997	SATELLITE
114U2601/00B	2012PAL/SECAM terminal	1.05.1998	SATELLITE

114U2801/08B	2012PAL/SECAM terminal		1.07.1998	SATELLITE
120U1591/19G	2012PAL/SECAM terminal		1.01.1997	SATELLITE
120U2601/19G	2012PAL/SECAM terminal			SATELLITE
120U2751/19G	2012PAL/SECAM terminal			SATELLITE
130S2803/13R	2012PAL/SECAM terminal		1.09.1996	SATELLITE
130T2601/00G	2012PAL/SECAM terminal		1.07.1996	SATELLITE
130U2601/06G	2012PAL/SECAM terminal			SATELLITE
130U2803/13M	2012PAL/SECAM terminal		1.12.1996	SATELLITE
132U2601/00B	2012PAL/SECAM terminal		1.09.1997	SATELLITE
132U2801/00B	2012PAL/SECAM terminal		1.09.1997	SATELLITE
133U2601/00B	2012PAL/SECAM terminal		1.05.1998	SATELLITE
133U2701/00B	2012PAL/SECAM terminal		1.09.1998	SATELLITE
133U2801/00B	2012PAL/SECAM terminal		1.05.1998	SATELLITE
133U2851/00B	2012PAL/SECAM terminal			SATELLITE
13NV950S/37R	700114i (13v) stereo		1.11.1999	TELEVISION
140T3601/00G	2012PAL/SECAM terminal		1.09.1996	SATELLITE
140U2701/00M	2012PAL/SECAM terminal		1.01.1997	SATELLITE
140U2801/06G	2012PAL/SECAM terminal			SATELLITE
140U2851/00M	2012PAL/SECAM terminal		1.01.1997	SATELLITE
141U2701/00B	2012PAL/SECAM terminal		1.01.1997	SATELLITE
141U2851/00B	2012PAL/SECAM terminal		1.02.1997	SATELLITE
142021IR/14B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
142821IR/14B	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
142T6601/00P	2012PAL/SECAM terminal		1.10.1997	SATELLITE
142U2701/00B	2012PAL/SECAM terminal		1.10.1997	SATELLITE
142U2801/06B	2012PAL/SECAM terminal			SATELLITE
142U2851/00B	2012PAL/SECAM terminal		1.10.1997	SATELLITE
1445RS/05	700114i (13v) mono		1.06.1998	TELEVISION
1465TS/05	700114i (13v) mono		1.06.1998	TELEVISION
14AA3122/19B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3320/19B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3322/08B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3322/10B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3322/19B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3322/19V	700114i (13v) stereo	ANUBIS_A	1.06.1992Basic TV	TELEVISION
14AA3322/20B	700114i (13v) stereo	ANUBIS_A	1.05.1992Basic TV	TELEVISION
14AA3322/28B	700114i (13v) stereo	ANUBIS_A	1.05.1992Basic TV	TELEVISION
14AA3322/40B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/05B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/07B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/08B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/10B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION

14AA3324/15B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/16B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/19B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/22B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/30B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3324/40B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3327/00B	700114i (13v) stereo	ANUBIS_A	1.07.1992Basic TV	TELEVISION
14AA3327/01B	700114i (13v) stereo	ANUBIS_A	1.07.1992Basic TV	TELEVISION
14AA3327/42B	700114i (13v) stereo	ANUBIS_A	1.08.1992Basic TV	TELEVISION
14AA3329/16B	700114i (13v) stereo	ANUBIS_A	1.04.1992Basic TV	TELEVISION
14AA3329/19B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
14AA3329/40B	700114i (13v) stereo	ANUBIS_A	1.04.1992Basic TV	TELEVISION
14AA3527/00B	700114i (13v) stereo	ANUBIS_A	1.12.1992Basic TV	TELEVISION
14AA3527/01B	700114i (13v) stereo	ANUBIS_A	1.02.1993Basic TV	TELEVISION
14AA3527/05B	700114i (13v) stereo	ANUBIS_A	1.01.1993Basic TV	TELEVISION
14AA3527/07B	700114i (13v) stereo	ANUBIS_A	1.08.1993Basic TV	TELEVISION
14AA3527/13B	700114i (13v) stereo	ANUBIS_A	1.02.1993Basic TV	TELEVISION
14CN2001/75S	700114i (13v) stereo	NC3	1.03.1992Basic TV	TELEVISION
14CN4415L/84	700114i (13v) stereo		1.05.1992	TELEVISION
14CT4001L/86	700114i (13v) stereo		1.04.1992	TELEVISION
14CT6005L/84	700114i (13v) stereo		1.06.1992	TELEVISION
14CT6018/73	710114i (13v) stereo	CTO-S	1.12.1993	TELEVISION
14CT6018L/73	700114i (13v) stereo		1.04.1992	TELEVISION
14CT6020L/73	700114i (13v) stereo		1.04.1992	TELEVISION
14CT6035L/84	700114i (13v) stereo		1.06.1992	TELEVISION
14CT6305L/84	700114i (13v) stereo		1.06.1992	TELEVISION
14CT6335L/84	700114i (13v) stereo		1.06.1992	TELEVISION
14CT6405L/77	700114i (13v) stereo		1.04.1992	TELEVISION
14CT6417/73	700114i (13v) stereo		1.06.1993	TELEVISION
14CT6417L/73	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1010L/55U	700114i (13v) stereo		1.07.1992	TELEVISION
14GL1010L/87	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1011L/78	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1012L/55	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1012L/87	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1013/78	700114i (13v) stereo		1.05.1993	TELEVISION
14GL1013L/78	700114i (13v) stereo		1.11.1992	TELEVISION
14GL1014/78	700114i (13v) stereo		1.09.1993	TELEVISION
14GL1014/78R	700114i (13v) stereo			TELEVISION
14GL1015/78R	700114i (13v) stereo			TELEVISION
14GL1017/78R	700114i (13v) stereo			TELEVISION
14GL1019/78R	700114i (13v) stereo		1.01.1997	TELEVISION

14GL1310L/55	700114i (13v) stereo		1.07.1992	TELEVISION
14GL1310L/77	700114i (13v) stereo		1.04.1992	TELEVISION
14GL1310L/86	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1310L/87	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1311L/78	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1313/78	700114i (13v) stereo		1.05.1993	TELEVISION
14GL1313L/78	700114i (13v) stereo		1.10.1992	TELEVISION
14GL1314/78	700114i (13v) stereo		1.10.1993	TELEVISION
14GL1314/78R	700114i (13v) stereo			TELEVISION
14GL1315/78R	700114i (13v) stereo			TELEVISION
14GL1315L/87	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1316/78R	700114i (13v) stereo			TELEVISION
14GL1319/78R	700114i (13v) stereo		1.01.1997	TELEVISION
14GL1411/78	700114i (13v) stereo		1.05.1993	TELEVISION
14GL1411L/78	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1412L/87	700114i (13v) stereo		1.03.1992	TELEVISION
14GL1420L/78	700114i (13v) stereo		1.03.1992	TELEVISION
14GN1818/68R	700114i (13v) stereo		1.08.1992	TELEVISION
14GR1021/02B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1021/05B	700114i (13v) stereo	GR1AX	1.06.1992Basic TV	TELEVISION
14GR1021/10B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1021/16B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1021/22B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1021/57R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1021/57X	700114i (13v) stereo	GR1AX	1.07.1992Basic TV	TELEVISION
14GR1021/59H	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1021P/65	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1022/87R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1023/67B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1023P/65	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1024/50B	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
14GR1024/50R	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1024/57R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1024/59R	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1024/75R	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1024P/65	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1024P/70	700114i (13v) stereo		1.07.1992	TELEVISION
14GR1033/65	700114i (13v) stereo	GR1AX	1.05.1993Basic TV	TELEVISION
14GR1033/67R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1033/68R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1033P/65	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1034/50R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION

14GR1034/55R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1034/57R	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
14GR1034/75R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1034/79R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1036/67R	700114i (13v) stereo		1.09.1992	TELEVISION
14GR1036/68R	700114i (13v) stereo		1.11.1992	TELEVISION
14GR1037/65	700114i (13v) stereo		1.05.1993	TELEVISION
14GR1037/67R	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1037P/65	700114i (13v) stereo		1.06.1992	TELEVISION
14GR1220/05B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/08B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/10B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/11B	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1220/11E	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1220/11G	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1220/16B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/22B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/50B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/54B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/57B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/59H	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/73B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/75B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/77B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/79B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/85B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1220/97B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/02B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/02W	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/05B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/05V	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/05W	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/07B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/08B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/10B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/10V	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1221/10W	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/15B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/16B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/16L	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/16V	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/16W	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION

14GR1221/22B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/32B	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1221/32V	700114i (13v) stereo	GR1AX	1.05.1992Basic TV	TELEVISION
14GR1221/42B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/42V	700114i (13v) stereo	GR1AX	1.06.1992Basic TV	TELEVISION
14GR1221/43B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/57L	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/57R	700114i (13v) stereo	GR1AX	1.07.1992Basic TV	TELEVISION
14GR1221/57W	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1221/59R	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
14GR1221/75R	700114i (13v) stereo	GR1AX	1.05.1992Basic TV	TELEVISION
14GR1221L/80	700114i (13v) stereo		1.11.1992	TELEVISION
14GR1221P/65	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1222/87R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1223/50B	700114i (13v) stereo	GR1AX	1.06.1993Basic TV	TELEVISION
14GR1223/79B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1223P/65	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1223P/70	700114i (13v) stereo		1.07.1992	TELEVISION
14GR1224/50B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1224/50R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1224/57R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1224/59H	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1224/75R	700114i (13v) stereo	GR1AX	1.06.1992Basic TV	TELEVISION
14GR1224/79R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1224L/80	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1224P/65	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1225/08B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1225/10B	700114i (13v) stereo	GR1AX	1.06.1992Basic TV	TELEVISION
14GR1225/15B	700114i (13v) stereo	GR1AX	1.05.1992Basic TV	TELEVISION
14GR1225/16B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1227/02B	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
14GR1227/05B	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
14GR1227/05W	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
14GR1227/07B	700114i (13v) stereo	GR1AX	1.07.1992Basic TV	TELEVISION
14GR1227/08B	700114i (13v) stereo	GR1AX	1.07.1992Basic TV	TELEVISION
14GR1227/10B	700114i (13v) stereo	GR1AX	1.07.1992Basic TV	TELEVISION
14GR1227/10W	700114i (13v) stereo	GR1AX	1.07.1992Basic TV	TELEVISION
14GR1227/15B	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
14GR1227/16B	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
14GR1227/42B	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
14GR1228/50R	700114i (13v) stereo	GR1AX-NTSC	1.08.1992Basic TV	TELEVISION
14GR1228/54R	700114i (13v) stereo	GR1AX-NTSC	1.01.1993Basic TV	TELEVISION

14GR1228/75R	700114i (13v) stereo	GR1AX-NTSC	1.09.1992Basic TV	TELEVISION
14GR1228/77R	700114i (13v) stereo	GR1AX-NTSC	1.11.1992Basic TV	TELEVISION
14GR1228/84R	700114i (13v) stereo	GR1AX-NTSC	1.03.1993Basic TV	TELEVISION
14GR1228/85R	700114i (13v) stereo	GR1AX-NTSC	1.12.1992Basic TV	TELEVISION
14GR1228/97R	700114i (13v) stereo	GR1AX-NTSC	1.01.1993Basic TV	TELEVISION
14GR1229/05B	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
14GR1229/10B	700114i (13v) stereo	GR1AX	1.05.1992Basic TV	TELEVISION
14GR1229/16B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1230/50R	700114i (13v) stereo	GR1AX	1.11.1992Basic TV	TELEVISION
14GR1230/57R	700114i (13v) stereo	GR1AX	1.10.1992Basic TV	TELEVISION
14GR1230/70R	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
14GR1233/65	700114i (13v) stereo	GR1AX	1.05.1993Basic TV	TELEVISION
14GR1233/67R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1233/68R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1233P/65	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1234/50R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/52R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/54R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/57R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/58	700114i (13v) stereo	GR1AX	1.05.1993Basic TV	TELEVISION
14GR1234/58R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/59H	700114i (13v) stereo	GR1AX	1.05.1992Basic TV	TELEVISION
14GR1234/59R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/62R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/73R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/75R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/77	700114i (13v) stereo	GR1AX	1.08.1993Basic TV	TELEVISION
14GR1234/77R	700114i (13v) stereo	GR1AX	1.06.1992Basic TV	TELEVISION
14GR1234/79R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234/85	700114i (13v) stereo	GR1AX	1.05.1993Basic TV	TELEVISION
14GR1234/85R	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
14GR1234/87R	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
14GR1234L/58	700114i (13v) stereo		1.05.1992	TELEVISION
14GR1234L/77	700114i (13v) stereo		1.04.1992	TELEVISION
14GR1234L/85	700114i (13v) stereo		1.02.1993	TELEVISION
14GR1236/50R	700114i (13v) stereo	GR1AX	1.05.1992Basic TV	TELEVISION
14GR1236/52R	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
14GR1236/54R	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
14GR1236/57R	700114i (13v) stereo	GR1AX	1.12.1992Basic TV	TELEVISION
14GR1236/58R	700114i (13v) stereo	GR1AX	1.07.1992Basic TV	TELEVISION
14GR1236/59H	700114i (13v) stereo	GR1AX	1.11.1992Basic TV	TELEVISION
14GR1236/59R	700114i (13v) stereo	GR1AX	1.10.1992Basic TV	TELEVISION

14GR1236/62R	700114i (13v) stereo	GR1AX	1.10.1993Basic TV	TELEVISION
14GR1236/65	700114i (13v) stereo	GR1AX	1.05.1993Basic TV	TELEVISION
14GR1236/67R	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
14GR1236/68R	700114i (13v) stereo	GR1AX	1.11.1992Basic TV	TELEVISION
14GR1236/75R	700114i (13v) stereo	GR1AX	1.06.1992Basic TV	TELEVISION
14GR1236/77	700114i (13v) stereo	GR1AX	1.05.1993Basic TV	TELEVISION
14GR1236/77R	700114i (13v) stereo	GR1AX	1.12.1992Basic TV	TELEVISION
14GR1236/79R	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
14GR1236/85	700114i (13v) stereo	GR1AX	1.05.1993Basic TV	TELEVISION
14GR1236/85R	700114i (13v) stereo	GR1AX	1.11.1992Basic TV	TELEVISION
14GR1236/87R	700114i (13v) stereo	GR1AX	1.10.1992Basic TV	TELEVISION
14GR1236L/77	700114i (13v) stereo		1.09.1992	TELEVISION
14GR1236P/65	700114i (13v) stereo		1.10.1992	TELEVISION
14GR1237/65	700114i (13v) stereo		1.05.1993	TELEVISION
14GR1237/67R	700114i (13v) stereo		1.03.1992	TELEVISION
14GR1237/68R	700114i (13v) stereo		1.01.1993	TELEVISION
14GR1237/73R	700114i (13v) stereo		1.02.1993	TELEVISION
14GR1237P/65	700114i (13v) stereo		1.05.1992	TELEVISION
14GR1239/50R	700114i (13v) stereo		1.05.1992	TELEVISION
14GR1239/57R	700114i (13v) stereo		1.02.1993	TELEVISION
14GR1239/59H	700114i (13v) stereo		1.04.1993	TELEVISION
14GR1239/65	700114i (13v) stereo		1.05.1993	TELEVISION
14GR1239P/65	700114i (13v) stereo		1.10.1992	TELEVISION
14GR1819/68R	700114i (13v) stereo		1.11.1992	TELEVISION
14GR2325/39B	710114i (13v) stereo	G90B	1.03.1992Basic TV	TELEVISION
14GR2520/05B	700114i (13v) stereo	G90AE	1.06.1992Basic TV	TELEVISION
14GX1020/67R	700114i (13v) stereo	ANUBIS_S	1.01.1994Basic TV	TELEVISION
14GX1310/67R	700114i (13v) stereo	ANUBIS_S	1.10.1993Basic TV	TELEVISION
14GX1315/67R	700114i (13v) stereo	ANUBIS_S	1.01.1995Basic TV	TELEVISION
14GX1320/67R	700114i (13v) stereo	ANUBIS_S	1.01.1994Basic TV	TELEVISION
14GX1510/52R	700114i (13v) stereo	ANUBIS_S	1.12.1993Basic TV	TELEVISION
14GX1510/54R	700114i (13v) stereo	ANUBIS_S	1.09.1993Basic TV	TELEVISION
14GX1510/56R	700114i (13v) stereo	ANUBIS_S	1.08.1993Basic TV	TELEVISION
14GX1510/58R	700114i (13v) stereo	ANUBIS_S	1.11.1993Basic TV	TELEVISION
14GX1510/71R	700114i (13v) stereo	ANUBIS_S	1.04.1994Basic TV	TELEVISION
14GX1510/77B	700114i (13v) stereo	ANUBIS_S	1.11.1993Basic TV	TELEVISION
14GX1510/77R	700114i (13v) stereo	ANUBIS_S	1.02.1994Basic TV	TELEVISION
14GX1510/85R	700114i (13v) stereo	ANUBIS_S	1.10.1993Basic TV	TELEVISION
14GX1510/87R	700114i (13v) stereo	ANUBIS_S	1.11.1993Basic TV	TELEVISION
14GX1512/50B	700114i (13v) stereo	ANUBIS_S	1.12.1993Basic TV	TELEVISION
14GX1512/50R	700114i (13v) stereo	ANUBIS_S	1.08.1993Basic TV	TELEVISION
14GX1512/57R	700114i (13v) stereo	ANUBIS_S	1.09.1993Basic TV	TELEVISION

14GX1512/59R	700114i (13v) stereo	ANUBIS_S	1.06.1994Basic TV	TELEVISION
14GX1512/62B	700114i (13v) stereo	ANUBIS_S	1.01.1994Basic TV	TELEVISION
14GX1512/62R	700114i (13v) mono	ANUBIS_S	1.02.1996Basic TV	TELEVISION
14GX1512/65B	700114i (13v) stereo	ANUBIS_S	1.11.1993Basic TV	TELEVISION
14GX1512/67R	700114i (13v) stereo	ANUBIS_S	1.10.1993Basic TV	TELEVISION
14GX1512/75R	700114i (13v) stereo	ANUBIS_S	1.12.1993Basic TV	TELEVISION
14GX1512/79R	700114i (13v) stereo	ANUBIS_S	1.11.1993Basic TV	TELEVISION
14GX1515/52R	700114i (13v) stereo	ANUBIS_S	1.11.1994Basic TV	TELEVISION
14GX1515/54R	700114i (13v) stereo	ANUBIS_S	1.08.1995Basic TV	TELEVISION
14GX1515/58R	700114i (13v) stereo	ANUBIS_S	1.09.1994Basic TV	TELEVISION
14GX1515/77B	700114i (13v) stereo	ANUBIS_S	1.06.1996Basic TV	TELEVISION
14GX1515/85R	700114i (13v) stereo	ANUBIS_S	1.08.1994Basic TV	TELEVISION
14GX1515/87R	700114i (13v) stereo	ANUBIS_S	1.04.1996Basic TV	TELEVISION
14GX1516/59R	700114i (13v) stereo	ANUBIS_S	1.06.1995Basic TV	TELEVISION
14GX1516/59S	700114i (13v) stereo	ANUBIS_S	1.01.1995Basic TV	TELEVISION
14GX1516/75R	700114i (13v) stereo	ANUBIS_S	1.09.1994Basic TV	TELEVISION
14GX1517/50R	700114i (13v) stereo	ANUBIS_S	1.10.1994Basic TV	TELEVISION
14GX1517/56R	700114i (13v) stereo	ANUBIS_S	1.09.1994Basic TV	TELEVISION
14GX1517/57B	700114i (13v) stereo	ANUBIS_S	1.03.1995Basic TV	TELEVISION
14GX1517/57R	700114i (13v) stereo	ANUBIS_S	1.09.1994Basic TV	TELEVISION
14GX1517/67R	700114i (13v) stereo	ANUBIS_S	1.01.1995Basic TV	TELEVISION
14GX1520/71R	700114i (13v) stereo	ANUBIS_S	1.04.1994Basic TV	TELEVISION
14GX1522/50B	700114i (13v) stereo	ANUBIS_S	1.03.1994Basic TV	TELEVISION
14GX1522/65B	700114i (13v) stereo	ANUBIS_S	1.02.1994Basic TV	TELEVISION
14GX1522/67R	700114i (13v) stereo	ANUBIS_S	1.01.1994Basic TV	TELEVISION
14GX1610/78	700114i (13v) stereo		1.10.1993	TELEVISION
14GX1610/78R	700114i (13v) mono			TELEVISION
14GX1616/78R	700114i (13v) stereo			TELEVISION
14GX1618/78R	700114i (13v) stereo			TELEVISION
14GX1619/78R	700114i (13v) stereo		1.01.1997	TELEVISION
14GX1710/50B	700114i (13v) stereo	ANUBIS_S	1.06.1994Basic TV	TELEVISION
14GX1710/50R	700114i (13v) stereo	ANUBIS_S	1.03.1994Basic TV	TELEVISION
14GX1715/56R	700114i (13v) stereo	ANUBIS_S	1.04.1994Basic TV	TELEVISION
14GX1810/54R	700114i (13v) stereo	ANUBIS_S	1.10.1993Basic TV	TELEVISION
14GX1810/77R	700114i (13v) stereo	ANUBIS_S	1.03.1994Basic TV	TELEVISION
14GX1810/85R	700114i (13v) stereo	ANUBIS_S	1.11.1993Basic TV	TELEVISION
14GX1810/87R	700114i (13v) stereo	ANUBIS_S	1.11.1993Basic TV	TELEVISION
14GX1815/54R	700114i (13v) stereo	ANUBIS_S	1.08.1995Basic TV	TELEVISION
14GX1815/77B	700114i (13v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
14GX1815/87R	700114i (13v) stereo	ANUBIS_S	1.04.1996Basic TV	TELEVISION
14GX3515/58R	700114i (13v) stereo	ANUBIS_S	1.10.1995Basic TV	TELEVISION
14GX3515/71R	700114i (13v) mono	ANUBIS_S	1.04.1997Basic TV	TELEVISION

14GX3516/59H	700114i (13v) mono	ANUBIS_S	Basic TV	TELEVISION
14GX3516/59R	700114i (13v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
14GX3516/62	700114i (13v) mono			TELEVISION
14GX3516/75R	700114i (13v) stereo	ANUBIS_S	1.09.1995Basic TV	TELEVISION
14GX3517/56H	700114i (13v) mono	ANUBIS_S	Basic TV	TELEVISION
14GX3517/56R	700114i (13v) mono	ANUBIS_S	1.12.1995Basic TV	TELEVISION
14GX3517/56Z	700114i (13v) stereo	ANUBIS_S	1.08.1996Basic TV	TELEVISION
14GX3517/57R	700114i (13v) stereo	ANUBIS_S	1.11.1995Basic TV	TELEVISION
14GX3517/58R	700114i (13v) stereo	ANUBIS_S	1.02.1996Basic TV	TELEVISION
14GX3517/70R	700114i (13v) stereo	ANUBIS_S	1.11.1996Basic TV	TELEVISION
14GX8310/00R	700114i (13v) stereo	ANUBIS_S	1.10.1996Basic TV	TELEVISION
14GX8310/50B	700114i (13v) stereo	ANUBIS_S	1.02.1997Basic TV	TELEVISION
14GX8310/75R	700114i (13v) stereo	ANUBIS_S	1.06.1995Basic TV	TELEVISION
14GX8325/00R	700114i (13v) stereo	ANUBIS_S	1.10.1996Basic TV	TELEVISION
14GX8510/52R	700114i (13v) stereo	ANUBIS_S	1.06.1995Basic TV	TELEVISION
14GX8510/54R	700114i (13v) stereo	ANUBIS_S	1.03.1996Basic TV	TELEVISION
14GX8510/58R	700114i (13v) stereo	ANUBIS_S	1.05.1995Basic TV	TELEVISION
14GX8510/59R	700114i (13v) stereo	ANUBIS_S	1.06.1995Basic TV	TELEVISION
14GX8510/71R	700114i (13v) mono	ANUBIS_S	1.04.1997Basic TV	TELEVISION
14GX8510/73R	700114i (13v) stereo	ANUBIS_S	Basic TV	TELEVISION
14GX8510/77B	700114i (13v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
14GX8510/77R	700114i (13v) stereo	ANUBIS_S	1.07.1998Basic TV	TELEVISION
14GX8510/87R	700114i (13v) stereo	ANUBIS_S	1.04.1996Basic TV	TELEVISION
14GX8510/97R	700114i (13v) stereo	ANUBIS_S	1.07.1996Basic TV	TELEVISION
14GX8512/50L	700114i (13v) stereo	ANUBIS_S	1.06.1996Basic TV	TELEVISION
14GX8512/50R	700114i (13v) stereo	ANUBIS_S	1.04.1995Basic TV	TELEVISION
14GX8512/57R	700114i (13v) stereo	ANUBIS_S	1.04.1995Basic TV	TELEVISION
14GX8512/59B	700114i (13v) stereo	ANUBIS_S	1.06.1995Basic TV	TELEVISION
14GX8512/59F	700114i (13v) stereo	ANUBIS_S	Basic TV	TELEVISION
14GX8512/59R	700114i (13v) stereo	ANUBIS_S	1.05.1995Basic TV	TELEVISION
14GX8512/59T	700114i (13v) mono	ANUBIS_S	1.04.1997Basic TV	TELEVISION
14GX8512/59Z	700114i (13v) stereo	ANUBIS_S	Basic TV	TELEVISION
14GX8512/62R	700114i (13v) stereo	ANUBIS_S	1.02.1996Basic TV	TELEVISION
14GX8512/93R	700114i (13v) stereo	ANUBIS_S	1.03.1996Basic TV	TELEVISION
14GX8518/77B	700114i (13v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
14GX8525/71R	700114i (13v) stereo	ANUBIS_S	1.04.1997Basic TV	TELEVISION
14HT3152/00	201314i (13v) mono ITV	AA5H.1	1.03.1996Institutional TV	INSTITUTIONAL TV
14HT3152/01	201314i (13v) mono ITV	AA5H.1	1.04.1996Institutional TV	INSTITUTIONAL TV
14HT3152/40	201314i (13v) mono ITV	AA5H.1	1.02.1998Institutional TV	INSTITUTIONAL TV
14HT3152/41	201314i (13v) mono ITV	AA5H.1	1.10.1997Institutional TV	INSTITUTIONAL TV
14HT3152/68	201314i (13v) mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
14HT3153/01	201314i (13v) mono ITV	L9H.2E	1.04.2000Institutional TV	INSTITUTIONAL TV

14HT3153/05	201314i (13v) mono ITV	L9H.2E	1.07.2000	Institutional TV	INSTITUTIONAL TV
14HT3153/58	201314i (13v) mono ITV	L9H.2E	1.08.2001	Institutional TV	INSTITUTIONAL TV
14HT3154/01	14i (13v) mono ITV				INSTITUTIONAL TV
14HT3154/05	14i (13v) mono ITV				INSTITUTIONAL TV
14HT3202/00	201314i (13v) mono ITV	AA5H.1	1.06.1996	Institutional TV	INSTITUTIONAL TV
14HT3202/01	201314i (13v) mono ITV	AA5H.1	1.07.1996	Institutional TV	INSTITUTIONAL TV
14HT3202/13	201314i (13v) mono ITV	AA5H.1	1.12.1996	Institutional TV	INSTITUTIONAL TV
14HT3202/40	201314i (13v) mono ITV	AA5H.1	1.02.1998	Institutional TV	INSTITUTIONAL TV
14HT3202/41	201314i (13v) mono ITV	AA5H.1	1.02.1998	Institutional TV	INSTITUTIONAL TV
14HT3252/00	201314i (13v) mono ITV	AA5H.1	1.06.1996	Institutional TV	INSTITUTIONAL TV
14HT3252/01	201314i (13v) mono ITV	AA5H.1	1.05.1996	Institutional TV	INSTITUTIONAL TV
14HT3252/07	201314i (13v) mono ITV	AA5H.1	1.11.1996	Institutional TV	INSTITUTIONAL TV
14HT3252/13	201314i (13v) mono ITV				INSTITUTIONAL TV
14HT3252/40	201314i (13v) mono ITV	AA5H.1	1.04.1998	Institutional TV	INSTITUTIONAL TV
14HT3252/41	201314i (13v) mono ITV	AA5H.1	1.10.1997	Institutional TV	INSTITUTIONAL TV
14HT3252/47	201314i (13v) mono ITV	AA5H.1	1.07.1998	Institutional TV	INSTITUTIONAL TV
14HT3253/01	201314i (13v) mono ITV	L9H.2E	1.05.2000	Institutional TV	INSTITUTIONAL TV
14HT3253/05	201314i (13v) mono ITV	L9H.2E	1.06.2000	Institutional TV	INSTITUTIONAL TV
14HT3253/58	201314i (13v) mono ITV	L9H.2E	1.09.2001	Institutional TV	INSTITUTIONAL TV
14HT3302/00	201314i (13v) mono ITV	AA5H.1	1.03.1996	Institutional TV	INSTITUTIONAL TV
14HT3302/01	201314i (13v) mono ITV	AA5H.1	1.05.1996	Institutional TV	INSTITUTIONAL TV
14HT3302/07	201314i (13v) mono ITV	AA5H.1	1.08.1996	Institutional TV	INSTITUTIONAL TV
14HT3302/13	201314i (13v) mono ITV	AA5H.1	1.10.1996	Institutional TV	INSTITUTIONAL TV
14HT3302/40	201314i (13v) mono ITV	AA5H.1	1.02.1998	Institutional TV	INSTITUTIONAL TV
14HT3302/41	201314i (13v) mono ITV	AA5H.1	1.10.1997	Institutional TV	INSTITUTIONAL TV
14HT3302/47	201314i (13v) mono ITV	AA5H.1	1.03.1998	Institutional TV	INSTITUTIONAL TV
14HT3303/01	201314i (13v) mono ITV	L9H.2E	1.05.2000	Institutional TV	INSTITUTIONAL TV
14HT3303/05	201314i (13v) mono ITV	L9H.2E	1.06.2000	Institutional TV	INSTITUTIONAL TV
14HT3303/58	201314i (13v) mono ITV	L9H.2E	1.06.2001	Institutional TV	INSTITUTIONAL TV
14HT3304/01	201314i (13v) mono ITV	L01H.2E	1.09.2001	Institutional TV	INSTITUTIONAL TV
14HT3304/05	14i (13v) mono ITV				INSTITUTIONAL TV
14HT4202/01Z	201314i (13v) mono ITV	AA5H.1	1.03.1997	Institutional TV	INSTITUTIONAL TV
14HT4202/07Z	201314i (13v) mono ITV				INSTITUTIONAL TV
14HT4202/13Z	201314i (13v) mono ITV				INSTITUTIONAL TV
14HT4202/21M	201314i (13v) mono ITV	AA5H.1	1.01.1998	Institutional TV	INSTITUTIONAL TV
14HT4202/41Z	201314i (13v) mono ITV				INSTITUTIONAL TV
14HT4202/61M	201314i (13v) mono ITV	AA5H.1	1.08.1998	Institutional TV	INSTITUTIONAL TV
14HT4202/67M	201314i (13v) mono ITV	AA5H.1	1.02.1999	Institutional TV	INSTITUTIONAL TV
14HT4203/21M	201314i (13v) mono ITV	L9H.2E	1.06.2000	Institutional TV	INSTITUTIONAL TV
14HT4203/25M	201314i (13v) mono ITV	L9H.2E	1.08.2000	Institutional TV	INSTITUTIONAL TV
14HT4203/78M	201314i (13v) mono ITV				INSTITUTIONAL TV
14NRC999/99	700114i (13v) stereo		1.07.1993		TELEVISION

14NRC999P/99	700114i (13v) stereo		1.03.1992	TELEVISION
14PB345/39S	1022Leader	TVCR-D	1.09.1999	TVCR
14PI3601/00	700121i Multimedia	AA5-CDI.1	1.11.1996Basic TV	TELEVISION
14PI3601/01	700121i Multimedia	AA5-CDI.1	Basic TV	TELEVISION
14PT118A/50B	700114i (13v) mono	L7.1A	1.02.1997Basic TV	TELEVISION
14PT121A/05	700114i (13v) stereo	GR1AX	1.02.1994Basic TV	TELEVISION
14PT121A/05W	700114i (13v) stereo	GR1AX	1.02.1994Basic TV	TELEVISION
14PT121A/10	700114i (13v) stereo	GR1AX	1.05.1993Basic TV	TELEVISION
14PT129B/05	700114i (13v) stereo			TELEVISION
14PT1322/00	700114i (13v) mono	L6.1	1.03.1997Basic TV	TELEVISION
14PT1323/00	700114i (13v) mono	L6.1	1.04.1998Basic TV	TELEVISION
14PT1324/00	700114i (13v) mono	L9.2E	Basic TV	TELEVISION
14PT132A/50B	700114i (13v) mono	L7.1A	1.06.1997Basic TV	TELEVISION
14PT132A/50R	700114i (13v) mono	L7.1A	1.02.1997Basic TV	TELEVISION
14PT132A/60R	700114i (13v) stereo	L7.1A	1.11.1997Basic TV	TELEVISION
14PT132A/75R	700114i (13v) stereo	L7.1A	1.03.1997Basic TV	TELEVISION
14PT1332/00	700114i (13v) mono	L6.1	1.03.1996Basic TV	TELEVISION
14PT1332/00W	700114i (13v) mono	L6.1	1.02.1997Basic TV	TELEVISION
14PT1332/01	700114i (13v) mono	L6.1	1.02.1997Basic TV	TELEVISION
14PT1332/05	700114i (13v) mono	L6.1	1.03.1996Basic TV	TELEVISION
14PT1332/05W	700114i (13v) mono	L6.1	1.08.1996Basic TV	TELEVISION
14PT1332/11	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1332/11W	700114i (13v) mono	L6.1	1.10.1996Basic TV	TELEVISION
14PT1332/P01	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1342/00	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1342/20	700114i (13v) mono	L6.1	1.04.2000Basic TV	TELEVISION
14PT1342/20S	700114i (13v) mono	L6.1	1.10.2001Basic TV	TELEVISION
14PT1342/21	700114i (13v) mono	L6.1	1.03.2000Basic TV	TELEVISION
14PT1342/25	700114i (13v) mono	L6.1	1.03.2000Basic TV	TELEVISION
14PT1342/43	700114i (13v) mono	L6.1	1.05.1997Basic TV	TELEVISION
14PT1342/58	700114i (13v) mono	L6.1	1.05.1996Basic TV	TELEVISION
14PT1345/58	700114i (13v) mono	L9.2E	1.10.2000Basic TV	TELEVISION
14PT1346/05	14i (13v) mono			TELEVISION
14PT1346/58	14i (13v) mono			TELEVISION
14PT1352/00	700114i (13v) mono	L6.1	1.08.1996Basic TV	TELEVISION
14PT1352/01	700114i (13v) mono	L6.1	1.08.1996Basic TV	TELEVISION
14PT1352/05	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1352/07	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1352/11	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1352/39	700114i (13v) mono	L6.1	1.07.1996Basic TV	TELEVISION
14PT1352/43	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1352/58	700114i (13v) mono	L6.1	1.10.1997Basic TV	TELEVISION

14PT1352/P11	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1353/00	700114i (13v) mono	L6.1	1.01.1998Basic TV	TELEVISION
14PT1353/01	700114i (13v) mono	L6.1	1.12.1997Basic TV	TELEVISION
14PT1353/05	700114i (13v) mono	L6.1	1.04.1998Basic TV	TELEVISION
14PT1353/07	700114i (13v) mono	L6.1	1.02.1998Basic TV	TELEVISION
14PT1353/11	700114i (13v) mono	L6.1	1.01.1998Basic TV	TELEVISION
14PT1353/20	700114i (13v) mono	L6.1	1.09.1998Basic TV	TELEVISION
14PT1353/21	700114i (13v) mono	L6.1	1.09.1998Basic TV	TELEVISION
14PT1353/25	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1353/27	700114i (13v) mono	L6.1	1.09.1998Basic TV	TELEVISION
14PT1353/31	700114i (13v) mono	L6.1	1.09.1998Basic TV	TELEVISION
14PT1353/43	700114i (13v) mono	L6.1	1.05.1998Basic TV	TELEVISION
14PT1353/58	700114i (13v) mono	L6.1	1.02.1998Basic TV	TELEVISION
14PT1354/58	700114i (13v) mono	L9.2E	1.05.1999Basic TV	TELEVISION
14PT1356/00	14i (13v) mono			TELEVISION
14PT1356/01	14i (13v) mono			TELEVISION
14PT1356/05	14i (13v) mono			TELEVISION
14PT1356/58	14i (13v) mono			TELEVISION
14PT135A/00	700114i (13v) stereo	ANUBIS_A	1.10.1993Basic TV	TELEVISION
14PT135A/01	700114i (13v) stereo	ANUBIS_A	1.10.1993Basic TV	TELEVISION
14PT135A/05	700114i (13v) stereo	ANUBIS_A	1.06.1994Basic TV	TELEVISION
14PT135A/07	700114i (13v) stereo	ANUBIS_A	1.05.1994Basic TV	TELEVISION
14PT135A/10	700114i (13v) stereo	ANUBIS_A	1.09.1994Basic TV	TELEVISION
14PT135A/11	700114i (13v) stereo	ANUBIS_A	1.12.1994Basic TV	TELEVISION
14PT135A/42	700114i (13v) stereo	ANUBIS_A	1.04.1994Basic TV	TELEVISION
14PT135B/00	700114i (13v) stereo	AA5	1.07.1995Basic TV	TELEVISION
14PT135B/01	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
14PT135B/05	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
14PT135B/07	700114i (13v) stereo	AA5	1.07.1995Basic TV	TELEVISION
14PT135B/11	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
14PT135B/15	700114i (13v) stereo	AA5	1.12.1995Basic TV	TELEVISION
14PT135B/16	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
14PT135B/25	700114i (13v) stereo	AA5	1.04.1996Basic TV	TELEVISION
14PT135B/42	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
14PT135B/58P	700114i (13v) stereo	AA5	1.02.1996Basic TV	TELEVISION
14PT1363/00	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1363/01	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1363/01B	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION
14PT1363/01C	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION
14PT1363/01G	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1363/01S	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION
14PT1363/01V	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION

14PT1363/01X	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION
14PT1363/01Z	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION
14PT1363/05	700114i (13v) mono	L6.1	1.02.1998Basic TV	TELEVISION
14PT1363/05W	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1363/11	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1363/11W	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1363/58B	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1363/58C	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1365/00	700114i (13v) mono	L6.1	1.05.2000Basic TV	TELEVISION
14PT1365/01	700114i (13v) mono	L6.1	1.05.2000Basic TV	TELEVISION
14PT1365/05	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT136A/00	700114i (13v) stereo	ANUBIS_A	1.03.1994Basic TV	TELEVISION
14PT136A/00W	700114i (13v) stereo	ANUBIS_A	1.06.1994Basic TV	TELEVISION
14PT136A/01	700114i (13v) stereo	ANUBIS_A	1.04.1994Basic TV	TELEVISION
14PT136A/01W	700114i (13v) stereo	ANUBIS_A	1.06.1994Basic TV	TELEVISION
14PT136A/05	700114i (13v) stereo	ANUBIS_A	1.05.1994Basic TV	TELEVISION
14PT136A/05W	700114i (13v) stereo	ANUBIS_A	1.07.1994Basic TV	TELEVISION
14PT136A/07	700114i (13v) stereo	ANUBIS_A	1.05.1994Basic TV	TELEVISION
14PT136A/42	700114i (13v) stereo	ANUBIS_A	1.03.1994Basic TV	TELEVISION
14PT136A/58	700114i (13v) stereo	ANUBIS_A	1.07.1994Basic TV	TELEVISION
14PT136B/00	700114i (13v) stereo	AA5	1.03.1995Basic TV	TELEVISION
14PT136B/00W	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
14PT136B/01	700114i (13v) stereo	AA5	1.04.1995Basic TV	TELEVISION
14PT136B/01W	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
14PT136B/05	700114i (13v) stereo	AA5	1.04.1995Basic TV	TELEVISION
14PT136B/05W	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
14PT136B/07	700114i (13v) stereo	AA5	1.07.1995Basic TV	TELEVISION
14PT136B/07W	700114i (13v) stereo	AA5	1.07.1995Basic TV	TELEVISION
14PT136B/11	700114i (13v) mono	AA5	1.03.1995Basic TV	TELEVISION
14PT136B/11W	700114i (13v) mono	AA5	1.07.1995Basic TV	TELEVISION
14PT136B/15	700114i (13v) stereo	AA5	1.12.1995Basic TV	TELEVISION
14PT136B/16	700114i (13v) stereo	AA5	1.03.1995Basic TV	TELEVISION
14PT136B/25	700114i (13v) mono	AA5	1.03.1996Basic TV	TELEVISION
14PT136B/25W	700114i (13v) mono	AA5	Basic TV	TELEVISION
14PT136B/39	700114i (13v) mono	AA5	1.04.1996Basic TV	TELEVISION
14PT136B/42	700114i (13v) stereo	AA5	1.05.1995Basic TV	TELEVISION
14PT136B/58	700114i (13v) stereo	AA5	1.05.1995Basic TV	TELEVISION
14PT136B/58P	700114i (13v) mono	AA5	Basic TV	TELEVISION
14PT136B/58W	700114i (13v) mono	AA5	1.05.1996Basic TV	TELEVISION
14PT1372/01G	700114i (13v) mono	L6.1	1.04.1998Basic TV	TELEVISION
14PT1373/01S	700114i (13v) mono	L6.1	1.09.1998Basic TV	TELEVISION
14PT1373/11S	700114i (13v) mono	L6.1	1.12.1998Basic TV	TELEVISION

14PT1373/58S	700114i (13v) mono	L6.1	1.12.1998Basic TV	TELEVISION
14PT1374/01B	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1374/01C	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1374/01G	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1374/01S	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1374/01V	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1374/01X	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1374/01Y	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1374/01Z	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1374/43B	700114i (13v) mono	L6.1	1.11.1999Basic TV	TELEVISION
14PT1374/43C	700114i (13v) mono	L6.1	1.12.2000Basic TV	TELEVISION
14PT1374/43S	700114i (13v) mono	L6.1	1.11.1999Basic TV	TELEVISION
14PT1374/58B	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1374/58C	700114i (13v) mono	L6.1	1.09.2000Basic TV	TELEVISION
14PT1374/58S	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT138A/50R	700114i (13v) stereo	L7.1A	1.12.1996Basic TV	TELEVISION
14PT138A/54R	700114i (13v) mono	L7.1A	1.10.1998Basic TV	TELEVISION
14PT138A/57R	700114i (13v) mono	L7.1A	1.01.1997Basic TV	TELEVISION
14PT138A/58H	700114i (13v) stereo	L7.1A	1.02.1997Basic TV	TELEVISION
14PT138A/58R	700114i (13v) mono	L7.1A	1.02.1997Basic TV	TELEVISION
14PT138A/59B	700114i (13v) stereo	L7.1A	1.02.1997Basic TV	TELEVISION
14PT138A/59H	700114i (13v) mono	L7.1A	Basic TV	TELEVISION
14PT138A/59R	700114i (13v) mono	L7.1A	1.12.1996Basic TV	TELEVISION
14PT138A/59T	700114i (13v) mono	L7.1A	Basic TV	TELEVISION
14PT138A/70B	700114i (13v) mono	L7.1A	1.07.1997Basic TV	TELEVISION
14PT138A/71R	700114i (13v) mono	L7.1A	1.05.1997Basic TV	TELEVISION
14PT138A/73R	700114i (13v) mono	L7.1A	Basic TV	TELEVISION
14PT138A/75R	700114i (13v) mono	L7.1A	1.03.1997Basic TV	TELEVISION
14PT1422/50R	700114i (13v) mono	L7.1A	1.06.1998Basic TV	TELEVISION
14PT1422/50T	700114i (13v) mono	L7.1A	1.05.1999Basic TV	TELEVISION
14PT1422/68R	700114i (13v) mono	L7.1A	1.03.1998Basic TV	TELEVISION
14PT1422/75R	700114i (13v) mono	L7.1A	1.05.1998Basic TV	TELEVISION
14PT1422/75T	700114i (13v) mono	L7.1A	1.04.1999Basic TV	TELEVISION
14PT1482/50R	700114i (13v) mono	L7.1A	1.03.1998Basic TV	TELEVISION
14PT1482/50T	700114i (13v) mono	L7.1A	1.02.1999Basic TV	TELEVISION
14PT1482/57R	700114i (13v) mono	L7.1A	1.04.1998Basic TV	TELEVISION
14PT1482/57T	700114i (13v) mono	L7.1A	1.03.1999Basic TV	TELEVISION
14PT1482/58R	700114i (13v) mono			TELEVISION
14PT1482/59B	700114i (13v) mono	L7.1A	1.03.1998Basic TV	TELEVISION
14PT1482/59M	700114i (13v) mono	L7.1A	Basic TV	TELEVISION
14PT1482/59R	700114i (13v) mono	L7.1A	Basic TV	TELEVISION
14PT1482/59T	700114i (13v) mono	L7.1A	1.09.1998Basic TV	TELEVISION

14PT1482/59V	700114i (13v) mono	L7.1A	1.04.1999Basic TV	TELEVISION
14PT1482/59W	700114i (13v) mono	L7.1A	1.12.1999Basic TV	TELEVISION
14PT1482/68R	700114i (13v) mono	L7.1A	1.04.1998Basic TV	TELEVISION
14PT1482/71R	700114i (13v) mono	L7.1A	1.06.1998Basic TV	TELEVISION
14PT1482/73R	700114i (13v) mono	L7.1A	Basic TV	TELEVISION
14PT1482/79R	700114i (13v) mono	L7.1A	1.06.1998Basic TV	TELEVISION
14PT1482/79T	700114i (13v) mono	L7.1A	1.04.1999Basic TV	TELEVISION
14PT149B/05	700114i (13v) stereo			TELEVISION
14PT151A/00	700114i (13v) stereo	ANUBIS_A	1.04.1993Basic TV	TELEVISION
14PT1532/00	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1532/00B	700114i (13v) mono	L6.1	1.04.1998Basic TV	TELEVISION
14PT1532/01	700114i (13v) mono	L6.1	1.04.1997Basic TV	TELEVISION
14PT1532/05	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1532/07	700114i (13v) mono	L6.1	1.02.1997Basic TV	TELEVISION
14PT1532/11	700114i (13v) mono	L6.1	1.10.1996Basic TV	TELEVISION
14PT1542/00	700114i (13v) mono	L6.1	1.10.1999Basic TV	TELEVISION
14PT1542/05	700114i (13v) mono	L6.1	1.11.1999Basic TV	TELEVISION
14PT1542/15	700114i (13v) mono	L6.1	1.06.2000Basic TV	TELEVISION
14PT1542/20	700114i (13v) mono	L6.1	1.04.2000Basic TV	TELEVISION
14PT1542/20S	700114i (13v) mono	L6.1	1.09.2001Basic TV	TELEVISION
14PT1542/21	700114i (13v) mono	L6.1	1.03.2000Basic TV	TELEVISION
14PT1542/25	700114i (13v) mono	L6.1	1.02.2000Basic TV	TELEVISION
14PT1542/43	700114i (13v) stereo	L6.1	1.05.1997Basic TV	TELEVISION
14PT1542/58	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1542/58H	700114i (13v) mono	L6.1	1.05.1997Basic TV	TELEVISION
14PT1542/60	700114i (13v) mono			TELEVISION
14PT1546/05	14i (13v) mono			TELEVISION
14PT1546/58	14i (13v) mono			TELEVISION
14PT1552/00	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
14PT1552/01	700114i (13v) mono	L6.1	1.04.1997Basic TV	TELEVISION
14PT1552/05	700114i (13v) mono	L6.1	1.10.1996Basic TV	TELEVISION
14PT1552/07	700114i (13v) stereo	L6.1	1.03.1998Basic TV	TELEVISION
14PT1552/11	700114i (13v) mono	L6.1	1.10.1996Basic TV	TELEVISION
14PT1552/15	700114i (13v) stereo	L6.1	1.02.1997Basic TV	TELEVISION
14PT1552/58	700114i (13v) mono	L6.1	1.07.1999Basic TV	TELEVISION
14PT1552/P11	700114i (13v) mono			TELEVISION
14PT1553/00	700114i (13v) mono	L6.1	1.02.1998Basic TV	TELEVISION
14PT1553/01	700114i (13v) mono	L6.1	1.02.1998Basic TV	TELEVISION
14PT1553/05	700114i (13v) mono	L6.1	1.04.1998Basic TV	TELEVISION
14PT1553/05S	700114i (13v) mono			TELEVISION
14PT1553/11	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1553/20	700114i (13v) mono	L6.1	1.09.1998Basic TV	TELEVISION

14PT1553/21	700114i (13v) mono			TELEVISION
14PT1553/25	700114i (13v) mono			TELEVISION
14PT1553/31	700114i (13v) mono			TELEVISION
14PT1556/00	14i (13v) mono			TELEVISION
14PT1556/01	14i (13v) mono			TELEVISION
14PT1556/05	14i (13v) mono			TELEVISION
14PT1556/21	14i (13v) mono			TELEVISION
14PT155A/00	700114i (13v) stereo	ANUBIS_A	1.10.1993Basic TV	TELEVISION
14PT155A/05	700114i (13v) stereo	ANUBIS_A	1.10.1993Basic TV	TELEVISION
14PT155B/00	700114i (13v) stereo	AA5	1.04.1995Basic TV	TELEVISION
14PT155B/13	700114i (13v) stereo	AA5	1.04.1995Basic TV	TELEVISION
14PT1562/00	700114i (13v) mono	L6.1	1.04.2000Basic TV	TELEVISION
14PT1562/58	700114i (13v) mono	L6.1	1.03.2000Basic TV	TELEVISION
14PT1563/00	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1563/01	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1563/05	700114i (13v) mono	L6.1	1.02.1998Basic TV	TELEVISION
14PT1563/05B	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION
14PT1563/05C	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION
14PT1563/05G	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1563/05S	700114i (13v) mono	L6.1	1.09.1998Basic TV	TELEVISION
14PT1563/05V	700114i (13v) mono	L6.1	1.04.1999Basic TV	TELEVISION
14PT1563/07	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1563/07B	700114i (13v) mono	L6.1	1.07.1999Basic TV	TELEVISION
14PT1563/07S	700114i (13v) mono	L6.1	1.07.1999Basic TV	TELEVISION
14PT1563/11	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1563/11W	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1563/15	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1563/43	700114i (13v) mono	L6.1	1.09.1997Basic TV	TELEVISION
14PT1563/58	700114i (13v) mono	L6.1	1.10.1997Basic TV	TELEVISION
14PT1563/58H	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
14PT1563/60	700114i (13v) mono	L6.1	1.12.1997Basic TV	TELEVISION
14PT1565/00	700114i (13v) mono	L6.1	1.05.2000Basic TV	TELEVISION
14PT1565/01	700114i (13v) mono	L6.1	1.05.2000Basic TV	TELEVISION
14PT1565/05	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1565/58	700114i (13v) mono	L6.1	1.05.2000Basic TV	TELEVISION
14PT156A/00	700114i (13v) stereo	ANUBIS_A	1.04.1994Basic TV	TELEVISION
14PT156A/01	700114i (13v) stereo	ANUBIS_A	1.06.1994Basic TV	TELEVISION
14PT156A/05	700114i (13v) stereo	ANUBIS_A	1.06.1994Basic TV	TELEVISION
14PT156A/07	700114i (13v) stereo	ANUBIS_A	1.06.1994Basic TV	TELEVISION
14PT156A/13	700114i (13v) stereo	ANUBIS_A	1.05.1994Basic TV	TELEVISION
14PT156A/16	700114i (13v) stereo	ANUBIS_A	1.05.1994Basic TV	TELEVISION
14PT156B/00	700114i (13v) stereo	AA5	1.03.1995Basic TV	TELEVISION

14PT156B/01	700114i (13v) stereo	AA5	1.03.1995Basic TV	TELEVISION
14PT156B/05	700114i (13v) stereo	AA5	1.04.1995Basic TV	TELEVISION
14PT156B/07	700114i (13v) stereo	AA5	1.03.1995Basic TV	TELEVISION
14PT156B/13	700114i (13v) mono	AA5	1.04.1995Basic TV	TELEVISION
14PT156B/25	700114i (13v) mono	AA5	1.04.1996Basic TV	TELEVISION
14PT156B/58P	700114i (13v) stereo	AA5	1.01.1996Basic TV	TELEVISION
14PT1573/01	700114i (13v) mono	L6.1	1.07.1998Basic TV	TELEVISION
14PT1573/11	700114i (13v) mono	L6.1	1.07.1998Basic TV	TELEVISION
14PT1573/15	700114i (13v) mono	L6.1	1.12.1998Basic TV	TELEVISION
14PT1574/00B	700114i (13v) mono	L6.1	1.05.1999Basic TV	TELEVISION
14PT1574/00C	700114i (13v) mono	L6.1	1.05.1999Basic TV	TELEVISION
14PT1574/00G	700114i (13v) mono	L6.1	1.05.1999Basic TV	TELEVISION
14PT1574/00S	700114i (13v) mono	L6.1	1.05.1999Basic TV	TELEVISION
14PT1574/00Y	700114i (13v) stereo	L6.1	1.09.1999Basic TV	TELEVISION
14PT1574/00Z	700114i (13v) mono	L6.1	1.10.1999Basic TV	TELEVISION
14PT1574/01B	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1574/01C	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1574/01G	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1574/01S	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1574/01Y	700114i (13v) mono	L6.1	1.10.1999Basic TV	TELEVISION
14PT1574/01Z	700114i (13v) mono	L6.1	1.10.1999Basic TV	TELEVISION
14PT1582/57R	700114i (13v) mono	L6.1	1.02.2000Basic TV	TELEVISION
14PT1582/59A	700114i (13v) mono	L6.1	1.05.2000Basic TV	TELEVISION
14PT1582/59B	700114i (13v) mono	L6.1	1.04.2000Basic TV	TELEVISION
14PT1582/59C	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1582/59R	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1582/59T	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1582/59V	700114i (13v) mono	L6.1	1.09.1999Basic TV	TELEVISION
14PT1582/59W	700114i (13v) mono	L6.1	1.01.2000Basic TV	TELEVISION
14PT1582/73R	700114i (13v) mono	L6.1	Basic TV	TELEVISION
14PT1582/75R	700114i (13v) mono	L6.1	1.03.2000Basic TV	TELEVISION
14PT1582/75T	700114i (13v) mono	L6.1	1.01.2000Basic TV	TELEVISION
14PT1686/01A	14i (13v) mono			TELEVISION
14PT1686/01B	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/01G	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/01P	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/01S	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/01V	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/05A	14i (13v) mono			TELEVISION
14PT1686/05B	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/05G	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/05R	14i (13v) mono			TELEVISION

14PT1686/05S	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/05V	700114i (13v) mono	L01.2E	1.08.2001Basic TV	TELEVISION
14PT1686/58A	14i (13v) mono			TELEVISION
14PT1686/58B	700114i (13v) mono	L01.2E	1.07.2001Basic TV	TELEVISION
14PT1686/58G	700114i (13v) mono	L01.2E	1.11.2001Basic TV	TELEVISION
14PT1686/58P	700114i (13v) mono	L01.2E	1.07.2001Basic TV	TELEVISION
14PT1686/58S	700114i (13v) mono	L01.2E	1.09.2001Basic TV	TELEVISION
14PT1686/58V	700114i (13v) mono	L01.2E	1.07.2001Basic TV	TELEVISION
14PT1782/94R	700114i (13v) stereo	L9.2A	1.09.2001Basic TV	TELEVISION
14PT1882/94A	14i (13v) stereo			TELEVISION
14PT189B/05	700114i (13v) stereo			TELEVISION
14PT2001/59A	14i (13v) mono			TELEVISION
14PT2001/59B	14i (13v) mono			TELEVISION
14PT2001/59C	14i (13v) mono			TELEVISION
14PT2001/79R	14i (13v) mono			TELEVISION
14PT2012/59A	14i (13v) mono			TELEVISION
14PT2012/59B	14i (13v) mono			TELEVISION
14PT2012/59C	14i (13v) mono			TELEVISION
14PT230A/50B	700114i (13v) stereo	ANUBIS_S	1.02.1997Basic TV	TELEVISION
14PT230A/50R	700114i (13v) stereo	ANUBIS_S	1.06.1996Basic TV	TELEVISION
14PT230A/58R	700114i (13v) stereo	ANUBIS_S	1.10.1996Basic TV	TELEVISION
14PT230A/59R	700114i (13v) stereo	ANUBIS_S	1.07.1996Basic TV	TELEVISION
14PT230A/75R	700114i (13v) stereo	ANUBIS_S	1.06.1996Basic TV	TELEVISION
14PT2321/50B	700114i (13v) mono	L7.1A	1.01.1998Basic TV	TELEVISION
14PT2321/50R	700114i (13v) mono	L7.1A	1.10.1997Basic TV	TELEVISION
14PT2321/59R	700114i (13v) mono	L7.1A	1.02.2000Basic TV	TELEVISION
14PT233A/71R	700114i (13v) mono	ANUBIS_S	1.04.1997Basic TV	TELEVISION
14PT235A/50B	700114i (13v) stereo	ANUBIS_S	1.02.1997Basic TV	TELEVISION
14PT235A/50R	700114i (13v) stereo	ANUBIS_S	1.06.1996Basic TV	TELEVISION
14PT2381/50B	700114i (13v) mono	L7.1A	1.12.1997Basic TV	TELEVISION
14PT2381/54R	700114i (13v) mono	L7.1A	1.01.1999Basic TV	TELEVISION
14PT2381/59B	700114i (13v) mono	L7.1A	1.10.1997Basic TV	TELEVISION
14PT2381/59R	700114i (13v) mono	L7.1A	1.10.1997Basic TV	TELEVISION
14PT2381/70B	700114i (13v) mono	L7.1A	Basic TV	TELEVISION
14PT2382/56R	700114i (13v) mono	L7.1A	1.01.1998Basic TV	TELEVISION
14PT2382/57R	700114i (13v) mono	L7.1A	1.12.1997Basic TV	TELEVISION
14PT2382/70R	700114i (13v) mono			TELEVISION
14PT2382/71R	700114i (13v) mono	L7.1A	1.07.1998Basic TV	TELEVISION
14PT2663/00	700114i (13v) stereo	L6.1	1.09.1997Basic TV	TELEVISION
14PT2665/00	700114i (13v) stereo	L9.2E	1.04.2000Basic TV	TELEVISION
14PT2665/01	700114i (13v) stereo	L9.2E	1.04.2000Basic TV	TELEVISION
14PT2665/05	700114i (13v) stereo	L9.2E	1.05.2000Basic TV	TELEVISION

14PT2665/58	700114i (13v) stereo	L9.2E	1.08.2000Basic TV	TELEVISION
14PT2666/01	700114i (13v) stereo	L01.2E	1.08.2001Basic TV	TELEVISION
14PT2666/05	700114i (13v) stereo	L01.2E	1.08.2001Basic TV	TELEVISION
14PT2666/05R	700114i (13v) stereo	L01.2E	1.09.2001Basic TV	TELEVISION
14PT2666/58	700114i (13v) stereo	L01.2E	1.07.2001Basic TV	TELEVISION
14PT2682/57R	700114i (13v) stereo	L7.1A	1.04.1998Basic TV	TELEVISION
14PT2683/01	700114i (13v) stereo	L6.2	1.10.1997Basic TV	TELEVISION
14PT2683/05	700114i (13v) stereo	L6.2	1.10.1997Basic TV	TELEVISION
14PT2683/11	700114i (13v) stereo	L6.2	1.10.1997Basic TV	TELEVISION
14PT2683/58	700114i (13v) stereo	L6.2	1.04.1998Basic TV	TELEVISION
14PT2685/01	700114i (13v) stereo	L9.2A	Basic TV	TELEVISION
14PT2685/05	700114i (13v) stereo	L9.2A	Basic TV	TELEVISION
14PT2685/58	700114i (13v) stereo	L9.2A	Basic TV	TELEVISION
14PT2694/01B	700114i (13v) stereo	L6.1	Basic TV	TELEVISION
14PT2694/01I	700114i (13v) stereo	L6.1	1.04.1999Basic TV	TELEVISION
14PT2694/05B	700114i (13v) stereo	L6.1	Basic TV	TELEVISION
14PT2694/05I	700114i (13v) stereo	L6.1	1.05.1999Basic TV	TELEVISION
14PT300A/00	700114i (13v) stereo	ANUBIS_A	1.04.1993Basic TV	TELEVISION
14PT300A/01	700114i (13v) stereo	ANUBIS_A	1.05.1993Basic TV	TELEVISION
14PT300A/07	700114i (13v) stereo	ANUBIS_A	1.09.1993Basic TV	TELEVISION
14PT310A/00	201321i (20v) mono ITV	AA5	1.06.1995Basic TV	INSTITUTIONAL TV
14PT310A/01	201321i (20v) mono ITV	AA5	1.07.1995Basic TV	INSTITUTIONAL TV
14PT3685/00	700114i (13v) stereo	L9.3E	1.06.2000Basic TV	TELEVISION
14PT3685/01	700114i (13v) stereo	L9.3E	1.06.2000Basic TV	TELEVISION
14PT3685/01E	700114i (13v) stereo	L9.3E	1.03.2001Basic TV	TELEVISION
14PT3685/05	700114i (13v) stereo	L9.3E	1.05.2000Basic TV	TELEVISION
14PT3722/59A	700114i (13v) mono	L9.2A	1.03.2000Basic TV	TELEVISION
14PT3722/59B	700114i (13v) mono	L9.2A	1.09.1999Basic TV	TELEVISION
14PT3722/59C	700114i (13v) mono	L9.2A	1.10.1999Basic TV	TELEVISION
14PT3822/56A	700114i (13v) stereo	L9.2A	Basic TV	TELEVISION
14PT3822/57R	700114i (13v) stereo	L9.2A	1.10.1999Basic TV	TELEVISION
14PT3822/68R	700114i (13v) stereo	L9.2A	1.10.1999Basic TV	TELEVISION
14PT3822/69R	700114i (13v) stereo	L9.2A	1.09.1999Basic TV	TELEVISION
14PT3862/57R	700114i (13v) stereo	L9.3A	1.11.1999Basic TV	TELEVISION
14PT3862/69R	700114i (13v) stereo	L9.3A	1.10.1999Basic TV	TELEVISION
14PT3862/79R	700114i (13v) stereo	L9.3A	1.12.1999Basic TV	TELEVISION
14PV010/00P	Leader	TVCR-D		TVCR
14PV010/01	1022Leader	TVCR-D	1.03.2000	TVCR
14PV010ES	1022Leader	TVCR-D	1.03.2000	TVCR
14PV010XE	1022Leader	TVCR-D	1.03.2000	TVCR
14PV100/01	1022Leader	TVCR-D	1.07.2000	TVCR
14PV100/07	1022Leader	TVCR-D	1.03.2001	TVCR

14PV100/58	1022Leader	TVCR-D	1.07.2000	TVCR
14PV100/EE	1022Leader	TVCR-D	1.06.2000	TVCR
14PV100DE	1022Leader			TVCR
14PV100EE	Leader			TVCR
14PV100ES	1022Leader	TVCR-D	1.08.2000	TVCR
14PV100GR	1022Leader			TVCR
14PV100XE	1022Leader			TVCR
14PV101/39	1022Step-up	TVCR-D	1.04.2000	TVCR
14PV110/01	1022Leader	TVCR-E	1.04.2001	TVCR
14PV110/07	1022Leader	TVCR-E	1.04.2001	TVCR
14PV110/58	1022Leader	TVCR-E	1.03.2001	TVCR
14PV110/ES	1022Leader	TVCR-E	1.04.2001	TVCR
14PV110/XE	1022Leader	TVCR-E	1.04.2001	TVCR
14PV111/58	Leader			TVCR
14PV162/01	1022Leader	TVCR-B	1.07.1996	TVCR
14PV162/02	1022Leader	TVCR-B	1.07.1996	TVCR
14PV162/05	1022Leader	TVCR-B	1.07.1996	TVCR
14PV162/07	1022Leader	TVCR-B	1.08.1996	TVCR
14PV162/08	1022Leader	TVCR-B	1.09.1996	TVCR
14PV162/13	1022Leader	TVCR-B	1.07.1996	TVCR
14PV162/58	1022Leader	TVCR-B	1.11.1996	TVCR
14PV163/05	1022Leader	TVCR-B	1.06.1996	TVCR
14PV163/05H	1022Leader	TVCR-B	1.06.1997	TVCR
14PV170/05	1022Leader	TVCR-B	1.04.1997	TVCR
14PV172/01	1022Leader	TVCR-B	1.03.1997	TVCR
14PV172/05	1022Leader	TVCR-B	1.04.1997	TVCR
14PV172/08	1022Leader	TVCR-B	1.04.1997	TVCR
14PV172/13	1022Leader	TVCR-B	1.05.1997	TVCR
14PV172/39	1022Leader	TVCR-B	1.08.1997	TVCR
14PV173/05W	1022Leader	TVCR-B	1.07.1997	TVCR
14PV182/00	1022Leader			TVCR
14PV182/05	1022Leader	TVCR-B	1.03.1998	TVCR
14PV182/39	1022Leader	TVCR-B	1.06.1998	TVCR
14PV182/58	1022Leader	TVCR-B	1.04.1998	TVCR
14PV182FR	1022Leader	TVCR-B	1.03.1999	TVCR
14PV183/01	1022Leader	TVCR-B	1.03.1998	TVCR
14PV183/08	1022Leader	TVCR-B	1.03.1998	TVCR
14PV183/08B	1022Leader	TVCR-B	1.06.1998	TVCR
14PV183/13	1022Leader	TVCR-B	1.03.1998	TVCR
14PV183/13G	1022Leader	TVCR-B	1.06.1998	TVCR
14PV184/05	1022Core	TVCR-B	1.05.1998	TVCR
14PV200/01	1022Leader	TVCR-D	1.05.2000	TVCR

14PV200/07	1022Leader	TVCR-D	1.10.1999	TVCR
14PV200DE	1022Leader	TVCR-D	1.05.2000	TVCR
14PV200ES	1022Leader	TVCR-D	1.05.2000	TVCR
14PV200GR	1022Leader			TVCR
14PV200IR	1022Leader	TVCR-D	1.03.2000	TVCR
14PV200XE	1022Leader	TVCR-D	1.05.2000	TVCR
14PV201/39	1022Leader	TVCR-D	1.02.2000	TVCR
14PV202/01	1022Leader	TVCR-E	1.04.2001	TVCR
14PV202/07	1022Leader	TVCR-E	1.04.2001	TVCR
14PV202/39	1022Leader	TVCR-E	1.02.2001	TVCR
14PV202/CH	1022Leader	TVCR-E	1.04.2001	TVCR
14PV202/ES	1022Leader	TVCR-E	1.04.2001	TVCR
14PV202/XE	1022Leader	TVCR-E	1.04.2001	TVCR
14PV203/58	Leader			TVCR
14PV210/01	1022Leader	TVCR-D	1.06.1999	TVCR
14PV210/07	1022Leader	TVCR-D	1.06.1999	TVCR
14PV210/39	1022Leader	TVCR-D	1.06.1999	TVCR
14PV210/58	1022Leader	TVCR-D	1.05.1999	TVCR
14PV210DE	1022Leader	TVCR-D	1.06.1999	TVCR
14PV210ES	1022Leader	TVCR-D	1.06.1999	TVCR
14PV210GR	1022Leader	TVCR-D	1.07.1999	TVCR
14PV210XE	1022Leader	TVCR-D	1.06.1999	TVCR
14PV211/01	1022Leader	TVCR-D	1.05.2000	TVCR
14PV211/07	1022Leader	TVCR-D	1.05.2000	TVCR
14PV211/39	1022Leader	TVCR-D	1.06.2000	TVCR
14PV211/58	1022Leader	TVCR-D	1.06.2000	TVCR
14PV211/IT	1022Leader	TVCR-D	1.09.2000	TVCR
14PV211DE	1022Leader	TVCR-D	1.05.2000	TVCR
14PV211ES	1022Leader	TVCR-D	1.06.2000	TVCR
14PV211GR	1022Leader	TVCR-D	1.05.2000	TVCR
14PV211XE	1022Leader	TVCR-D	1.05.2000	TVCR
14PV217/01	1022Leader	TVCR-D	1.05.2000	TVCR
14PV217/07	1022Leader	TVCR-D	1.05.2000	TVCR
14PV217/39	1022Leader	TVCR-D	1.06.2000	TVCR
14PV217/IT	1022Leader	TVCR-D	1.09.2000	TVCR
14PV217DE	1022Leader	TVCR-D	1.05.2000	TVCR
14PV217ES	1022Leader	TVCR-D	1.05.2000	TVCR
14PV217GR	1022Leader	TVCR-D	1.09.2000	TVCR
14PV217XE	1022Leader	TVCR-D	1.06.2000	TVCR
14PV220/01	1022Leader	TVCR-E	1.03.2001	TVCR
14PV220/07	1022Leader	TVCR-E	1.04.2001	TVCR
14PV220/39	1022Leader	TVCR-E	1.07.2001	TVCR

14PV220/58	1022Leader	TVCR-E	1.03.2001	TVCR
14PV220/ES	1022Leader	TVCR-E	1.05.2001	TVCR
14PV220/GR	1022Leader	TVCR-E	1.06.2001	TVCR
14PV220/XE	1022Leader	TVCR-E	1.04.2001	TVCR
14PV227/01	1022Leader	TVCR-E	1.04.2001	TVCR
14PV227/07	1022Leader	TVCR-E	1.04.2001	TVCR
14PV227/39	1022Leader	TVCR-E	1.05.2001	TVCR
14PV227/CH	1022Leader	TVCR-E	1.04.2001	TVCR
14PV227/ES	1022Leader	TVCR-E	1.05.2001	TVCR
14PV227/GR	Leader	TVCR-E	1.06.2001	TVCR
14PV227/XE	1022Leader	TVCR-E	1.04.2001	TVCR
14PV263/01	1022Leader	TVCR-B	1.05.1996	TVCR
14PV263/02	1022Leader	TVCR-B	1.05.1996	TVCR
14PV263/08	1022Leader	TVCR-B	1.05.1996	TVCR
14PV263/13	1022Leader	TVCR-B	1.06.1996	TVCR
14PV264/39	1022Step-up	TVCR-B	1.05.1996	TVCR
14PV274/01	1022Step-up	TVCR-B	1.05.1997	TVCR
14PV274/05	1022Leader	TVCR-B	1.05.1997	TVCR
14PV274/08	1022Step-up	TVCR-B	1.05.1997	TVCR
14PV274/13	1022Step-up	TVCR-B	1.06.1997	TVCR
14PV274/39W	1022Step-up	TVCR-B	1.06.1997	TVCR
14PV284/01	1022Step-up	TVCR-B	1.04.1998	TVCR
14PV284/05	1022Step-up	TVCR-B	1.05.1998	TVCR
14PV284/05S	1022Step-up	TVCR-B	1.10.1998	TVCR
14PV284/05W	1022Step-up	TVCR-B	1.06.1998	TVCR
14PV284/08	1022Step-up	TVCR-B	1.04.1998	TVCR
14PV284/08B	1022Leader	TVCR-B	1.06.1998	TVCR
14PV284/13	1022Step-up	TVCR-B	1.05.1998	TVCR
14PV284/39	1022Step-up	TVCR-B	1.06.1998	TVCR
14PV284/39S	1022Step-up	TVCR-B	1.07.1998	TVCR
14PV284/39W	1022Step-up	TVCR-B	1.05.1998	TVCR
14PV284DE	1022Step-up	TVCR-B	1.01.1999	TVCR
14PV284FR	1022Step-up	TVCR-B	1.03.1999	TVCR
14PV284SD/E	1022Leader	TVCR-B	1.02.1999	TVCR
14PV284SF/R	1022Leader	TVCR-B	1.03.1999	TVCR
14PV284SG/R	1022Leader		1.02.1999	TVCR
14PV284WD/E	1022Leader	TVCR-B	1.02.1999	TVCR
14PV284WF/R	1022Leader	TVCR-B	1.03.1999	TVCR
14PV320/01	1022Step-up	TVCR-D	1.08.1999	TVCR
14PV320/05	1022Step-up	TVCR-D	1.07.1999	TVCR
14PV320/39	1022Step-up	TVCR-D	1.08.1999	TVCR
14PV320DE	1022Step-up	TVCR-D	1.08.1999	TVCR

14PV320ES	1022Step-up	TVCR-D	1.07.1999	TVCR
14PV320SG/R	1022Leader	TVCR-D	1.09.1999	TVCR
14PV320XE	1022Step-up	TVCR-D	1.07.1999	TVCR
14PV325/05S	1022Step-up	TVCR-D	1.09.1999	TVCR
14PV325/39S	1022Step-up	TVCR-D	1.09.1999	TVCR
14PV325SD/E	1022Leader	TVCR-D	1.09.1999	TVCR
14PV325SE/S	1022Leader	TVCR-D	1.09.1999	TVCR
14PV325SF/R	1022Leader	TVCR-D	1.09.1999	TVCR
14PV325SG/R	1022Step-up	TVCR-D	1.10.1999	TVCR
14PV325SX/E	1022Leader			TVCR
14PV327/05B	1022Step-up	TVCR-D	1.09.1999	TVCR
14PV327/39B	1022Step-up	TVCR-D	1.09.1999	TVCR
14PV327BD/E	1022Leader	TVCR-D	1.09.1999	TVCR
14PV327BE/S	1022Leader	TVCR-D	1.09.1999	TVCR
14PV327BF/R	1022Leader	TVCR-D	1.09.1999	TVCR
14PV327BG/R	1022Step-up	TVCR-D	1.03.2000	TVCR
14PV327BX/E	1022Step-up	TVCR-D	1.10.1999	TVCR
14PV330/01	1022Step-up	TVCR-D	1.05.2000	TVCR
14PV330/07	1022Step-up	TVCR-D	1.04.2000	TVCR
14PV330/39	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV330/IT	1022Step-up	TVCR-D	1.09.2000	TVCR
14PV330DE	1022Step-up	TVCR-D	1.05.2000	TVCR
14PV330ES	1022Step-up	TVCR-D	1.05.2000	TVCR
14PV330GR	1022Step-up			TVCR
14PV330XE	1022Step-up	TVCR-D	1.05.2000	TVCR
14PV334/01	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV334/07	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV334/39	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV334/IT	1022Step-up	TVCR-D	1.09.2000	TVCR
14PV334DE	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV334ES	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV334GR	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV334XE	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV335/01	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV335/07	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV335/39	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV335/IT	1022Step-up	TVCR-D	1.09.2000	TVCR
14PV335DE	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV335ES	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV335GR	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV335XE	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV340/01	1022Step-up	TVCR-D	1.08.1999	TVCR

14PV340/05	1022Step-up	TVCR-D	1.07.1999	TVCR
14PV340/05Z	1022Step-up			TVCR
14PV340/39	1022Step-up	TVCR-D	1.08.1999	TVCR
14PV340/39Z	1022Step-up	TVCR-D		TVCR
14PV340/58	1022Step-up	TVCR-D	1.08.1999	TVCR
14PV340DE	1022Step-up	TVCR-D	1.08.1999	TVCR
14PV340ES	1022Step-up	TVCR-D	1.09.1999	TVCR
14PV340SE/S	1022Leader	TVCR-D	1.10.1999	TVCR
14PV340XE	1022Step-up	TVCR-D	1.08.1999	TVCR
14PV345/05S	1022Step-up	TVCR-D	1.09.1999	TVCR
14PV345/39S	1022Step-up	TVCR-D	1.10.1999	TVCR
14PV345SD/E	1022Leader	TVCR-D	1.09.1999	TVCR
14PV345SE/S	1022Leader	TVCR-D	1.09.1999	TVCR
14PV345SF/R	1022Leader	TVCR-D	1.09.1999	TVCR
14PV345SG/R	1022Step-up	TVCR-D	1.03.2000	TVCR
14PV345SX/E	1022Leader	TVCR-D	1.09.1999	TVCR
14PV350/01	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV350/07	1022Step-up	TVCR-E	1.05.2001	TVCR
14PV350/39	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV350/CH	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV350/ES	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV350/XE	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV353/39	1022Step-up	TVCR-E	1.07.2001	TVCR
14PV354/01	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV354/07	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV354/39	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV354/CH	1022Step-up	TVCR-E	1.07.2001	TVCR
14PV354/ES	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV354/GR	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV354/XE	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV358/01	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV358/07	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV358/39	Step-up			TVCR
14PV358/CH	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV358/ES	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV358/GR	1022Step-up	TVCR-E	1.08.2001	TVCR
14PV358/XE	1022Step-up	TVCR-E	1.06.2001	TVCR
14PV365/58	Step-up			TVCR
14PV400/01	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV400/07	1022Step-up	TVCR-D	1.05.2000	TVCR
14PV400/39	1022Step-up	TVCR-D	1.08.2000	TVCR
14PV400/58	1022Step-up	TVCR-D	1.06.2000	TVCR

14PV400/IT	1022Step-up	TVCR-D	1.09.2000	TVCR
14PV400DE	1022Step-up	TVCR-D	1.05.2000	TVCR
14PV400ES	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV400GR	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV400XE	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV404/01	1022Step-up	TVCR-D	1.07.2000	TVCR
14PV404/07	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV404/39	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV404DE	1022Step-up	TVCR-D	1.05.2000	TVCR
14PV404ES	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV404GR	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV404XE	1022Step-up			TVCR
14PV405/01	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV405/07	1022Step-up			TVCR
14PV405/39	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV405/58	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV405/IT	1022Step-up	TVCR-D	1.09.2000	TVCR
14PV405DE	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV405ES	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV405GR	1022Step-up			TVCR
14PV405XE	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV406/01	1022Step-up	TVCR-D	1.08.2000	TVCR
14PV406/07	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV406/39	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV406/IT	1022Step-up	TVCR-D	1.09.2000	TVCR
14PV406DE	1022Step-up			TVCR
14PV406ES	1022Step-up	TVCR-D	1.06.2000	TVCR
14PV406GR	1022Step-up			TVCR
14PV406XE	1022Step-up			TVCR
14PV460/58	Leader			TVCR
14PV465/58	Leader			TVCR
14PV503/01	1022Step-up	TVCR-D	1.03.2001	TVCR
14PV503/07	1022Step-up	TVCR-D	1.03.2001	TVCR
14PV503/39	Step-up	TVCR-D		TVCR
14PV503/58	1022Step-up	TVCR-D	1.03.2001	TVCR
14PV503/ES	1022Step-up	TVCR-D	1.03.2001	TVCR
14PV503/GR	1022Step-up	TVCR-D	1.06.2001	TVCR
14PV503/XE	1022Step-up	TVCR-D	1.05.2001	TVCR
14PV505/01	1022Step-up	TVCR-D	1.03.2001	TVCR
14PV505/07	1022Step-up	TVCR-D	1.03.2001	TVCR
14PV505/39	Step-up	TVCR-D		TVCR
14PV505/58	1022Step-up	TVCR-D	1.03.2001	TVCR

14PV505/ES	1022Step-up	TVCR-D	1.03.2001	TVCR
14PV505/GR	1022Step-up	TVCR-D	1.07.2001	TVCR
14PV505/XE	1022Step-up	TVCR-D	1.04.2001	TVCR
14RA01/05	700114i (13v) stereo	L9.2E	Basic TV	TELEVISION
14STVR602	1022Leader		1.12.1996	TVCR
14TA01/05	700114i (13v) stereo	L9.2E	Basic TV	TELEVISION
14TVCR240/01	1022Leader	TVCR-A	1.11.1994	TVCR
14TVCR240/01N	1022Leader	TVCR-A	1.12.1996	TVCR
14TVCR240/02	1022Leader	TVCR-A	1.11.1994	TVCR
14TVCR240/05	1022Leader	TVCR-A	1.11.1994	TVCR
14TVCR240/07	1022Leader	TVCR-A	1.07.1995	TVCR
14TVCR240/08	1022Leader	TVCR-A	1.11.1994	TVCR
14TVCR240/13	1022Leader	TVCR-A	1.02.1995	TVCR
14TVCR240/39	1022Leader	TVCR-A	1.11.1994	TVCR
14TVCR240/59	1022Leader	TVCR-A	1.02.1995	TVCR
14VP461/78R	1022Leader		1.03.1997	TVCR
15AA3330/10B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3330/19B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3330/22B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3330/30B	700115i mono	ANUBIS_A	1.04.1992Basic TV	TELEVISION
15AA3330/39B	700115i mono	ANUBIS_A	1.08.1992Basic TV	TELEVISION
15AA3332/05B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/07B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/08B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/10B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/10V	700115i mono	ANUBIS_A	1.05.1992Basic TV	TELEVISION
15AA3332/15B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/16B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/19B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/22B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/22V	700115i mono	ANUBIS_A	1.07.1992Basic TV	TELEVISION
15AA3332/30B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/36B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/39B	700115i mono	ANUBIS_A	1.06.1992Basic TV	TELEVISION
15AA3332/39W	700115i mono	ANUBIS_A	1.06.1992Basic TV	TELEVISION
15AA3332/40B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3332/42B	700115i mono	ANUBIS_A	1.04.1992Basic TV	TELEVISION
15AA3334/19B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
15AA3336/00B	700115i mono	ANUBIS_A	1.12.1992Basic TV	TELEVISION
15AA3336/01B	700115i mono	ANUBIS_A	1.12.1992Basic TV	TELEVISION
15AA3537/00B	700115i mono	ANUBIS_A	1.01.1993Basic TV	TELEVISION
15AA3537/01B	700115i mono	ANUBIS_A	1.04.1993Basic TV	TELEVISION

15AA3537/07B	700115i mono	ANUBIS_A	1.08.1993Basic TV	TELEVISION
15AA3537/13B	700115i mono	ANUBIS_A	1.05.1993Basic TV	TELEVISION
15AB3536/00B	700115i mono	ANUBIS_B	1.08.1992Basic TV	TELEVISION
15AB3536/13B	700115i mono	ANUBIS_B	1.10.1992Basic TV	TELEVISION
15AQ5520/99	1041Radio cassette recorders - mono		1.12.1993	RADIO MONO + STEREO
15CE1210/16B	700115i mono	CP90	1.03.1992Basic TV	TELEVISION
15CN4420/75R	700115i mono	NCF	1.06.1992	TELEVISION
15DV1/16	1021Leader	OLIVIA_ECN	1.06.1995Economy	VCR
15DV1/39	1021Leader	OLIVIA_ECN	1.05.1995Economy	VCR
15DV6/07	1021Leader	OLIVIA_ECN	1.10.1995Economy	VCR
15GR2330/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2330/10B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2330/16B	700115i mono	G90AE	1.04.1992Basic TV	TELEVISION
15GR2331/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2331/05B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2331/08B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2331/10B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2331/13B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2331/16B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2331/22B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2331/30B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2336/30B	710115i mono	G90B	1.05.1993Basic TV	TELEVISION
15GR2336/39B	710115i mono	G90B	1.03.1992Basic TV	TELEVISION
15GR2336/95B	710115i mono	G90B	1.03.1992Basic TV	TELEVISION
15GR2530/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2530/05B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2530/08B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2530/10B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2530/16B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2530/22B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2530/33B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2532/08B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2532/10B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2532/16B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2532/22B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2532/30B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
15GR2730/22B	710115i mono	G90B	1.03.1992Basic TV	TELEVISION
15GR2730/28B	710115i mono	G90B	1.05.1992Basic TV	TELEVISION
15GR2730/30B	710115i mono	G90B	1.03.1992Basic TV	TELEVISION
15GX1562/62R	700121i (20v) mono			TELEVISION
15PT136A/00	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
15PT136A/01	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION

15PT136A/42	700115i mono	ANUBIS_A	1.11.1994Basic TV	TELEVISION
15PT136B/00	700115i mono	AA5	1.04.1995Basic TV	TELEVISION
15PT136B/01	700115i mono	AA5	1.04.1995Basic TV	TELEVISION
15PT136B/15	700115i mono	AA5	1.11.1995Basic TV	TELEVISION
15PT136B/42	700115i mono	AA5	1.05.1995Basic TV	TELEVISION
15PT156B/00	700115i mono	AA5	1.03.1995Basic TV	TELEVISION
15PT156B/01	700115i mono	AA5	1.04.1995Basic TV	TELEVISION
15PT156B/13	700115i mono	AA5	1.04.1995Basic TV	TELEVISION
15PT161A/05	700115i mono	ANUBIS_A	1.03.1993Basic TV	TELEVISION
15PT166A/00	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
15PT166A/01	700115i mono	ANUBIS_A	1.09.1994Basic TV	TELEVISION
15PT166A/13	700115i mono	ANUBIS_A	1.09.1994Basic TV	TELEVISION
15PT2302/56A	700114i (13v) stereo	L01.2A	1.10.2001Basic TV	TELEVISION
15PT2302/57R	700114i (13v) stereo	L01.2A	1.09.2001Basic TV	TELEVISION
15PT2302/68R	700114i (13v) stereo	L01.2A	1.09.2001Basic TV	TELEVISION
15PT2302/69R	700114i (13v) stereo	L01.2A	1.10.2001Basic TV	TELEVISION
15PT2302/79R	700114i (13v) stereo	L01.2A	1.11.2001Basic TV	TELEVISION
16DMQ162/65	700115i mono		1.07.1993	TELEVISION
16DMQ1625/65	700115i mono		1.03.1992	TELEVISION
16GL1031L/78	700115i mono		1.03.1992	TELEVISION
16GL1032L/78	700115i mono		1.06.1992	TELEVISION
16GL1033/78	700115i mono		1.01.1993	TELEVISION
16GL1034/78	700115i mono		1.10.1993	TELEVISION
16GL1034/78R	700115i mono			TELEVISION
16GL1331L/78	700115i mono		1.03.1992	TELEVISION
16GL1332L/78	700115i mono		1.06.1992	TELEVISION
16GL1333/78	700115i mono		1.01.1993	TELEVISION
16GN1628/68S	700115i mono		1.03.1992	TELEVISION
16GR1629/68S	700115i mono		1.03.1992	TELEVISION
17AA3340/10B	700117i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3340/15B	700115i mono	ANUBIS_A	1.04.1992Basic TV	TELEVISION
17AA3340/19B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3340/22B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3340/30B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3340/39B	700115i mono	ANUBIS_A	1.05.1992Basic TV	TELEVISION
17AA3342/07B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/08B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/10B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/10V	700115i mono	ANUBIS_A	1.06.1992Basic TV	TELEVISION
17AA3342/15B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/16B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/19B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION

17AA3342/20B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/22B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/30B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/39B	700115i mono	ANUBIS_A	1.07.1992Basic TV	TELEVISION
17AA3342/40B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
17AA3342/42B	700115i mono	ANUBIS_A	1.04.1992Basic TV	TELEVISION
17AA3342/42V	700115i mono	ANUBIS_A	1.07.1992Basic TV	TELEVISION
17AA3346/00B	700115i mono	ANUBIS_A	1.12.1992Basic TV	TELEVISION
17AA3346/01B	700115i mono	ANUBIS_A	1.12.1992Basic TV	TELEVISION
17AA3346/07B	700115i mono	ANUBIS_A	1.08.1993Basic TV	TELEVISION
17AA3346/42B	700115i mono	ANUBIS_A	1.07.1993Basic TV	TELEVISION
17AA3547/00B	700115i mono	ANUBIS_A	1.02.1993Basic TV	TELEVISION
17AA3547/01B	700115i mono	ANUBIS_A	1.03.1993Basic TV	TELEVISION
17AA3547/13B	700115i mono	ANUBIS_A	1.03.1993Basic TV	TELEVISION
17AB3546/00B	700115i mono	ANUBIS_B	1.10.1992Basic TV	TELEVISION
17AB3546/13B	700115i mono	ANUBIS_B	1.11.1992Basic TV	TELEVISION
17CE1230/07B	700115i mono	CP90	1.03.1993Basic TV	TELEVISION
17CE1530/16B	700115i mono	CP90	1.07.1992Basic TV	TELEVISION
17GR2340/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2340/10B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2340/16B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2341/02B	700115i mono	G90AE	1.05.1992Basic TV	TELEVISION
17GR2341/05B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2341/08B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2341/10B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2341/16B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2341/22B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2341/30B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/05B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/07B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/08B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/10B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/13B	700115i mono	G90AE	1.05.1992Basic TV	TELEVISION
17GR2540/16B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/22B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/33B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
17GR2540/36B	700115i mono	G90AE	1.05.1992Basic TV	TELEVISION
17GR2646/39B	710115i mono	G90B	1.03.1993Basic TV	TELEVISION
17GR2740/30B	710115i mono	G90B	1.03.1992Basic TV	TELEVISION
17GR2742/33B	710115i mono	G90B	1.08.1992Basic TV	TELEVISION
17GR2742/36B	710115i mono	G90B	1.03.1992Basic TV	TELEVISION

17HT1340/00Z	201321i (20v) mono ITV	ANUBIS_B	1.08.1993Basic TV	INSTITUTIONAL TV
17HT1340/01B	201321i (20v) mono ITV	ANUBIS_B	1.07.1993Basic TV	INSTITUTIONAL TV
17HT1340/05Z	201317i mono ITV			INSTITUTIONAL TV
17HT1340/20Z	201321i (20v) mono ITV	ANUBIS_B	1.03.1994Basic TV	INSTITUTIONAL TV
17HT1340/21B	201321i (20v) mono ITV	ANUBIS_B	1.02.1994Basic TV	INSTITUTIONAL TV
17HT1340/25Z	201321i (20v) mono ITV	ANUBIS_B	1.06.1995Basic TV	INSTITUTIONAL TV
17HT1349/01B	201321i (20v) mono ITV	ANUBIS_B	1.06.1993Basic TV	INSTITUTIONAL TV
17HT1349/21B	201321i (20v) mono ITV	ANUBIS_B	1.06.1994Basic TV	INSTITUTIONAL TV
17HT1540/00B	201321i (20v) mono ITV	ANUBIS_B	1.06.1993Basic TV	INSTITUTIONAL TV
17HT1540/20B	201321i (20v) mono ITV	ANUBIS_B	1.12.1993Basic TV	INSTITUTIONAL TV
17HT1549/00B	201321i (20v) mono ITV	ANUBIS_B	1.04.1993Basic TV	INSTITUTIONAL TV
17HT1549/20B	201321i (20v) mono ITV	ANUBIS_B	1.02.1994Basic TV	INSTITUTIONAL TV
17HT1549/25B	201321i (20v) mono ITV	ANUBIS_B	1.09.1994Basic TV	INSTITUTIONAL TV
17HT1549/33B	201321i (20v) mono ITV	ANUBIS_B	1.12.1993Basic TV	INSTITUTIONAL TV
17HT3152/00	201317i mono ITV	AA5H.1	1.04.1996Institutional TV	INSTITUTIONAL TV
17HT3152/01	201317i mono ITV	AA5H.1	1.03.1996Institutional TV	INSTITUTIONAL TV
17HT3152/07	201317i mono ITV	AA5H.1	1.07.1997Institutional TV	INSTITUTIONAL TV
17HT3152/40	201317i mono ITV	AA5H.1	1.02.1998Institutional TV	INSTITUTIONAL TV
17HT3152/41	201317i mono ITV	AA5H.1	1.10.1997Institutional TV	INSTITUTIONAL TV
17HT3153/01	201317i mono ITV	L9H.2E	1.07.2000Institutional TV	INSTITUTIONAL TV
17HT3153/01S	201317i mono ITV	L9H.2E	1.05.2001Institutional TV	INSTITUTIONAL TV
17HT3153/05	201317i mono ITV	L9H.2E	1.08.2000Institutional TV	INSTITUTIONAL TV
17HT3153/05S	201317i mono ITV	L9H.2E	1.04.2001Institutional TV	INSTITUTIONAL TV
17HT3153/58	201317i mono ITV	L9H.2E	1.09.2001Institutional TV	INSTITUTIONAL TV
17HT3154/01	17i mono ITV			INSTITUTIONAL TV
17HT3154/05	17i mono ITV			INSTITUTIONAL TV
17HT3202/00	201317i mono ITV	AA5H.1	1.07.1996Institutional TV	INSTITUTIONAL TV
17HT3202/01	201317i mono ITV	AA5H.1	1.06.1996Institutional TV	INSTITUTIONAL TV
17HT3202/13	201317i mono ITV			INSTITUTIONAL TV
17HT3202/40	201317i mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
17HT3202/41	201317i mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
17HT3252/00	201317i mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
17HT3252/01	201317i mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
17HT3252/07	201317i mono ITV	AA5H.1	1.08.1996Institutional TV	INSTITUTIONAL TV
17HT3252/13	201317i mono ITV	AA5H.1	1.02.1997Institutional TV	INSTITUTIONAL TV
17HT3252/40	201317i mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
17HT3252/41	201317i mono ITV	AA5H.1	1.10.1997Institutional TV	INSTITUTIONAL TV
17HT3252/47	201317i mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
17HT3253/01	201317i mono ITV	L9H.2E	1.07.2000Institutional TV	INSTITUTIONAL TV
17HT3253/01S	201317i mono ITV	L9H.2E	1.04.2001Institutional TV	INSTITUTIONAL TV
17HT3253/05	201317i mono ITV	L9H.2E	1.08.2000Institutional TV	INSTITUTIONAL TV
17HT3253/05S	201317i mono ITV	L9H.2E	1.04.2001Institutional TV	INSTITUTIONAL TV

17HT3253/58	201317i mono ITV	L9H.2E	1.08.2001Institutional TV	INSTITUTIONAL TV
17HT3302/00	201317i mono ITV	AA5H.1	1.03.1996Institutional TV	INSTITUTIONAL TV
17HT3302/01	201317i mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
17HT3302/07	201317i mono ITV	AA5H.1	1.06.1997Institutional TV	INSTITUTIONAL TV
17HT3302/13	201317i mono ITV	AA5H.1	1.12.1996Institutional TV	INSTITUTIONAL TV
17HT3302/40	201317i mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
17HT3302/41	201317i mono ITV	AA5H.1	1.10.1997Institutional TV	INSTITUTIONAL TV
17HT3302/47	201317i mono ITV	AA5H.1	1.10.1998Institutional TV	INSTITUTIONAL TV
17HT3304/01	17i mono ITV			INSTITUTIONAL TV
17HT3304/05	17i mono ITV			INSTITUTIONAL TV
17HT3352/00	201317i mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
17HT3352/00Z	201317i mono ITV	AA5H.1	1.10.1996Institutional TV	INSTITUTIONAL TV
17HT3352/01	201317i mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
17HT3352/01Z	201317i mono ITV	AA5H.1	1.03.1997Institutional TV	INSTITUTIONAL TV
17HT3352/20P	201321i (20v) mono ITV	AA5H.1	1.07.1996Institutional TV	INSTITUTIONAL TV
17HT3352/21P	201317i mono ITV	AA5H.1	1.10.1996Institutional TV	INSTITUTIONAL TV
17HT3352/27P	201317i mono ITV	AA5H.1	1.06.1996Institutional TV	INSTITUTIONAL TV
17HT3352/41Z	201317i mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
17HT3352/61P	201317i mono ITV	AA5H.1	1.04.1998Institutional TV	INSTITUTIONAL TV
17HT3352/67P	201317i mono ITV	AA5H.1	1.05.1999Institutional TV	INSTITUTIONAL TV
17HT3352/88P	201317i mono ITV	AA5H.1	1.04.1998Institutional TV	INSTITUTIONAL TV
17HT3402/00	201317i mono ITV			INSTITUTIONAL TV
17HT3402/00Z	201321i (20v) mono ITV	AA5H.1	1.09.1996Institutional TV	INSTITUTIONAL TV
17HT3402/01Z	201317i mono ITV	AA5H.1	1.09.1996Institutional TV	INSTITUTIONAL TV
17HT3402/07Z	201317i mono ITV	AA5H.1	1.06.1996Institutional TV	INSTITUTIONAL TV
17HT3402/27V	201317i mono ITV			INSTITUTIONAL TV
17HT3402/41Z	201317i mono ITV	AA5H.1	1.05.1998Institutional TV	INSTITUTIONAL TV
17HT3402/47Z	201317i mono ITV	AA5H.1	1.02.1999Institutional TV	INSTITUTIONAL TV
17HT3402/61R	201317i mono ITV	AA5H.1	1.07.1998Institutional TV	INSTITUTIONAL TV
17HT3402/67R	201317i mono ITV	AA5H.1	1.04.1999Institutional TV	INSTITUTIONAL TV
17HT4202/01Z	201317i mono ITV	AA5H.1	1.03.1997Institutional TV	INSTITUTIONAL TV
17HT4202/07Z	201317i mono ITV			INSTITUTIONAL TV
17HT4202/13Z	201317i mono ITV			INSTITUTIONAL TV
17HT4202/21M	201317i mono ITV	AA5H.1	1.10.1997Institutional TV	INSTITUTIONAL TV
17HT4202/41Z	201317i mono ITV	AA5H.1	1.07.1998Institutional TV	INSTITUTIONAL TV
17HT4202/61M	201317i mono ITV	AA5H.1	1.06.1998Institutional TV	INSTITUTIONAL TV
17HT4202/67M	201317i mono ITV	AA5H.1	1.02.1999Institutional TV	INSTITUTIONAL TV
17HT5403/01S	201317i mono ITV	L9H.2E	1.01.2001Institutional TV	INSTITUTIONAL TV
17HT5403/01Z	201317i mono ITV	L9H.2E	1.08.2000Institutional TV	INSTITUTIONAL TV
17HT5403/05S	201317i mono ITV	L9H.2E	1.02.2001Institutional TV	INSTITUTIONAL TV
17HT5403/05Z	201317i mono ITV	L9H.2E	1.07.2000Institutional TV	INSTITUTIONAL TV
17HT5403/21R	201317i mono ITV	L9H.2E	1.07.2000Institutional TV	INSTITUTIONAL TV

17HT5403/25R	201317i mono ITV	L9H.2E	1.08.2000Institutional TV	INSTITUTIONAL TV
17HT5403/58Z	201317i mono ITV	L9H.2E	1.08.2000Institutional TV	INSTITUTIONAL TV
17HT5403/78R	17i mono ITV			INSTITUTIONAL TV
17HT5404/01Z	17i mono ITV			INSTITUTIONAL TV
17HT5404/05Z	17i mono ITV			INSTITUTIONAL TV
17HT5404/21R	17i mono ITV			INSTITUTIONAL TV
17HT5404/25R	17i mono ITV			INSTITUTIONAL TV
17HT5423/21R	201317i mono ITV	L9H.2E	1.10.2001Institutional TV	INSTITUTIONAL TV
17HT5423/25R	17i mono ITV			INSTITUTIONAL TV
17PT136A/00	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
17PT136A/01	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
17PT136A/42	700115i mono	ANUBIS_A	1.09.1994Basic TV	TELEVISION
17PT136A/58	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
17PT136B/00	700115i mono	AA5	1.04.1995Basic TV	TELEVISION
17PT136B/01	700115i mono	AA5	1.04.1995Basic TV	TELEVISION
17PT136B/15	700117i mono	AA5	1.11.1995Basic TV	TELEVISION
17PT136B/58	700115i mono	AA5	1.04.1995Basic TV	TELEVISION
17PT1563/01	700117i mono	L7.2E	1.04.1998Basic TV	TELEVISION
17PT1563/05	700117i mono	L7.2E	1.04.1998Basic TV	TELEVISION
17PT1563/11	700117i mono	L7.2E	1.03.1998Basic TV	TELEVISION
17PT1563/43	700117i mono	L7.2E	1.06.1998Basic TV	TELEVISION
17PT1563/58	700117i mono	L7.2E	1.04.1998Basic TV	TELEVISION
17PT1564/00	700117i mono	L9.2E	1.08.1999Basic TV	TELEVISION
17PT1564/01	700117i mono	L9.2E	1.09.1999Basic TV	TELEVISION
17PT1564/01S	700117i mono	L9.2E	1.04.2000Basic TV	TELEVISION
17PT1564/05	700117i mono	L9.2E	1.08.1999Basic TV	TELEVISION
17PT1564/58	700117i mono	L9.2E	1.09.1999Basic TV	TELEVISION
17PT1564/58S	700117i mono	L9.2E	Basic TV	TELEVISION
17PT1565/00	700117i mono	L9.2E	1.07.2000Basic TV	TELEVISION
17PT1565/01	700117i mono	L9.2E	1.07.2000Basic TV	TELEVISION
17PT1565/05	700117i mono	L9.2E	1.07.2000Basic TV	TELEVISION
17PT1565/58	700117i mono	L9.2E	1.08.2000Basic TV	TELEVISION
17PT156B/00	700117i mono	AA5	1.03.1995Basic TV	TELEVISION
17PT156B/01	700115i mono	AA5	1.03.1995Basic TV	TELEVISION
17PT156B/05	700115i mono	AA5	1.04.1995Basic TV	TELEVISION
17PT156B/13	700117i mono	AA5	1.04.1995Basic TV	TELEVISION
17PT156B/25	700115i mono	AA5	1.01.1996Basic TV	TELEVISION
17PT156B/58P	700115i mono	AA5	1.01.1996Basic TV	TELEVISION
17PT161A/05	700115i mono	ANUBIS_A	1.04.1993Basic TV	TELEVISION
17PT1666/00	17i mono			TELEVISION
17PT1666/01	17i mono			TELEVISION
17PT1666/05	17i mono			TELEVISION

17PT1666/58	17i mono			TELEVISION
17PT166A/00	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
17PT166A/01	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
17PT166A/05	700115i mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
17PT166A/13	700115i mono	ANUBIS_A	1.08.1994Basic TV	TELEVISION
17PT310A/00	201321i (20v) mono ITV	AA5	1.07.1995Basic TV	INSTITUTIONAL TV
17PT310A/01	201321i (20v) mono ITV	AA5	1.07.1995Basic TV	INSTITUTIONAL TV
17PT313A/00	700125i mono	AA5	1.10.1995Basic TV	TELEVISION
18MC205T/,,	6010	X1-B/W		OBSERVATION SYSTEMS
1SB51/08	1021Leader	OLIVIA_ECN	1.05.1995Economy	VCR
1SB51/16	1021Leader	OLIVIA_ECN	1.09.1995Economy	VCR
1SB51/38	1021Leader	OLIVIA_ECN	1.08.1995Economy	VCR
205021IR/14B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
205021IR/34B	700120i (19v) mono	GR1AX	1.07.1992Basic TV	TELEVISION
20CN4065L/84	700120i (19v) mono		1.04.1992	TELEVISION
20CN4362/56R	700120i (19v) mono	NCF-CR	1.03.1992	TELEVISION
20CN4465L/84	700120i (19v) mono		1.05.1992	TELEVISION
20CN4466L/77	700120i (19v) mono		1.04.1992	TELEVISION
20CN4764/50R	700120i (19v) mono	NCF-CR	1.04.1992	TELEVISION
20CT6000L/84	700120i (19v) mono		1.06.1992	TELEVISION
20CT6050L/80	700120i (19v) mono		1.10.1992	TELEVISION
20CT6060/73	700120i (19v) mono		1.08.1993	TELEVISION
20CT6060L/73	700120i (19v) mono		1.11.1992	TELEVISION
20CT6350L/73	700120i (19v) mono		1.03.1992	TELEVISION
20CT6350L/80	700120i (19v) mono		1.01.1993	TELEVISION
20CT6400L/84	700120i (19v) mono		1.06.1992	TELEVISION
20CT6550L/73	700120i (19v) mono		1.08.1992	TELEVISION
20CT6557L/77	700120i (19v) mono		1.08.1992	TELEVISION
20CT6650/73R	700120i (19v) mono		1.06.1993	TELEVISION
20CT6650L/73R	700120i (19v) mono		1.03.1992	TELEVISION
20DV20/39	1021Subleader	APOLLO12	1.06.2000	VCR
20DV30/39	1021Subleader	APOLLO13	1.07.2001	VCR
20DV7/39	1021Leader	QUEEN_VL	1.06.1997Volume Line	VCR
20DV9/39	1021Leader	APOLLO11	1.07.1999	VCR
20GL1040L/77	700120i (19v) mono		1.03.1992	TELEVISION
20GL1040L/87	700120i (19v) mono		1.03.1992	TELEVISION
20GL1041L/78	700120i (19v) mono		1.03.1992	TELEVISION
20GL1042L/55	700120i (19v) mono		1.03.1992	TELEVISION
20GL1042L/78	700120i (19v) mono		1.04.1992	TELEVISION
20GL1043/78	700120i (19v) mono		1.05.1993	TELEVISION
20GL1043L/78	700120i (19v) mono		1.11.1992	TELEVISION
20GL1044/78	700120i (19v) mono		1.09.1993	TELEVISION

20GL1044/78R	700120i (19v) mono		TELEVISION
20GL1045/78R	700120i (19v) mono		TELEVISION
20GL1047/78R	700120i (19v) mono		TELEVISION
20GL1049/78R	700120i (19v) mono	1.01.1997	TELEVISION
20GL1340L/55	700120i (19v) mono	1.06.1992	TELEVISION
20GL1340L/77	700120i (19v) mono	1.03.1992	TELEVISION
20GL1340L/86	700120i (19v) mono	1.07.1992	TELEVISION
20GL1340L/87	700120i (19v) mono	1.03.1992	TELEVISION
20GL1341L/78	700120i (19v) mono	1.03.1992	TELEVISION
20GL1342L/78	700120i (19v) mono	1.04.1992	TELEVISION
20GL1343/78	700120i (19v) mono	1.05.1993	TELEVISION
20GL1343L/78	700120i (19v) mono	1.10.1992	TELEVISION
20GL1344/78	700120i (19v) mono	1.10.1993	TELEVISION
20GL1344/78R	700120i (19v) mono		TELEVISION
20GL1345/78R	700120i (19v) mono		TELEVISION
20GL1346/78R	700120i (19v) mono		TELEVISION
20GL1349/78R	700120i (19v) mono	1.01.1997	TELEVISION
20GN6268/68R	700120i (19v) mono	1.04.1992	TELEVISION
20GN8833/68R	700120i (19v) mono	1.03.1992	TELEVISION
20GR1050/16B	700120i (19v) mono	GR1AX 1.03.1992Basic TV	TELEVISION
20GR1050/50R	700120i (19v) mono	GR1AX 1.04.1992Basic TV	TELEVISION
20GR1050/65	700120i (19v) mono	GR1AX 1.07.1993Basic TV	TELEVISION
20GR1050/67R	700120i (19v) mono	GR1AX 1.03.1992Basic TV	TELEVISION
20GR1050/73R	700120i (19v) mono	GR1AX 1.06.1993Basic TV	TELEVISION
20GR1050L/73R	700120i (19v) mono	1.03.1992	TELEVISION
20GR1050P/65	700120i (19v) mono	1.03.1992	TELEVISION
20GR1052/50B	700120i (19v) mono	GR1AX 1.03.1992Basic TV	TELEVISION
20GR1052/75B	700120i (19v) mono	GR1AX 1.03.1992Basic TV	TELEVISION
20GR1052P/65	700120i (19v) mono	1.03.1992	TELEVISION
20GR1052P/70	700120i (19v) mono	1.07.1992	TELEVISION
20GR1055/50R	700120i (19v) mono	GR1AX 1.03.1992Basic TV	TELEVISION
20GR1055/55R	700120i (19v) mono	GR1AX 1.05.1992Basic TV	TELEVISION
20GR1055/65	700120i (19v) mono	GR1AX 1.09.1993Basic TV	TELEVISION
20GR1055/67R	700120i (19v) mono	GR1AX 1.03.1992Basic TV	TELEVISION
20GR1055/68R	700120i (19v) mono	GR1AX 1.03.1992Basic TV	TELEVISION
20GR1055/75R	700120i (19v) mono	GR1AX 1.03.1992Basic TV	TELEVISION
20GR1055/77	700120i (19v) mono	GR1AX 1.05.1993Basic TV	TELEVISION
20GR1055L/77	700120i (19v) mono	1.04.1992	TELEVISION
20GR1055P/65	700120i (19v) mono	1.03.1992	TELEVISION
20GR1056/68R	700120i (19v) mono	GR1AX 1.10.1992Basic TV	TELEVISION
20GR1240/73	700120i (19v) mono	1.06.1993	TELEVISION
20GR1240L/73	700120i (19v) mono	1.03.1992	TELEVISION

20GR1250/02B	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
20GR1250/07B	700120i (19v) mono	GR1AX	1.04.1993Basic TV	TELEVISION
20GR1250/08B	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1250/10B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1250/15B	700120i (19v) mono	GR1AX	1.04.1993Basic TV	TELEVISION
20GR1250/16B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1250/30B	700120i (19v) mono	GR1AX	1.04.1993Basic TV	TELEVISION
20GR1250/36B	700120i (19v) mono	GR1AX	1.07.1992Basic TV	TELEVISION
20GR1250/50R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1250/58	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1250/59H	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1250/59P	700120i (19v) mono	GR1AX	1.04.1993Basic TV	TELEVISION
20GR1250/59R	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
20GR1250/65	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1250/67R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1250/73	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1250/73T	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1250L/58	700120i (19v) mono		1.03.1992	TELEVISION
20GR1250L/73	700120i (19v) mono		1.03.1992	TELEVISION
20GR1250L/80	700120i (19v) mono		1.09.1992	TELEVISION
20GR1250P/65	700120i (19v) mono		1.03.1992	TELEVISION
20GR1252/50B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1252/52B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1252/57B	700120i (19v) mono	GR1AX	1.06.1992Basic TV	TELEVISION
20GR1252/59B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1252/59H	700120i (19v) mono	GR1AX	1.06.1992Basic TV	TELEVISION
20GR1252/59P	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1252/75B	700120i (19v) mono	GR1AX	1.04.1992Basic TV	TELEVISION
20GR1252/79B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1252L/80	700120i (19v) mono		1.03.1992	TELEVISION
20GR1252P/65	700120i (19v) mono		1.03.1992	TELEVISION
20GR1252P/70	700120i (19v) mono		1.07.1992	TELEVISION
20GR1258/02B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1258/22B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1259/02B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1259/10B	700120i (19v) mono	GR1AX	1.04.1992Basic TV	TELEVISION
20GR1345/73R	700120i (19v) mono		1.05.1993	TELEVISION
20GR1345L/73R	700120i (19v) mono		1.05.1992	TELEVISION
20GR1355/50R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/52R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/54R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/57R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION

20GR1355/58R	700120i (19v) mono	GR1AX	1.04.1992Basic TV	TELEVISION
20GR1355/59H	700120i (19v) mono	GR1AX	1.07.1992Basic TV	TELEVISION
20GR1355/59R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/65	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1355/67R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/68R	700120i (19v) mono	GR1AX	1.04.1992Basic TV	TELEVISION
20GR1355/73R	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1355/75R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/77	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1355/77R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/79R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/85	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1355/85R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355/87R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
20GR1355L/73R	700120i (19v) mono		1.04.1992	TELEVISION
20GR1355L/77	700120i (19v) mono		1.03.1992	TELEVISION
20GR1355L/80	700120i (19v) mono		1.04.1992	TELEVISION
20GR1355L/85	700120i (19v) mono		1.02.1993	TELEVISION
20GR1355P/65	700120i (19v) mono		1.03.1992	TELEVISION
20GR1356/50R	700120i (19v) mono	GR1AX	1.10.1992Basic TV	TELEVISION
20GR1356/52R	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
20GR1356/54R	700120i (19v) mono	GR1AX	1.10.1992Basic TV	TELEVISION
20GR1356/57R	700120i (19v) mono	GR1AX	1.10.1992Basic TV	TELEVISION
20GR1356/58R	700120i (19v) mono	GR1AX	1.10.1992Basic TV	TELEVISION
20GR1356/59R	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
20GR1356/62R	700120i (19v) mono	GR1AX	1.10.1993Basic TV	TELEVISION
20GR1356/65	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1356/67R	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
20GR1356/68R	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
20GR1356/73	700120i (19v) mono	GR1AX	1.06.1993Basic TV	TELEVISION
20GR1356/75R	700120i (19v) mono	GR1AX	1.10.1992Basic TV	TELEVISION
20GR1356/77	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1356/77R	700120i (19v) mono	GR1AX	1.12.1992Basic TV	TELEVISION
20GR1356/85	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1356/85R	700120i (19v) mono	GR1AX	1.12.1992Basic TV	TELEVISION
20GR1356/87R	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
20GR1356L/77	700120i (19v) mono		1.11.1992	TELEVISION
20GR1356P/65	700120i (19v) mono		1.10.1992	TELEVISION
20GR1358/50R	700120i (19v) mono	GR1AX	1.04.1992Basic TV	TELEVISION
20GR1358/59H	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
20GR1359/50R	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
20GR1359/50T	700120i (19v) mono	GR1AX	1.01.1993Basic TV	TELEVISION

20GR1359/51R	700120i (19v) mono	GR1AX	1.06.1993Basic TV	TELEVISION
20GR1359/59H	700120i (19v) mono	GR1AX	1.10.1992Basic TV	TELEVISION
20GR1359/65	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
20GR1359/79R	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
20GR1359P/65	700120i (19v) mono		1.11.1992	TELEVISION
20GR6688/68R	700120i (19v) mono		1.03.1992	TELEVISION
20GR8899/68R	700120i (19v) mono		1.03.1992	TELEVISION
20GX1350/50S	700120i (19v) mono	ANUBIS_S	1.11.1994Basic TV	TELEVISION
20GX1350/67R	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
20GX1550/51R	700120i (19v) mono	ANUBIS_S	1.05.1994Basic TV	TELEVISION
20GX1550/52R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1550/54R	700120i (19v) mono	ANUBIS_S	1.09.1993Basic TV	TELEVISION
20GX1550/56R	700120i (19v) mono	ANUBIS_S	1.08.1993Basic TV	TELEVISION
20GX1550/58R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1550/71R	700120i (19v) mono	ANUBIS_S	1.03.1994Basic TV	TELEVISION
20GX1550/77B	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1550/85R	700120i (19v) mono	ANUBIS_S	1.09.1993Basic TV	TELEVISION
20GX1550/87R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1552/50B	700120i (19v) mono	ANUBIS_S	1.12.1993Basic TV	TELEVISION
20GX1552/50R	700120i (19v) mono	ANUBIS_S	1.09.1993Basic TV	TELEVISION
20GX1552/59R	700120i (19v) mono	ANUBIS_S	1.08.1993Basic TV	TELEVISION
20GX1552/62B	700120i (19v) mono	ANUBIS_S	1.12.1993Basic TV	TELEVISION
20GX1552/65B	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1552/67R	700120i (19v) mono	ANUBIS_S	1.09.1993Basic TV	TELEVISION
20GX1552/75R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1552/79R	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
20GX1553/00R	700120i (19v) mono	ANUBIS_S	1.10.1996Basic TV	TELEVISION
20GX1553/65B	700120i (19v) mono	ANUBIS_S	1.03.1994Basic TV	TELEVISION
20GX1555/52R	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
20GX1555/54R	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
20GX1555/58H	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
20GX1555/58R	700120i (19v) mono	ANUBIS_S	1.10.1994Basic TV	TELEVISION
20GX1555/77B	700120i (19v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
20GX1555/85R	700120i (19v) mono	ANUBIS_S	1.08.1994Basic TV	TELEVISION
20GX1555/87R	700120i (19v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
20GX1556/59R	700120i (19v) mono	ANUBIS_S	1.01.1995Basic TV	TELEVISION
20GX1556/59S	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
20GX1556/75R	700120i (19v) mono	ANUBIS_S	1.08.1994Basic TV	TELEVISION
20GX1557/50R	700120i (19v) mono	ANUBIS_S	1.08.1994Basic TV	TELEVISION
20GX1557/56R	700120i (19v) mono	ANUBIS_S	1.08.1994Basic TV	TELEVISION
20GX1557/56Z	700120i (19v) mono	ANUBIS_S	1.11.1995Basic TV	TELEVISION
20GX1557/57B	700120i (19v) mono	ANUBIS_S	1.03.1995Basic TV	TELEVISION

20GX1557/97R	700120i (19v) mono	ANUBIS_S	1.12.1994Basic TV	TELEVISION
20GX1558/97R	700120i (19v) mono	ANUBIS_S	1.01.1995Basic TV	TELEVISION
20GX1650/78	700120i (19v) mono		1.10.1993	TELEVISION
20GX1650/78R	700120i (19v) mono			TELEVISION
20GX1656/78R	700120i (19v) mono			TELEVISION
20GX1658/78R	700120i (19v) mono			TELEVISION
20GX1659/78R	700120i (19v) mono		1.01.1997	TELEVISION
20GX1750/58R	700120i (19v) mono	ANUBIS_S	1.03.1994Basic TV	TELEVISION
20GX1750/62B	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1750/62R	700120i (19v) mono	ANUBIS_S	1.02.1996Basic TV	TELEVISION
20GX1755/58R	700120i (19v) mono	ANUBIS_S	1.10.1994Basic TV	TELEVISION
20GX1850/54R	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
20GX1850/77B	700120i (19v) mono	ANUBIS_S	1.03.1994Basic TV	TELEVISION
20GX1850/85R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1850/87R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
20GX1855/54R	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
20GX1855/77B	700120i (19v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
20GX1855/85R	700120i (19v) mono	ANUBIS_S	1.08.1995Basic TV	TELEVISION
20GX1855/87R	700120i (19v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
20GX3555/58H	700120i (19v) mono	ANUBIS_S	1.02.1996Basic TV	TELEVISION
20GX3555/58R	700120i (19v) mono	ANUBIS_S	1.11.1995Basic TV	TELEVISION
20GX3555/71R	700120i (19v) mono	ANUBIS_S	1.04.1997Basic TV	TELEVISION
20GX3556/50B	700120i (19v) mono	ANUBIS_S	1.02.1997Basic TV	TELEVISION
20GX3556/59R	700120i (19v) mono	ANUBIS_S	1.09.1995Basic TV	TELEVISION
20GX3556/73R	700120i (19v) mono	ANUBIS_S	Basic TV	TELEVISION
20GX3556/75R	700120i (19v) mono	ANUBIS_S	1.09.1995Basic TV	TELEVISION
20GX3557/56R	700120i (19v) mono	ANUBIS_S	1.11.1996Basic TV	TELEVISION
20GX3557/57R	700120i (19v) mono	ANUBIS_S	1.10.1995Basic TV	TELEVISION
20GX3558/70R	700120i (19v) mono	ANUBIS_S	1.11.1996Basic TV	TELEVISION
20GX3558/97R	700120i (19v) mono	ANUBIS_S	1.10.1995Basic TV	TELEVISION
20GX3755/58R	700120i (19v) mono	ANUBIS_S	1.10.1995Basic TV	TELEVISION
20GX8350/00R	700120i (19v) mono	ANUBIS_S	1.10.1996Basic TV	TELEVISION
20GX8350/75R	700120i (19v) mono	ANUBIS_S	1.06.1995Basic TV	TELEVISION
20GX8550/52R	700120i (19v) mono	ANUBIS_S	1.06.1995Basic TV	TELEVISION
20GX8550/54R	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
20GX8550/58H	700120i (19v) mono	ANUBIS_S	1.07.1995Basic TV	TELEVISION
20GX8550/58R	700120i (19v) mono	ANUBIS_S	1.05.1995Basic TV	TELEVISION
20GX8550/59R	700120i (19v) mono	ANUBIS_S	1.06.1995Basic TV	TELEVISION
20GX8550/71R	700120i (19v) mono	ANUBIS_S	1.04.1997Basic TV	TELEVISION
20GX8550/75R	700120i (19v) mono	ANUBIS_S	1.09.1995Basic TV	TELEVISION
20GX8550/77B	700120i (19v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
20GX8550/77R	700120i (19v) mono	ANUBIS_S	1.07.1998Basic TV	TELEVISION

20GX8550/85R	700120i (19v) mono	ANUBIS_S	1.05.1996Basic TV	TELEVISION
20GX8550/87R	700120i (19v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
20GX8550/97R	700120i (19v) mono	ANUBIS_S	1.05.1995Basic TV	TELEVISION
20GX8552/50L	700120i (19v) mono	ANUBIS_S	1.11.1996Basic TV	TELEVISION
20GX8552/50R	700120i (19v) mono	ANUBIS_S	1.04.1995Basic TV	TELEVISION
20GX8552/57R	700120i (19v) mono	ANUBIS_S	1.04.1995Basic TV	TELEVISION
20GX8552/59B	700120i (19v) mono	ANUBIS_S	1.06.1995Basic TV	TELEVISION
20GX8552/59F	700120i (19v) mono	ANUBIS_S	Basic TV	TELEVISION
20GX8552/59R	700120i (19v) mono	ANUBIS_S	1.03.1995Basic TV	TELEVISION
20GX8552/59T	700120i (19v) mono	ANUBIS_S	Basic TV	TELEVISION
20GX8552/62R	700120i (19v) mono	ANUBIS_S	1.02.1996Basic TV	TELEVISION
20GX8552/93R	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
20GX8558/77B	700120i (19v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
20HT1582/59Z	201320i (19v) mono ITV	L9H.2A	1.09.1999Institutional TV	INSTITUTIONAL TV
20HT1582/68Z	201320i (19v) mono ITV	L9H.2A	Institutional TV	INSTITUTIONAL TV
20HT1582/75Z	201320i (19v) mono ITV	L9H.2A	1.11.1999Institutional TV	INSTITUTIONAL TV
20HT3153/01	201320i (19v) mono ITV	L9H.2E	1.04.2000Institutional TV	INSTITUTIONAL TV
20HT3153/05	201320i (19v) mono ITV	L9H.2E	1.06.2000Institutional TV	INSTITUTIONAL TV
20HT3153/58	201320i (19v) mono ITV	L9H.2E	1.08.2001Institutional TV	INSTITUTIONAL TV
20HT3253/01	201320i (19v) mono ITV	L9H.2E	1.04.2000Institutional TV	INSTITUTIONAL TV
20HT3253/05	201320i (19v) mono ITV	L9H.2E	1.06.2000Institutional TV	INSTITUTIONAL TV
20HT3253/58	201320i (19v) mono ITV	L9H.2E	1.08.2001Institutional TV	INSTITUTIONAL TV
20HT3303/01	201320i (19v) mono ITV	L9H.2E	1.04.2000Institutional TV	INSTITUTIONAL TV
20HT3303/05	201320i (19v) mono ITV	L9H.2E	1.06.2000Institutional TV	INSTITUTIONAL TV
20HT3303/58	201320i (19v) mono ITV	L9H.2E	1.06.2001Institutional TV	INSTITUTIONAL TV
20HT4203/21M	201320i (19v) mono ITV	L9H.2E	1.05.2000Institutional TV	INSTITUTIONAL TV
20HT4203/25M	201320i (19v) mono ITV	L9H.2E	1.03.2000Institutional TV	INSTITUTIONAL TV
20HT4203/78M	201320i (19v) mono ITV	L9H.2E	Institutional TV	INSTITUTIONAL TV
20PF9925/12S	Flat TV			FLAT TV
20PT118A/50B	700120i (19v) mono	L7.1A	1.03.1997Basic TV	TELEVISION
20PT118A/73R	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT118A/75R	700120i (19v) mono	L7.1A	1.02.1997Basic TV	TELEVISION
20PT132A/50R	700120i (19v) mono	L7.1A	1.06.1997Basic TV	TELEVISION
20PT132A/60R	700120i (19v) mono	L7.1A	1.11.1997Basic TV	TELEVISION
20PT1342/00	700120i (19v) mono	L6.1	1.04.2000Basic TV	TELEVISION
20PT1342/43	700120i (19v) mono	L6.1	1.05.1997Basic TV	TELEVISION
20PT1342/58	700120i (19v) mono	L6.1	1.07.1996Basic TV	TELEVISION
20PT1342/58S	700120i (19v) mono	L6.1	Basic TV	TELEVISION
20PT1346/00	20i (19v) mono			TELEVISION
20PT1346/01	20i (19v) mono			TELEVISION
20PT1346/58	20i (19v) mono			TELEVISION
20PT1352/00	700120i (19v) mono	L6.1	1.07.1996Basic TV	TELEVISION

20PT1352/01	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
20PT1352/39	700120i (19v) mono	L6.1	1.08.1996Basic TV	TELEVISION
20PT1353/00	700120i (19v) mono	L6.1	1.02.1998Basic TV	TELEVISION
20PT1353/01	700120i (19v) mono	L6.1	1.03.1998Basic TV	TELEVISION
20PT1353/43	700120i (19v) mono	L6.1	1.08.1998Basic TV	TELEVISION
20PT1353/58	700120i (19v) mono	L6.1	1.02.1998Basic TV	TELEVISION
20PT1353/58S	700120i (19v) mono	L6.1	Basic TV	TELEVISION
20PT1354/58	700120i (19v) mono	L9.2E	1.05.1999Basic TV	TELEVISION
20PT135A/00	700120i (19v) mono	ANUBIS_A	1.03.1994Basic TV	TELEVISION
20PT135A/01	700120i (19v) mono	ANUBIS_A	1.03.1994Basic TV	TELEVISION
20PT135A/07	700120i (19v) mono	ANUBIS_A	1.05.1994Basic TV	TELEVISION
20PT135A/42	700120i (19v) mono	ANUBIS_A	1.03.1994Basic TV	TELEVISION
20PT135B/00	700120i (19v) mono	AA5	1.04.1995Basic TV	TELEVISION
20PT135B/07	700120i (19v) mono	AA5	1.06.1995Basic TV	TELEVISION
20PT135B/11	700120i (19v) mono	AA5	1.04.1995Basic TV	TELEVISION
20PT135B/15	700120i (19v) mono	AA5	1.11.1995Basic TV	TELEVISION
20PT135B/16	700120i (19v) mono	AA5	1.04.1995Basic TV	TELEVISION
20PT135B/42	700120i (19v) mono	AA5	1.05.1995Basic TV	TELEVISION
20PT138A/50R	700120i (19v) mono	L7.1A	1.12.1996Basic TV	TELEVISION
20PT138A/54R	700120i (19v) mono	L7.1A	1.01.1999Basic TV	TELEVISION
20PT138A/57R	700120i (19v) mono	L7.1A	1.02.1997Basic TV	TELEVISION
20PT138A/58H	700120i (19v) mono	L7.1A	1.05.1997Basic TV	TELEVISION
20PT138A/58R	700120i (19v) mono	L7.1A	1.03.1997Basic TV	TELEVISION
20PT138A/59B	700120i (19v) mono	L7.1A	1.01.1997Basic TV	TELEVISION
20PT138A/59H	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT138A/59R	700120i (19v) mono	L7.1A	1.12.1996Basic TV	TELEVISION
20PT138A/70B	700120i (19v) mono	L7.1A	1.07.1997Basic TV	TELEVISION
20PT138A/71R	700120i (19v) mono	L7.1A	1.05.1997Basic TV	TELEVISION
20PT138A/73R	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT138A/75R	700120i (19v) mono	L7.1A	1.03.1997Basic TV	TELEVISION
20PT138A/97R	700120i (19v) mono	L7.1A	1.02.1997Basic TV	TELEVISION
20PT1422/50R	700120i (19v) mono	L7.1A	1.05.1998Basic TV	TELEVISION
20PT1482/50R	700120i (19v) mono	L7.1A	1.04.1998Basic TV	TELEVISION
20PT1482/57R	700120i (19v) mono	L7.1A	1.05.1998Basic TV	TELEVISION
20PT1482/59B	700120i (19v) mono	L7.1A	1.04.1998Basic TV	TELEVISION
20PT1482/59M	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT1482/59R	700120i (19v) mono	L7.1A	1.08.1998Basic TV	TELEVISION
20PT1482/68R	700120i (19v) mono	L7.1A	1.05.1998Basic TV	TELEVISION
20PT1482/71R	700120i (19v) mono	L7.1A	1.06.1998Basic TV	TELEVISION
20PT1482/73R	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT1482/79R	700120i (19v) mono	L7.1A	1.05.1998Basic TV	TELEVISION
20PT1482/97R	700120i (19v) mono	L7.1A	1.06.1998Basic TV	TELEVISION

20PT150A/00	700120i (19v) mono	ANUBIS_A	1.04.1993Basic TV	TELEVISION
20PT150A/01	700120i (19v) mono	ANUBIS_A	1.05.1993Basic TV	TELEVISION
20PT150A/07	700120i (19v) mono	ANUBIS_A	1.08.1993Basic TV	TELEVISION
20PT150A/13	700120i (19v) mono	ANUBIS_A	1.09.1993Basic TV	TELEVISION
20PT150A/16	700120i (19v) mono	ANUBIS_A	1.05.1993Basic TV	TELEVISION
20PT150A/20	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
20PT150A/21	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
20PT150A/27	700120i (19v) mono	ANUBIS_A	1.01.1994Basic TV	TELEVISION
20PT150A/33	700120i (19v) mono	ANUBIS_A	1.12.1993Basic TV	TELEVISION
20PT150A/36	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
20PT1542/43	700120i (19v) mono	L6.1	1.04.1997Basic TV	TELEVISION
20PT1542/58	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
20PT1542/58H	700120i (19v) mono	L6.1	1.05.1997Basic TV	TELEVISION
20PT1542/58S	700120i (19v) mono	L6.1	1.03.2001Basic TV	TELEVISION
20PT1546/00	20i (19v) mono			TELEVISION
20PT1546/01	20i (19v) mono			TELEVISION
20PT1546/58	20i (19v) mono			TELEVISION
20PT1552/00	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
20PT1552/07	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
20PT1552/11	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
20PT1552/15	700120i (19v) mono	L6.1	1.02.1997Basic TV	TELEVISION
20PT1553/00	700120i (19v) mono	L6.1	1.02.1998Basic TV	TELEVISION
20PT1553/01	700120i (19v) mono	L6.1	1.03.1998Basic TV	TELEVISION
20PT1553/07	700120i (19v) mono	L6.1	1.02.1998Basic TV	TELEVISION
20PT1553/11	700120i (19v) mono	L6.1	1.02.1998Basic TV	TELEVISION
20PT1553/43	700120i (19v) mono	L6.1	1.08.1998Basic TV	TELEVISION
20PT1553/58	700120i (19v) mono	L6.1	1.03.1998Basic TV	TELEVISION
20PT1553/58H	700120i (19v) mono	L6.1	1.03.1998Basic TV	TELEVISION
20PT1553/60S	700120i (19v) mono	L6.1	Basic TV	TELEVISION
20PT1554/58	700120i (19v) mono	L9.2E	1.08.1999Basic TV	TELEVISION
20PT155A/00	700120i (19v) mono	ANUBIS_A	1.04.1994Basic TV	TELEVISION
20PT155A/01	700120i (19v) mono	ANUBIS_A	1.04.1994Basic TV	TELEVISION
20PT155A/07	700120i (19v) mono	ANUBIS_A	1.05.1994Basic TV	TELEVISION
20PT155A/13	700120i (19v) mono	ANUBIS_A	1.04.1994Basic TV	TELEVISION
20PT155B/00	700120i (19v) mono	AA5	1.04.1995Basic TV	TELEVISION
20PT155B/01	700120i (19v) mono	AA5	1.05.1995Basic TV	TELEVISION
20PT155B/07	700120i (19v) mono	AA5	1.02.1996Basic TV	TELEVISION
20PT155B/13	700120i (19v) mono	AA5	1.05.1995Basic TV	TELEVISION
20PT1582/59A	700120i (19v) mono	L9.2A	1.12.1999Basic TV	TELEVISION
20PT1582/59B	700120i (19v) mono	L9.2A	1.09.1999Basic TV	TELEVISION
20PT1582/59C	700120i (19v) mono	L9.2A	1.10.1999Basic TV	TELEVISION
20PT1582/59R	700120i (19v) mono	L9.2A	Basic TV	TELEVISION

20PT1582/73R	700120i (19v) mono	L9.2A	Basic TV	TELEVISION
20PT1582/75R	700120i (19v) mono	L9.2A	1.10.1999Basic TV	TELEVISION
20PT2001/59A	20i (19v) mono			TELEVISION
20PT2001/59B	20i (19v) mono			TELEVISION
20PT2001/79R	20i (19v) mono			TELEVISION
20PT2012/59A	20i (19v) mono			TELEVISION
20PT2012/59B	20i (19v) mono			TELEVISION
20PT2012/59C	20i (19v) mono			TELEVISION
20PT2152/69R	20i (19i) stereo medium			TELEVISION
20PT2381/50B	700120i (19v) mono	L7.1A	1.08.1997Basic TV	TELEVISION
20PT2381/50R	700120i (19v) mono	L7.1A	1.06.1997Basic TV	TELEVISION
20PT2381/54R	700120i (19v) mono	L7.1A	1.01.1999Basic TV	TELEVISION
20PT2381/59B	700120i (19v) mono	L7.1A	1.09.1997Basic TV	TELEVISION
20PT2381/59M	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT2381/59R	700120i (19v) mono	L7.1A	1.09.1997Basic TV	TELEVISION
20PT2381/70B	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT2381/73R	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT2382/56R	700120i (19v) mono	L7.1A	1.08.1997Basic TV	TELEVISION
20PT2382/57R	700120i (19v) mono	L7.1A	1.08.1997Basic TV	TELEVISION
20PT2382/71R	700120i (19v) mono	L7.1A	1.06.1998Basic TV	TELEVISION
20PT2682/70R	700120i (19v) mono			TELEVISION
20PT2682/97R	700120i (19v) mono	L7.1A	1.03.1998Basic TV	TELEVISION
20PT2722/50R	700120i (19v) mono	L7.1A	1.10.1998Basic TV	TELEVISION
20PT2782/50R	700120i (19v) mono	L7.1A	1.10.1998Basic TV	TELEVISION
20PT2782/59M	700120i (19v) mono	L7.1A	1.12.1998Basic TV	TELEVISION
20PT2782/59R	700120i (19v) mono	L7.1A	1.10.1998Basic TV	TELEVISION
20PT2782/68R	700120i (19v) mono	L7.1A	1.01.1999Basic TV	TELEVISION
20PT2782/71R	700120i (19v) mono	L7.1A	1.03.1999Basic TV	TELEVISION
20PT2782/73R	700120i (19v) mono	L7.1A	Basic TV	TELEVISION
20PT2882/57R	700120i (19v) mono	L7.1A	1.09.1998Basic TV	TELEVISION
20PT2882/71R	700120i (19v) mono	L7.1A	1.10.1998Basic TV	TELEVISION
20PT2882/97R	700120i (19v) mono	L7.1A	1.11.1998Basic TV	TELEVISION
20PT3722/59A	700120i (19v) mono	L9.2A	1.12.1999Basic TV	TELEVISION
20PT3722/59B	700120i (19v) mono	L9.2A	1.09.1999Basic TV	TELEVISION
20PT3722/59C	700120i (19v) mono	L9.2A	1.10.1999Basic TV	TELEVISION
20PT3722/59R	700120i (19v) mono	L9.2A	1.04.2000Basic TV	TELEVISION
20PT3722/73R	700120i (19v) mono	L9.2A	Basic TV	TELEVISION
20PT3742/59A	700120i (19i) stereo medium	L9.2A	1.09.2001Basic TV	TELEVISION
20PT3742/59B	20i (19i) stereo medium	L9.2A	Basic TV	TELEVISION
20PT3742/59C	700120i (19i) stereo medium	L9.2A	1.07.2001Basic TV	TELEVISION
20PT3822/57R	700120i (19i) stereo medium	L9.2A	1.11.1999Basic TV	TELEVISION
20PT3822/68R	700120i (19i) stereo medium	L9.2A	1.01.2000Basic TV	TELEVISION

20PT3822/69R	700120i (19i) stereo medium	L9.2A	1.09.1999Basic TV	TELEVISION
20PT3842/68R	700120i (19i) stereo medium	L9.2A	1.09.2001Basic TV	TELEVISION
20PT3842/69R	700120i (19i) stereo medium	L9.2A	1.07.2001Basic TV	TELEVISION
20PV164/02	1022Core	TVCR-B	1.06.1996	TVCR
20PV164/05	1022Core	TVCR-B	1.06.1996	TVCR
20PV164/08	1022Core	TVCR-B	1.06.1996	TVCR
20PV164/13	1022Core	TVCR-B	1.08.1996	TVCR
20PV184/01	1022Core	TVCR-B	1.05.1998	TVCR
20PV184/05	1022Core	TVCR-B	1.05.1998	TVCR
20PV184/08	1022Core	TVCR-B	1.05.1998	TVCR
20PV184/08B	1022Leader	TVCR-B	1.06.1998	TVCR
20PV184/13	1022Core	TVCR-B	1.05.1998	TVCR
20PV210/01	1022Step-up	TVCR-D	1.10.1999	TVCR
20PV220/01	1022Step-up	TVCR-D	1.08.1999	TVCR
20PV220/07	1022Step-up	TVCR-D	1.07.1999	TVCR
20PV220/IT	1022Step-up	TVCR-D	1.09.2000	TVCR
20PV220DE	1022Step-up	TVCR-D	1.08.1999	TVCR
20PV220ES	1022Step-up	TVCR-D	1.07.1999	TVCR
20PV220XE	1022Step-up	TVCR-D	1.08.1999	TVCR
20PV230/01	1022Step-up	TVCR-E	1.07.2001	TVCR
20PV230/07	1022Step-up	TVCR-E	1.07.2001	TVCR
20PV230/ES	1022Step-up	TVCR-E	1.07.2001	TVCR
20PV230/XE	1022Step-up	TVCR-E	1.07.2001	TVCR
20PV471/78	1022Leader		1.06.1997	TVCR
20PW6302/00	700124i WS 50Hz no dolby mainstream			TELEVISION
20RA01/05	700114i (13v) stereo	L9.2E	Basic TV	TELEVISION
20S250C/87	700120i (19v) mono		1.08.1993	TELEVISION
20TA01/05	700114i (13v) stereo	L9.2E	Basic TV	TELEVISION
21AA3350/05B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/08B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/10B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/15B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/16B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/19B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/20B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/22B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/30B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/30V	700120i (19v) mono	ANUBIS_A	1.08.1992Basic TV	TELEVISION
21AA3350/39B	700120i (19v) mono	ANUBIS_A	1.05.1992Basic TV	TELEVISION
21AA3350/40B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
21AA3350/42B	700120i (19v) mono	ANUBIS_A	1.04.1992Basic TV	TELEVISION
21AA3356/00B	700120i (19v) mono	ANUBIS_A	1.09.1992Basic TV	TELEVISION

21AA3356/01B	700120i (19v) mono	ANUBIS_A	1.08.1992Basic TV	TELEVISION
21AA3356/05B	700120i (19v) mono	ANUBIS_A	1.09.1992Basic TV	TELEVISION
21AA3356/20B	700120i (19v) mono	ANUBIS_A	1.01.1993Basic TV	TELEVISION
21AA3356/21B	700120i (19v) mono	ANUBIS_A	1.01.1993Basic TV	TELEVISION
21AA3356/42B	700120i (19v) mono	ANUBIS_A	1.12.1992Basic TV	TELEVISION
21AA3356/43B	700120i (19v) mono	ANUBIS_A	1.03.1993Basic TV	TELEVISION
21AA3557/00B	700120i (19v) mono	ANUBIS_A	1.01.1993Basic TV	TELEVISION
21AA3557/01B	700120i (19v) mono	ANUBIS_A	1.01.1993Basic TV	TELEVISION
21AA3557/07B	700120i (19v) mono	ANUBIS_A	1.07.1993Basic TV	TELEVISION
21AA3557/13B	700120i (19v) mono	ANUBIS_A	1.01.1993Basic TV	TELEVISION
21AA3557/13W	700120i (19v) mono	ANUBIS_A	1.05.1993Basic TV	TELEVISION
21AA3557/42B	700120i (19v) mono	ANUBIS_A	1.04.1993Basic TV	TELEVISION
21AB3357/01B	700120i (19v) mono	ANUBIS_B	1.08.1992Basic TV	TELEVISION
21AB3556/00B	700121i (20v) mono	ANUBIS_B	1.06.1992Basic TV	TELEVISION
21AB3556/01B	700120i (19v) mono	ANUBIS_B	1.07.1992Basic TV	TELEVISION
21AB3556/05B	700120i (19v) mono	ANUBIS_B	1.08.1992Basic TV	TELEVISION
21AB3556/13B	700120i (19v) mono	ANUBIS_B	1.09.1992Basic TV	TELEVISION
21AB3556/13W	700120i (19v) mono	ANUBIS_B	1.12.1992Basic TV	TELEVISION
21CN4460/56T	700120i (19v) mono	NCF	1.04.1992	TELEVISION
21CN4460/93R	700120i (19v) mono	NCF	1.03.1992	TELEVISION
21CN4461/93R	700120i (19v) mono		1.07.1992	TELEVISION
21CN4462/50R	700120i (19v) mono	NCF-CR	1.04.1992	TELEVISION
21CN4462/56R	700120i (19v) mono	NCF-CR	1.07.1992	TELEVISION
21CN4462/56T	700120i (19v) mono	NCF-CR	1.04.1992	TELEVISION
21CN4462/57R	700120i (19v) mono	NCF-CR	1.07.1992	TELEVISION
21CN4462L/62	700120i (19v) mono		1.03.1992	TELEVISION
21CN4472/56H	700120i (19v) mono	NCF	1.03.1992	TELEVISION
21CN4472/56R	700120i (19v) mono	NCF	1.03.1992	TELEVISION
21CN4472/57R	700120i (19v) mono	NCF	1.07.1992	TELEVISION
21CN4472/59P	700120i (19v) mono	NCF	1.03.1992	TELEVISION
21CN4472/59R	700120i (19v) mono	NCF	1.03.1992	TELEVISION
21CN4472/67R	700120i (19v) mono	NCF	1.03.1992	TELEVISION
21CN4472L/80	700120i (19v) mono		1.03.1992	TELEVISION
21CN4762/50R	700120i (19v) mono	NCF-CR	1.03.1992	TELEVISION
21CN4762/75R	700120i (19v) mono	NCF-CR	1.04.1992	TELEVISION
21CN4763/75R	700120i (19v) mono	NCF	1.07.1992	TELEVISION
21CN4772/50R	700120i (19v) mono	NCF-CR	1.03.1992	TELEVISION
21CN4772/75R	700120i (19v) mono	NCF-CR	1.03.1992	TELEVISION
21CN4775/75R	700120i (19v) mono	NCF-CR	1.03.1992	TELEVISION
21CN4775/79R	700120i (19v) mono	NCF-CR	1.03.1992	TELEVISION
21CT8870/50Z	710120i (19v) mono	2B-S	1.03.1992Basic TV	TELEVISION
21CT9460L/73	700120i (19v) mono		1.03.1992	TELEVISION

21CT9460L/80	700120i (19v) mono		1.03.1992	TELEVISION
21CT9952/75Z	710125i stereo large 50Hz	CTO-S	1.08.1992	TELEVISION
21DI4210/00R	700120i (19v) mono		1.10.1996	TELEVISION
21DV1/16	1021Leader	KATE _STN	1.03.1994Standard	VCR
21DV2/16	1021Leader	KATE _STN	1.01.1994Standard	VCR
21ET2434/05B	700125i stereo large 50Hz		1.11.1992	TELEVISION
21FIGHTER/00R	700120i (19v) mono		1.10.1996	TELEVISION
21GL1369/78R	700120i (19v) mono		1.01.1997	TELEVISION
21GL1451/78	700120i (19v) mono		1.05.1993	TELEVISION
21GL1451L/78	700120i (19v) mono		1.03.1992	TELEVISION
21GL1452L/55	700120i (19v) mono		1.03.1992	TELEVISION
21GL1452L/55U	700120i (19v) mono		1.04.1992	TELEVISION
21GL1452L/87	700120i (19v) mono		1.03.1992	TELEVISION
21GR1051/16B	700120i (19v) mono	GR1AX	1.04.1992Basic TV	TELEVISION
21GR1251/02B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1251/07B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1251/10B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1251/10V	700120i (19v) mono	GR1AX	1.04.1992Basic TV	TELEVISION
21GR1251/15B	700120i (19v) mono	GR1AX	1.06.1992Basic TV	TELEVISION
21GR1251/16B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1251/22B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1251/32B	700120i (19v) mono	GR1AX	1.06.1992Basic TV	TELEVISION
21GR1251/32V	700120i (19v) mono	GR1AX	1.05.1992Basic TV	TELEVISION
21GR1251/42B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1251/42V	700120i (19v) mono	GR1AX	1.06.1992Basic TV	TELEVISION
21GR1257/02B	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
21GR1257/07B	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
21GR1257/10B	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
21GR1257/15B	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
21GR1257/16B	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
21GR1257/42B	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
21GR1260/50R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/52R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/54R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/57R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/58	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
21GR1260/58R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/59H	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/59R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/62B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/65	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
21GR1260/67R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION

21GR1260/68R	700120i (19v) mono	GR1AX	1.05.1992Basic TV	TELEVISION
21GR1260/73	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
21GR1260/75R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/77	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
21GR1260/77R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/79R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260/87R	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
21GR1260L/58	700120i (19v) mono		1.03.1992	TELEVISION
21GR1260L/73	700120i (19v) mono		1.04.1992	TELEVISION
21GR1260L/77	700120i (19v) mono		1.07.1992	TELEVISION
21GR1260L/80	700120i (19v) mono		1.03.1992	TELEVISION
21GR1260P/65	700120i (19v) mono		1.03.1992	TELEVISION
21GR1261/75R	700120i (19v) mono		1.08.1993	TELEVISION
21GR1268/50R	700120i (19v) mono	GR1AX	1.04.1992Basic TV	TELEVISION
21GR1268/59H	700120i (19v) mono	GR1AX	1.06.1992Basic TV	TELEVISION
21GR1366/52R	700120i (19v) mono		1.02.1993	TELEVISION
21GR1366/54R	700120i (19v) mono		1.09.1992	TELEVISION
21GR1366/57R	700120i (19v) mono		1.09.1992	TELEVISION
21GR1366/58R	700120i (19v) mono		1.10.1992	TELEVISION
21GR1366/59R	700120i (19v) mono		1.01.1993	TELEVISION
21GR1366/67R	700120i (19v) mono		1.09.1992	TELEVISION
21GR1366/73R	700120i (19v) mono		1.10.1993	TELEVISION
21GR1366/75R	700120i (19v) mono		1.08.1992	TELEVISION
21GR1366/77	700120i (19v) mono		1.05.1993	TELEVISION
21GR1366/77R	700120i (19v) mono		1.12.1992	TELEVISION
21GR1366/85R	700120i (19v) mono		1.01.1993	TELEVISION
21GR1366/87R	700120i (19v) mono		1.12.1992	TELEVISION
21GR1366L/77	700120i (19v) mono		1.02.1993	TELEVISION
21GR1369/50R	700120i (19v) mono	GR1AX	1.08.1992Basic TV	TELEVISION
21GR1369/51R	700120i (19v) mono	GR1AX	1.03.1993Basic TV	TELEVISION
21GR1369/59H	700120i (19v) mono	GR1AX	1.09.1992Basic TV	TELEVISION
21GR1369/65	700120i (19v) mono	GR1AX	1.05.1993Basic TV	TELEVISION
21GR1369/68R	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
21GR1369/79R	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
21GR1369P/65	700120i (19v) mono		1.10.1992	TELEVISION
21GR1990/50R	710125i stereo large 50Hz	G110-S	1.08.1992Basic TV	TELEVISION
21GR2150/10B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2168/68R	700120i (19v) mono		1.03.1992	TELEVISION
21GR2350/02B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2350/05B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2350/07B	700120i (19v) mono	G90AE	1.05.1992Basic TV	TELEVISION
21GR2350/10B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION

21GR2350/16B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2350/20B	700120i (19v) mono	G90AE	1.04.1992Basic TV	TELEVISION
21GR2350/22B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2356/30B	710120i (19v) mono	G90B	1.10.1992Basic TV	TELEVISION
21GR2356/39B	710120i (19v) mono	G90B	1.03.1992Basic TV	TELEVISION
21GR2356/95B	710120i (19v) mono	G90B	1.03.1992Basic TV	TELEVISION
21GR2357/39B	710120i (19v) mono	G90B	1.03.1992Basic TV	TELEVISION
21GR2396/19B	710120i (19v) mono	G90B	1.03.1992Basic TV	TELEVISION
21GR2550/02B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2550/05B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2550/07B	700120i (19v) mono	G90AE	1.02.1993Basic TV	TELEVISION
21GR2550/10B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2550/10W	700120i (19v) mono	G90AE	1.08.1992Basic TV	TELEVISION
21GR2550/13B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2550/13W	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2550/16B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2550/20B	700120i (19v) mono	G90AE	1.06.1992Basic TV	TELEVISION
21GR2552/05B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2552/10B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2552/16B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/05B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/07B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/08B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/10B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/10W	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/13B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/13W	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/16B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/22B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/30B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
21GR2554/36B	700120i (19v) mono	G90AE	1.04.1992Basic TV	TELEVISION
21GR2556/30B	710120i (19v) mono	G90B	1.03.1992Basic TV	TELEVISION
21GR2650/10B	710125i stereo large 50Hz	G90B	1.02.1993Basic TV	TELEVISION
21GR2650/30B	710125i stereo large 50Hz	G90B	1.11.1992Basic TV	TELEVISION
21GR2651/30B	710125i stereo large 50Hz	G90B	1.04.1992Basic TV	TELEVISION
21GR2656/49B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR2657/49B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR2750/10B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR2750/22B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR2751/02B	710125i stereo large 50Hz	G90B	1.04.1992Basic TV	TELEVISION
21GR2751/10B	710125i stereo large 50Hz	G90B	1.08.1992Basic TV	TELEVISION
21GR2751/20B	710125i stereo large 50Hz	G90B	1.07.1992Basic TV	TELEVISION

21GR2752/05B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR2752/13B	710125i stereo large 50Hz	G90B	1.06.1992Basic TV	TELEVISION
21GR2752/16B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR2752/25B	710125i stereo large 50Hz	G90B	1.04.1992Basic TV	TELEVISION
21GR2950/08B	700120i (19v) mono	G90AE-SAT	1.03.1992Basic TV	TELEVISION
21GR2950/10B	700120i (19v) mono	G90AE-SAT	1.03.1992Basic TV	TELEVISION
21GR5656/19B	710125i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
21GR5750/02B	710125i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
21GR5750/10B	710125i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
21GR5750/16B	710125i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
21GR6755/50R	710125i stereo large 50Hz	G110-S	1.04.1992Basic TV	TELEVISION
21GR6756/56H	710125i stereo large 50Hz	G110-S	1.03.1992Basic TV	TELEVISION
21GR6756/56R	710125i stereo large 50Hz	G110-S	1.04.1992Basic TV	TELEVISION
21GR6756/65R	710125i stereo large 50Hz	G110-S	1.12.1992Basic TV	TELEVISION
21GR6756/75R	710125i stereo large 50Hz	G110-S	1.06.1992Basic TV	TELEVISION
21GR6756/79R	710125i stereo large 50Hz	G110-S	1.05.1992Basic TV	TELEVISION
21GR6760/69R	700125i stereo large 50Hz		1.03.1992	TELEVISION
21GR6761/56S	710125i stereo large 50Hz	G111-S	1.06.1993Basic TV	TELEVISION
21GR6761/75R	710125i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
21GR6761/79R	710125i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
21GR6762/69R	700125i stereo large 50Hz		1.03.1992	TELEVISION
21GR6762/69T	700125i stereo large 50Hz		1.07.1993	TELEVISION
21GR6763/56H	700125i stereo large 50Hz		1.11.1992	TELEVISION
21GR6763/57R	700125i stereo large 50Hz		1.03.1992	TELEVISION
21GR6763/57T	700125i stereo large 50Hz		1.05.1992	TELEVISION
21GR6763/75R	700125i stereo large 50Hz		1.04.1992	TELEVISION
21GR7560/78	700125i stereo large 50Hz		1.05.1993	TELEVISION
21GR7560L/78	700125i stereo large 50Hz		1.03.1992	TELEVISION
21GR9650/10B	710125i stereo large 50Hz	G90B	1.03.1994Basic TV	TELEVISION
21GR9650/30B	710125i stereo large 50Hz	G90B	1.03.1994Basic TV	TELEVISION
21GR9651/10B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9651/15B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9651/30B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9651/35B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9651/42B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9656/19B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9656/39B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9657/39B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9750/08B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9750/10B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9750/22B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9750/28B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION

21GR9750/30B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9751/02B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9751/10B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9751/15B	710125i stereo large 50Hz	G90B	1.04.1992Basic TV	TELEVISION
21GR9751/22B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9751/28B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9751/30B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9751/35B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9751/42B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9752/05B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9752/13B	710125i stereo large 50Hz	G90B	1.08.1992Basic TV	TELEVISION
21GR9752/25B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9752/33B	710125i stereo large 50Hz	G90B	1.04.1992Basic TV	TELEVISION
21GR9752/36B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9753/33B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9753/36B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GR9756/10B	710125i stereo large 50Hz	G90B	1.10.1992Basic TV	TELEVISION
21GR9757/30B	710125i stereo large 50Hz	G90B	1.03.1992Basic TV	TELEVISION
21GX1560/51R	700120i (19v) mono	ANUBIS_S	1.05.1994Basic TV	TELEVISION
21GX1560/52R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
21GX1560/54R	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
21GX1560/56R	700120i (19v) mono	ANUBIS_S	1.07.1993Basic TV	TELEVISION
21GX1560/56S	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
21GX1560/58R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
21GX1560/71R	700120i (19v) mono	ANUBIS_S	1.03.1994Basic TV	TELEVISION
21GX1560/77B	700120i (19v) mono	ANUBIS_S	1.12.1993Basic TV	TELEVISION
21GX1560/85R	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
21GX1560/87R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
21GX1562/50B	700120i (19v) mono	ANUBIS_S	1.12.1993Basic TV	TELEVISION
21GX1562/50R	700120i (19v) mono	ANUBIS_S	1.07.1993Basic TV	TELEVISION
21GX1562/59R	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
21GX1562/62B	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
21GX1562/65B	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
21GX1562/67R	700120i (19v) mono	ANUBIS_S	1.09.1993Basic TV	TELEVISION
21GX1562/75R	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
21GX1562/79R	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
21GX1563/00R	700120i (19v) mono	ANUBIS_S	1.10.1996Basic TV	TELEVISION
21GX1563/56R	700120i (19v) mono	ANUBIS_S	1.07.1993Basic TV	TELEVISION
21GX1563/65B	700120i (19v) mono	ANUBIS_S	1.11.1993Basic TV	TELEVISION
21GX1563/67R	700120i (19v) mono	ANUBIS_S	1.09.1993Basic TV	TELEVISION
21GX1565/52R	700120i (19v) mono	ANUBIS_S	1.11.1994Basic TV	TELEVISION
21GX1565/54R	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION

21GX1565/56H	700120i (19v) mono	ANUBIS_S	1.03.1995Basic TV	TELEVISION
21GX1565/56S	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
21GX1565/58H	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
21GX1565/58R	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
21GX1565/85R	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
21GX1565/87R	700120i (19v) mono	ANUBIS_S	1.05.1996Basic TV	TELEVISION
21GX1566/59R	700120i (19v) mono	ANUBIS_S	1.01.1995Basic TV	TELEVISION
21GX1566/59S	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
21GX1566/75R	700120i (19v) mono	ANUBIS_S	1.08.1994Basic TV	TELEVISION
21GX1567/50R	700120i (19v) mono	ANUBIS_S	1.10.1994Basic TV	TELEVISION
21GX1567/56R	700120i (19v) mono	ANUBIS_S	1.10.1994Basic TV	TELEVISION
21GX1567/57B	700120i (19v) mono	ANUBIS_S	1.06.1995Basic TV	TELEVISION
21GX1568/56R	700120i (19v) mono	ANUBIS_S	1.08.1994Basic TV	TELEVISION
21GX1660/78	700120i (19v) mono		1.10.1993	TELEVISION
21GX1660/78R	700121i (20v) mono			TELEVISION
21GX1665/78	700125i stereo large 50Hz		1.10.1993	TELEVISION
21GX1665/78R	700121i (20v) mono			TELEVISION
21GX1666/78R	700120i (19v) mono			TELEVISION
21GX1668/78R	700120i (19v) mono			TELEVISION
21GX1669/78R	700120i (19v) mono		1.01.1997	TELEVISION
21GX1760/50B	700120i (19v) mono	ANUBIS_S	1.01.1994Basic TV	TELEVISION
21GX1760/50R	700120i (19v) mono	ANUBIS_S	1.05.1994Basic TV	TELEVISION
21GX1760/58R	700120i (19v) mono	ANUBIS_S	1.01.1994Basic TV	TELEVISION
21GX1760/62B	700120i (19v) mono	ANUBIS_S	1.10.1993Basic TV	TELEVISION
21GX1760/62R	700121i (20v) mono	ANUBIS_S	1.02.1996Basic TV	TELEVISION
21GX1760/75R	700120i (19v) mono	ANUBIS_S	1.03.1994Basic TV	TELEVISION
21GX1765/50R	700120i (19v) mono	ANUBIS_S	1.07.1994Basic TV	TELEVISION
21GX1765/56R	700120i (19v) mono	ANUBIS_S	1.08.1994Basic TV	TELEVISION
21GX1765/58R	700120i (19v) mono	ANUBIS_S	1.10.1994Basic TV	TELEVISION
21GX1765/75R	700120i (19v) mono	ANUBIS_S	1.02.1995Basic TV	TELEVISION
21GX1865/54R	700120i (19v) mono	ANUBIS_S	1.08.1994Basic TV	TELEVISION
21GX1865/77B	700121i (20v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
21GX1865/87R	700120i (19v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
21GX1865/97R	700120i (19v) mono	ANUBIS_S	1.01.1995Basic TV	TELEVISION
21GX1865/97T	700120i (19v) mono	ANUBIS_S	1.02.1995Basic TV	TELEVISION
21GX1870/57R	700120i (19v) mono	ANUBIS_S	1.04.1994Basic TV	TELEVISION
21GX1870/57T	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
21GX1870/67R	700120i (19v) mono	ANUBIS_S	1.10.1994Basic TV	TELEVISION
21GX1870/75R	700120i (19v) mono	ANUBIS_S	1.07.1994Basic TV	TELEVISION
21GX1870/79R	700120i (19v) mono	ANUBIS_S	1.07.1994Basic TV	TELEVISION
21GX1871/56R	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION
21GX1871/58R	700120i (19v) mono	ANUBIS_S	1.09.1994Basic TV	TELEVISION

21GX1872/97R	700120i (19v) mono	ANUBIS_S	1.07.1994Basic TV	TELEVISION
21GX1872/97T	700120i (19v) mono	ANUBIS_S	1.12.1994Basic TV	TELEVISION
21GX1875/00R	700120i (19i) stereo medium	ANUBIS_S	1.10.1996Basic TV	TELEVISION
21GX1875/57R	700120i (19i) stereo medium	ANUBIS_S	1.09.1995Basic TV	TELEVISION
21GX1875/75R	700120i (19i) stereo medium	ANUBIS_S	1.10.1995Basic TV	TELEVISION
21GX1877/97R	700120i (19i) stereo medium	ANUBIS_S	1.12.1995Basic TV	TELEVISION
21GX1970/58R	700120i (19i) stereo medium	ANUBIS_S	1.07.1994Basic TV	TELEVISION
21GX1970/69H	700120i (19i) stereo medium	ANUBIS_S	1.09.1995Basic TV	TELEVISION
21GX1970/69R	700120i (19i) stereo medium	ANUBIS_S	1.04.1994Basic TV	TELEVISION
21GX1970/69T	700120i (19i) stereo medium	ANUBIS_S	1.01.1995Basic TV	TELEVISION
21GX1970/69Z	700120i (19i) stereo medium	ANUBIS_S	1.10.1995Basic TV	TELEVISION
21GX1975/69R	700120i (19i) stereo medium	ANUBIS_S	1.07.1995Basic TV	TELEVISION
21GX1975/69Z	700120i (19i) stereo medium	ANUBIS_S	1.06.1996Basic TV	TELEVISION
21GX3565/52R	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
21GX3565/56H	700120i (19v) mono	ANUBIS_S	1.11.1995Basic TV	TELEVISION
21GX3565/58H	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
21GX3565/58R	700120i (19v) mono	ANUBIS_S	1.11.1995Basic TV	TELEVISION
21GX3566/59R	700121i (20v) mono	ANUBIS_S	1.10.1995Basic TV	TELEVISION
21GX3566/75R	700120i (19v) mono	ANUBIS_S	1.10.1995Basic TV	TELEVISION
21GX3567/50R	700120i (19v) mono	ANUBIS_S	1.10.1995Basic TV	TELEVISION
21GX3567/57R	700120i (19v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
21GX3567/58R	700120i (19v) mono	ANUBIS_S	1.11.1995Basic TV	TELEVISION
21GX3568/56R	700121i (20v) mono	ANUBIS_S	1.01.1996Basic TV	TELEVISION
21GX3568/56Z	700120i (19v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
21GX3568/70R	700120i (19v) mono	ANUBIS_S	1.07.1997Basic TV	TELEVISION
21GX3765/58R	700120i (19v) mono	ANUBIS_S	1.02.1996Basic TV	TELEVISION
21GX3765/62R	700121i (20v) mono			TELEVISION
21GX3765/75R	700120i (19v) mono	ANUBIS_S	1.10.1995Basic TV	TELEVISION
21GX3865/97T	700120i (19v) mono	ANUBIS_S	1.10.1995Basic TV	TELEVISION
21GX8560/77B	700120i (19v) mono			TELEVISION
21GX8568/59B	700120i (19v) mono	ANUBIS_S	1.01.1997Basic TV	TELEVISION
21GX8568/59R	700120i (19v) mono	ANUBIS_S	1.10.1996Basic TV	TELEVISION
21HT1350/00Z	201321i (20v) mono ITV	ANUBIS_B	1.06.1993Basic TV	INSTITUTIONAL TV
21HT1350/01B	201321i (20v) mono ITV	ANUBIS_B	1.05.1993Basic TV	INSTITUTIONAL TV
21HT1350/05Z	201321i (20v) mono ITV	ANUBIS_B	1.09.1993Basic TV	INSTITUTIONAL TV
21HT1350/20W	201321i (20v) mono ITV	ANUBIS_B	1.12.1995Basic TV	INSTITUTIONAL TV
21HT1350/20Z	201321i (20v) mono ITV	ANUBIS_B	1.05.1994Basic TV	INSTITUTIONAL TV
21HT1350/21B	201321i (20v) mono ITV	ANUBIS_B	1.01.1994Basic TV	INSTITUTIONAL TV
21HT1350/21Z	201321i (20v) mono ITV	ANUBIS_B	1.12.1993Basic TV	INSTITUTIONAL TV
21HT1350/25Z	201321i (20v) mono ITV	ANUBIS_B	1.11.1993Basic TV	INSTITUTIONAL TV
21HT1350/40Z	201321i (20v) mono ITV	ANUBIS_B	1.11.1995Basic TV	INSTITUTIONAL TV
21HT1359/01B	201321i (20v) mono ITV	ANUBIS_B	1.04.1993Basic TV	INSTITUTIONAL TV

21HT1359/21B	201321i (20v) mono ITV	ANUBIS_B	1.08.1994Basic TV	INSTITUTIONAL TV
21HT1550/00B	201321i (20v) mono ITV	ANUBIS_B	1.05.1993Basic TV	INSTITUTIONAL TV
21HT1550/20B	201321i (20v) mono ITV	ANUBIS_B	1.05.1994Basic TV	INSTITUTIONAL TV
21HT1559/00B	201321i (20v) mono ITV	ANUBIS_B	1.02.1993Basic TV	INSTITUTIONAL TV
21HT1559/20B	201321i (20v) mono ITV	ANUBIS_B	1.05.1994Basic TV	INSTITUTIONAL TV
21HT1559/33B	201321i (20v) mono ITV	ANUBIS_B	1.01.1994Basic TV	INSTITUTIONAL TV
21HT1582/56Y	21i (20v) mono ITV			INSTITUTIONAL TV
21HT1582/59Z	201321i (20v) mono ITV	L9H.2A	1.12.1999Institutional TV	INSTITUTIONAL TV
21HT1582/68Z	201321i (20v) mono ITV	L9H.2A	1.09.2001Institutional TV	INSTITUTIONAL TV
21HT1582/75R	201321i (20v) mono ITV	L9H.2A	1.11.1999Institutional TV	INSTITUTIONAL TV
21HT1582/75Z	201321i (20v) mono ITV	L9H.2A	1.12.1999Institutional TV	INSTITUTIONAL TV
21HT3152/00	201321i (20v) mono ITV	AA5H.1	1.04.1996Institutional TV	INSTITUTIONAL TV
21HT3152/01	201321i (20v) mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
21HT3152/40	201321i (20v) mono ITV	AA5H.1	1.01.1998Institutional TV	INSTITUTIONAL TV
21HT3152/41	201321i (20v) mono ITV	AA5H.1	1.10.1997Institutional TV	INSTITUTIONAL TV
21HT3202/00	201321i (20v) mono ITV	AA5H.1	1.07.1996Institutional TV	INSTITUTIONAL TV
21HT3202/01	201321i (20v) mono ITV	AA5H.1	1.07.1996Institutional TV	INSTITUTIONAL TV
21HT3202/13	201321i (20v) mono ITV	AA5H.1	1.02.1997Institutional TV	INSTITUTIONAL TV
21HT3202/40	201321i (20v) mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
21HT3202/41	201321i (20v) mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
21HT3252/00	201321i (20v) mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
21HT3252/01	201321i (20v) mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
21HT3252/07	201321i (20v) mono ITV	AA5H.1	1.02.1997Institutional TV	INSTITUTIONAL TV
21HT3252/13	201321i (20v) mono ITV	AA5H.1	1.03.1997Institutional TV	INSTITUTIONAL TV
21HT3252/40	201321i (20v) mono ITV	AA5H.1	1.02.1998Institutional TV	INSTITUTIONAL TV
21HT3252/41	201321i (20v) mono ITV	AA5H.1	1.10.1997Institutional TV	INSTITUTIONAL TV
21HT3252/47	201321i (20v) mono ITV	AA5H.1	1.05.1998Institutional TV	INSTITUTIONAL TV
21HT3302/00	201321i (20v) mono ITV	AA5H.1	1.04.1996Institutional TV	INSTITUTIONAL TV
21HT3302/01	201321i (20v) mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
21HT3302/07	201321i (20v) mono ITV	AA5H.1	1.09.1996Institutional TV	INSTITUTIONAL TV
21HT3302/13	201321i (20v) mono ITV	AA5H.1	1.10.1996Institutional TV	INSTITUTIONAL TV
21HT3302/40	201321i (20v) mono ITV	AA5H.1	1.01.1998Institutional TV	INSTITUTIONAL TV
21HT3302/41	201321i (20v) mono ITV	AA5H.1	1.10.1997Institutional TV	INSTITUTIONAL TV
21HT3302/47	201321i (20v) mono ITV	AA5H.1	1.04.1998Institutional TV	INSTITUTIONAL TV
21HT3304/01	21i (20v) mono ITV			INSTITUTIONAL TV
21HT3304/05	21i (20v) mono ITV			INSTITUTIONAL TV
21HT3352/00	201321i (20v) mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
21HT3352/00Z	201321i (20v) mono ITV	AA5H.1	1.09.1996Institutional TV	INSTITUTIONAL TV
21HT3352/01Z	201321i (20v) mono ITV	AA5H.1	1.09.1996Institutional TV	INSTITUTIONAL TV
21HT3352/07Z	201321i (20v) mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
21HT3352/20P	201321i (20v) mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
21HT3352/21P	201321i (20v) mono ITV	AA5H.1	1.08.1996Institutional TV	INSTITUTIONAL TV

21HT3352/27P	201321i (20v) mono ITV	AA5H.1	1.05.1996Institutional TV	INSTITUTIONAL TV
21HT3352/41Z	201321i (20v) mono ITV	AA5H.1	1.02.1998Institutional TV	INSTITUTIONAL TV
21HT3352/61P	201321i (20v) mono ITV	AA5H.1	1.02.1998Institutional TV	INSTITUTIONAL TV
21HT3352/67P	201321i (20v) mono ITV	AA5H.1	1.05.1999Institutional TV	INSTITUTIONAL TV
21HT3352/78P	201321i (20v) mono ITV	AA5H.1	1.03.1997Institutional TV	INSTITUTIONAL TV
21HT3352/88P	201321i (20v) mono ITV	AA5H.1	1.04.1998Institutional TV	INSTITUTIONAL TV
21HT3402/00	201321i (20v) mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
21HT3402/00Z	201321i (20v) mono ITV	AA5H.1	1.06.1996Institutional TV	INSTITUTIONAL TV
21HT3402/01Z	201321i (20v) mono ITV	AA5H.1	1.06.1996Institutional TV	INSTITUTIONAL TV
21HT3402/05	201321i (20v) mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
21HT3402/07Z	201321i (20v) mono ITV	AA5H.1	1.07.1996Institutional TV	INSTITUTIONAL TV
21HT3402/27V	201321i (20v) mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
21HT3402/41Z	201321i (20v) mono ITV	AA5H.1	1.03.1998Institutional TV	INSTITUTIONAL TV
21HT3402/47Z	201321i (20v) mono ITV	AA5H.1	1.08.1998Institutional TV	INSTITUTIONAL TV
21HT3402/61R	201321i (20v) mono ITV	AA5H.1	1.06.1998Institutional TV	INSTITUTIONAL TV
21HT3402/67R	201321i (20v) mono ITV	AA5H.1	1.10.1998Institutional TV	INSTITUTIONAL TV
21HT3402/68Z	201321i (20v) mono ITV	AA5H.1	Institutional TV	INSTITUTIONAL TV
21HT3622/57R	201321i (20v) Stereo ITV	L9H.2A	1.04.2000Institutional TV	INSTITUTIONAL TV
21HT3622/69R	201321i (20v) Stereo ITV	L9H.2A	1.10.2000Institutional TV	INSTITUTIONAL TV
21HT3627/57Y	201321i (20v) Stereo ITV	L9H.2A	1.10.2000Institutional TV	INSTITUTIONAL TV
21HT3627/69Y	201321i (20v) Stereo ITV	L9H.2A	Institutional TV	INSTITUTIONAL TV
21HT3627/79Y	201321i (20v) Stereo ITV	L9H.2A	1.12.1999Institutional TV	INSTITUTIONAL TV
21HT3627/94Y	201321i (20v) Stereo ITV	L9H.2A	Institutional TV	INSTITUTIONAL TV
21HT3942/69R	201321i (20v) Stereo ITV	L9H.1A	1.01.2001Institutional TV	INSTITUTIONAL TV
21HT3942/69Z	201321i (20v) Stereo ITV	L9H.1A	1.10.2000Institutional TV	INSTITUTIONAL TV
21HT5403/01S	201321i (20v) mono ITV	L9H.2E	1.01.2001Institutional TV	INSTITUTIONAL TV
21HT5403/01Z	201321i (20v) mono ITV	L9H.2E	1.12.1999Institutional TV	INSTITUTIONAL TV
21HT5403/05S	21i (20v) mono ITV			INSTITUTIONAL TV
21HT5403/05Z	201321i (20v) mono ITV	L9H.2E	1.03.2000Institutional TV	INSTITUTIONAL TV
21HT5403/21R	201321i (20v) mono ITV	L9H.2E	1.05.2000Institutional TV	INSTITUTIONAL TV
21HT5403/25R	201321i (20v) mono ITV	L9H.2E	1.05.2000Institutional TV	INSTITUTIONAL TV
21HT5403/58Z	201321i (20v) mono ITV	L9H.2E	1.07.2000Institutional TV	INSTITUTIONAL TV
21HT5403/78R	201321i (20v) mono ITV	L9H.2A	1.04.2001Institutional TV	INSTITUTIONAL TV
21HT5404/01Z	201321i (20v) mono ITV	L01H.1E	1.10.2001Institutional TV	INSTITUTIONAL TV
21HT5404/05Z	201321i (20v) mono ITV	L01H.1E	1.11.2001Institutional TV	INSTITUTIONAL TV
21HT5404/21R	21i (20v) mono ITV			INSTITUTIONAL TV
21HT5404/25R	21i (20v) mono ITV			INSTITUTIONAL TV
21HT5413/01Z	201321i (20v) mono ITV	L9H.2E	1.06.2001Institutional TV	INSTITUTIONAL TV
21HT5413/05Z	201321i (20v) mono ITV	L9H.2E	1.09.2001Institutional TV	INSTITUTIONAL TV
21HT5413/21R	21i (20v) mono ITV			INSTITUTIONAL TV
21HT5413/25R	21i (20v) mono ITV			INSTITUTIONAL TV
21HT5423/21R	201321i (20v) mono ITV	L9H.2E	1.09.2001Institutional TV	INSTITUTIONAL TV

21HT5423/25R	21i (20v) mono ITV			INSTITUTIONAL TV
21MK2460/52R	710120i (19v) mono	MK2	1.09.1992Basic TV	TELEVISION
21MK2460/56H	710120i (19v) mono	MK2	1.09.1992Basic TV	TELEVISION
21MK2460/56R	710120i (19v) mono	MK2	1.03.1992Basic TV	TELEVISION
21MK2460/59R	710120i (19v) mono	MK2	1.03.1992Basic TV	TELEVISION
21MK2460/73	710120i (19v) mono	MK2	1.05.1993Basic TV	TELEVISION
21MK2460/73R	710120i (19v) mono	MK2	1.08.1992Basic TV	TELEVISION
21MK2460/75R	710120i (19v) mono	MK2	1.03.1992Basic TV	TELEVISION
21MK2460/79R	710120i (19v) mono	MK2	1.04.1992Basic TV	TELEVISION
21MK2460L/73	700120i (19v) mono		1.11.1992	TELEVISION
21MK2760/50R	710120i (19v) mono	MK2	1.03.1992Basic TV	TELEVISION
21MK2760/50T	710120i (19v) mono	MK2	1.01.1993Basic TV	TELEVISION
21MK2760/56R	710120i (19v) mono	MK2	1.04.1993Basic TV	TELEVISION
21MK2760/58R	710120i (19v) mono	MK2	1.03.1992Basic TV	TELEVISION
21MK2760/62	710120i (19v) mono	MK2	1.05.1993Basic TV	TELEVISION
21MK2760/62R	710120i (19v) mono	MK2	1.05.1992Basic TV	TELEVISION
21MK2760/75R	710120i (19v) mono	MK2	1.03.1992Basic TV	TELEVISION
21MK2760L/62	700120i (19v) mono		1.08.1992	TELEVISION
21MMTV/57V	710121i Multimedia	PV4.0	1.11.1996Basic TV	TELEVISION
21MMTV/69V	710121i Multimedia	PV4.0	1.09.1996Basic TV	TELEVISION
21MMTV/75V	710121i Multimedia	PV4.0	1.10.1996Basic TV	TELEVISION
21MMTV/79V	710121i Multimedia	PV4.0	1.11.1996Basic TV	TELEVISION
21PI288A/93	700121i Multimedia		1.12.1995	TELEVISION
21PT118A/75R	700120i (19v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
21PT128A/50R	700120i (19v) mono	ANUBIS_S	1.05.1996Basic TV	TELEVISION
21PT128A/59B	700120i (19v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
21PT128A/59H	700120i (19v) mono	ANUBIS_S	Basic TV	TELEVISION
21PT128A/59R	700120i (19v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
21PT128A/59S	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
21PT128A/68R	700120i (19v) mono	ANUBIS_S	1.02.1997Basic TV	TELEVISION
21PT128A/71R	700121i (20v) mono	ANUBIS_S	1.04.1997Basic TV	TELEVISION
21PT128A/75R	700120i (19v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION
21PT128A/77B	700120i (19v) mono	ANUBIS_S	1.01.1997Basic TV	TELEVISION
21PT128A/97R	700120i (19v) mono	ANUBIS_S	1.10.1996Basic TV	TELEVISION
21PT129A/97R	700120i (19v) mono	ANUBIS_S	1.08.1996Basic TV	TELEVISION
21PT131A/05	700120i (19v) mono	ANUBIS_A	1.04.1993Basic TV	TELEVISION
21PT131B/05	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
21PT1321/50B	700121i (20v) mono	L7.1A	1.12.1997Basic TV	TELEVISION
21PT1321/50R	700121i (20v) mono	L7.1A	1.09.1997Basic TV	TELEVISION
21PT1321/50T	700121i (20v) mono	L7.1A	1.03.1999Basic TV	TELEVISION
21PT1321/50Z	700121i (20v) mono	L7.1A	1.05.1998Basic TV	TELEVISION
21PT1321/60R	700121i (20v) mono	L7.1A	1.11.1997Basic TV	TELEVISION

21PT1321/75R	700121i (20v) mono	L7.1A	1.09.1997Basic TV	TELEVISION
21PT1321/75T	700121i (20v) mono	L7.1A	1.04.1999Basic TV	TELEVISION
21PT132A/50R	700120i (19v) mono	ANUBIS_S	1.05.1996Basic TV	TELEVISION
21PT132A/75R	700120i (19v) mono	ANUBIS_S	1.08.1996Basic TV	TELEVISION
21PT1332/58	700121i (20v) mono	L6.1	Basic TV	TELEVISION
21PT133A/51R	700120i (19v) mono	ANUBIS_S	1.03.1996Basic TV	TELEVISION
21PT133A/58R	700121i (20v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
21PT1342/58	700121i (20v) mono	L6.1	1.05.1996Basic TV	TELEVISION
21PT1342/58C	21i (20v) mono			TELEVISION
21PT1342/58S	700121i (20v) mono	L6.1	Basic TV	TELEVISION
21PT134B/00	700120i (19v) mono	ANUBIS_A	1.09.1993Basic TV	TELEVISION
21PT134B/01	700120i (19v) mono	ANUBIS_A	1.09.1993Basic TV	TELEVISION
21PT134B/42	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
21PT1353/00	700121i (20v) mono	L6.2	1.10.1997Basic TV	TELEVISION
21PT1353/01	700121i (20v) mono	L6.2	1.10.1997Basic TV	TELEVISION
21PT1353/58	700121i (20v) mono	L6.2	1.05.1998Basic TV	TELEVISION
21PT1353/58P	700121i (20v) mono	L6.2	1.01.1998Basic TV	TELEVISION
21PT1353/58S	700121i (20v) mono	L6.2	Basic TV	TELEVISION
21PT1353/78P	700121i (20v) mono	L6.2	Basic TV	TELEVISION
21PT1354/00	700121i (20v) mono	L9.2E	1.09.2000Basic TV	TELEVISION
21PT1354/01	700121i (20v) mono	L9.2E	1.09.2000Basic TV	TELEVISION
21PT1354/48	700121i (20v) mono	L9.2E	1.06.2000Basic TV	TELEVISION
21PT1354/58	700121i (20v) mono	L9.2E	1.05.1999Basic TV	TELEVISION
21PT1354/58C	700121i (20v) mono	L9.2E	1.01.2001Basic TV	TELEVISION
21PT135A/00	700120i (19v) mono	ANUBIS_A	1.03.1994Basic TV	TELEVISION
21PT135A/01	700120i (19v) mono	ANUBIS_A	1.03.1994Basic TV	TELEVISION
21PT135A/07	700120i (19v) mono	ANUBIS_A	1.06.1994Basic TV	TELEVISION
21PT135A/42	700120i (19v) mono	ANUBIS_A	1.04.1994Basic TV	TELEVISION
21PT135B/00	700121i (20v) mono	AA5	1.08.1995Basic TV	TELEVISION
21PT135B/01	700121i (20v) mono	AA5	1.07.1995Basic TV	TELEVISION
21PT135B/11	700120i (19v) mono	AA5	1.07.1995Basic TV	TELEVISION
21PT135B/16	700120i (19v) mono	AA5	1.09.1995Basic TV	TELEVISION
21PT1364/58	700121i (20v) mono	L9.2E	Basic TV	TELEVISION
21PT136A/00	700120i (19v) mono	ANUBIS_A	1.06.1994Basic TV	TELEVISION
21PT136A/01	700120i (19v) mono	ANUBIS_A	1.05.1994Basic TV	TELEVISION
21PT136A/05	700120i (19v) mono	ANUBIS_A	1.06.1994Basic TV	TELEVISION
21PT136A/42	700120i (19v) mono	ANUBIS_A	1.07.1994Basic TV	TELEVISION
21PT136A/58	700120i (19v) mono	ANUBIS_A	1.08.1994Basic TV	TELEVISION
21PT136B/00	700120i (19v) mono	AA5	1.06.1995Basic TV	TELEVISION
21PT136B/01	700121i (20v) mono	AA5	1.06.1995Basic TV	TELEVISION
21PT136B/05	700121i (20v) mono	AA5	1.08.1995Basic TV	TELEVISION
21PT136B/07	700120i (19v) mono	AA5	1.07.1995Basic TV	TELEVISION

21PT136B/11	700121i (20v) mono	AA5	1.09.1995Basic TV	TELEVISION
21PT136B/15	700121i (20v) mono	AA5	1.11.1995Basic TV	TELEVISION
21PT136B/16	700120i (19v) mono	AA5	1.09.1995Basic TV	TELEVISION
21PT136B/39	700121i (20v) mono	AA5	1.04.1996Basic TV	TELEVISION
21PT136B/40	700121i (20v) mono	AA5	1.06.1997Basic TV	TELEVISION
21PT136B/58	700121i (20v) mono	AA5	1.08.1995Basic TV	TELEVISION
21PT136B/58P	700121i (20v) mono	AA5	1.09.1997Basic TV	TELEVISION
21PT137A/58R	700120i (19v) mono	ANUBIS_S	1.04.1996Basic TV	TELEVISION
21PT137A/60R	700120i (19v) mono	ANUBIS_S	1.05.1996Basic TV	TELEVISION
21PT137A/62R	700121i (20v) mono	ANUBIS_S	Basic TV	TELEVISION
21PT1381/50B	700121i (20v) mono	L7.2E	1.12.1997Basic TV	TELEVISION
21PT1381/50R	700121i (20v) mono	L7.2E	1.09.1997Basic TV	TELEVISION
21PT1381/50T	700121i (20v) mono	L7.2E	1.04.1999Basic TV	TELEVISION
21PT1381/57R	700121i (20v) mono	L7.2E	1.01.1998Basic TV	TELEVISION
21PT1381/57T	700121i (20v) mono	L7.2E	1.04.1999Basic TV	TELEVISION
21PT1381/58R	700121i (20v) mono	L7.2E	1.11.1997Basic TV	TELEVISION
21PT1381/58T	700121i (20v) mono	L7.2E	Basic TV	TELEVISION
21PT1381/59B	700121i (20v) mono	L7.2E	1.12.1997Basic TV	TELEVISION
21PT1381/59H	700121i (20v) mono	L7.2E	Basic TV	TELEVISION
21PT1381/59R	700121i (20v) mono	L7.2E	1.09.1997Basic TV	TELEVISION
21PT1381/59T	700121i (20v) mono	L7.2E	1.09.1998Basic TV	TELEVISION
21PT1381/59V	700121i (20v) mono	L7.2E	Basic TV	TELEVISION
21PT1381/70B	700121i (20v) mono	L7.2E	Basic TV	TELEVISION
21PT1381/71R	700121i (20v) mono	L7.2E	1.05.1998Basic TV	TELEVISION
21PT1381/75R	700121i (20v) mono	L7.2E	1.09.1997Basic TV	TELEVISION
21PT1381/75T	700121i (20v) mono	L7.2E	1.04.1999Basic TV	TELEVISION
21PT1386/59Z	201321i (20v) mono ITV			INSTITUTIONAL TV
21PT1386/75W	201321i (20v) mono	L7.2E	1.04.1999Basic TV	TELEVISION
21PT138A/57R	700121i (20v) mono	ANUBIS_S	1.05.1996Basic TV	TELEVISION
21PT1532/05	700121i (20v) mono	L6.1	1.09.1996Basic TV	TELEVISION
21PT1532/58	700121i (20v) mono	L6.1	1.05.1997Basic TV	TELEVISION
21PT1532/58H	700121i (20v) mono	L6.1	1.06.1997Basic TV	TELEVISION
21PT1532/59B	700121i (20v) stereo medium	L7.1A	Basic TV	TELEVISION
21PT1532/59C	700121i (20v) stereo medium	L7.1A	Basic TV	TELEVISION
21PT1532/75R	700121i (20v) stereo medium	L7.1A	Basic TV	TELEVISION
21PT1542/43	700121i (20v) mono	L6.1	1.04.1997Basic TV	TELEVISION
21PT1542/48S	21i (20v) mono			TELEVISION
21PT1542/58	700121i (20v) mono	L6.1	1.09.1996Basic TV	TELEVISION
21PT1542/58C	21i (20v) mono			TELEVISION
21PT1542/58H	700121i (20v) mono	L6.1	1.05.1997Basic TV	TELEVISION
21PT1542/58S	700121i (20v) mono	L6.1	1.03.2001Basic TV	TELEVISION
21PT154B/58P	700120i (19v) mono	AA5	1.12.1995Basic TV	TELEVISION

21PT1582/59C	700121i (20v) mono	L9.2A	1.10.1999Basic TV	TELEVISION
21PT1582/59V	700121i (20v) mono	L9.2A	1.09.1999Basic TV	TELEVISION
21PT1582/75T	700121i (20v) mono	L9.2A	1.01.2000Basic TV	TELEVISION
21PT159B/05	700120i (19v) mono			TELEVISION
21PT161A/00	700120i (19v) mono	ANUBIS_A	1.03.1993Basic TV	TELEVISION
21PT161A/05	700120i (19v) mono	ANUBIS_A	1.02.1993Basic TV	TELEVISION
21PT161B/00	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
21PT161B/05	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
21PT164A/00	700120i (19v) mono	ANUBIS_A	1.03.1993Basic TV	TELEVISION
21PT164A/05	700120i (19v) mono	ANUBIS_A	1.04.1993Basic TV	TELEVISION
21PT164B/00	700120i (19v) mono	ANUBIS_A	1.09.1993Basic TV	TELEVISION
21PT164B/01	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
21PT164B/07	700120i (19v) mono	ANUBIS_A	1.11.1993Basic TV	TELEVISION
21PT164B/13	700120i (19v) mono	ANUBIS_A	1.10.1993Basic TV	TELEVISION
21PT164B/13W	700120i (19v) mono	ANUBIS_A	1.12.1993Basic TV	TELEVISION
21PT164B/42	700120i (19v) mono	ANUBIS_A	1.03.1994Basic TV	TELEVISION
21PT1653/00	700121i (20v) mono	L6.2	1.10.1997Basic TV	TELEVISION
21PT1653/01	700120i (19v) mono	L6.2	1.03.1998Basic TV	TELEVISION
21PT1653/05	700121i (20v) mono	L6.2	1.10.1997Basic TV	TELEVISION
21PT1653/11	700121i (20v) mono	L6.2	1.10.1997Basic TV	TELEVISION
21PT1653/15	21i (20v) mono			TELEVISION
21PT1653/43	700121i (20v) mono	L6.2	1.09.1997Basic TV	TELEVISION
21PT1653/43P	700121i (20v) mono	L6.2	Basic TV	TELEVISION
21PT1653/58	700121i (20v) mono	L6.2	1.11.1997Basic TV	TELEVISION
21PT1653/58H	700121i (20v) mono	L6.2	1.03.1998Basic TV	TELEVISION
21PT1653/58P	700121i (20v) mono	L6.2	1.12.1997Basic TV	TELEVISION
21PT1653/58Y	700121i (20v) mono	L6.2	1.04.1998Basic TV	TELEVISION
21PT1653/60	700121i (20v) mono	L6.2	1.10.1998Basic TV	TELEVISION
21PT1653/60S	700121i (20v) mono	L6.2	Basic TV	TELEVISION
21PT1653/78P	700121i (20v) mono	L6.2	Basic TV	TELEVISION
21PT1654/00	700121i (20v) mono	L9.2E	1.09.2000Basic TV	TELEVISION
21PT1654/01	700121i (20v) mono	L9.2E	1.06.2001Basic TV	TELEVISION
21PT1654/05	21i (20v) mono			TELEVISION
21PT1654/48	700121i (20v) mono	L9.2E	1.06.2000Basic TV	TELEVISION
21PT1654/58	700121i (20v) mono	L9.2E	1.08.1999Basic TV	TELEVISION
21PT1654/58C	700121i (20v) mono	L9.2E	1.01.2001Basic TV	TELEVISION
21PT165A/00	700120i (19v) mono	ANUBIS_A	1.04.1994Basic TV	TELEVISION
21PT165A/05	700120i (19v) mono	ANUBIS_A	1.03.1994Basic TV	TELEVISION
21PT165A/13	700120i (19v) mono	ANUBIS_A	1.05.1994Basic TV	TELEVISION
21PT165A/25	700120i (19v) mono	ANUBIS_A	1.03.1994Basic TV	TELEVISION
21PT165B/00	700120i (19v) mono	AA5	1.09.1995Basic TV	TELEVISION
21PT165B/01	700121i (20v) mono	AA5	1.09.1995Basic TV	TELEVISION

21PT165B/02	700121i (20v) mono	AA5	1.08.1995Basic TV	TELEVISION
21PT165B/05	700120i (19v) mono	AA5	1.08.1995Basic TV	TELEVISION
21PT165B/13	700121i (20v) mono	AA5	1.08.1995Basic TV	TELEVISION
21PT165B/58	700121i (20v) mono	AA5	1.02.1996Basic TV	TELEVISION
21PT165B/58P	700120i (19v) mono	AA5	1.01.1996Basic TV	TELEVISION
21PT165C/58P	700121i (20v) mono	AA5	1.01.1997Basic TV	TELEVISION
21PT1663/00	700121i (20v) mono	L7.2E	Basic TV	TELEVISION
21PT1663/01	700121i (20v) mono	L7.2E	1.03.1998Basic TV	TELEVISION
21PT1663/05	700121i (20v) mono	L7.2E	1.02.1998Basic TV	TELEVISION
21PT1663/07	700121i (20v) mono	L7.2E	1.04.1998Basic TV	TELEVISION
21PT1663/11	700121i (20v) mono	L7.2E	1.03.1998Basic TV	TELEVISION
21PT1663/43	700121i (20v) mono	L7.2E	1.05.1998Basic TV	TELEVISION
21PT1663/58	700121i (20v) mono	L7.2E	1.04.1998Basic TV	TELEVISION
21PT1663/60	700121i (20v) mono	L7.2E	1.06.1998Basic TV	TELEVISION
21PT1664/00	700121i (20v) mono	L9.2E	1.07.1999Basic TV	TELEVISION
21PT1664/00S	700121i (20v) mono	L9.2E	1.04.2000Basic TV	TELEVISION
21PT1664/01	700121i (20v) mono	L9.2E	1.08.1999Basic TV	TELEVISION
21PT1664/01S	700121i (20v) mono	L9.2E	1.05.2000Basic TV	TELEVISION
21PT1664/05	700121i (20v) mono	L9.2E	1.07.1999Basic TV	TELEVISION
21PT1664/05S	700121i (20v) mono	L9.2E	1.04.2000Basic TV	TELEVISION
21PT1664/58	700121i (20v) mono	L9.2E	1.08.1999Basic TV	TELEVISION
21PT1664/58C	700121i (20v) mono	L9.2E	1.01.2001Basic TV	TELEVISION
21PT1664/58S	700121i (20v) mono	L9.2E	1.05.2000Basic TV	TELEVISION
21PT166A/00	700120i (19v) mono	ANUBIS_A	1.05.1994Basic TV	TELEVISION
21PT166A/01	700120i (19v) mono	ANUBIS_A	1.05.1994Basic TV	TELEVISION
21PT166A/05	700120i (19v) mono	ANUBIS_A	1.06.1994Basic TV	TELEVISION
21PT166A/07	700120i (19v) mono	ANUBIS_A	1.06.1994Basic TV	TELEVISION
21PT166A/13	700120i (19v) mono	ANUBIS_A	1.06.1994Basic TV	TELEVISION
21PT166A/25	700120i (19v) mono	ANUBIS_A	1.06.1994Basic TV	TELEVISION
21PT166A/58	700120i (19v) mono	ANUBIS_A	1.06.1994Basic TV	TELEVISION
21PT166B/00	700121i (20v) mono	AA5	1.06.1995Basic TV	TELEVISION
21PT166B/01	700121i (20v) mono	AA5	1.06.1995Basic TV	TELEVISION
21PT166B/01P	700121i (20v) mono	AA5	1.11.1997Basic TV	TELEVISION
21PT166B/02	700121i (20v) mono	AA5	1.06.1995Basic TV	TELEVISION
21PT166B/05	700120i (19v) mono	AA5	1.08.1995Basic TV	TELEVISION
21PT166B/07	700121i (20v) mono	AA5	1.09.1995Basic TV	TELEVISION
21PT166B/13	700121i (20v) mono	AA5	1.08.1995Basic TV	TELEVISION
21PT166B/58	700121i (20v) mono	AA5	1.07.1995Basic TV	TELEVISION
21PT166B/58P	700120i (19v) mono	AA5	1.01.1996Basic TV	TELEVISION
21PT166B/60	700121i (20v) mono	AA5	1.09.1995Basic TV	TELEVISION
21PT166B/60P	700121i (20v) mono	AA5	1.09.1997Basic TV	TELEVISION
21PT166C/58P	700121i (20v) mono	AA5	1.01.1997Basic TV	TELEVISION

21PT1865/58	700121i (20v) mono	L9.2E	1.09.2000Basic TV	TELEVISION
21PT1865/58C	700121i (20v) mono	L9.2E	1.01.2001Basic TV	TELEVISION
21PT2001/59B	21i (20v) mono			TELEVISION
21PT2001/79R	21i (20v) mono			TELEVISION
21PT2012/59A	21i (20v) mono			TELEVISION
21PT2012/59B	21i (20v) mono			TELEVISION
21PT2012/59C	21i (20v) mono			TELEVISION
21PT2012/79R	21i (20v) mono			TELEVISION
21PT2251/97R	21i (20v) stereo medium			TELEVISION
21PT2252/56A	21i (20v) stereo medium			TELEVISION
21PT2252/57R	21i (20v) stereo medium			TELEVISION
21PT2252/68R	21i (20v) stereo medium			TELEVISION
21PT2252/69R	21i (20v) stereo medium			TELEVISION
21PT2252/79R	21i (20v) stereo medium			TELEVISION
21PT2264/00	700121i (20v) stereo medium	L9.2E	1.01.2000Basic TV	TELEVISION
21PT2264/20	700121i (20v) stereo medium	L9.2E	1.06.2000Basic TV	TELEVISION
21PT2265/00	700121i (20v) stereo medium	L9.2E	1.08.2000Basic TV	TELEVISION
21PT2301/97R	21i (20v) stereo medium			TELEVISION
21PT2302/56A	21i (20v) stereo medium			TELEVISION
21PT2302/57A	21i (20v) stereo medium			TELEVISION
21PT2302/57R	21i (20v) stereo medium			TELEVISION
21PT2302/68R	21i (20v) stereo medium			TELEVISION
21PT2302/69R	21i (20v) stereo medium			TELEVISION
21PT2302/79R	21i (20v) stereo medium			TELEVISION
21PT2321/50R	700121i (20v) mono	L7.1A	1.11.1997Basic TV	TELEVISION
21PT2321/50T	700121i (20v) mono			TELEVISION
21PT2321/58R	700121i (20v) mono	L7.1A	1.03.1999Basic TV	TELEVISION
21PT232A/50B	700120i (19v) mono	ANUBIS_S	1.02.1997Basic TV	TELEVISION
21PT232A/58R	700120i (19v) mono	ANUBIS_S	1.08.1996Basic TV	TELEVISION
21PT233A/71R	710121i (20v) mono	PV4.0	1.05.1997Basic TV	TELEVISION
21PT2381/58R	700121i (20v) mono	L7.1A	1.01.1998Basic TV	TELEVISION
21PT2381/59B	700121i (20v) mono	L7.1A	1.12.1997Basic TV	TELEVISION
21PT2381/59M	700121i (20v) mono	L7.1A	Basic TV	TELEVISION
21PT2381/59R	700121i (20v) mono	L7.1A	1.10.1997Basic TV	TELEVISION
21PT2381/59T	700121i (20v) mono	L7.1A	Basic TV	TELEVISION
21PT2381/59V	700121i (20v) mono	L7.1A	Basic TV	TELEVISION
21PT2382/56R	700121i (20v) mono	L7.2E	1.03.1998Basic TV	TELEVISION
21PT2382/57R	700121i (20v) mono	L7.2E	1.12.1997Basic TV	TELEVISION
21PT2382/71R	700121i (20v) mono	L7.2E	1.05.1998Basic TV	TELEVISION
21PT2386/75Y	700121i (20v) mono	L7.2A	1.06.1999Basic TV	TELEVISION
21PT238A/50B	700120i (19v) mono	ANUBIS_S	1.02.1997Basic TV	TELEVISION
21PT238A/56R	700120i (19v) mono	ANUBIS_S	1.06.1996Basic TV	TELEVISION

21PT238A/57R	700120i (19v) mono	ANUBIS_S	1.07.1996Basic TV	TELEVISION
21PT238A/58H	700120i (19v) mono	ANUBIS_S	1.02.1997Basic TV	TELEVISION
21PT238A/58R	700120i (19v) mono	ANUBIS_S	1.11.1996Basic TV	TELEVISION
21PT238A/59R	700120i (19v) mono	ANUBIS_S	1.09.1996Basic TV	TELEVISION
21PT238A/75R	700120i (19v) mono	ANUBIS_S	1.07.1996Basic TV	TELEVISION
21PT241A/70R	700121i (20v) mono	ANUBIS_S	1.04.1997Basic TV	TELEVISION
21PT2563/11	700121i (20v) stereo medium	L6.1	1.05.1999Basic TV	TELEVISION
21PT2564/00	700121i (20v) stereo medium	L6.1	1.10.1999Basic TV	TELEVISION
21PT2584/01	700121i (20v) stereo medium	L6.1	1.10.1999Basic TV	TELEVISION
21PT260A/57R	700121i (20v) stereo medium	ANUBIS_S	1.05.1996Basic TV	TELEVISION
21PT260A/75R	700120i (19i) stereo medium	ANUBIS_S	1.06.1996Basic TV	TELEVISION
21PT2622/68R	700121i (20v) stereo medium	L7.2A	1.03.1998Basic TV	TELEVISION
21PT2622/69R	700121i (20v) stereo medium	L7.2A	1.02.1998Basic TV	TELEVISION
21PT2622/70R	700121i (20v) stereo medium			TELEVISION
21PT2622/75R	700121i (20v) stereo medium	L7.2A	1.04.1998Basic TV	TELEVISION
21PT2626/69V	700121i (20v) stereo medium	L7.2A	1.04.1999Basic TV	TELEVISION
21PT2626/94Y	700121i (20v) stereo medium	L7.2A	Basic TV	TELEVISION
21PT262A/68R	700120i (19i) stereo medium	ANUBIS_S	1.02.1997Basic TV	TELEVISION
21PT262A/69R	700120i (19i) stereo medium	ANUBIS_S	1.05.1996Basic TV	TELEVISION
21PT262A/79R	700120i (19i) stereo medium	ANUBIS_S	1.07.1996Basic TV	TELEVISION
21PT263A/97R	700121i (20v) stereo medium	ANUBIS_S	1.02.1997Basic TV	TELEVISION
21PT2664/00	700121i (20v) stereo medium	L9.2E	1.08.1999Basic TV	TELEVISION
21PT2664/20	700121i (20v) stereo medium	L9.2E	1.06.2000Basic TV	TELEVISION
21PT2665/00	700121i (20v) stereo medium	L9.2E	1.07.2000Basic TV	TELEVISION
21PT2665/01	700121i (20v) stereo medium	L9.2E	1.08.2000Basic TV	TELEVISION
21PT2665/05	700121i (20v) stereo medium	L9.2E	1.08.2000Basic TV	TELEVISION
21PT2665/58	700121i (20v) stereo medium	L9.2E	1.07.2000Basic TV	TELEVISION
21PT2665/58C	700121i (20v) stereo medium	L9.2E	1.01.2001Basic TV	TELEVISION
21PT2682/56H	700121i (20v) mono	L7.2A	Basic TV	TELEVISION
21PT2682/56R	700121i (20v) stereo medium	L7.2A	Basic TV	TELEVISION
21PT2682/57R	700121i (20v) stereo medium	L7.2A	1.04.1998Basic TV	TELEVISION
21PT2682/57Y	700121i (20v) stereo medium	L7.2A	Basic TV	TELEVISION
21PT2682/70R	700121i (20v) stereo medium	L7.2A	Basic TV	TELEVISION
21PT2682/71R	700121i (20v) stereo medium	L7.2A	1.04.1998Basic TV	TELEVISION
21PT2683/58	700121i (20v) stereo medium	L7.2E	1.04.1998Basic TV	TELEVISION
21PT2684/01	700121i (20v) stereo medium	L9.2E	1.08.1999Basic TV	TELEVISION
21PT2684/05	700121i (20v) stereo medium	L9.2E	1.07.1999Basic TV	TELEVISION
21PT2684/21	700121i (20v) stereo medium	L9.2E	1.08.2000Basic TV	TELEVISION
21PT2684/25	700121i (20v) stereo medium	L9.2E	1.08.2000Basic TV	TELEVISION
21PT2684/48	700121i (20v) stereo medium	L9.2E	1.06.2000Basic TV	TELEVISION
21PT2684/58	700121i (20v) stereo medium	L9.2E	1.05.1999Basic TV	TELEVISION
21PT2684/P00	21i (20v) stereo medium			TELEVISION

21PT2685/01	700121i (20v) stereo medium	L9.2E	Basic TV	TELEVISION
21PT2685/58	700121i (20v) stereo medium	L9.2E	Basic TV	TELEVISION
21PT2686/57W	700121i (20v) stereo medium	L7.2A	1.08.1999Basic TV	TELEVISION
21PT2686/57Y	700121i (20v) stereo medium	L7.2A	1.02.1999Basic TV	TELEVISION
21PT310A/00	201321i (20v) mono ITV	AA5	1.09.1995Basic TV	INSTITUTIONAL TV
21PT310A/01	201321i (20v) mono ITV	AA5	1.07.1995Basic TV	INSTITUTIONAL TV
21PT313A/00	201321i (20v) mono ITV	AA5	1.10.1995Basic TV	INSTITUTIONAL TV
21PT350A/00	700125i stereo large 50Hz	ANUBIS_B	1.08.1993Basic TV	TELEVISION
21PT350A/01	700125i stereo large 50Hz	ANUBIS_B	1.08.1993Basic TV	TELEVISION
21PT351A/00	700120i (19v) mono	TV/VCR-1	1.12.1993Basic TV	TELEVISION
21PT351A/01	700120i (19v) mono	TV/VCR-1	1.03.1994Basic TV	TELEVISION
21PT351A/13	700121i (20v) stereo medium	TV/VCR-1	1.04.1994Basic TV	TELEVISION
21PT351B/00	700121i (20v) mono	TV/VCR-1	1.03.1995Basic TV	TELEVISION
21PT351B/01	700120i (19v) mono	TV/VCR-1	1.03.1995Basic TV	TELEVISION
21PT351B/13	700120i (19v) mono	TV/VCR-1	1.04.1995Basic TV	TELEVISION
21PT352A/11	700121i (20v) stereo medium	ANUBIS_B	1.06.1994Basic TV	TELEVISION
21PT352A/13	700125i stereo large 50Hz	ANUBIS_B	1.06.1994Basic TV	TELEVISION
21PT3722/59A	700121i (20v) mono	L9.2A	1.09.1999Basic TV	TELEVISION
21PT3722/59B	700121i (20v) mono	L9.2A	1.10.1999Basic TV	TELEVISION
21PT3722/59C	700121i (20v) mono	L9.2A	1.10.1999Basic TV	TELEVISION
21PT3722/75R	700121i (20v) mono	L9.2A	1.10.1999Basic TV	TELEVISION
21PT3742/59A	700121i (20v) stereo medium	L9.2A	1.10.2000Basic TV	TELEVISION
21PT3742/59B	700121i (20v) stereo medium	L9.2A	1.09.2000Basic TV	TELEVISION
21PT3742/59C	700121i (20v) stereo medium	L9.2A	1.03.2001Basic TV	TELEVISION
21PT3742/75R	700121i (20v) stereo medium	L9.2A	1.09.2000Basic TV	TELEVISION
21PT3822/56T	700121i (20v) stereo medium	L9.2A	1.02.2000Basic TV	TELEVISION
21PT3822/57T	700121i (20v) stereo medium	L9.2A	1.09.1999Basic TV	TELEVISION
21PT3822/68R	700121i (20v) stereo medium	L9.2A	1.10.1999Basic TV	TELEVISION
21PT3822/69R	700121i (20v) stereo medium	L9.2A	1.08.1999Basic TV	TELEVISION
21PT3822/69T	700121i (20v) stereo medium	L9.2A	1.12.1999Basic TV	TELEVISION
21PT3822/79T	700121i (20v) stereo medium	L9.2A	1.01.2000Basic TV	TELEVISION
21PT3832/97R	700121i (20v) mono	L9.2A	1.09.2001Basic TV	TELEVISION
21PT3842/56A	700121i (20v) mono	L9.2A	1.08.2001Basic TV	TELEVISION
21PT3842/57R	21i (20v) mono			TELEVISION
21PT3842/68R	700121i (20v) mono	L9.2A	1.08.2001Basic TV	TELEVISION
21PT3842/69R	700121i (20v) mono	L9.2A	1.07.2001Basic TV	TELEVISION
21PT3842/79R	700121i (20v) mono	L9.2A	1.10.2001Basic TV	TELEVISION
21PT3885/94R	700121i (20v) stereo medium	L9.2A	1.08.2001Basic TV	TELEVISION
21PT3921/69R	700121i (20v) stereo medium	L9.1A	1.04.2001Basic TV	TELEVISION
21PT3921/79R	21i (20v) stereo medium			TELEVISION
21PT3932/97R	700121i (20v) stereo medium			TELEVISION
21PT3942/56A	700121i (20v) stereo medium	L9.2A	1.10.2000Basic TV	TELEVISION

21PT3942/57R	700121i (20v) stereo medium	L9.2A	1.08.2000Basic TV	TELEVISION
21PT3942/68R	700121i (20v) stereo medium	L9.2A	1.07.2000Basic TV	TELEVISION
21PT3942/69R	700121i (20v) stereo medium	L9.2A	1.06.2000Basic TV	TELEVISION
21PT3942/79R	700121i (20v) stereo medium	L9.2A	1.07.2000Basic TV	TELEVISION
21PT3952/97R	700121i (20v) stereo medium	L9.1A	1.12.2000Basic TV	TELEVISION
21PT3962/56A	700121i (20v) stereo medium	L9.1A	1.08.2001Basic TV	TELEVISION
21PT3962/57R	700121i (20v) stereo medium	L9.1A	1.12.2000Basic TV	TELEVISION
21PT3962/68R	700121i (20v) stereo medium	L9.1A	1.12.2000Basic TV	TELEVISION
21PT3962/69R	700121i (20v) stereo medium	L9.1A	1.10.2000Basic TV	TELEVISION
21PT3962/79R	700121i (20v) stereo medium	L9.1A	1.03.2001Basic TV	TELEVISION
21PT4204/00	700121i (20v) stereo medium	L7.2E	1.07.1998Basic TV	TELEVISION
21PT4255/00	700121i (20v) stereo medium			TELEVISION
21PT4301/00	710120i (19i) stereo medium	GR2.4	1.11.1995Basic TV	TELEVISION
21PT4303/02	710121i (20v) stereo medium	MD1.2E	1.05.1997Basic TV	TELEVISION
21PT4304/00	700121i (20v) stereo medium	L6.2	1.12.1997Basic TV	TELEVISION
21PT4305/00	700121i (20v) stereo medium	L7.2E	1.05.1998Basic TV	TELEVISION
21PT4324/01	700121i (20v) stereo medium	L6.2	1.01.1998Basic TV	TELEVISION
21PT4325/01	700121i (20v) stereo medium	L7.2E	1.08.1998Basic TV	TELEVISION
21PT4355/00	700120i (19i) stereo medium	L9.2E	Basic TV	TELEVISION
21PT4375/01	700120i (19i) stereo medium	L9.2E	Basic TV	TELEVISION
21PT4403/00	700121i (20v) stereo medium	L6.2	1.10.1997Basic TV	TELEVISION
21PT4404/00	700121i (20v) stereo medium	L7.2E	1.05.1998Basic TV	TELEVISION
21PT4406/01	21i (20v) stereo medium			TELEVISION
21PT4406/05	21i (20v) stereo medium			TELEVISION
21PT4406/58	21i (20v) stereo medium			TELEVISION
21PT440A/00	710125i stereo large 50Hz	GR2.2	1.11.1993Basic TV	TELEVISION
21PT440A/06	710125i stereo large 50Hz	GR2.2	1.01.1994Basic TV	TELEVISION
21PT440A/19	710125i stereo large 50Hz	GR2.2	1.04.1994Basic TV	TELEVISION
21PT440A/43	710125i stereo large 50Hz	GR2.2	1.12.1994Basic TV	TELEVISION
21PT440B/00	710121i (20v) stereo medium	MD1.1E	1.07.1995Basic TV	TELEVISION
21PT440B/00B	710121i (20v) stereo medium	MD1.1E	1.04.1997Basic TV	TELEVISION
21PT440B/03	710120i (19i) stereo medium	MD1.1E	1.10.1995Basic TV	TELEVISION
21PT440B/58	710120i (19i) stereo medium	MD1.1E	1.01.1996Basic TV	TELEVISION
21PT440B/58B	710121i (20v) stereo medium	MD1.1E	1.05.1997Basic TV	TELEVISION
21PT440B/58P	710120i (19i) stereo medium	MD1.1E	1.09.1995Basic TV	TELEVISION
21PT441B/02	710120i (19i) stereo medium	MD1.1E	1.08.1995Basic TV	TELEVISION
21PT441B/02B	710121i (20v) stereo medium	MD1.1E	1.03.1997Basic TV	TELEVISION
21PT4422/01	710121i (20v) stereo medium	MD1.2E	1.03.1997Basic TV	TELEVISION
21PT4423/01	700121i (20v) stereo medium	L6.2	1.10.1997Basic TV	TELEVISION
21PT4423/05	700121i (20v) stereo medium	L6.2	1.01.1998Basic TV	TELEVISION
21PT4423/11	700121i (20v) stereo medium	L6.2	1.10.1997Basic TV	TELEVISION
21PT4423/58	700121i (20v) stereo medium	L6.2	1.10.1997Basic TV	TELEVISION

21PT4423/58P	700121i (20v) stereo medium	L6.2	1.01.1998Basic TV	TELEVISION
21PT4424/01	700121i (20v) stereo medium	L7.2E	1.06.1998Basic TV	TELEVISION
21PT4424/05	700121i (20v) stereo medium	L7.2E	1.06.1998Basic TV	TELEVISION
21PT4424/07	700121i (20v) stereo medium	L7.2E	1.06.1998Basic TV	TELEVISION
21PT4424/11	700121i (20v) stereo medium	L7.2E	1.06.1998Basic TV	TELEVISION
21PT4424/15	700121i (20v) stereo medium	L7.2E	1.09.1998Basic TV	TELEVISION
21PT4425/58	700121i (20v) stereo medium	L9.2E	1.02.2001Basic TV	TELEVISION
21PT4425/58C	700121i (20v) stereo medium	L9.2E	1.05.2001Basic TV	TELEVISION
21PT442A/07	710125i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
21PT442A/11	710125i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
21PT442A/13	710125i stereo large 50Hz	GR2.2	1.11.1993Basic TV	TELEVISION
21PT442A/16	710125i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
21PT442B/01	710120i (19i) stereo medium	MD1.1E	1.07.1995Basic TV	TELEVISION
21PT442B/05	710120i (19i) stereo medium	MD1.1E	1.09.1995Basic TV	TELEVISION
21PT442B/05B	710120i (19i) stereo medium	MD1.1E	1.04.1997Basic TV	TELEVISION
21PT442B/07	710120i (19i) stereo medium	MD1.1E	1.07.1995Basic TV	TELEVISION
21PT442B/07B	710121i (20v) stereo medium	MD1.1E	1.05.1997Basic TV	TELEVISION
21PT442B/13	710120i (19i) stereo medium	MD1.1E	1.08.1995Basic TV	TELEVISION
21PT442B/13B	710121i (20v) stereo medium	MD1.1E	1.05.1997Basic TV	TELEVISION
21PT442B/16	710120i (19i) stereo medium	MD1.1E	1.07.1995Basic TV	TELEVISION
21PT442B/16B	710121i (20v) stereo medium	MD1.1E	1.04.1997Basic TV	TELEVISION
21PT442B/19	710120i (19i) stereo medium	MD1.1E	1.05.1996Basic TV	TELEVISION
21PT4454/00	700121i (20v) stereo medium	L6.3	1.09.1998Basic TV	TELEVISION
21PT4455/00	700121i (20v) stereo medium	L9.2E	1.07.1999Basic TV	TELEVISION
21PT4455/20	700121i (20v) stereo medium	L9.2E	1.06.2000Basic TV	TELEVISION
21PT4456/00	700121i (20v) stereo medium	L9.2E	1.08.2001Basic TV	TELEVISION
21PT4456/01	700121i (20v) stereo medium	L9.2E	1.08.2001Basic TV	TELEVISION
21PT4456/05	700121i (20v) stereo medium	L9.2E	1.08.2001Basic TV	TELEVISION
21PT4456/58	700121i (20v) stereo medium	L9.2E	1.08.2001Basic TV	TELEVISION
21PT4456/58C	700121i (20v) stereo medium	L9.2E	1.09.2001Basic TV	TELEVISION
21PT4474/01	700121i (20v) stereo medium	L6.3	1.11.1998Basic TV	TELEVISION
21PT4475/01	700121i (20v) stereo medium	L9.2E	1.08.1999Basic TV	TELEVISION
21PT4475/05	700121i (20v) stereo medium	L9.2E	1.08.1999Basic TV	TELEVISION
21PT4475/21	700121i (20v) stereo medium	L9.2E	1.06.2000Basic TV	TELEVISION
21PT4475/25	700121i (20v) stereo medium	L9.2E	1.06.2000Basic TV	TELEVISION
21PT4475/48	700121i (20v) stereo medium	L9.2E	1.06.2000Basic TV	TELEVISION
21PT4475/58	700121i (20v) stereo medium	L9.2E	1.04.1999Basic TV	TELEVISION
21PT4475/58C	700121i (20v) stereo medium	L9.2E	1.01.2001Basic TV	TELEVISION
21PT4494/05	700121i (20v) stereo medium	L6.3	1.09.1998Basic TV	TELEVISION
21PT4655/00	700121i (20v) stereo medium	L9.2E	Basic TV	TELEVISION
21PT520A/00	710125i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
21PT520A/06	710125i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION

21PT520A/19	710125i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
21PT520B/00	710120i (19i) stereo medium	GR2.4	1.09.1994Basic TV	TELEVISION
21PT520B/01	710120i (19i) stereo medium	GR2.4	1.09.1994Basic TV	TELEVISION
21PT520B/20	710120i (19i) stereo medium	GR2.4	1.03.1995Basic TV	TELEVISION
21PT520B/21	710120i (19i) stereo medium	GR2.4	1.03.1995Basic TV	TELEVISION
21PT522A/05	710125i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
21PT522A/11	710125i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
21PT522A/13	710125i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
21PT522A/16	710125i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
21PT522B/01	710125i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
21PT522B/05	710125i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
21PT522B/11	710125i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
21PT522B/21	710125i stereo large 50Hz	GR2.4	1.05.1995Basic TV	TELEVISION
21PT522B/25	710125i stereo large 50Hz	GR2.4	1.04.1995Basic TV	TELEVISION
21PT522B/31	710125i stereo large 50Hz	GR2.4	1.06.1995Basic TV	TELEVISION
21PT522B/39	710125i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
21PT5301/00	710120i (19i) stereo medium	GR2.4	1.09.1995Basic TV	TELEVISION
21PT5301/01	710120i (19i) stereo medium	GR2.4	1.10.1995Basic TV	TELEVISION
21PT5301/15	710120i (19i) stereo medium	GR2.4	1.10.1995Basic TV	TELEVISION
21PT5301/58	710120i (19i) stereo medium	GR2.4	1.10.1995Basic TV	TELEVISION
21PT5302/00	710121i (20v) stereo medium	MD1.2E	1.01.1997Basic TV	TELEVISION
21PT5302/15	710121i (20v) stereo medium	MD1.2E	1.01.1997Basic TV	TELEVISION
21PT5304/00R	710121i (20v) stereo medium	A8.0E	1.02.1999Basic TV	TELEVISION
21PT5305/00	700121i (20v) stereo medium	L9.1E	1.06.2000Basic TV	TELEVISION
21PT5305/01	700121i (20v) stereo medium	L9.1E	1.06.2000Basic TV	TELEVISION
21PT5305/58	700121i (20v) stereo medium	L9.1E	Basic TV	TELEVISION
21PT5306/01	21i (20v) stereo medium			TELEVISION
21PT530A/00	710125i stereo large 50Hz	GR2.2	1.11.1993Basic TV	TELEVISION
21PT530A/06	710125i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
21PT530A/15	710125i stereo large 50Hz	GR2.2	1.01.1994Basic TV	TELEVISION
21PT530A/19	710125i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
21PT530A/42	710125i stereo large 50Hz	GR2.2	1.05.1994Basic TV	TELEVISION
21PT530B/00	710125i stereo large 50Hz	GR2.4	1.01.1995Basic TV	TELEVISION
21PT530B/01	710125i stereo large 50Hz	GR2.4	1.01.1995Basic TV	TELEVISION
21PT530B/15	710125i stereo large 50Hz	GR2.4	1.01.1995Basic TV	TELEVISION
21PT530B/20	710125i stereo large 50Hz	GR2.4	1.03.1995Basic TV	TELEVISION
21PT530B/21	710125i stereo large 50Hz	GR2.4	1.06.1995Basic TV	TELEVISION
21PT530B/35	710125i stereo large 50Hz	GR2.4	1.03.1995Basic TV	TELEVISION
21PT530B/42	710125i stereo large 50Hz	GR2.4	1.02.1995Basic TV	TELEVISION
21PT530B/58	710125i stereo large 50Hz	GR2.4	1.06.1995Basic TV	TELEVISION
21PT5321/01	710121i (20v) stereo medium	GR2.4	1.09.1995Basic TV	TELEVISION
21PT5321/05	710121i (20v) stereo medium	GR2.4	1.10.1995Basic TV	TELEVISION

21PT5321/11	710120i (19i) stereo medium	GR2.4	1.10.1995Basic TV	TELEVISION
21PT5321/13	710121i (20v) stereo medium	GR2.4	1.10.1995Basic TV	TELEVISION
21PT5322/01	710121i (20v) stereo medium	MD1.2E	1.01.1997Basic TV	TELEVISION
21PT5322/05	710121i (20v) stereo medium	MD1.2E	1.01.1997Basic TV	TELEVISION
21PT5322/16	710121i (20v) stereo medium	MD1.2E	1.01.1997Basic TV	TELEVISION
21PT5324/01R	710121i (20v) stereo medium	A8.0E	1.02.1999Basic TV	TELEVISION
21PT5324/05R	710121i (20v) stereo medium	A8.0E	Basic TV	TELEVISION
21PT5324/58R	710121i (20v) stereo medium	A8.0E	1.04.1999Basic TV	TELEVISION
21PT532A/05	710125i stereo large 50Hz	GR2.2	1.02.1994Basic TV	TELEVISION
21PT532A/11	710125i stereo large 50Hz	GR2.2	1.01.1994Basic TV	TELEVISION
21PT532A/13	710125i stereo large 50Hz	GR2.2	1.01.1994Basic TV	TELEVISION
21PT532A/16	710125i stereo large 50Hz	GR2.2	1.03.1994Basic TV	TELEVISION
21PT532B/05	710120i (19i) stereo medium	GR2.4	1.01.1995Basic TV	TELEVISION
21PT532B/11	710120i (19i) stereo medium	GR2.4	1.01.1995Basic TV	TELEVISION
21PT532B/13	710120i (19i) stereo medium	GR2.4	1.02.1995Basic TV	TELEVISION
21PT532B/19	710120i (19i) stereo medium	GR2.4	1.09.1994Basic TV	TELEVISION
21PT532B/25	710120i (19i) stereo medium	GR2.4	1.03.1995Basic TV	TELEVISION
21PT532B/31	710120i (19i) stereo medium	GR2.4	1.04.1995Basic TV	TELEVISION
21PT532B/33	710120i (19i) stereo medium	GR2.4	1.04.1995Basic TV	TELEVISION
21PT532B/39	710120i (19i) stereo medium	GR2.4	1.03.1995Basic TV	TELEVISION
21PT5405/01	700121i (20v) stereo medium	L9.1E	1.07.2001Basic TV	TELEVISION
21PT5406/00	700121i (20v) stereo medium	L9.1E	1.09.2001Basic TV	TELEVISION
21PT5406/01	700121i (20v) stereo medium	L9.1E	1.09.2001Basic TV	TELEVISION
21PT5406/05	21i (20v) stereo medium		1.12.2001	TELEVISION
21PT5406/58	700121i (20v) stereo medium	L9.1E	1.09.2001Basic TV	TELEVISION
21PT5505/00	700121i (20v) stereo medium	L9.1E	1.09.2000Basic TV	TELEVISION
21PT5505/00S	700121i (20v) stereo medium	L9.1E	1.07.2001Basic TV	TELEVISION
21PT5505/01	700121i (20v) stereo medium	L9.1E	1.08.2000Basic TV	TELEVISION
21PT5505/01S	700121i (20v) stereo medium	L9.1E	1.07.2001Basic TV	TELEVISION
21PT5505/05	700121i (20v) stereo medium	L9.1E	1.09.2000Basic TV	TELEVISION
21PT5505/05S	700121i (20v) stereo medium	L9.1E	1.07.2001Basic TV	TELEVISION
21PT5505/58	700121i (20v) stereo medium	L9.1E	1.09.2000Basic TV	TELEVISION
21PT5505/58S	700121i (20v) stereo medium	L9.1E	1.09.2001Basic TV	TELEVISION
21PT5506/01	21i (20v) stereo medium			TELEVISION
21PT5506/05	21i (20v) stereo medium			TELEVISION
21PT5506/58	21i (20v) stereo medium			TELEVISION
21PT570A/01	710125i stereo large 50Hz	GR2.2	1.10.1993Basic TV	TELEVISION
21PT700A/00R	720125i stereo large 50Hz	FL1.0	1.03.1993Upmarket TV	TELEVISION
21PT700A/01R	720125i stereo large 50Hz	FL1.0	1.04.1993Upmarket TV	TELEVISION
21PT700A/19R	720125i stereo large 50Hz	FL1.0	1.04.1993Upmarket TV	TELEVISION
21PT700A/20	720125i stereo large 50Hz	FL1.0	1.09.1993Upmarket TV	TELEVISION
21PT700A/21	720125i stereo large 50Hz	FL1.0	1.10.1993Upmarket TV	TELEVISION

21PT700A/39	720125i stereo large 50Hz	FL1.0	1.10.1993Upmarket TV	TELEVISION
21PT701A/00	710125i stereo large 50Hz	GR2.3	1.04.1994Basic TV	TELEVISION
21PT701A/01	710125i stereo large 50Hz	GR2.3	1.06.1994Basic TV	TELEVISION
21PT701B/00	710125i stereo large 50Hz	GR2.4	1.01.1995Basic TV	TELEVISION
21PT701B/01	710125i stereo large 50Hz	GR2.4	1.03.1995Basic TV	TELEVISION
21PT701C/00	710120i (19i) stereo medium	GR2.4	1.08.1995Basic TV	TELEVISION
21PT702A/12R	720125i stereo large 50Hz	FL*.10	1.04.1993Upmarket TV	TELEVISION
21PT702A/32	720125i stereo large 50Hz	FL*.10	1.10.1993Upmarket TV	TELEVISION
21PT703A/11	710125i stereo large 50Hz	GR2.3	1.05.1994Basic TV	TELEVISION
21PT703B/01	710125i stereo large 50Hz	GR2.4	1.11.1994Basic TV	TELEVISION
21PT703C/01	710121i (20v) stereo medium	GR2.4	1.08.1995Basic TV	TELEVISION
21PTPV4/00R	700120i (19v) mono		1.10.1996	TELEVISION
21PV267/01	1022Step-up	TVCR-B	1.04.1996	TVCR
21PV267/02	1022Step-up	TVCR-B	1.04.1996	TVCR
21PV267/08	1022Step-up	TVCR-B	1.04.1996	TVCR
21PV267/13	1022Step-up	TVCR-B	1.05.1996	TVCR
21PV267/39	1022Step-up	TVCR-B	1.04.1996	TVCR
21PV267/58	1022Step-up	TVCR-B	1.11.1996	TVCR
21PV288/01	1022Step-up	TVCR-B	1.04.1998	TVCR
21PV288/05	1022Step-up	TVCR-B	1.05.1998	TVCR
21PV288/08	1022Step-up	TVCR-B	1.05.1998	TVCR
21PV288/08B	1022High-end	TVCR-B	1.06.1998	TVCR
21PV288/08G	1022Step-up	TVCR-B	1.07.1998	TVCR
21PV288/13	1022Step-up	TVCR-B	1.04.1998	TVCR
21PV288/39	1022Step-up	TVCR-B	1.06.1998	TVCR
21PV288/39S	1022Step-up	TVCR-B	1.03.1999	TVCR
21PV288/58	1022Step-up	TVCR-B	1.04.1998	TVCR
21PV288/58C	1022Step-up	TVCR-B	1.04.1998	TVCR
21PV288FR	1022Step-up	TVCR-B	1.03.1999	TVCR
21PV288SF/R	1022Step-up	TVCR-B	1.04.1999	TVCR
21PV320/01	1022Step-up	TVCR-D	1.07.1999	TVCR
21PV320/05	1022Step-up	TVCR-D	1.07.1999	TVCR
21PV320/39	1022Step-up	TVCR-D	1.08.1999	TVCR
21PV320DE	1022Step-up	TVCR-D	1.08.1999	TVCR
21PV320ES	1022Step-up	TVCR-D	1.07.1999	TVCR
21PV320GR	1022Step-up	TVCR-D	1.08.1999	TVCR
21PV320XE	1022Step-up	TVCR-D	1.07.1999	TVCR
21PV325/39S	1022Step-up	TVCR-D	1.01.2000	TVCR
21PV325/IT	1022Step-up	TVCR-D	1.09.2000	TVCR
21PV330/01	1022Leader	TVCR-D	1.06.2000	TVCR
21PV330/07	1022Leader	TVCR-D	1.05.2000	TVCR
21PV330/39	1022Leader	TVCR-D	1.06.2000	TVCR

21PV330/58	1022Leader	TVCR-D	1.06.2000	TVCR
21PV330/IT	1022Leader	TVCR-D	1.09.2000	TVCR
21PV330DE	1022Leader	TVCR-D	1.06.2000	TVCR
21PV330ES	1022Leader	TVCR-D	1.06.2000	TVCR
21PV330GR	1022Leader	TVCR-D	1.06.2000	TVCR
21PV330XE	1022Leader	TVCR-D	1.06.2000	TVCR
21PV335/01	1022Leader	TVCR-D	1.10.2000	TVCR
21PV335/39	1022Leader	TVCR-D	1.10.2000	TVCR
21PV340/01	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV340/39	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV340/CH	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV340/ES	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV340/GR	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV340/XE	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV355/39	1022Leader	TVCR-D	1.02.2001	TVCR
21PV520/58	1022Step-up	TVCR-D	1.07.1999	TVCR
21PV548/01	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV548/07	1022Step-up	TVCR-E	1.07.2001	TVCR
21PV548/39	1022Step-up	TVCR-E	1.07.2001	TVCR
21PV548/58	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV548/CH	1022Step-up	TVCR-E	1.06.2001	TVCR
21PV548/ES	1022Step-up	TVCR-E	1.09.2001	TVCR
21PV548/XE	Step-up			TVCR
21PV620/07	1022High-end	TVCR-G	1.10.1999	TVCR
21PV620/39	1022High-end	TVCR-G	1.10.1999	TVCR
21PV620/58	1022High-end	TVCR-G		TVCR
21PV620ES	1022High-end	TVCR-G	1.10.1999	TVCR
21PV620FR	1022High-end	TVCR-G	1.10.1999	TVCR
21PV620XE	1022High-end	TVCR-G	1.10.1999	TVCR
21PV677/05	1022High-end	TVCR-B		TVCR
21PV688/05	1022High-end	TVCR-G	1.07.1998	TVCR
21PV688/39	1022High-end	TVCR-G	1.07.1998	TVCR
21PV688/39B	1022High-end	TVCR-G	1.08.1998	TVCR
21PV688/39F	1022High-end	TVCR-G	1.08.1998	TVCR
21PV688/39I	1022High-end	TVCR-G	1.08.1998	TVCR
21PV688/39N	1022High-end	TVCR-G	1.08.1998	TVCR
21PV688FR	1022High-end	TVCR-G	1.03.1999	TVCR
21PV700/07	1022High-end			TVCR
21PV700/39	1022High-end			TVCR
21PV700DE	1022High-end			TVCR
21PV700ES	1022High-end			TVCR
21PV700FR	1022High-end			TVCR

21PV700GR	1022High-end			TVCR
21PV700XE	1022High-end			TVCR
21PV708/07	1022High-end	TVCR-D	1.06.2000	TVCR
21PV708/39	1022High-end	TVCR-D	1.06.2000	TVCR
21PV708/EE	1022High-end	TVCR-D	1.12.2000	TVCR
21PV708/IT	1022High-end	TVCR-D	1.10.2000	TVCR
21PV708DE	1022High-end	TVCR-D	1.06.2000	TVCR
21PV708ES	1022High-end	TVCR-D	1.06.2000	TVCR
21PV708FR	1022High-end	TVCR-D	1.07.2000	TVCR
21PV708GR	1022High-end	TVCR-D	1.09.2000	TVCR
21PV708XE	1022High-end	TVCR-D	1.07.2000	TVCR
21PV715/07	1022High-end	TVCR-D	1.07.2001	TVCR
21PV715/39	1022High-end	TVCR-D	1.07.2001	TVCR
21PV715/EE	1022High-end	TVCR-D	1.07.2001	TVCR
21PV715/ES	1022High-end	TVCR-D	1.07.2001	TVCR
21PV715/FR	1022High-end	TVCR-D	1.07.2001	TVCR
21PV715/XE	1022High-end	TVCR-D	1.09.2001	TVCR
21PV805/58	High-end			TVCR
21PV808/58	High-end			TVCR
21PV908/07	1022High-end	TVCR-D	1.05.2001	TVCR
21PV908/39	1022High-end	TVCR-D	1.05.2001	TVCR
21PV908/EE	1022High-end	TVCR-D	1.06.2001	TVCR
21PV908/ES	1022High-end	TVCR-D	1.06.2001	TVCR
21PV908/FR	1022High-end	TVCR-D	1.05.2001	TVCR
21PV908/GR	1022High-end	TVCR-D	1.06.2001	TVCR
21PV908/XE	1022High-end	TVCR-D	1.05.2001	TVCR
21PV918/EE	High-end			TVCR
21RA01/05	700120i (19v) mono			TELEVISION
21SA01/05	700120i (19i) stereo medium	L9.2E	Basic TV	TELEVISION
21SL5100/00B	720125i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
21SL5101/00B	720125i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
21SL5101/10B	720125i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
21SL5101/19B	720125i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
21SL5750/00B	720125i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
21SL5750/02B	720125i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
21SL5756/00B	720125i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
21SL5756/10B	720125i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
21SL5756/16B	720125i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
21SL5756/19B	720125i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
21ST1636/39B	710125i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
21ST1730/10B	710125i stereo large 50Hz	GR2.1	1.11.1992Basic TV	TELEVISION
21ST1730/22B	710125i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION

21ST1730/25B	710125i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
21ST1730/28B	710125i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
21ST1730/30B	710125i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
21ST1730/32B	710125i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
21ST1730/33B	710125i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
21ST1730/36B	710125i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
21ST2430/02B	710125i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
21ST2430/07B	710125i stereo large 50Hz	GR2.2	1.06.1993Basic TV	TELEVISION
21ST2430/08B	710125i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
21ST2430/10B	710125i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
21ST2430/12B	710125i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
21ST2430/13B	710125i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
21ST2436/10B	710125i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
21ST2436/42B	710125i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
21ST2636/19B	710125i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
21ST2637/19B	710125i stereo large 50Hz	GR2.2	1.04.1992Basic TV	TELEVISION
21ST2637/42B	710125i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
21ST2730/05B	710125i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
21ST2730/08B	710125i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
21ST2730/10B	710125i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
21ST2730/12B	710125i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
21ST2730/13B	710125i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
21ST2730/16B	710125i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
21ST2731/02B	710125i stereo large 50Hz	GR2.2	1.04.1992Basic TV	TELEVISION
21ST2731/05B	710125i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
21ST2731/07B	710125i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
21ST2731/08B	710125i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
21ST2731/10B	710125i stereo large 50Hz	GR2.2	1.04.1992Basic TV	TELEVISION
21ST2731/12B	710125i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
21ST2731/13B	710125i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
21ST2731/16B	710125i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
21ST2737/10B	710125i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
21ST2737/42B	710125i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
21ST2737/43	710125i stereo large 50Hz	GR2.2	1.03.1994Basic TV	TELEVISION
21ST2931/10B	710125i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
21ST2937/19B	710125i stereo large 50Hz	GR2.2	1.10.1992Basic TV	TELEVISION
21TA01/05	700120i (19v) mono			TELEVISION
21TCDI30/00	700121i Multimedia	ANUBIS_A	1.02.1995Basic TV	TELEVISION
21TCDI30/01	700121i Multimedia	ANUBIS_A	1.03.1995Basic TV	TELEVISION
21VR3213/99	1021Leader		1.03.1992	VCR
21VR6695/99	1021Leader		1.03.1992	VCR
22AV1221/00	Others ITV			INSTITUTIONAL TV

22MS055T/,,	2010			OBSERVATION SYSTEMS
22MS405T/,,	2010	VM4		OBSERVATION SYSTEMS
22MS605R/,,	2010			OBSERVATION SYSTEMS
22MS645R/,,	2010			OBSERVATION SYSTEMS
22MS850R/,,	2010	VM8		OBSERVATION SYSTEMS
22MS855R/,,	2010	VM8		OBSERVATION SYSTEMS
23AJ1310/99	1041Clock radio		1.06.1993	CLOCKRADIO
23AJ1310/99W	1041Clock radio		1.02.1994	CLOCKRADIO
23AJ1320/99	1041Clock radio		1.05.1994	CLOCKRADIO
23AJ3044/99	1041Clock radio		1.09.1993	CLOCKRADIO
23AS129/99	1041Clock radio		1.06.1993	CLOCKRADIO
23AZ8325/99	1042Single deck		1.09.1993	RADIORECORDERS + CD
23DV1/01	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
23DV1/02	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
23DV1/06	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
23DV1/08	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
23DV1/16	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
24CE3070/16B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
24DV1/01	1021Leader	NORA _STN	1.09.1994Standard	VCR
24DV1/02	1021Leader	NORA _STN	1.09.1994Standard	VCR
24DV1/08	1021Leader	NORA _STN	1.11.1994Standard	VCR
24DV19/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
24DV69/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
24PW462A/57R	710224i WS 50Hz no dolby mainstream MD1.0A		1.12.1996Basic TV	TELEVISION
24PW463A/61R	710224i WS 50Hz no dolby mainstream MD1.0A		Basic TV	TELEVISION
24PW469A/69R	710224i WS 50Hz no dolby mainstream MD1.0A		1.12.1996Basic TV	TELEVISION
24PW6005/01	710224i WS 50Hz no dolby mainstream A10E		1.08.2000Basic TV	TELEVISION
24PW6005/05	710224i WS 50Hz no dolby mainstream A10E		1.07.2000Basic TV	TELEVISION
24PW6005/58	700224i WS 50Hz no dolby mainstream			TELEVISION
24PW6006/01	700224i WS 50Hz no dolby mainstream L01.1E		1.07.2001Basic TV	TELEVISION
24PW6006/05	700224i WS 50Hz no dolby mainstream L01.1E		1.09.2001Basic TV	TELEVISION
24PW6301/02	710224i WS 50Hz no dolby mainstream MD1.1E		1.09.1995Basic TV	TELEVISION
24PW6301/03	710224i WS 50Hz no dolby mainstream MD1.1E		1.03.1996Basic TV	TELEVISION
24PW6301/58	710224i WS 50Hz no dolby mainstream MD1.1E		1.01.1996Basic TV	TELEVISION
24PW6302/00	710224i WS 50Hz no dolby mainstream MD1.2E		1.04.1997Basic TV	TELEVISION
24PW6302/58	710224i WS 50Hz no dolby mainstream MD1.2E		Basic TV	TELEVISION
24PW6304/00R	710224i WS 50Hz no dolby mainstream A8.0E		1.07.1999Basic TV	TELEVISION
24PW6321/01	710224i WS 50Hz no dolby mainstream MD1.1E		1.10.1995Basic TV	TELEVISION
24PW6321/05	710224i WS 50Hz no dolby mainstream MD1.1E		1.12.1995Basic TV	TELEVISION
24PW6321/12	710224i WS 50Hz no dolby mainstream MD1.1E		1.11.1995Basic TV	TELEVISION
24PW6321/16	710224i WS 50Hz no dolby mainstream MD1.1E		1.12.1995Basic TV	TELEVISION
24PW6322/01	710224i WS 50Hz no dolby mainstream MD1.2E		1.04.1997Basic TV	TELEVISION

24PW6322/05	710224i WS 50Hz no dolby mainstream MD1.2E	1.02.1998Basic TV	TELEVISION
24PW6322/16	710224i WS 50Hz no dolby mainstream MD1.2E	1.04.1997Basic TV	TELEVISION
24PW6322/58	710224i WS 50Hz no dolby mainstream MD1.2E	1.06.1997Basic TV	TELEVISION
24PW6324/01R	710224i WS 50Hz no dolby mainstream A8.0E	1.06.1999Basic TV	TELEVISION
24PW6324/05R	710224i WS 50Hz no dolby mainstream A8.0E	1.07.1999Basic TV	TELEVISION
24PW6324/11R	710224i WS 50Hz no dolby mainstream A8.0E	Basic TV	TELEVISION
24PW6324/58R	710224i WS 50Hz no dolby mainstream A8.0E	1.07.1999Basic TV	TELEVISION
24PW8504/12	720224i WS 100Hz MG2.1E	1.09.1998Upmarket TV	TELEVISION
24PW8504/19	720224i WS 100Hz MG2.1E	1.10.1998Upmarket TV	TELEVISION
24PW9502/12	720224i WS 100Hz MD2.12E	1.09.1996Upmarket TV	TELEVISION
24PW9502/19	720224i WS 100Hz MD2.12E	1.08.1996Upmarket TV	TELEVISION
24PW9553/12	720224i WS 100Hz MD2.22E	1.07.1997Upmarket TV	TELEVISION
24PW9553/19	720224i WS 100Hz MD2.22E	1.08.1997Upmarket TV	TELEVISION
250571SB/02R	710225i stereo large 50Hz GR2.1	1.03.1992Basic TV	TELEVISION
250571SB/22R	710225i stereo large 50Hz GR2.1	1.03.1992Basic TV	TELEVISION
255231CB/34R	710225i mono GR2.1	1.09.1992Basic TV	TELEVISION
255251CB/16	710225i mono GR2.2	1.11.1993Basic TV	TELEVISION
255831CB/42R	710225i mono GR2.1	1.07.1993Basic TV	TELEVISION
256279IR/22M	710225i stereo large 50Hz G110	1.03.1992Basic TV	TELEVISION
256341SB/22B	710225i stereo large 50Hz GR2.1	1.03.1992Basic TV	TELEVISION
256372SB/02R	710225i stereo large 50Hz GR2.2	1.07.1992Basic TV	TELEVISION
256392SB/02R	710225i stereo large 50Hz GR2.2	1.10.1992Basic TV	TELEVISION
256NS/05	700225i stereo large 50Hz	1.07.1998	TELEVISION
25CE5574/16B	710225i mono 2B	1.03.1992Basic TV	TELEVISION
25CE6269/39B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6269/42B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6270/05B	710225i mono CP110	1.06.1992Basic TV	TELEVISION
25CE6270/07B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6270/10B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6270/15B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6270/16B	710225i mono CP110	1.01.1993Basic TV	TELEVISION
25CE6271/08B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6271/10B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6271/16B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6276/19B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6276/39B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6286/16B	710225i mono CP110	1.06.1992Basic TV	TELEVISION
25CE6287/19B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6570/05B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6570/08B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6570/10B	710225i mono CP110	1.03.1992Basic TV	TELEVISION
25CE6570/13B	710225i mono CP110	1.03.1992Basic TV	TELEVISION

25CE6570/16B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
25CE6570/22B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
25CE6571/10B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
25CE6571/13B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
25CE6571/16B	710225i mono	CP110	1.04.1992Basic TV	TELEVISION
25CE6578/42B	710225i mono	CP110	1.06.1992Basic TV	TELEVISION
25CT8880/50Z	710225i mono	2B-S	1.04.1992Basic TV	TELEVISION
25CT9475/73R	700225i mono		1.05.1993	TELEVISION
25CT9475L/73R	700225i mono		1.03.1992	TELEVISION
25CT9975/73R	700225i mono		1.06.1993	TELEVISION
25CT9975L/73R	700225i mono		1.03.1992	TELEVISION
25DC2060/20R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2060/32R	720225i stereo large 100Hz	D16	1.04.1992Upmarket TV	TELEVISION
25DC2060/39R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2065/00R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2065/16R	720225i stereo large 100Hz	D16	1.06.1992Upmarket TV	TELEVISION
25DC2065/20R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2065/33R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2065/39R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2065/49R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2660/00R	720225i stereo large 50Hz	D16	1.06.1992Upmarket TV	TELEVISION
25DC2660/20R	720225i stereo large 50Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2660/21R	720225i stereo large 50Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2660/32R	720225i stereo large 50Hz	D16	1.04.1992Upmarket TV	TELEVISION
25DC2660/36R	720225i stereo large 50Hz	D16	1.03.1992Upmarket TV	TELEVISION
25DC2660/39R	720225i stereo large 50Hz	D16	1.04.1992Upmarket TV	TELEVISION
25DV20/05	1021Leader show view			VCR
25DV20/39	1021Leader show view	APOLLO12	1.06.2000	VCR
25DV6/39	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
25DV6/39M	1021Leader	OLIVIA_STN	1.02.1996Standard	VCR
25DV7/39	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
25DV9/39	1021Leader show view	APOLLO11	1.08.1999	VCR
25ET2764/05Z	700225i stereo large 50Hz		1.11.1992	TELEVISION
25FL1760/56R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
25FL1760/57R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
25FL1760/75R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
25FL1760/79R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
25GR1990/50R	710225i mono	G110-S	1.04.1992Basic TV	TELEVISION
25GR5560/25B	710225i mono	G110	1.10.1993Basic TV	TELEVISION
25GR5660L/80	700225i mono		1.03.1992	TELEVISION
25GR5711/02Z	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
25GR5711/22Z	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION

25GR5721/02B	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
25GR5721/10B	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
25GR5721/13B	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
25GR5721/22B	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
25GR5762/25B	710225i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
25GR5763/33B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR5764/05B	710225i stereo large 50Hz	G110	1.06.1992Basic TV	TELEVISION
25GR5764/30B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR5764/33B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR5765/30B	710225i stereo large 50Hz	G110	Basic TV	TELEVISION
25GR5964/10B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR5964/16B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR5964/33B	710225i stereo large 50Hz	G110	1.05.1992Basic TV	TELEVISION
25GR6765/50R	710225i mono	G110-S	1.04.1992Basic TV	TELEVISION
25GR6765/75R	710225i mono	G110-S	1.08.1992Basic TV	TELEVISION
25GR6766/56H	710225i mono	G110-S	1.07.1992Basic TV	TELEVISION
25GR6766/56R	710225i mono	G110-S	1.03.1992Basic TV	TELEVISION
25GR6766/65R	710225i mono	G110-S	1.03.1992Basic TV	TELEVISION
25GR6766/75R	710225i mono	G110-S	1.05.1992Basic TV	TELEVISION
25GR6770/58R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6770/62R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6770/69R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6770/75R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6771/56R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6771/56S	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6771/57R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6771/75R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6771/79R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
25GR6771/93R	710225i stereo large 50Hz	G111-S	1.03.1994Basic TV	TELEVISION
25GR9660/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9660/30B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9660/36B	710225i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
25GR9666/39B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9667/39B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9760/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9760/28B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9760/30B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9760/42B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9761/22B	700225i stereo large 50Hz	GR1AX	1.04.1992Basic TV	TELEVISION
25GR9762/25B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9762/36B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9763/25B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION

25GR9763/33B	710225i stereo large 50Hz	G110	1.05.1992Basic TV	TELEVISION
25GR9763/36B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9765/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9765/30B	710225i stereo large 50Hz	G110	1.05.1992Basic TV	TELEVISION
25GR9867/19B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9960/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9960/30B	710225i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
25GR9963/13W	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9963/32B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9963/33B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GR9975/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
25GX1880/57R	700225i stereo large 50Hz	ANUBIS_S	1.04.1994Basic TV	TELEVISION
25GX1880/57T	700225i stereo large 50Hz	ANUBIS_S	1.11.1994Basic TV	TELEVISION
25GX1880/67R	700225i stereo large 50Hz	ANUBIS_S	1.10.1994Basic TV	TELEVISION
25GX1880/73R	700225i stereo large 50Hz	ANUBIS_S	1.12.1994Basic TV	TELEVISION
25GX1880/73T	700225i stereo large 50Hz	ANUBIS_S	1.07.1995Basic TV	TELEVISION
25GX1880/75R	700225i stereo large 50Hz	ANUBIS_S	1.04.1994Basic TV	TELEVISION
25GX1881/00R	700225i stereo large 50Hz	ANUBIS_S	1.10.1996Basic TV	TELEVISION
25GX1881/56H	700225i stereo large 50Hz	ANUBIS_S	1.06.1995Basic TV	TELEVISION
25GX1881/56R	700225i stereo large 50Hz	ANUBIS_S	1.05.1994Basic TV	TELEVISION
25GX1881/58H	700225i stereo large 50Hz	ANUBIS_S	1.08.1994Basic TV	TELEVISION
25GX1881/58R	700225i stereo large 50Hz	ANUBIS_S	1.06.1994Basic TV	TELEVISION
25GX1881/59R	700225i stereo large 50Hz	ANUBIS_S	1.02.1995Basic TV	TELEVISION
25GX1881/67R	700225i stereo large 50Hz	ANUBIS_S	1.10.1994Basic TV	TELEVISION
25GX1881/69R	700225i stereo large 50Hz	ANUBIS_S	1.05.1995Basic TV	TELEVISION
25GX1881/75R	700225i stereo large 50Hz	ANUBIS_S	1.02.1995Basic TV	TELEVISION
25GX1882/54R	700225i stereo large 50Hz	ANUBIS_S	1.08.1994Basic TV	TELEVISION
25GX1882/54T	700225i stereo large 50Hz	ANUBIS_S	1.03.1996Basic TV	TELEVISION
25GX1882/71R	700225i stereo large 50Hz	ANUBIS_S	1.07.1994Basic TV	TELEVISION
25GX1882/77B	700225i stereo large 50Hz	ANUBIS_S	1.06.1996Basic TV	TELEVISION
25GX1882/97R	700225i stereo large 50Hz	ANUBIS_S	1.07.1994Basic TV	TELEVISION
25GX1882/97T	700225i stereo large 50Hz	ANUBIS_S	1.12.1994Basic TV	TELEVISION
25GX1885/57R	700225i stereo large 50Hz	ANUBIS_S	1.10.1995Basic TV	TELEVISION
25GX1885/73R	700225i stereo large 50Hz	ANUBIS_S	Basic TV	TELEVISION
25GX1885/75R	700225i stereo large 50Hz	ANUBIS_S	1.10.1995Basic TV	TELEVISION
25GX1886/00R	700225i stereo large 50Hz	ANUBIS_S	1.10.1996Basic TV	TELEVISION
25GX1886/56H	700225i stereo large 50Hz	ANUBIS_S	1.11.1995Basic TV	TELEVISION
25GX1886/58H	700225i stereo large 50Hz	ANUBIS_S	1.02.1996Basic TV	TELEVISION
25GX1886/58R	700225i stereo large 50Hz	ANUBIS_S	1.10.1995Basic TV	TELEVISION
25GX1886/59R	700225i stereo large 50Hz	ANUBIS_S	1.03.1996Basic TV	TELEVISION
25GX1886/75R	700225i stereo large 50Hz	ANUBIS_S	1.09.1995Basic TV	TELEVISION
25GX1886/75Z	700225i stereo large 50Hz	ANUBIS_S	1.03.1996Basic TV	TELEVISION

25GX1887/71R	700225i stereo large 50Hz	ANUBIS_S	1.11.1995Basic TV	TELEVISION
25GX1887/97R	700225i stereo large 50Hz	ANUBIS_S	1.03.1996Basic TV	TELEVISION
25GX1888/78R	700225i stereo large 50Hz		1.01.1997	TELEVISION
25GX1889/78R	700225i stereo large 50Hz			TELEVISION
25GX1980/58R	700225i stereo large 50Hz	ANUBIS_S	1.08.1994Basic TV	TELEVISION
25GX1980/69E	700225i stereo large 50Hz	ANUBIS_S	1.11.1995Basic TV	TELEVISION
25GX1980/69R	700225i stereo large 50Hz	ANUBIS_S	1.03.1994Basic TV	TELEVISION
25GX1980/69T	700225i stereo large 50Hz	ANUBIS_S	1.08.1994Basic TV	TELEVISION
25GX1980/69Z	700225i stereo large 50Hz	ANUBIS_S	1.10.1995Basic TV	TELEVISION
25GX1980/75R	700225i stereo large 50Hz	ANUBIS_S	1.07.1994Basic TV	TELEVISION
25GX1980/79R	700225i stereo large 50Hz	ANUBIS_S	1.07.1994Basic TV	TELEVISION
25GX1985/69R	700225i stereo large 50Hz	ANUBIS_S	1.12.1995Basic TV	TELEVISION
25GX1985/79R	700225i stereo large 50Hz	ANUBIS_S	1.07.1995Basic TV	TELEVISION
25HT2212/69R	201321i (20v) Stereo ITV	L01H.1A	1.11.2001Institutional TV	INSTITUTIONAL TV
25HT2217/69Y	25i (25v) Stereo ITV			INSTITUTIONAL TV
25HT2217/79Y	25i (25v) Stereo ITV			INSTITUTIONAL TV
25HT3352/21P	201325i (25v) mono ITV	AA5H.1	1.01.1997Institutional TV	INSTITUTIONAL TV
25HT3352/41Z	201325i (25v) mono ITV	AA5H.1	1.07.1998Institutional TV	INSTITUTIONAL TV
25HT3352/61P	201325i (25v) mono ITV	AA5H.1	1.06.1998Institutional TV	INSTITUTIONAL TV
25HT3352/67P	201325i (25v) mono ITV	AA5H.1	1.03.1999Institutional TV	INSTITUTIONAL TV
25HT3352/88P	201325i (25v) mono ITV	AA5H.1	1.06.1998Institutional TV	INSTITUTIONAL TV
25HT3402/41Z	201325i (25v) mono ITV	A7H.1	1.07.1998Institutional TV	INSTITUTIONAL TV
25HT3402/47Z	201325i (25v) mono ITV	A7H.1	1.07.1999Institutional TV	INSTITUTIONAL TV
25HT3402/61R	201325i (25v) mono ITV	A7H.1	1.12.1998Institutional TV	INSTITUTIONAL TV
25HT3402/67R	201325i (25v) mono ITV	A7H.1	1.05.1999Institutional TV	INSTITUTIONAL TV
25HT4672/69R	201325i (25v) Stereo ITV	L9H.1A	1.09.1999Institutional TV	INSTITUTIONAL TV
25HT4672/71R	201325i (25v) Stereo ITV	L9H.1A	1.07.2001Institutional TV	INSTITUTIONAL TV
25HT4672/79R	201325i (25v) Stereo ITV	L9H.1A	1.12.1999Institutional TV	INSTITUTIONAL TV
25HT4672/94R	201325i (25v) Stereo ITV	L9H.1A	Institutional TV	INSTITUTIONAL TV
25HT4677/57Y	201325i (25v) Stereo ITV	L9H.1A	1.11.1999Institutional TV	INSTITUTIONAL TV
25HT4677/69Y	201325i (25v) Stereo ITV	L9H.1A	1.11.1999Institutional TV	INSTITUTIONAL TV
25HT4677/79Y	201325i (25v) Stereo ITV	L9H.1A	1.08.2000Institutional TV	INSTITUTIONAL TV
25HT4677/94Y	201325i (25v) Stereo ITV	L9H.1A	Institutional TV	INSTITUTIONAL TV
25HT4822/71Z	201325i (25v) Stereo ITV	L9H.1A	1.11.1999Institutional TV	INSTITUTIONAL TV
25HT5403/01Z	201325i (25v) Stereo ITV	L9H.1E	1.12.1999Institutional TV	INSTITUTIONAL TV
25HT5403/05Z	201325i (25v) Stereo ITV	L9H.1E	1.07.2001Institutional TV	INSTITUTIONAL TV
25HT5403/21R	201325i (25v) Stereo ITV	L9H.1E	1.06.2000Institutional TV	INSTITUTIONAL TV
25HT5403/25R	201325i (25v) Stereo ITV		1.07.2001	INSTITUTIONAL TV
25HT5403/58Z	201325i (25v) Stereo ITV	L9H.1E	1.05.2001Institutional TV	INSTITUTIONAL TV
25HT5403/78R	201325i (25v) Stereo ITV	L9H.1E	1.09.2001Institutional TV	INSTITUTIONAL TV
25HT5404/01Z	25i (25v) Stereo ITV			INSTITUTIONAL TV
25HT5404/05Z	25i (25v) Stereo ITV			INSTITUTIONAL TV

25HT5404/21R	25i (25v) Stereo ITV			INSTITUTIONAL TV
25HT5404/25R	25i (25v) Stereo ITV			INSTITUTIONAL TV
25HT5423/21R	201325i (25v) Stereo ITV	L9H.1E	1.10.2001	Institutional TV
25HT5423/25R	25i (25v) Stereo ITV			INSTITUTIONAL TV
25MK2480/56H	710225i mono	MK2	1.04.1992	Basic TV
25MK2480/73	710225i mono	MK2	1.05.1993	Basic TV
25MK2480/73R	710225i mono	MK2	1.09.1992	Basic TV
25MK2480/79R	710225i mono	MK2	1.04.1992	Basic TV
25MK2480L/73	700225i mono		1.07.1992	
25MK2780/58R	710225i mono	MK2	1.04.1992	Basic TV
25MK2780/62R	710225i mono	MK2	1.05.1992	Basic TV
25MK2780/79R	710225i mono	MK2	1.06.1993	Basic TV
25ML8300/00B	720225i stereo large 100Hz	FL1.7	1.09.1992	Upmarket TV
25ML8300/05B	720225i stereo large 100Hz	FL1.7	1.09.1992	Upmarket TV
25ML8300/13B	720225i stereo large 100Hz	FL1.7	1.11.1992	Upmarket TV
25ML8300/19B	720225i stereo large 100Hz	FL1.7	1.09.1992	Upmarket TV
25ML8305/00B	720225i stereo large 100Hz	FL1.7	1.09.1992	Upmarket TV
25ML8305/10B	720225i stereo large 100Hz	FL1.7	1.09.1992	Upmarket TV
25ML8305/19B	720225i stereo large 100Hz	FL1.7	1.09.1992	Upmarket TV
25ML8500/02B	720225i stereo large 100Hz	FL1.6	1.06.1992	Upmarket TV
25ML8500/05B	720225i stereo large 100Hz	FL1.6	1.07.1992	Upmarket TV
25ML8500/08B	720225i stereo large 100Hz	FL1.6	1.09.1992	Upmarket TV
25ML8500/19B	720225i stereo large 100Hz	FL1.6	1.06.1992	Upmarket TV
25ML8505/00B	720225i stereo large 100Hz	FL1.6	1.05.1992	Upmarket TV
25ML8505/02B	720225i stereo large 100Hz	FL1.6	1.06.1992	Upmarket TV
25ML8505/06B	720225i stereo large 100Hz	FL1.6	1.06.1992	Upmarket TV
25ML8505/07B	720225i stereo large 100Hz	FL1.6	1.09.1992	Upmarket TV
25ML8505/08B	720225i stereo large 100Hz	FL1.6	1.09.1992	Upmarket TV
25ML8505/10B	720225i stereo large 100Hz	FL1.6	1.06.1992	Upmarket TV
25ML8505/13B	720225i stereo large 100Hz	FL1.6	1.08.1992	Upmarket TV
25ML8505/16B	720225i stereo large 100Hz	FL1.6	1.07.1992	Upmarket TV
25ML8505/36B	720225i stereo large 100Hz	FL1.6	1.10.1993	Upmarket TV
25ML8760/05B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV
25ML8766/00B	720225i stereo large 100Hz	FL1.7	1.04.1992	Upmarket TV
25ML8766/02B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV
25ML8766/08B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV
25ML8766/19B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV
25ML8966/00B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV
25ML8966/02B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV
25ML8966/06B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV
25ML8966/07B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV
25ML8966/08B	720225i stereo large 100Hz	FL1.7	1.03.1992	Upmarket TV

25ML8966/10B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
25ML8966/13B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
25ML8966/16B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
25ML8966/19B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
25MN1350/10B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
25MN1350/30B	710225i mono	GR2.1	1.05.1992Basic TV	TELEVISION
25MN1353/28B	710225i mono	GR2.2	1.09.1992Basic TV	TELEVISION
25MN1353/30B	710225i mono	GR2.2	1.03.1993Basic TV	TELEVISION
25MN1353/36B	710225i mono	GR2.2	1.10.1992Basic TV	TELEVISION
25MN1355/39B	710225i mono	GR2.2	1.06.1992Basic TV	TELEVISION
25MN1355/40B	710225i mono	GR2.2	1.05.1993Basic TV	TELEVISION
25MN1356/15B	710225i mono	GR2.1	1.05.1992Basic TV	TELEVISION
25MN1356/19B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
25MN1356/39B	710225i mono	GR2.1	1.05.1992Basic TV	TELEVISION
25MN1356/42B	710225i mono	GR2.1	1.05.1992Basic TV	TELEVISION
25MN1550/02B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
25MN1550/05B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
25MN1550/07B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
25MN1550/08B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
25MN1550/10B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
25MN1550/16B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
25MN1550/22B	710225i mono	GR2.1	1.06.1992Basic TV	TELEVISION
25MN1550/25B	710225i mono	GR2.1	1.06.1992Basic TV	TELEVISION
25MN1550/27B	710225i mono	GR2.1	1.09.1992Basic TV	TELEVISION
25MN1550/28B	710225i mono	GR2.1	1.09.1992Basic TV	TELEVISION
25MN1550/30B	710225i mono	GR2.1	1.05.1992Basic TV	TELEVISION
25MN1550/33B	710225i mono	GR2.1	1.04.1992Basic TV	TELEVISION
25MN1550/36B	710225i mono	GR2.1	1.06.1992Basic TV	TELEVISION
25MN1553/30B	710225i mono	GR2.2	1.08.1992Basic TV	TELEVISION
25MN1553/33B	710225i mono	GR2.2	1.08.1992Basic TV	TELEVISION
25PT2152/56A	25i stereo large 50Hz			TELEVISION
25PT2152/69R	25i stereo large 50Hz			TELEVISION
25PT2152/71R	25i stereo large 50Hz			TELEVISION
25PT2152/79R	25i stereo large 50Hz			TELEVISION
25PT2252/56A	700225i stereo large 50Hz	L01.1A	1.10.2001Basic TV	TELEVISION
25PT2252/57R	700225i stereo large 50Hz	L01.1A	1.09.2001Basic TV	TELEVISION
25PT2252/68R	700225i stereo large 50Hz	L01.1A	1.09.2001Basic TV	TELEVISION
25PT2252/69R	700225i stereo large 50Hz	L01.1A	1.10.2001Basic TV	TELEVISION
25PT2252/79R	700225i stereo large 50Hz	L01.1A	1.11.2001Basic TV	TELEVISION
25PT4001/01	700225i mono	AA5	1.02.1996Basic TV	TELEVISION
25PT4001/15	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
25PT4001/39	700225i mono	AA5	1.03.1996Basic TV	TELEVISION

25PT4001/58	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
25PT400A/00	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT400A/15	710225i mono	GR2.2	1.04.1994Basic TV	TELEVISION
25PT400A/16	710225i mono	GR2.2	1.12.1994Basic TV	TELEVISION
25PT400A/42	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT4051/01	700225i mono	AA5	1.11.1995Basic TV	TELEVISION
25PT405A/00	710225i mono	GR2.2	1.10.1994Basic TV	TELEVISION
25PT405A/19	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT4101/00	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
25PT4101/05	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
25PT4101/07	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
25PT4101/13	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
25PT4101/58	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
25PT4101/58P	700225i mono	AA5	1.07.1996Basic TV	TELEVISION
25PT4103/00	700225i mono	L6.2	1.06.1997Basic TV	TELEVISION
25PT4103/01	700225i mono	L6.2	1.06.1997Basic TV	TELEVISION
25PT4103/05	700225i mono	L6.2	1.07.1997Basic TV	TELEVISION
25PT4103/07	700225i mono	L6.2	1.07.1997Basic TV	TELEVISION
25PT4103/15	700225i mono	L6.2	1.12.1998Basic TV	TELEVISION
25PT4103/39	700225i mono	L6.2	1.07.1997Basic TV	TELEVISION
25PT4103/58	700225i mono	L6.2	1.08.1997Basic TV	TELEVISION
25PT4103/58H	700225i mono	L6.2	Basic TV	TELEVISION
25PT4103/58P	700225i mono	L6.2	1.04.1998Basic TV	TELEVISION
25PT4103/60	700225i mono	L6.2	1.09.1997Basic TV	TELEVISION
25PT4104/58	700225i mono	L9.1E	1.09.1999Basic TV	TELEVISION
25PT410A/00	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT410A/05	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT410A/07	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT410A/13	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT410A/16	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT410A/42	710225i mono	GR2.2	1.10.1994Basic TV	TELEVISION
25PT4151/00	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
25PT420A/00	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT420A/16	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
25PT420A/19	710225i mono	GR2.2	1.04.1994Basic TV	TELEVISION
25PT4223/59C	700225i stereo large 50Hz	L9.1A	1.10.1999Basic TV	TELEVISION
25PT4273/75T	700225i stereo large 50Hz	L9.1A	1.09.1999Basic TV	TELEVISION
25PT4275/00	700225i stereo large 50Hz	L9.1E	1.07.2000Basic TV	TELEVISION
25PT4275/01	700225i stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
25PT4275/21	700225i stereo large 50Hz	L9.1E	1.09.2000Basic TV	TELEVISION
25PT4301/02	710225i stereo large 50Hz	MD1.1E	1.12.1995Basic TV	TELEVISION
25PT4301/22	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION

25PT4323/11	700225i stereo large 50Hz	L6.2	1.07.1997Basic TV	TELEVISION
25PT4342/59C	700225i stereo large 50Hz	L9.1A	1.12.2000Basic TV	TELEVISION
25PT4342/75R	700225i stereo large 50Hz	L9.1A	1.09.2000Basic TV	TELEVISION
25PT4375/01	700225i stereo large 50Hz	L9.1E	Basic TV	TELEVISION
25PT4401/00	710225i stereo large 50Hz	MD1.1E	1.03.1996Basic TV	TELEVISION
25PT4403/00	700225i stereo large 50Hz	L6.2	1.09.1997Basic TV	TELEVISION
25PT4403/43	700225i stereo large 50Hz	L6.2	1.09.1997Basic TV	TELEVISION
25PT440A/00	710225i stereo large 50Hz	GR2.2	1.03.1995Basic TV	TELEVISION
25PT440A/20	710225i stereo large 50Hz	GR2.2	1.05.1995Basic TV	TELEVISION
25PT440A/58	710225i stereo large 50Hz	GR2.2	1.06.1995Basic TV	TELEVISION
25PT4421/13	710225i stereo large 50Hz	MD1.1E	1.03.1996Basic TV	TELEVISION
25PT4421/16	710225i stereo large 50Hz	MD1.1E	1.03.1996Basic TV	TELEVISION
25PT4423/11	700225i stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
25PT4423/58	700225i stereo large 50Hz	L6.2	1.10.1997Basic TV	TELEVISION
25PT4423/58P	700225i stereo large 50Hz	L6.2	1.04.1998Basic TV	TELEVISION
25PT4426/01	25i stereo large 50Hz			TELEVISION
25PT4428/68R	700225i stereo large 50Hz	L7.3A	1.07.1998Basic TV	TELEVISION
25PT442A/13	710225i stereo large 50Hz	GR2.2	1.04.1995Basic TV	TELEVISION
25PT442A/16	710225i stereo large 50Hz	GR2.2	1.03.1995Basic TV	TELEVISION
25PT442A/33	710225i stereo large 50Hz	GR2.2	1.05.1995Basic TV	TELEVISION
25PT442A/36	710225i stereo large 50Hz	GR2.2	1.06.1995Basic TV	TELEVISION
25PT443A/01	710225i stereo large 50Hz	GR2.4	1.03.1995Basic TV	TELEVISION
25PT4454/00	700225i stereo large 50Hz	L6.3	1.09.1998Basic TV	TELEVISION
25PT4455/00	700225i stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
25PT4455/20	700225i stereo large 50Hz	L9.1E	1.03.2000Basic TV	TELEVISION
25PT4456/00	700225i stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
25PT4456/01	700225i stereo large 50Hz	L9.1E	1.07.2001Basic TV	TELEVISION
25PT4456/05	700225i stereo large 50Hz	L9.1E	1.07.2001Basic TV	TELEVISION
25PT4456/20	700225i stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
25PT4456/21	700225i stereo large 50Hz	L9.1E	1.09.2001Basic TV	TELEVISION
25PT4456/25	700225i stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
25PT4456/48	700225i stereo large 50Hz	L9.1E	1.10.2001Basic TV	TELEVISION
25PT4456/58	700225i stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
25PT4457/01	25i stereo large 50Hz			TELEVISION
25PT4457/05	25i stereo large 50Hz			TELEVISION
25PT4457/58	25i stereo large 50Hz			TELEVISION
25PT4473/69R	700225i stereo large 50Hz	L7.3A	1.06.1998Basic TV	TELEVISION
25PT4473/69T	700225i mono	L7.3A	1.03.1999Basic TV	TELEVISION
25PT4473/75R	700225i stereo large 50Hz	L7.3A	1.07.1998Basic TV	TELEVISION
25PT4473/75T	700225i mono	L7.3A	1.05.1999Basic TV	TELEVISION
25PT4473/79R	700225i stereo large 50Hz	L7.3A	1.05.1998Basic TV	TELEVISION
25PT4475/01	700225i stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION

25PT4475/05	700225i stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
25PT4475/21	700225i stereo large 50Hz	L9.1E	1.09.2000Basic TV	TELEVISION
25PT4475/48	700225i stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
25PT4475/58	700225i stereo large 50Hz	L9.1E	1.09.1999Basic TV	TELEVISION
25PT4476/75W	700225i stereo large 50Hz	L9.1A	1.11.1999Basic TV	TELEVISION
25PT4476/75Y	700225i stereo large 50Hz	L9.1A	1.07.1999Basic TV	TELEVISION
25PT448A/56H	710225i stereo large 50Hz	PV4.0	1.03.1997Basic TV	TELEVISION
25PT448A/56R	710225i stereo large 50Hz	PV4.0	1.04.1997Basic TV	TELEVISION
25PT448A/59B	710225i stereo large 50Hz	PV4.0	1.10.1996Basic TV	TELEVISION
25PT448A/59H	710225i stereo large 50Hz	PV4.0	1.05.1997Basic TV	TELEVISION
25PT448A/59R	710225i stereo large 50Hz	PV4.0	1.09.1997Basic TV	TELEVISION
25PT448A/68R	710225i stereo large 50Hz	PV4.0	1.02.1997Basic TV	TELEVISION
25PT448A/75R	710225i stereo large 50Hz	PV4.0	1.10.1996Basic TV	TELEVISION
25PT4494/05	700225i stereo large 50Hz	L6.3	1.09.1998Basic TV	TELEVISION
25PT449A/79R	710225i stereo large 50Hz	PV4.0	1.10.1996Basic TV	TELEVISION
25PT4501/00	710225i stereo large 50Hz	MD1.1E	1.08.1995Basic TV	TELEVISION
25PT4501/03	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
25PT4501/20	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT4501/23	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT4501/43	710225i stereo large 50Hz	MD1.1E	1.01.1996Basic TV	TELEVISION
25PT4501/58	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT4501/58P	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT4501/60	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
25PT4503/00	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT4503/15	710225i stereo large 50Hz	MD1.2E	1.04.1997Basic TV	TELEVISION
25PT4503/20	710225i stereo large 50Hz	MD1.2E	1.12.1997Basic TV	TELEVISION
25PT4503/43	710225i stereo large 50Hz	MD1.2E	1.11.1997Basic TV	TELEVISION
25PT4503/58	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT450A/00	710225i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
25PT450A/06	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT450A/15	710225i stereo large 50Hz	GR2.2	1.03.1994Basic TV	TELEVISION
25PT450A/20	710225i stereo large 50Hz	GR2.2	1.03.1995Basic TV	TELEVISION
25PT450A/42	710225i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
25PT450A/43	710225i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
25PT4511/02	710225i stereo large 50Hz	MD1.1E	1.07.1995Basic TV	TELEVISION
25PT4511/22	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT4512/02	710225i stereo large 50Hz	MD1.1E	1.03.1996Basic TV	TELEVISION
25PT4513/02	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT451A/00	710225i stereo large 50Hz	GR2.2	1.02.1995Basic TV	TELEVISION
25PT451A/20	710225i stereo large 50Hz	GR2.2	1.04.1995Basic TV	TELEVISION
25PT4521/01	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
25PT4521/05	710225i stereo large 50Hz	MD1.1E	1.07.1995Basic TV	TELEVISION

25PT4521/07	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
25PT4521/13	710225i stereo large 50Hz	MD1.1E	1.08.1995Basic TV	TELEVISION
25PT4521/16	710225i stereo large 50Hz	MD1.1E	1.07.1995Basic TV	TELEVISION
25PT4521/19	710225i stereo large 50Hz	MD1.1E	1.08.1995Basic TV	TELEVISION
25PT4521/21	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
25PT4521/25	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
25PT4521/33	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT4521/36	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT4521/38	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT4521/39	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
25PT4523/01	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT4523/05	710225i stereo large 50Hz	MD1.2E	1.04.1997Basic TV	TELEVISION
25PT4523/07	710225i stereo large 50Hz	MD1.2E	1.04.1997Basic TV	TELEVISION
25PT4523/13	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT4523/16	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT4523/21	710225i stereo large 50Hz	MD1.2E	1.11.1997Basic TV	TELEVISION
25PT4523/25	710225i stereo large 50Hz	MD1.2E	1.12.1997Basic TV	TELEVISION
25PT4523/33	710225i stereo large 50Hz	MD1.2E	1.12.1997Basic TV	TELEVISION
25PT4523/36	710225i stereo large 50Hz	MD1.2E	1.11.1997Basic TV	TELEVISION
25PT4523/58	710225i stereo large 50Hz	MD1.2E	1.05.1997Basic TV	TELEVISION
25PT4524/01R	710225i stereo large 50Hz	A8.0E	Basic TV	TELEVISION
25PT4524/05R	710225i stereo large 50Hz	A8.0E	Basic TV	TELEVISION
25PT4524/58R	710225i stereo large 50Hz	A8.0E	Basic TV	TELEVISION
25PT452A/07	710225i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
25PT452A/11	710225i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
25PT452A/13	710225i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
25PT452A/16	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT452A/36	710225i stereo large 50Hz	GR2.2	1.05.1995Basic TV	TELEVISION
25PT4622/71R	700225i stereo large 50Hz	L7.3A	1.08.1998Basic TV	TELEVISION
25PT4623/56A	700225i stereo large 50Hz	L7.3A	Basic TV	TELEVISION
25PT4623/56R	700225i stereo large 50Hz	L7.3A	1.06.1998Basic TV	TELEVISION
25PT4623/56T	700225i stereo large 50Hz	L7.3A	1.03.1999Basic TV	TELEVISION
25PT4623/57R	700225i stereo large 50Hz	L7.3A	1.07.1998Basic TV	TELEVISION
25PT4623/57T	700225i stereo large 50Hz	L7.3A	1.02.1999Basic TV	TELEVISION
25PT4623/73R	700225i stereo large 50Hz	L7.3A	Basic TV	TELEVISION
25PT462A/68R	710225i stereo large 50Hz	PV4.0	1.02.1997Basic TV	TELEVISION
25PT462A/69R	710225i stereo large 50Hz	PV4.0	1.09.1996Basic TV	TELEVISION
25PT462A/79R	710225i stereo large 50Hz	PV4.0	1.10.1996Basic TV	TELEVISION
25PT4632/71R	700225i stereo large 50Hz	L7.3A	1.06.2001Basic TV	TELEVISION
25PT463A/61R	710225i stereo large 50Hz	PV4.0	Basic TV	TELEVISION
25PT463A/71R	710225i stereo large 50Hz	PV4.0	1.12.1996Basic TV	TELEVISION
25PT4642/56A	700225i stereo large 50Hz	L7.3A	1.12.2000Basic TV	TELEVISION

25PT4642/57R	700225i stereo large 50Hz	L7.3A	1.08.2000Basic TV	TELEVISION
25PT4642/69R	700225i stereo large 50Hz	L7.3A	1.06.2000Basic TV	TELEVISION
25PT4642/79R	700225i stereo large 50Hz	L7.3A	1.08.2000Basic TV	TELEVISION
25PT4654/00	700225i stereo large 50Hz	L6.3	1.09.1998Basic TV	TELEVISION
25PT4655/00	700225i stereo large 50Hz	L9.1E	1.07.1999Basic TV	TELEVISION
25PT4655/20	700225i stereo large 50Hz	L9.1E	1.04.2000Basic TV	TELEVISION
25PT4673/68R	700225i stereo large 50Hz	L7.3A	1.10.1998Basic TV	TELEVISION
25PT4673/69R	700225i stereo large 50Hz	L7.3A	1.06.1998Basic TV	TELEVISION
25PT4673/69T	700225i stereo large 50Hz	L7.3A	1.03.1999Basic TV	TELEVISION
25PT4673/75R	700225i stereo large 50Hz	L7.3A	1.08.1998Basic TV	TELEVISION
25PT4673/79R	700225i stereo large 50Hz	L7.3A	1.05.1998Basic TV	TELEVISION
25PT4673/79T	700225i stereo large 50Hz	L7.3A	1.05.1999Basic TV	TELEVISION
25PT4674/01	700225i stereo large 50Hz			TELEVISION
25PT4674/05	700225i stereo large 50Hz			TELEVISION
25PT4675/01	700225i stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
25PT4675/05	700225i stereo large 50Hz	L9.1E	Basic TV	TELEVISION
25PT4676/69V	700225i stereo large 50Hz	L7.3A	1.07.1998Basic TV	TELEVISION
25PT4676/69Y	700225i stereo large 50Hz	L7.3A	1.07.1999Basic TV	TELEVISION
25PT4676/94Y	700225i stereo large 50Hz	L7.3A	Basic TV	TELEVISION
25PT468A/57R	710225i stereo large 50Hz	PV4.0	1.09.1996Basic TV	TELEVISION
25PT468A/73R	710225i stereo large 50Hz	PV4.0	Basic TV	TELEVISION
25PT468A/75R	710225i stereo large 50Hz	PV4.0	1.10.1996Basic TV	TELEVISION
25PT470A/00	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT470A/19	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT470B/19	710225i stereo large 50Hz	GR2.2	1.06.1994Basic TV	TELEVISION
25PT4721/13	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
25PT4721/16	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
25PT4721/33	710225i stereo large 50Hz	MD1.1E	1.12.1995Basic TV	TELEVISION
25PT4721/36	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
25PT472A/13	710225i stereo large 50Hz	GR2.2	1.10.1994Basic TV	TELEVISION
25PT472A/16	710225i stereo large 50Hz	GR2.2	1.10.1993Basic TV	TELEVISION
25PT472B/19	710225i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
25PT480A/00	710225i stereo large 50Hz	GR2.2	1.06.1993Basic TV	TELEVISION
25PT480A/06	710225i stereo large 50Hz	GR2.2	1.07.1995Basic TV	TELEVISION
25PT480B/00	710225i stereo large 50Hz	GR2.2	1.05.1994Basic TV	TELEVISION
25PT480C/00	710225i stereo large 50Hz	GR2.2	1.11.1994Basic TV	TELEVISION
25PT481B/00	710225i stereo large 50Hz	GR2.2	1.11.1994Basic TV	TELEVISION
25PT4821/36	710225i stereo large 50Hz	MD1.1E	1.04.1996Basic TV	TELEVISION
25PT4822/71T	700225i stereo large 50Hz	L9.1A	1.09.1999Basic TV	TELEVISION
25PT4823/57T	700225i stereo large 50Hz	L9.1E	1.10.1999Basic TV	TELEVISION
25PT482A/05	710225i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
25PT482A/16	710225i stereo large 50Hz	GR2.2	1.06.1994Basic TV	TELEVISION

25PT4873/56A	700225i stereo large 50Hz	L9.1A	Basic TV	TELEVISION
25PT4873/56T	700225i stereo large 50Hz	L9.1A	1.12.1999Basic TV	TELEVISION
25PT4873/69R	700225i stereo large 50Hz	L9.1A	1.04.1999Basic TV	TELEVISION
25PT4873/69T	700225i stereo large 50Hz	L9.1A	1.08.1999Basic TV	TELEVISION
25PT4873/79T	700225i stereo large 50Hz	L9.1A	1.10.1999Basic TV	TELEVISION
25PT490A/00	710225i stereo large 50Hz	GR2.2	1.10.1993Basic TV	TELEVISION
25PT5005/00	700225i mono	L9.1E	Basic TV	TELEVISION
25PT5025/01	700225i stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
25PT5025/05	700225i stereo large 50Hz	L9.1E	Basic TV	TELEVISION
25PT5025/58	700225i stereo large 50Hz	L9.1E	1.07.1999Basic TV	TELEVISION
25PT5101/00	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
25PT5101/03	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT5101/15	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
25PT5105/00	700225i stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
25PT5105/58	700225i stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
25PT5106/00	700225i stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
25PT5106/01	700225i stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
25PT5106/58	700225i stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
25PT510A/00	710225i stereo large 50Hz	GR2.2	1.02.1993Basic TV	TELEVISION
25PT510B/00	710225i stereo large 50Hz	GR2.2	1.09.1994Basic TV	TELEVISION
25PT510B/42	710225i stereo large 50Hz	GR2.2	1.11.1994Basic TV	TELEVISION
25PT5111/02	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT5121/01	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT5121/13	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT5121/16	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
25PT5121/39	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
25PT5123/16	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT5124/01	710225i stereo large 50Hz	A8.0E	Basic TV	TELEVISION
25PT5125/01	700225i stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
25PT5125/05	700225i stereo large 50Hz	L9.1E	Basic TV	TELEVISION
25PT512A/16	710225i stereo large 50Hz	GR2.2	1.04.1993Basic TV	TELEVISION
25PT512B/11	710225i stereo large 50Hz	GR2.2	1.09.1994Basic TV	TELEVISION
25PT512B/13	710225i stereo large 50Hz	GR2.2	1.12.1994Basic TV	TELEVISION
25PT512B/16	710225i stereo large 50Hz	GR2.2	1.09.1994Basic TV	TELEVISION
25PT512C/19	710225i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
25PT5155/00S	700225i stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
25PT520A/00	710225i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
25PT520A/06	710225i stereo large 50Hz	GR2.2	1.02.1994Basic TV	TELEVISION
25PT522A/11	710225i stereo large 50Hz	GR2.2	1.02.1994Basic TV	TELEVISION
25PT522A/13	710225i stereo large 50Hz	GR2.2	1.03.1994Basic TV	TELEVISION
25PT522A/16	710225i stereo large 50Hz	GR2.2	1.03.1994Basic TV	TELEVISION
25PT522B/01	710225i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION

25PT5301/00	710225i stereo large 50Hz	GR2.4	1.08.1995Basic TV	TELEVISION
25PT5301/01	710225i stereo large 50Hz	GR2.4	1.08.1995Basic TV	TELEVISION
25PT5301/15	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
25PT5301/58	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
25PT5302/00	710225i stereo large 50Hz	MD1.2E	1.02.1997Basic TV	TELEVISION
25PT5302/15	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT5302/58	710225i stereo large 50Hz	MD1.2E	1.04.1997Basic TV	TELEVISION
25PT5304/00R	710225i stereo large 50Hz	A8.0E	1.12.1998Basic TV	TELEVISION
25PT5305/00	700225i stereo large 50Hz	L9.1E	1.07.2000Basic TV	TELEVISION
25PT5305/01	700225i stereo large 50Hz	L9.1E	1.06.2000Basic TV	TELEVISION
25PT5305/58	700225i stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
25PT530A/00	710225i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
25PT530A/06	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT530A/15	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT530A/19	710225i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
25PT530B/00	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
25PT530B/01	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
25PT530B/15	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
25PT5321/01	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
25PT5321/11	710225i stereo large 50Hz	GR2.4	1.10.1995Basic TV	TELEVISION
25PT5321/13	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
25PT5322/01	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT5322/11	710225i stereo large 50Hz	MD1.2E	1.12.1997Basic TV	TELEVISION
25PT5322/13	710225i stereo large 50Hz	MD1.2E	1.04.1997Basic TV	TELEVISION
25PT5322/16	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT5322/58	710225i stereo large 50Hz	MD1.2E	1.05.1997Basic TV	TELEVISION
25PT5324/01R	710225i stereo large 50Hz	A8.0E	1.11.1998Basic TV	TELEVISION
25PT5324/05R	710225i stereo large 50Hz	A8.0E	Basic TV	TELEVISION
25PT5324/58R	710225i stereo large 50Hz	A8.0E	1.03.1999Basic TV	TELEVISION
25PT532A/05	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT532A/11	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT532A/13	710225i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
25PT532A/16	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
25PT532B/01	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
25PT532B/05	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
25PT532B/11	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
25PT532B/13	710225i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
25PT5401/00	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
25PT5402/00	710225i stereo large 50Hz	GR2.4	1.08.1996Basic TV	TELEVISION
25PT5403/00	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT5405/00	710225i stereo large 50Hz	A8.0E	1.02.1999Basic TV	TELEVISION
25PT540A/00	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION

25PT540B/00	710225i stereo large 50Hz	GR2.4	1.01.1995Basic TV	TELEVISION
25PT541B/00	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
25PT5423/16	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT5424/16	710225i stereo large 50Hz	MD1.2E	1.07.1997Basic TV	TELEVISION
25PT5425/01	710225i stereo large 50Hz	A8.0E	1.01.1999Basic TV	TELEVISION
25PT542A/16	710225i stereo large 50Hz	GR2.2	1.10.1993Basic TV	TELEVISION
25PT542B/11	710225i stereo large 50Hz	GR2.4	1.03.1995Basic TV	TELEVISION
25PT542B/13	710225i stereo large 50Hz	GR2.4	1.03.1995Basic TV	TELEVISION
25PT5506/58	26i (25v) stereo large 50Hz			TELEVISION
25PT550A/00	710225i stereo large 50Hz	GR2.2	1.06.1993Basic TV	TELEVISION
25PT550B/00	710225i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
25PT560A/00	710225i stereo large 50Hz	GR2.3	1.11.1993Basic TV	TELEVISION
25PT560A/02	710225i stereo large 50Hz	GR2.3	1.03.1994Basic TV	TELEVISION
25PT5621/13	710225i stereo large 50Hz	GR2.4	1.11.1995Basic TV	TELEVISION
25PT562A/11	710225i stereo large 50Hz	GR2.3	1.11.1993Basic TV	TELEVISION
25PT562A/13	710225i stereo large 50Hz	GR2.3	1.12.1993Basic TV	TELEVISION
25PT570A/01	710225i stereo large 50Hz	GR2.2	1.02.1994Basic TV	TELEVISION
25PT630A/00	710225i stereo large 50Hz	GR2.4	1.10.1995Basic TV	TELEVISION
25PT6322/05	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
25PT632A/05	710225i stereo large 50Hz	GR2.4	1.12.1995Basic TV	TELEVISION
25PT700B/00	710225i stereo large 50Hz	GR2.4	1.11.1994Basic TV	TELEVISION
25PT702B/11	710225i stereo large 50Hz	GR2.4	1.11.1994Basic TV	TELEVISION
25PT7106/12	720225i stereo large 100Hz	EM2E	1.06.2000Upmarket TV	TELEVISION
25PT7106/12R	720225i stereo large 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
25PT7106/58	720225i stereo large 100Hz	EM2E	1.08.2000Upmarket TV	TELEVISION
25PT7106/58R	720225i stereo large 100Hz	EM2E	1.02.2001Upmarket TV	TELEVISION
25PT722B/01	710225i stereo large 50Hz	GR2.4	1.10.1995Basic TV	TELEVISION
25PT727B/05	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
25PT7302/12	720225i stereo large 100Hz	MD2.11E	1.05.1996Upmarket TV	TELEVISION
25PT7303/12	720225i stereo large 100Hz	MD2.21E	1.06.1997Upmarket TV	TELEVISION
25PT7304/12	720225i stereo large 100Hz	MG2.1E	1.09.1998Upmarket TV	TELEVISION
25PT800A/00	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
25PT800A/01	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
25PT800A/19	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
25PT800B/00	720225i stereo large 100Hz	FL*.17	1.09.1994Upmarket TV	TELEVISION
25PT800B/01	720225i stereo large 100Hz	FL*.17	1.09.1994Upmarket TV	TELEVISION
25PT802A/05	720225i stereo large 100Hz	FL*.17	1.11.1993Upmarket TV	TELEVISION
25PT802A/12	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
25PT802B/12	720225i stereo large 100Hz	FL*.17	1.09.1994Upmarket TV	TELEVISION
25PT802B/13	720225i stereo large 100Hz	FL*.17	1.09.1995Upmarket TV	TELEVISION
25PT802B/19	720225i stereo large 100Hz	FL*.17	1.09.1994Upmarket TV	TELEVISION
25PT805A/00	720225i stereo large 100Hz	FL1.7	1.06.1993Upmarket TV	TELEVISION

25PT805A/01	720225i stereo large 100Hz	FL1.7	1.10.1993Upmarket TV	TELEVISION
25PT805A/20	720225i stereo large 100Hz	FL1.7	1.10.1993Upmarket TV	TELEVISION
25PT805B/00	720225i stereo large 100Hz	FL*.17	1.09.1994Upmarket TV	TELEVISION
25PT805B/01	720225i stereo large 100Hz	FL*.17	1.09.1994Upmarket TV	TELEVISION
25PT815A/00	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
25PT817A/12	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
25PT820A/00	720225i stereo large 100Hz	FL*.17	1.07.1994Upmarket TV	TELEVISION
25PT820A/01	720225i stereo large 100Hz	FL*.17	1.07.1994Upmarket TV	TELEVISION
25PT820A/58	720225i stereo large 100Hz	FL*.17	1.12.1994Upmarket TV	TELEVISION
25PT822A/05	720225i stereo large 100Hz	FL*.17	1.08.1994Upmarket TV	TELEVISION
25PT822A/12	720225i stereo large 100Hz	FL*.17	1.07.1994Upmarket TV	TELEVISION
25PT822A/13	720225i stereo large 100Hz	FL*.17	1.08.1994Upmarket TV	TELEVISION
25PT825A/00	720225i stereo large 100Hz	FL*.16	1.09.1994Upmarket TV	TELEVISION
25PT825A/01	720225i stereo large 100Hz	FL*.16	1.12.1994Upmarket TV	TELEVISION
25PT825B/00	720225i stereo large 100Hz	FL*.26	1.06.1995Upmarket TV	TELEVISION
25PT825B/01	720225i stereo large 100Hz	FL*.26	1.07.1995Upmarket TV	TELEVISION
25PT827A/12	720225i stereo large 100Hz	FL*.16	1.09.1994Upmarket TV	TELEVISION
25PT827B/12	720225i stereo large 100Hz	FL*.26	1.06.1995Upmarket TV	TELEVISION
25PT8302/12	720225i stereo large 100Hz	MD2.12E	1.04.1996Upmarket TV	TELEVISION
25PT8302/19	720225i stereo large 100Hz	MD2.12E	1.04.1996Upmarket TV	TELEVISION
25PT8302/58	720225i stereo large 100Hz	MD2.12E	1.08.1996Upmarket TV	TELEVISION
25PT8303/12	720225i stereo large 100Hz	MD2.22E	1.03.1997Upmarket TV	TELEVISION
25PT8303/19	720225i stereo large 100Hz	MD2.22E	1.03.1997Upmarket TV	TELEVISION
25PT8303/58	720225i stereo large 100Hz	MD2.22E	1.05.1997Upmarket TV	TELEVISION
25PT8304/12	720225i stereo large 100Hz	MG2.1E	1.09.1998Upmarket TV	TELEVISION
25PT8304/19	720225i stereo large 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
25PT8304/58	720225i stereo large 100Hz	MG2.1E	1.11.1998Upmarket TV	TELEVISION
25PT8702/12	720225i stereo large 100Hz	MD2.12E	1.08.1996Upmarket TV	TELEVISION
25PT8703/12	720225i stereo large 100Hz	MD2.22E	1.05.1997Upmarket TV	TELEVISION
25PT8703/32	720225i stereo large 100Hz	MD2.22E	1.06.1998Upmarket TV	TELEVISION
25PT9001/01	720225i stereo large 100Hz	GFL2.20E	1.05.1995Upmarket TV	TELEVISION
25PT9001/58	720225i stereo large 100Hz	GFL2.20E	1.08.1995Upmarket TV	TELEVISION
25PT900A/01	720225i stereo large 100Hz	FL*.16	1.06.1993Upmarket TV	TELEVISION
25PT900A/19	720225i stereo large 100Hz	FL*.16	1.09.1993Upmarket TV	TELEVISION
25PT900A/21	720225i stereo large 100Hz	FL*.16	1.04.1994Upmarket TV	TELEVISION
25PT900A/39	720225i stereo large 100Hz	FL*.16	1.04.1994Upmarket TV	TELEVISION
25PT900B/01	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
25PT9011/01	720225i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
25PT9021/05	720225i stereo large 100Hz	GFL2.20E	1.06.1995Upmarket TV	TELEVISION
25PT9021/12	720225i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
25PT9021/19	720225i stereo large 100Hz	GFL2.20E	1.06.1995Upmarket TV	TELEVISION
25PT902A/05	720225i stereo large 100Hz	FL*.16	1.07.1993Upmarket TV	TELEVISION

25PT902B/19	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
25PT9031/12	720225i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
25PT9101/01	720225i stereo large 100Hz	GFL2.20E	1.05.1995Upmarket TV	TELEVISION
25PT910A/01	720225i stereo large 100Hz	FL*.16	1.06.1993Upmarket TV	TELEVISION
25PT910A/19	720225i stereo large 100Hz	FL*.16	1.08.1993Upmarket TV	TELEVISION
25PT910A/21	720225i stereo large 100Hz	FL*.16	1.04.1994Upmarket TV	TELEVISION
25PT910B/01	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
25PT9121/12	720225i stereo large 100Hz	GFL2.20E	1.06.1995Upmarket TV	TELEVISION
25PT912A/12	720225i stereo large 100Hz	FL*.16	1.06.1993Upmarket TV	TELEVISION
25PT912A/13	720225i stereo large 100Hz	FL*.16	1.08.1993Upmarket TV	TELEVISION
25PT912A/32	720225i stereo large 100Hz	FL*.16	1.04.1994Upmarket TV	TELEVISION
25PT912B/12	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
25PT912B/13	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
25PV720/07	1022High-end	TVCR-D	1.09.1999	TVCR
25PV720/39	1022High-end	TVCR-D	1.09.1999	TVCR
25PV720DE	1022High-end	TVCR-D	1.09.1999	TVCR
25PV720ES	1022High-end	TVCR-D	1.09.1999	TVCR
25PV720FR	1022High-end	TVCR-D	1.09.1999	TVCR
25PV720GR	1022High-end		1.02.2000	TVCR
25PV720XE	1022High-end		1.09.1999	TVCR
25PV7505/00B	720225i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
25PV7505/20	720225i stereo large 50Hz	FL1.0	1.07.1993Upmarket TV	TELEVISION
25PV7506/00B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
25PV7506/10B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
25PV7506/19B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
25PV7506/32	720225i stereo large 50Hz	FL1.0	1.08.1993Upmarket TV	TELEVISION
25PV7506/39	720225i stereo large 50Hz	FL1.0	1.12.1993Upmarket TV	TELEVISION
25PV7960/00B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7960/02B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7960/20B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7960/20S	720225i stereo large 50Hz	FL1.0	1.05.1992Upmarket TV	TELEVISION
25PV7960/30B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7966/00B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7966/10B	720225i stereo large 50Hz	FL1.0	1.04.1992Upmarket TV	TELEVISION
25PV7966/13B	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION
25PV7966/16B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7966/19B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7966/20B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7966/20S	720225i stereo large 50Hz	FL1.0	1.05.1992Upmarket TV	TELEVISION
25PV7966/30B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7966/30S	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION
25PV7966/33B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION

25PV7966/36B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7966/39B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25PV7966/39S	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
25PV805/39	High-end			TVCR
25PV805/58	High-end			TVCR
25PV808/07	1022High-end	TVCR-D	1.06.2000	TVCR
25PV808/39	1022High-end	TVCR-D	1.06.2000	TVCR
25PV808/58	High-end	TVCR-D		TVCR
25PV808/EE	1022High-end	TVCR-D	1.06.2000	TVCR
25PV808/IT	1022High-end	TVCR-D	1.09.2000	TVCR
25PV808DE	1022High-end	TVCR-D	1.06.2000	TVCR
25PV808EE	1022High-end	TVCR-D	1.03.2001	TVCR
25PV808ES	1022High-end	TVCR-D	1.06.2000	TVCR
25PV808FR	1022High-end	TVCR-D	1.09.2000	TVCR
25PV808GR	1022High-end	TVCR-D	1.07.2000	TVCR
25PV808XE	1022High-end	TVCR-D	1.07.2000	TVCR
25PV815/07	1022High-end	TVCR-D	1.07.2001	TVCR
25PV815/39	1022High-end	TVCR-D	1.06.2001	TVCR
25PV815/EE	1022High-end	TVCR-D	1.07.2001	TVCR
25PV815/ES	1022High-end	TVCR-D	1.07.2001	TVCR
25PV815/FR	1022High-end	TVCR-D	1.07.2001	TVCR
25PV815/GR	1022High-end	TVCR-D	1.10.2001	TVCR
25PV815/XE	1022High-end	TVCR-D	1.07.2001	TVCR
25SA01/05	700225i stereo large 50Hz	L9.1E	Basic TV	TELEVISION
25SL5500/00B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
25SL5500/20	720225i stereo large 50Hz	FL1.0	1.07.1993Upmarket TV	TELEVISION
25SL5501/00B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
25SL5501/07B	720225i stereo large 50Hz	FL1.0	1.12.1992Upmarket TV	TELEVISION
25SL5501/10B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
25SL5501/13B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
25SL5501/19B	720225i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
25SL5501/39	720225i stereo large 50Hz	FL1.0	1.09.1993Upmarket TV	TELEVISION
25SL5760/00B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5760/20B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5760/20S	720225i stereo large 50Hz	FL1.0	1.05.1992Upmarket TV	TELEVISION
25SL5760/25B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5766/00B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5766/10B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5766/13B	720225i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
25SL5766/16B	720225i stereo large 50Hz	FL1.0	1.05.1992Upmarket TV	TELEVISION
25SL5766/19B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5766/20B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION

25SL5766/20S	720225i stereo large 50Hz	FL1.0	1.05.1992Upmarket TV	TELEVISION
25SL5766/30B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5766/30S	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION
25SL5766/33B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5766/36B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5766/39B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
25SL5766/39S	720225i stereo large 50Hz	FL1.0	1.07.1992Upmarket TV	TELEVISION
25SP1688/56S	710225i stereo large 50Hz	G112	1.04.1992Basic TV	TELEVISION
25SP1688/57R	710225i stereo large 50Hz	G112	1.05.1992Basic TV	TELEVISION
25SP1688/57T	710225i stereo large 50Hz	G112	1.09.1992Basic TV	TELEVISION
25SP1688/75R	710225i stereo large 50Hz	G112	1.03.1992Basic TV	TELEVISION
25SP1688/79R	710225i stereo large 50Hz	G112	1.04.1992Basic TV	TELEVISION
25SP1788/69R	710225i stereo large 50Hz	G112	1.05.1992Basic TV	TELEVISION
25SP1788/75R	710225i stereo large 50Hz	G112	1.03.1992Basic TV	TELEVISION
25SP1788/79R	710225i stereo large 50Hz	G112	1.09.1992Basic TV	TELEVISION
25ST1607/19B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1607/39B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1627/19B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1627/39B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1666/19B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1666/39B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1667/39B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1702/02B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1702/10B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1702/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/02B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/08B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/10B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/10V	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/13B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/16B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/28B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/30V	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/33B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1704/36B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1707/10B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1707/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1724/02B	710225i stereo large 50Hz	GR2.1	1.08.1992Basic TV	TELEVISION
25ST1724/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1724/25B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION

25ST1724/28B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1750/05B	710225i stereo large 50Hz	GR2.1	1.04.1993Basic TV	TELEVISION
25ST1750/25B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/02B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/08B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/10B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/12B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/13B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/16B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/28B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/32B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/33B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1760/36B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1761/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1761/25B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1761/28B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1761/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1761/33B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1761/36B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1767/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1804/12B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1804/32B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST1861/32B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
25ST2451/02B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
25ST2451/07B	710225i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
25ST2451/08B	710225i stereo large 50Hz	GR2.2	1.10.1992Basic TV	TELEVISION
25ST2451/10B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2451/12B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2451/13B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
25ST2451/16B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
25ST2454/42B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2457/10B	710225i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
25ST2457/42B	710225i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
25ST2657/19B	710225i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
25ST2664/19B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2664/42B	710225i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
25ST2666/19B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2666/39B	710225i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
25ST2666/42B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
25ST2759/02Z	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION

25ST2760/08B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
25ST2760/10B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2760/13B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2760/16B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
25ST2761/02B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
25ST2761/05B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
25ST2761/07B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
25ST2761/08B	710225i stereo large 50Hz	GR2.2	1.10.1992Basic TV	TELEVISION
25ST2761/10B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2761/13B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2761/16B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
25ST2761/22B	710225i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
25ST2767/10B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2860/12B	710225i stereo large 50Hz	GR2.2	1.08.1992Basic TV	TELEVISION
25ST2864/12B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
25ST2961/10B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
25ST2961/16B	710225i stereo large 50Hz	GR2.2	1.10.1992Basic TV	TELEVISION
25ST2967/19B	710225i stereo large 50Hz	GR2.2	1.10.1992Basic TV	TELEVISION
25SX8661/56H	710225i stereo large 50Hz	G8	1.01.1994Upmarket TV	TELEVISION
25SX8661/57R	710225i stereo large 50Hz	G8	1.05.1994Upmarket TV	TELEVISION
25SX8662/97R	710225i stereo large 50Hz	G8	1.12.1993Upmarket TV	TELEVISION
25SX8666/57R	710225i stereo large 50Hz	G8.1	1.09.1994Upmarket TV	TELEVISION
25SX8666/93R	710225i stereo large 50Hz	G8.1	1.10.1995Upmarket TV	TELEVISION
25SX8667/97R	710225i stereo large 50Hz	G8.1	1.12.1994Upmarket TV	TELEVISION
25SX8761/56H	710225i stereo large 50Hz	G8	1.11.1993Upmarket TV	TELEVISION
25SX8761/57R	710225i stereo large 50Hz	G8	1.07.1993Upmarket TV	TELEVISION
25SX8761/67R	710225i stereo large 50Hz	G8	1.12.1993Upmarket TV	TELEVISION
25SX8761/69R	710225i stereo large 50Hz	G8	1.08.1993Upmarket TV	TELEVISION
25SX8761/75R	710225i stereo large 50Hz	G8	1.11.1993Upmarket TV	TELEVISION
25SX8761/79R	710225i stereo large 50Hz	G8	1.09.1993Upmarket TV	TELEVISION
25SX8766/69R	710225i stereo large 50Hz	G8.1	1.09.1994Upmarket TV	TELEVISION
26CE1991/75R	700225i mono	SAMPO	1.03.1992	TELEVISION
26CE1991/79R	700225i mono	SAMPO	1.11.1992	TELEVISION
26CT6071L/73	700225i mono		1.04.1992	TELEVISION
26DMQ162/65	700215i mono		1.05.1993	TELEVISION
27CE3090/16B	700225i mono		1.03.1993	TELEVISION
27CE7590/10S	720225i stereo large 50Hz	3A	1.07.1992Upmarket TV	TELEVISION
27CE7594/42R	720225i stereo large 50Hz	3A	1.07.1992Upmarket TV	TELEVISION
27K271L/76	700225i stereo large 50Hz		1.03.1992	TELEVISION
27K291L/76	700225i stereo large 50Hz		1.04.1992	TELEVISION
27PT8419/17	29i stereo large 100HZ			TELEVISION
281571SB/02R	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION

281571SB/22R	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
286NS/05	700228i (27v) stereo large 50Hz	L6.2	1.07.1998Basic TV	TELEVISION
287231CB/34R	710225i mono	GR2.2	1.11.1992Basic TV	TELEVISION
287279IR/22M	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
288371SB/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
288372SB/02R	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
288392SB/02R	710225i stereo large 50Hz	GR2.2	1.10.1992Basic TV	TELEVISION
288572SB/02B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
288572SB/10B	710225i stereo large 50Hz	GR2.2	1.02.1993Basic TV	TELEVISION
288572SB/16B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
289279IR/22M	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
289326EK/11R	710228i (27v) mono	CP110	Basic TV	TELEVISION
28CE5594/16B	710225i mono	2B	1.03.1992Basic TV	TELEVISION
28CE6290/07B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6290/10B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6290/15B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6290/16B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6291/08B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6291/10B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6291/16B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6296/19B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6298/10B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6298/19B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6298/39B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6590/05B	710225i mono	CP110	1.06.1992Basic TV	TELEVISION
28CE6590/08B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6590/10B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6590/13B	710225i mono	CP110	1.07.1992Basic TV	TELEVISION
28CE6590/13W	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6590/16B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6591/10B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6591/13B	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
28CE6591/16B	710225i mono	CP110	1.06.1992Basic TV	TELEVISION
28CL6770/05Z	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28CL6770/25	720225i stereo large 50Hz	FL1.0	1.10.1993Upmarket TV	TELEVISION
28CL6770/25Z	720228i (27v) stereo large 50Hz	FL1.0	1.04.1994Upmarket TV	TELEVISION
28CL6776/00Z	720225i stereo large 50Hz	FL1.0	1.07.1992Upmarket TV	TELEVISION
28CL6776/10Z	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION
28CL6776/13Z	720225i stereo large 50Hz	FL1.0	1.07.1992Upmarket TV	TELEVISION
28CL6776/33	720225i stereo large 50Hz	FL1.0	1.10.1993Upmarket TV	TELEVISION
28CL6776/33Z	720225i stereo large 50Hz	FL1.0	1.04.1994Upmarket TV	TELEVISION
28CL6970/00Z	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION

28CL6976/00Z	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION
28CL6976/16Z	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28CL6976/19Z	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION
28CT7690L/55	700225i stereo large 50Hz		1.04.1992	TELEVISION
28CT7691L/77	700225i stereo large 50Hz		1.04.1992	TELEVISION
28CT7693L/55	700225i stereo large 50Hz		1.03.1992	TELEVISION
28CT7693L/87	700225i stereo large 50Hz		1.03.1992	TELEVISION
28CT9495/73	710225i mono	CTO-N	1.05.1993	TELEVISION
28CT9495L/73	700225i mono		1.03.1992	TELEVISION
28DC2070/00R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2070/02R	720225i stereo large 100Hz	D16	1.04.1992Upmarket TV	TELEVISION
28DC2070/16R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2070/20R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2070/25R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2070/32R	720228i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2070/33R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2070/36R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2070/39R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2070/49R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2075/02R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2075/20R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2075/36R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2075/39R	720225i stereo large 100Hz	D16	1.05.1992Upmarket TV	TELEVISION
28DC2171/02R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2171/19R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2173/19R	700228i stereo large 100Hz			TELEVISION
28DC2173/20R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2271/00R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2271/02R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2271/13R	700228i stereo large 100Hz			TELEVISION
28DC2271/19R	700228i stereo large 100Hz			TELEVISION
28DC2271/22R	720225i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2670/00R	720225i stereo large 50Hz	D16	1.04.1992Upmarket TV	TELEVISION
28DC2670/20R	720225i stereo large 50Hz	D16	1.05.1992Upmarket TV	TELEVISION
28DC2670/21R	720225i stereo large 50Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2670/36R	720225i stereo large 50Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DC2670/39R	720225i stereo large 50Hz	D16	1.03.1992Upmarket TV	TELEVISION
28DW6557/05	Digital CRT DVB 50/60Hz 28i WS			DIGITAL TV
28DW6715/05	7102Digital CRT DVB 50/60Hz 28i WS			DIGITAL TV
28DW6734/05	7102Digital CRT DVB 50/60Hz 28i WSMD1.2E		1.04.1999Basic TV	DIGITAL TV
28DW6734/25	7102Digital CRT DVB 50/60Hz 28i WSMD1.2E		1.11.1999Basic TV	DIGITAL TV
28DW8957/05	Digital CRT DVB 100Hz 28i WS			DIGITAL TV

28DW9625/05R	7202Digital CRT DVB 100Hz 28i WS	MG4.1E	1.05.2001Upmarket TV	DIGITAL TV
28FL2871/57R	720228i WS 100Hz	FL2-G	1.02.1994Upmarket TV	TELEVISION
28FL2871/69R	720228i WS 100Hz	FL2-G	1.12.1993Upmarket TV	TELEVISION
28FL2871/79R	720228i WS 100Hz	FL2-G	1.06.1994Upmarket TV	TELEVISION
28FL2871/93R	720228i WS 100Hz	FL2-G	1.05.1994Upmarket TV	TELEVISION
28FL2872/97R	720228i WS 100Hz	FL2-G	1.06.1994Upmarket TV	TELEVISION
28GR1990/50R	710225i stereo large 50Hz	G110-S	1.03.1992Basic TV	TELEVISION
28GR5606/19Z	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
28GR5670/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR5670/36B	710225i stereo large 50Hz	G110	1.03.1994Basic TV	TELEVISION
28GR5676/39B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR5677/39B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR5701/02Z	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
28GR5701/22Z	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
28GR5706/10Z	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
28GR5731/02B	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
28GR5731/10B	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
28GR5731/13B	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
28GR5731/22B	710225i stereo large 50Hz	G110-2	1.03.1992Basic TV	TELEVISION
28GR5774/22B	710225i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
28GR5774/30B	710225i stereo large 50Hz	G110	1.06.1992Basic TV	TELEVISION
28GR5775/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR5775/30B	710225i stereo large 50Hz	G110	1.06.1992Basic TV	TELEVISION
28GR5974/10B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR5974/16B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR6775/50R	710225i stereo large 50Hz	G110-S	1.03.1992Basic TV	TELEVISION
28GR6775/75R	710225i stereo large 50Hz	G110-S	1.04.1992Basic TV	TELEVISION
28GR6776/56R	710225i stereo large 50Hz	G110-S	1.03.1992Basic TV	TELEVISION
28GR6776/59R	710225i stereo large 50Hz	G110-S	1.06.1992Basic TV	TELEVISION
28GR6776/75R	710225i stereo large 50Hz	G110-S	1.12.1992Basic TV	TELEVISION
28GR6780/58R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6780/62R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6780/69R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6780/75R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6781/56R	710225i stereo large 50Hz	G111-S	1.04.1992Basic TV	TELEVISION
28GR6781/56S	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6781/57R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6781/65R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6781/67R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6781/68R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6781/70R	710225i stereo large 50Hz	G111-S	1.11.1992Basic TV	TELEVISION
28GR6781/75R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION

28GR6781/79R	710225i stereo large 50Hz	G111-S	1.03.1992Basic TV	TELEVISION
28GR6781/80	710225i stereo large 50Hz	G111-S	1.05.1993Basic TV	TELEVISION
28GR6781L/80	700225i stereo large 50Hz		1.03.1992	TELEVISION
28GR7580/78	700225i stereo large 50Hz		1.05.1993	TELEVISION
28GR7580L/78	700225i stereo large 50Hz		1.03.1992	TELEVISION
28GR7585/78	700225i stereo large 50Hz		1.06.1993	TELEVISION
28GR7585/78R	700228i (27v) stereo large 50Hz			TELEVISION
28GR7680/78	700225i stereo large 50Hz		1.05.1993	TELEVISION
28GR7680L/78	700225i stereo large 50Hz		1.03.1992	TELEVISION
28GR7685/78	700225i stereo large 50Hz		1.06.1993	TELEVISION
28GR7685/78R	700228i (27v) stereo large 50Hz			TELEVISION
28GR9670/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9670/30B	710225i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
28GR9676/39B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9677/39B	710225i stereo large 50Hz	G110	1.05.1992Basic TV	TELEVISION
28GR9770/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9770/28B	710225i stereo large 50Hz	G110	1.10.1992Basic TV	TELEVISION
28GR9770/30B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9770/30W	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9770/42B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9772/25B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9772/36B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9773/33B	710225i stereo large 50Hz	G110	1.05.1993Basic TV	TELEVISION
28GR9773/36B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9775/30B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9778/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9875/22B	710225i stereo large 50Hz	G110	1.05.1992Basic TV	TELEVISION
28GR9970/22B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9970/30B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9973/13W	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9973/32B	710228i (27v) stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
28GR9973/33B	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
28GR9979/13B	710225i stereo large 50Hz	G110	1.07.1992Basic TV	TELEVISION
28HT5403/01Z	201328i Stereo ITV	L9H.1E	1.01.2000Institutional TV	INSTITUTIONAL TV
28HT5403/05Z	201328i Stereo ITV		1.07.2001	INSTITUTIONAL TV
28HT5403/21R	201328i Stereo ITV	L9H.1E	1.06.2000Institutional TV	INSTITUTIONAL TV
28HT5403/25R	201328i Stereo ITV			INSTITUTIONAL TV
28HT5404/01Z	28i Stereo ITV			INSTITUTIONAL TV
28HT5404/05Z	28i Stereo ITV			INSTITUTIONAL TV
28HW6404/01Z	201328i (26W) WS 50/60Hz Stereo ITV	L01H.1E	1.10.2001Institutional TV	INSTITUTIONAL TV
28HW6404/05Z	28i (26W) WS 50/60Hz Stereo ITV			INSTITUTIONAL TV
28HW6404/21R	28i (26W) WS 50/60Hz Stereo ITV			INSTITUTIONAL TV

28HW6404/25R	28i (26W) WS 50/60Hz Stereo ITV			INSTITUTIONAL TV
28MK2490/54R	710225i mono	MK2	1.03.1993Basic TV	TELEVISION
28MK2490/56H	710225i mono	MK2	1.05.1992Basic TV	TELEVISION
28MK2490/56R	710225i mono	MK2	1.09.1992Basic TV	TELEVISION
28MK2490/73	710225i mono	MK2	1.05.1993Basic TV	TELEVISION
28MK2490/73R	710225i mono	MK2	1.05.1992Basic TV	TELEVISION
28MK2490/77R	710225i mono	MK2	1.11.1992Basic TV	TELEVISION
28MK2490/79R	710225i mono	MK2	1.09.1992Basic TV	TELEVISION
28MK2490L/73	700225i mono		1.03.1992	TELEVISION
28MK2496/73	700225i mono		1.07.1993	TELEVISION
28MK2496L/73	700225i mono		1.05.1992	TELEVISION
28MK2790/56R	710225i mono	MK2	1.06.1992Basic TV	TELEVISION
28MK2790/58R	710225i mono	MK2	1.04.1992Basic TV	TELEVISION
28MK2790/62R	710225i mono	MK2	1.05.1992Basic TV	TELEVISION
28MK2790/79R	710225i mono	MK2	1.06.1993Basic TV	TELEVISION
28ML8600/00B	720225i stereo large 100Hz	FL1.7	1.09.1992Upmarket TV	TELEVISION
28ML8600/05B	720225i stereo large 100Hz	FL1.7	1.09.1992Upmarket TV	TELEVISION
28ML8600/13B	720225i stereo large 100Hz	FL1.7	1.09.1992Upmarket TV	TELEVISION
28ML8600/19B	720225i stereo large 100Hz	FL1.7	1.09.1992Upmarket TV	TELEVISION
28ML8605/00B	720225i stereo large 100Hz	FL1.7	1.08.1992Upmarket TV	TELEVISION
28ML8605/10B	720225i stereo large 100Hz	FL1.7	1.09.1992Upmarket TV	TELEVISION
28ML8605/19B	720225i stereo large 100Hz	FL1.7	1.09.1992Upmarket TV	TELEVISION
28ML8762/00B	720228i WS 100Hz	FL1.2 AB	1.09.1992Upmarket TV	TELEVISION
28ML8762/05B	720228i WS 100Hz	FL1.2 AB	1.10.1992Upmarket TV	TELEVISION
28ML8762/19B	720228i WS 100Hz	FL1.2 AB	1.10.1992Upmarket TV	TELEVISION
28ML8765/00B	720228i WS 100Hz	FL1.2 AB	1.09.1992Upmarket TV	TELEVISION
28ML8765/10B	720228i WS 100Hz	FL1.2 AB	1.09.1992Upmarket TV	TELEVISION
28ML8770/05B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8776/00B	720225i stereo large 100Hz	FL1.7	1.05.1992Upmarket TV	TELEVISION
28ML8776/02B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8776/08B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8776/19B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8785/00B	720228i WS 100Hz	FL1.2 AB	1.10.1992Upmarket TV	TELEVISION
28ML8785/19B	720228i WS 100Hz	FL1.2 AB	1.01.1993Upmarket TV	TELEVISION
28ML8800/02B	720225i stereo large 100Hz	FL1.6	1.06.1992Upmarket TV	TELEVISION
28ML8800/05B	720225i stereo large 100Hz	FL1.6	1.09.1992Upmarket TV	TELEVISION
28ML8800/08B	720225i stereo large 100Hz	FL1.6	1.07.1992Upmarket TV	TELEVISION
28ML8800/19B	720225i stereo large 100Hz	FL1.6	1.06.1992Upmarket TV	TELEVISION
28ML8805/00B	720225i stereo large 100Hz	FL1.6	1.05.1992Upmarket TV	TELEVISION
28ML8805/02B	720225i stereo large 100Hz	FL1.6	1.05.1992Upmarket TV	TELEVISION
28ML8805/06B	720225i stereo large 100Hz	FL1.6	1.06.1992Upmarket TV	TELEVISION
28ML8805/07B	720225i stereo large 100Hz	FL1.6	1.12.1992Upmarket TV	TELEVISION

28ML8805/08B	720225i stereo large 100Hz	FL1.6	1.09.1992Upmarket TV	TELEVISION
28ML8805/10B	720225i stereo large 100Hz	FL1.6	1.06.1992Upmarket TV	TELEVISION
28ML8805/13B	720228i (27v) stereo large 50Hz	FL1.6	1.07.1992Upmarket TV	TELEVISION
28ML8805/16B	720225i stereo large 100Hz	FL1.6	1.07.1992Upmarket TV	TELEVISION
28ML8805/19B	720225i stereo large 100Hz	FL1.6	1.05.1992Upmarket TV	TELEVISION
28ML8805/36B	720225i stereo large 100Hz	FL1.6	1.10.1993Upmarket TV	TELEVISION
28ML8805/42B	720228i stereo large 100Hz	FL1.6	1.06.1992Upmarket TV	TELEVISION
28ML8916/00B	720228i WS 100Hz	FL1.2 AB	1.03.1992Upmarket TV	TELEVISION
28ML8916/05B	720228i WS 100Hz	FL1.2 AB	1.06.1992Upmarket TV	TELEVISION
28ML8916/10B	720228i WS 100Hz	FL1.2 AB	1.04.1992Upmarket TV	TELEVISION
28ML8916/13B	720228i WS 100Hz	FL1.2 AB	1.04.1992Upmarket TV	TELEVISION
28ML8916/19B	720228i WS 100Hz	FL1.2 AB	1.04.1992Upmarket TV	TELEVISION
28ML8916/30B	720228i WS 100Hz	FL1.2 AB	1.06.1992Upmarket TV	TELEVISION
28ML8926/00B	720228i WS 100Hz	FL1.2 AB	1.05.1992Upmarket TV	TELEVISION
28ML8926/10B	720228i WS 100Hz	FL1.2 AB	1.06.1992Upmarket TV	TELEVISION
28ML8926/80	720228i WS 100Hz	FL1.2 AB	1.06.1993Upmarket TV	TELEVISION
28ML8926L/80	700225i stereo large 50Hz		1.12.1992	TELEVISION
28ML8976/00B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8976/02B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8976/06B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8976/07B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8976/08B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8976/10B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8976/13B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8976/16B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28ML8976/19B	720225i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
28MN1370/10B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
28MN1370/28B	710225i mono	GR2.1	1.07.1992Basic TV	TELEVISION
28MN1370/30B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
28MN1376/19B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
28MN1376/39B	710225i mono	GR2.1	1.04.1992Basic TV	TELEVISION
28MN1376/40B	710225i mono	GR2.1	1.09.1993Basic TV	TELEVISION
28MN1376/42B	710225i mono	GR2.1	1.06.1992Basic TV	TELEVISION
28MN1570/02B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
28MN1570/08B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
28MN1570/10B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
28MN1570/16B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION
28MN1570/22B	710225i mono	GR2.1	1.06.1992Basic TV	TELEVISION
28MN1570/28B	710225i mono	GR2.1	1.06.1992Basic TV	TELEVISION
28MN1570/30B	710225i mono	GR2.1	1.05.1992Basic TV	TELEVISION
28MN1570/33B	710225i mono	GR2.1	1.04.1992Basic TV	TELEVISION
28MN1570/36B	710225i mono	GR2.1	1.03.1992Basic TV	TELEVISION

28PN9611/02	720228i WS 100Hz	GFL2.30E	1.10.1996Upmarket TV	TELEVISION
28PN9611/12	720228i WS 100Hz	GFL2.30E	1.10.1996Upmarket TV	TELEVISION
28PN9671/19	720228i WS 100Hz	GFL2.30E	1.11.1996Upmarket TV	TELEVISION
28PT2665/00	700228i (27v) stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
28PT2665/01	700228i (27v) stereo large 50Hz	L9.1E	1.10.2001Basic TV	TELEVISION
28PT2665/20	700228i (27v) stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
28PT2665/21	700228i (27v) stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
28PT2665/48	700228i (27v) stereo large 50Hz	L9.1E	1.10.2001Basic TV	TELEVISION
28PT2665/58	700228i (27v) stereo large 50Hz	L9.1E	1.09.2001Basic TV	TELEVISION
28PT4001/00	700225i mono	AA5	1.04.1996Basic TV	TELEVISION
28PT4001/01	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
28PT4001/39	700225i mono	AA5	1.03.1996Basic TV	TELEVISION
28PT4001/58	700228i (27v) mono	AA5	1.12.1995Basic TV	TELEVISION
28PT400A/00	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
28PT400A/42	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
28PT4051/01	700225i mono	AA5	1.01.1996Basic TV	TELEVISION
28PT405A/00	710225i mono	GR2.2	1.10.1994Basic TV	TELEVISION
28PT405A/19	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
28PT4101/00	700228i (27v) mono	AA5	1.12.1995Basic TV	TELEVISION
28PT4101/07	700225i mono	AA5	1.12.1995Basic TV	TELEVISION
28PT4101/13	700228i (27v) mono	AA5	1.01.1996Basic TV	TELEVISION
28PT4102/00	700228i (27v) mono	L6.2	1.07.1997Basic TV	TELEVISION
28PT4103/00	700228i (27v) mono	L6.2	1.04.1997Basic TV	TELEVISION
28PT4103/01	700225i mono	L6.2	1.06.1997Basic TV	TELEVISION
28PT4103/39	700225i mono	L6.2	1.07.1997Basic TV	TELEVISION
28PT4103/58	700228i (27v) mono	L6.2	1.08.1997Basic TV	TELEVISION
28PT4103/60	700228i (27v) mono	L6.2	1.09.1997Basic TV	TELEVISION
28PT4104/58	700228i (27v) mono	L9.1E	1.10.1999Basic TV	TELEVISION
28PT410A/00	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
28PT410A/07	710225i mono	GR2.2	1.11.1994Basic TV	TELEVISION
28PT410A/13	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
28PT410A/16	710225i mono	GR2.2	1.03.1994Basic TV	TELEVISION
28PT4151/00	700225i mono	AA5	1.01.1996Basic TV	TELEVISION
28PT4204/00	700228i (27v) stereo large 50Hz	L6.2	1.09.1998Basic TV	TELEVISION
28PT4224/11	700228i (27v) stereo large 50Hz	L6.2	1.09.1998Basic TV	TELEVISION
28PT4254/00	700228i (27v) stereo large 50Hz	L6.3	1.10.1998Basic TV	TELEVISION
28PT4255/00	700228i (27v) stereo large 50Hz	L9.1E	1.09.1999Basic TV	TELEVISION
28PT4255/20	700228i (27v) stereo large 50Hz	L9.1E	1.04.2000Basic TV	TELEVISION
28PT4275/01	700228i (27v) stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
28PT4301/02	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
28PT4323/11	700225i stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
28PT4375/01	700225i stereo large 50Hz	L9.1E	Basic TV	TELEVISION

28PT4401/00	710225i stereo large 50Hz	MD1.1E	1.03.1996Basic TV	TELEVISION
28PT4403/00	700228i (27v) stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
28PT4403/43	700228i (27v) stereo large 50Hz	L6.2	1.03.1998Basic TV	TELEVISION
28PT4404/00	700228i (27v) stereo large 50Hz	L9.1E	1.03.2000Basic TV	TELEVISION
28PT4404/20	700228i (27v) stereo large 50Hz	L9.1E	1.05.2000Basic TV	TELEVISION
28PT4404/30	700228i (27v) stereo large 50Hz	L9.1E	1.07.2000Basic TV	TELEVISION
28PT4404/58	700228i (27v) stereo large 50Hz	L9.1E	1.02.2001Basic TV	TELEVISION
28PT4406/58	28i (27v) stereo large 50Hz			TELEVISION
28PT440A/00	710225i stereo large 50Hz	GR2.2	1.03.1995Basic TV	TELEVISION
28PT440A/06	710225i stereo large 50Hz	GR2.2	1.03.1995Basic TV	TELEVISION
28PT440A/58	710225i stereo large 50Hz	GR2.2	1.05.1995Basic TV	TELEVISION
28PT4421/01	710225i stereo large 50Hz	MD1.1E	1.03.1996Basic TV	TELEVISION
28PT4421/13	710225i stereo large 50Hz	MD1.1E	1.04.1996Basic TV	TELEVISION
28PT4421/16	710228i (27v) stereo large 50Hz	MD1.1E	1.03.1996Basic TV	TELEVISION
28PT4423/01	700228i (27v) stereo large 50Hz	L6.1	1.06.1997Basic TV	TELEVISION
28PT4423/11	700228i (27v) stereo large 50Hz	L6.1	1.06.1997Basic TV	TELEVISION
28PT4423/58	700228i (27v) stereo large 50Hz	L6.1	1.03.1998Basic TV	TELEVISION
28PT4423/58P	700228i (27v) stereo large 50Hz	L6.1	1.06.1998Basic TV	TELEVISION
28PT442A/13	710225i stereo large 50Hz	GR2.2	1.04.1995Basic TV	TELEVISION
28PT442A/16	710225i stereo large 50Hz	GR2.2	1.04.1995Basic TV	TELEVISION
28PT443A/01	710225i stereo large 50Hz	GR2.4	1.03.1995Basic TV	TELEVISION
28PT4453/00	700228i (27v) stereo large 50Hz	L6.2	1.10.1997Basic TV	TELEVISION
28PT4454/00	700228i (27v) stereo large 50Hz	L6.3	1.09.1998Basic TV	TELEVISION
28PT4455/00	700228i (27v) stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
28PT4455/20	700228i (27v) stereo large 50Hz	L9.1E	1.03.2000Basic TV	TELEVISION
28PT4455/30	700228i (27v) stereo large 50Hz	L9.1E	1.01.2001Basic TV	TELEVISION
28PT4456/00	700228i (27v) stereo large 50Hz	L9.1E	1.07.2001Basic TV	TELEVISION
28PT4456/01	700228i (27v) stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
28PT4456/05	700228i (27v) stereo large 50Hz	L9.1E	1.07.2001Basic TV	TELEVISION
28PT4456/58	700228i (27v) stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
28PT4473/01	700228i (27v) stereo large 50Hz	L6.2	1.11.1997Basic TV	TELEVISION
28PT4473/11	700228i (27v) stereo large 50Hz	L6.2	1.02.1998Basic TV	TELEVISION
28PT4474/01	700228i (27v) stereo large 50Hz	L6.3	1.11.1998Basic TV	TELEVISION
28PT4475/01	700228i (27v) stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
28PT4475/05	700228i (27v) stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
28PT4475/21	28i (27v) stereo large 50Hz			TELEVISION
28PT4475/58	700228i (27v) stereo large 50Hz	L9.1E	1.09.1999Basic TV	TELEVISION
28PT4494/05	700228i (27v) stereo large 50Hz	L6.3	1.09.1998Basic TV	TELEVISION
28PT4501/00	710225i stereo large 50Hz	MD1.1E	1.06.1995Basic TV	TELEVISION
28PT4501/03	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
28PT4501/43	710225i stereo large 50Hz	MD1.1E	1.01.1996Basic TV	TELEVISION
28PT4501/58	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION

28PT4501/58P	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
28PT4501/60	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
28PT4503/00	710228i (27v) stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
28PT4503/15	710228i (27v) stereo large 50Hz	MD1.2E	1.01.1998Basic TV	TELEVISION
28PT4503/20	710228i (27v) stereo large 50Hz	MD1.2E	1.04.1998Basic TV	TELEVISION
28PT4503/43	710228i (27v) stereo large 50Hz	MD1.2E	1.02.1997Basic TV	TELEVISION
28PT4503/58	710228i (27v) stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
28PT450A/00	710225i stereo large 50Hz	GR2.2	1.06.1993Basic TV	TELEVISION
28PT450A/06	710225i stereo large 50Hz	GR2.2	1.10.1993Basic TV	TELEVISION
28PT450A/42	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT450A/43	710225i stereo large 50Hz	GR2.2	1.01.1994Basic TV	TELEVISION
28PT4511/02	710225i stereo large 50Hz	MD1.1E	1.07.1995Basic TV	TELEVISION
28PT4512/02	710225i stereo large 50Hz	MD1.1E	1.03.1996Basic TV	TELEVISION
28PT4513/02	710228i (27v) stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
28PT451A/00	710225i stereo large 50Hz	GR2.2	1.02.1995Basic TV	TELEVISION
28PT4521/01	710225i stereo large 50Hz	MD1.1E	1.08.1995Basic TV	TELEVISION
28PT4521/05	710225i stereo large 50Hz	MD1.1E	1.07.1995Basic TV	TELEVISION
28PT4521/13	710225i stereo large 50Hz	MD1.1E	1.08.1995Basic TV	TELEVISION
28PT4521/16	710225i stereo large 50Hz	MD1.1E	1.08.1995Basic TV	TELEVISION
28PT4521/19	710225i stereo large 50Hz	MD1.1E	1.07.1995Basic TV	TELEVISION
28PT4521/39	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
28PT4523/01	710228i (27v) stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
28PT4523/05	710228i (27v) stereo large 50Hz	MD1.2E	1.04.1997Basic TV	TELEVISION
28PT4523/07	710228i (27v) stereo large 50Hz	MD1.2E	1.09.1998Basic TV	TELEVISION
28PT4523/13	710228i (27v) stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
28PT4523/16	710228i (27v) stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
28PT4523/21	710228i (27v) stereo large 50Hz	MD1.2E	1.04.1998Basic TV	TELEVISION
28PT4523/25	710228i (27v) stereo large 50Hz	MD1.2E	1.04.1998Basic TV	TELEVISION
28PT4523/33	710228i (27v) stereo large 50Hz	MD1.2E	1.04.1998Basic TV	TELEVISION
28PT4523/36	710228i (27v) stereo large 50Hz	MD1.2E	1.04.1998Basic TV	TELEVISION
28PT4523/58	710228i (27v) stereo large 50Hz	MD1.2E	1.05.1997Basic TV	TELEVISION
28PT4524/01R	710228i (27v) stereo large 50Hz	A8.0E	Basic TV	TELEVISION
28PT4524/05R	710228i (27v) stereo large 50Hz	A8.0E	Basic TV	TELEVISION
28PT4524/58R	710228i (27v) stereo large 50Hz	A8.0E	Basic TV	TELEVISION
28PT452A/11	710225i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
28PT452A/13	710225i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
28PT452A/16	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT4654/00	700228i (27v) stereo large 50Hz	L6.3	1.09.1998Basic TV	TELEVISION
28PT4655/00	700228i (27v) stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
28PT4655/20	700228i (27v) stereo large 50Hz	L9.1E	1.04.2000Basic TV	TELEVISION
28PT4674/01	700228i (27v) stereo large 50Hz	L6.3	1.12.1998Basic TV	TELEVISION
28PT4674/05	700228i (27v) stereo large 50Hz	L6.3	Basic TV	TELEVISION

28PT4675/01	700228i (27v) stereo large 50Hz	L9.1E	1.09.1999Basic TV	TELEVISION
28PT4675/05	700228i (27v) stereo large 50Hz	L9.1E	Basic TV	TELEVISION
28PT470A/00	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT470A/19	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT470B/19	710225i stereo large 50Hz	GR2.2	1.06.1994Basic TV	TELEVISION
28PT4721/13	710228i (27v) stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
28PT4721/16	710225i stereo large 50Hz	MD1.1E	1.09.1995Basic TV	TELEVISION
28PT472A/13	710225i stereo large 50Hz	GR2.2	1.10.1994Basic TV	TELEVISION
28PT472A/16	710225i stereo large 50Hz	GR2.2	1.10.1993Basic TV	TELEVISION
28PT472B/19	710225i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
28PT4755/00	700228i (27v) stereo large 50Hz	L9.1E	1.10.1999Basic TV	TELEVISION
28PT4755/00S	700228i (27v) stereo large 50Hz	L9.1E	1.05.2000Basic TV	TELEVISION
28PT4775/01	700228i (27v) stereo large 50Hz	L9.1E	1.10.1999Basic TV	TELEVISION
28PT4775/21	28i (27v) stereo large 50Hz			TELEVISION
28PT480A/00	710225i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
28PT480A/06	710225i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
28PT480B/00	710225i stereo large 50Hz	GR2.2	1.05.1994Basic TV	TELEVISION
28PT480C/00	710225i stereo large 50Hz	GR2.2	1.11.1994Basic TV	TELEVISION
28PT481B/00	710225i stereo large 50Hz	GR2.2	1.11.1994Basic TV	TELEVISION
28PT4821/16	710225i stereo large 50Hz	MD1.1E	1.04.1996Basic TV	TELEVISION
28PT482A/05	710225i stereo large 50Hz	GR2.2	1.07.1993Basic TV	TELEVISION
28PT482A/16	710225i stereo large 50Hz	GR2.2	1.06.1994Basic TV	TELEVISION
28PT4855/00S	700228i (27v) stereo large 50Hz	L9.1E	1.11.2001Basic TV	TELEVISION
28PT490A/00	710225i stereo large 50Hz	GR2.2	1.10.1993Basic TV	TELEVISION
28PT5001/02	710225i stereo large 50Hz	MD1.1E	1.08.1996Basic TV	TELEVISION
28PT5001/02B	710228i (27v) stereo large 50Hz	MD1.1E	1.05.1997Basic TV	TELEVISION
28PT5005/00	700228i (27v) stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
28PT5025/01	700228i (27v) stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
28PT5025/05	700228i (27v) stereo large 50Hz	L9.1E	Basic TV	TELEVISION
28PT5025/58	700228i (27v) stereo large 50Hz	L9.1E	1.07.1999Basic TV	TELEVISION
28PT5101/00	710225i stereo large 50Hz	MD1.1E	1.01.1996Basic TV	TELEVISION
28PT5101/03	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
28PT5105/00	700228i (27v) stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
28PT5105/58	700228i (27v) stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
28PT5106/00	700228i (27v) stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
28PT5106/01	700228i (27v) stereo large 50Hz	L9.1E	1.08.2001Basic TV	TELEVISION
28PT5106/58	700228i (27v) stereo large 50Hz	L9.1E	1.09.2001Basic TV	TELEVISION
28PT510A/00	710225i stereo large 50Hz	GR2.2	1.02.1993Basic TV	TELEVISION
28PT510B/00	710225i stereo large 50Hz	GR2.2	1.09.1994Basic TV	TELEVISION
28PT510B/06	710225i stereo large 50Hz	GR2.2	1.05.1995Basic TV	TELEVISION
28PT510B/42	710225i stereo large 50Hz	GR2.2	1.11.1994Basic TV	TELEVISION
28PT5111/02	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION

28PT5121/01	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
28PT5121/13	710225i stereo large 50Hz	MD1.1E	1.11.1995Basic TV	TELEVISION
28PT5121/16	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
28PT5121/39	710225i stereo large 50Hz	MD1.1E	1.10.1995Basic TV	TELEVISION
28PT5125/01	700228i (27v) stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
28PT5125/05	700228i (27v) stereo large 50Hz	L9.1E	Basic TV	TELEVISION
28PT512A/05	710225i stereo large 50Hz	GR2.2	1.09.1994Basic TV	TELEVISION
28PT512A/11	710225i stereo large 50Hz	GR2.2	1.03.1993Basic TV	TELEVISION
28PT512A/16	710225i stereo large 50Hz	GR2.2	1.03.1993Basic TV	TELEVISION
28PT512B/11	710225i stereo large 50Hz	GR2.2	1.09.1994Basic TV	TELEVISION
28PT512B/13	710225i stereo large 50Hz	GR2.2	1.12.1994Basic TV	TELEVISION
28PT512B/16	710225i stereo large 50Hz	GR2.2	1.09.1994Basic TV	TELEVISION
28PT512C/19	710225i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
28PT5155/00S	700228i (27v) stereo large 50Hz	L9.1E	1.06.2000Basic TV	TELEVISION
28PT5205/00	700228i (27v) stereo large 50Hz	L9.1E	1.07.1999Basic TV	TELEVISION
28PT520A/00	710225i stereo large 50Hz	GR2.2	1.12.1993Basic TV	TELEVISION
28PT520A/06	710225i stereo large 50Hz	GR2.2	1.03.1994Basic TV	TELEVISION
28PT522A/11	710225i stereo large 50Hz	GR2.2	1.02.1994Basic TV	TELEVISION
28PT522A/13	710225i stereo large 50Hz	GR2.2	1.03.1994Basic TV	TELEVISION
28PT522A/16	710225i stereo large 50Hz	GR2.2	1.04.1994Basic TV	TELEVISION
28PT522B/01	710225i stereo large 50Hz	GR2.4	1.10.1994Basic TV	TELEVISION
28PT530A/00	710225i stereo large 50Hz	GR2.2	1.08.1993Basic TV	TELEVISION
28PT530A/06	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT530A/15	710225i stereo large 50Hz	GR2.2	1.10.1993Basic TV	TELEVISION
28PT530A/19	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT530B/00	710225i stereo large 50Hz	GR2.4	1.05.1994Basic TV	TELEVISION
28PT530B/01	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
28PT530B/15	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
28PT532A/05	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT532A/11	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT532A/13	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT532A/16	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT532B/01	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
28PT532B/05	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
28PT532B/11	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
28PT532B/13	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
28PT5401/00	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
28PT540A/00	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT540B/00	710225i stereo large 50Hz	GR2.4	1.01.1995Basic TV	TELEVISION
28PT541B/00	710225i stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
28PT542A/16	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28PT542B/01	710225i stereo large 50Hz	GR2.4	1.05.1995Basic TV	TELEVISION

28PT542B/11	710225i stereo large 50Hz	GR2.4	1.02.1995Basic TV	TELEVISION
28PT542B/13	710225i stereo large 50Hz	GR2.4	1.03.1995Basic TV	TELEVISION
28PT5505/01	710228i (27v) stereo large 50Hz	A10E	1.01.2001Basic TV	TELEVISION
28PT550A/00	710225i stereo large 50Hz	GR2.2	1.06.1993Basic TV	TELEVISION
28PT550B/00	710228i (27v) stereo large 50Hz	GR2.4	1.09.1994Basic TV	TELEVISION
28PT552A/13	710225i stereo large 50Hz	GR2.2	1.01.1994Basic TV	TELEVISION
28PT552B/13	710225i stereo large 50Hz	GR2.4	1.12.1994Basic TV	TELEVISION
28PT560A/00	710225i stereo large 50Hz	GR2.3	1.11.1993Basic TV	TELEVISION
28PT560A/02	710225i stereo large 50Hz	GR2.3	1.03.1994Basic TV	TELEVISION
28PT562A/11	710225i stereo large 50Hz	GR2.3	1.12.1993Basic TV	TELEVISION
28PT562A/13	710225i stereo large 50Hz	GR2.3	1.12.1993Basic TV	TELEVISION
28PT570A/01	710225i stereo large 50Hz	GR2.2	1.02.1994Basic TV	TELEVISION
28PT7007/12	720228i stereo large 100Hz	EM2E	1.11.2001Upmarket TV	TELEVISION
28PT7103/12	720228i stereo large 100Hz	MD2.21E	1.10.1997Upmarket TV	TELEVISION
28PT7104/12	720228i stereo large 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
28PT7106/12	720228i stereo large 100Hz	EM2E	1.06.2000Upmarket TV	TELEVISION
28PT7106/12R	720228i stereo large 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
28PT7106/19	720228i stereo large 100Hz	EM2E	1.06.2000Upmarket TV	TELEVISION
28PT7106/19R	720228i stereo large 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
28PT7155/12	720228i stereo large 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
28PT7156/12	720228i stereo large 100Hz	EM2E	1.06.2000Upmarket TV	TELEVISION
28PT7156/12R	720228i stereo large 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
28PT7202/12	720228i stereo large 100Hz	MD2.11E	1.02.1997Upmarket TV	TELEVISION
28PT7203/12	720228i stereo large 100Hz	MD2.21E	1.06.1997Upmarket TV	TELEVISION
28PT7204/12	720228i stereo large 100Hz	MG2.1E	Upmarket TV	TELEVISION
28PT7206/12	720228i stereo large 100Hz	EM2E	1.06.2000Upmarket TV	TELEVISION
28PT7206/12R	720228i stereo large 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
28PT7302/12	720228i stereo large 100Hz	MD2.11E	1.05.1996Upmarket TV	TELEVISION
28PT7302/19	720228i stereo large 100Hz	MD2.11E	1.02.1997Upmarket TV	TELEVISION
28PT7302/58	720225i stereo large 100Hz	MD2.11E	1.08.1997Upmarket TV	TELEVISION
28PT7303/12	720228i stereo large 100Hz	MD2.21E	1.06.1997Upmarket TV	TELEVISION
28PT7303/19	720228i stereo large 100Hz	MD2.21E	1.09.1997Upmarket TV	TELEVISION
28PT7304/12	720228i stereo large 100Hz	MG2.1E	1.09.1998Upmarket TV	TELEVISION
28PT7304/19	720228i stereo large 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
28PT7304/58	720228i stereo large 100Hz	MG2.1E	1.10.1999Upmarket TV	TELEVISION
28PT7306/12	720228i stereo large 100Hz	EM2E	1.06.2000Upmarket TV	TELEVISION
28PT7306/12R	720228i stereo large 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
28PT7306/58	720228i stereo large 100Hz	EM2E	1.06.2000Upmarket TV	TELEVISION
28PT7306/58R	720228i stereo large 100Hz	EM2E	1.01.2001Upmarket TV	TELEVISION
28PT7403/12	720228i stereo large 100Hz	MD2.21E	1.08.1997Upmarket TV	TELEVISION
28PT7404/12	720228i stereo large 100Hz	MG2.1E	1.04.1999Upmarket TV	TELEVISION
28PT800A/00	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION

28PT800A/01	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT800A/19	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT800B/00	720225i stereo large 100Hz	FL*.17	1.05.1994Upmarket TV	TELEVISION
28PT800B/01	720225i stereo large 100Hz	FL*.17	1.08.1994Upmarket TV	TELEVISION
28PT800B/19	720225i stereo large 100Hz	FL*.17	1.05.1994Upmarket TV	TELEVISION
28PT800B/58	720225i stereo large 100Hz	FL*.17	1.02.1996Upmarket TV	TELEVISION
28PT802A/05	720225i stereo large 100Hz	FL*.17	1.11.1993Upmarket TV	TELEVISION
28PT802A/12	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT802B/12	720225i stereo large 100Hz	FL*.17	1.05.1994Upmarket TV	TELEVISION
28PT802B/13	720225i stereo large 100Hz	FL*.17	1.05.1995Upmarket TV	TELEVISION
28PT802B/19	720225i stereo large 100Hz	FL*.17	1.09.1994Upmarket TV	TELEVISION
28PT805A/00	720225i stereo large 100Hz	FL1.7	1.06.1993Upmarket TV	TELEVISION
28PT805A/01	720225i stereo large 100Hz	FL1.7	1.10.1993Upmarket TV	TELEVISION
28PT805A/20	720225i stereo large 100Hz	FL1.7	1.10.1993Upmarket TV	TELEVISION
28PT815A/00	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT817A/12	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT840A/00	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT840A/19	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT840A/20	720225i stereo large 100Hz	FL*.17	1.03.1994Upmarket TV	TELEVISION
28PT840A/39	720225i stereo large 100Hz	FL*.17	1.03.1994Upmarket TV	TELEVISION
28PT840B/00	720225i stereo large 100Hz	FL*.16	1.03.1995Upmarket TV	TELEVISION
28PT842A/12	720225i stereo large 100Hz	FL*.17	1.11.1993Upmarket TV	TELEVISION
28PT842A/27	720225i stereo large 100Hz	FL*.17	1.08.1994Upmarket TV	TELEVISION
28PT842A/32	720225i stereo large 100Hz	FL*.17	1.04.1994Upmarket TV	TELEVISION
28PT842A/39	720225i stereo large 100Hz	FL*.17	1.09.1994Upmarket TV	TELEVISION
28PT842B/07	720225i stereo large 100Hz	FL*.16	1.11.1995Upmarket TV	TELEVISION
28PT842B/12	720225i stereo large 100Hz	FL*.16	1.03.1995Upmarket TV	TELEVISION
28PT842B/13	720225i stereo large 100Hz	FL*.16	1.03.1995Upmarket TV	TELEVISION
28PT842B/19	720225i stereo large 100Hz	FL*.16	1.03.1995Upmarket TV	TELEVISION
28PT845A/00	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT845A/01	720225i stereo large 100Hz	FL*.17	1.10.1993Upmarket TV	TELEVISION
28PT845A/20	720225i stereo large 100Hz	FL*.17	1.03.1994Upmarket TV	TELEVISION
28PT845A/21	720225i stereo large 100Hz	FL*.17	1.04.1994Upmarket TV	TELEVISION
28PT845A/58	720225i stereo large 100Hz	FL*.17	1.11.1994Upmarket TV	TELEVISION
28PT845B/00	720225i stereo large 100Hz	FL*.16	1.03.1995Upmarket TV	TELEVISION
28PT845B/01	720225i stereo large 100Hz	FL*.16	1.03.1995Upmarket TV	TELEVISION
28PT845B/58	720225i stereo large 100Hz	FL*.16	1.04.1995Upmarket TV	TELEVISION
28PT847A/12	720225i stereo large 100Hz	FL*.17	1.12.1993Upmarket TV	TELEVISION
28PT900A/01	720225i stereo large 100Hz	FL*.16	1.06.1993Upmarket TV	TELEVISION
28PT900A/19	720225i stereo large 100Hz	FL*.16	1.08.1993Upmarket TV	TELEVISION
28PT902A/05	720225i stereo large 100Hz	FL*.16	1.07.1993Upmarket TV	TELEVISION
28PT910A/01	720228i stereo large 100Hz	FL*.16	1.06.1993Upmarket TV	TELEVISION

28PT910A/19	720225i stereo large 100Hz	FL*.16	1.07.1993Upmarket TV	TELEVISION
28PT910A/42	720228i stereo large 100Hz	FL*.16	1.03.1994Upmarket TV	TELEVISION
28PT912A/12	720225i stereo large 100Hz	FL*.16	1.06.1993Upmarket TV	TELEVISION
28PT912A/13	720225i stereo large 100Hz	FL*.16	1.08.1993Upmarket TV	TELEVISION
28PV7805/00B	720225i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
28PV7805/20	720225i stereo large 50Hz	FL1.0	1.08.1993Upmarket TV	TELEVISION
28PV7806/00B	720225i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
28PV7806/10B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28PV7806/19B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28PV7806/32	720225i stereo large 50Hz	FL1.0	1.08.1993Upmarket TV	TELEVISION
28PV7806/39	720225i stereo large 50Hz	FL1.0	1.11.1993Upmarket TV	TELEVISION
28PV7970/00B	720225i stereo large 50Hz	FL1.0	1.12.1992Upmarket TV	TELEVISION
28PV7970/02B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7970/20B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7970/20S	720225i stereo large 50Hz	FL1.0	1.05.1992Upmarket TV	TELEVISION
28PV7970/22B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7970/30B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7970/30S	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28PV7976/00B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7976/10B	720228i (27v) stereo large 50Hz	FL1.0	1.04.1992Upmarket TV	TELEVISION
28PV7976/13B	720225i stereo large 50Hz	FL1.0	1.04.1992Upmarket TV	TELEVISION
28PV7976/16B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7976/19B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7976/20B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7976/20S	720228i (27v) stereo large 50Hz	FL1.0	1.04.1992Upmarket TV	TELEVISION
28PV7976/30B	720228i (27v) stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7976/30S	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION
28PV7976/33B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7976/36B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7976/36S	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION
28PV7976/39B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7976/39S	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28PV7978/00B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28PV7978/13B	720228i (27v) stereo large 50Hz	FL1.0	1.03.1993Upmarket TV	TELEVISION
28PV7978/13S	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28PW463A/61R	710228i WS 50Hz no dolby mainstream MD1.0A		Basic TV	TELEVISION
28PW468A/57R	710228i WS 50Hz no dolby mainstream MD1.0A		1.09.1996Basic TV	TELEVISION
28PW468A/75R	710224i WS 50Hz no dolby mainstream MD1.0A		1.11.1996Basic TV	TELEVISION
28PW469A/69R	710228i WS 50Hz no dolby mainstream MD1.0A		1.09.1996Basic TV	TELEVISION
28PW5304/00	710228i WS 50Hz no dolby mainstream A8.0E		1.03.1999Basic TV	TELEVISION
28PW5324/01	710228i WS 50Hz no dolby mainstream A8.0E		1.12.1998Basic TV	TELEVISION
28PW5324/05	710228i WS 50Hz no dolby mainstream A8.0E		1.05.1999Basic TV	TELEVISION

28PW5405/01	710228i WS 50Hz no dolby mainstream A10E	1.08.2000Basic TV	TELEVISION
28PW5406/01	710228i WS 50Hz no dolby mainstream A10E	1.11.2000Basic TV	TELEVISION
28PW5407/01	700228i WS 50Hz no dolby mainstream L01.1E	1.08.2001Basic TV	TELEVISION
28PW5407/05	700228i WS 50Hz no dolby mainstream L01.1E	1.09.2001Basic TV	TELEVISION
28PW5424/01	710228i WS 50Hz no dolby mainstream A8.0E	1.05.2000Basic TV	TELEVISION
28PW6005/01	710228i WS 50Hz no dolby mainstream A10E	1.06.2000Basic TV	TELEVISION
28PW6005/05	710228i WS 50Hz no dolby mainstream A10E	1.06.2000Basic TV	TELEVISION
28PW6005/58	700228i WS 50Hz no dolby mainstream		TELEVISION
28PW6006/01	700228i WS 50Hz no dolby mainstream L01.1E	1.07.2001Basic TV	TELEVISION
28PW6006/05	700228i WS 50Hz no dolby mainstream L01.1E	1.06.2001Basic TV	TELEVISION
28PW6006/21	700228i WS 50Hz no dolby mainstream L01.1E	1.10.2001Basic TV	TELEVISION
28PW6006/25	28i WS 50Hz no dolby mainstream		TELEVISION
28PW6006/48	28i WS 50Hz no dolby mainstream		TELEVISION
28PW6006/58	700228i WS 50Hz no dolby mainstream L01.1E	1.09.2001Basic TV	TELEVISION
28PW6106/05	700228i WS 50Hz no dolby mainstream L01.1E	1.11.2001Basic TV	TELEVISION
28PW6202/00	710228i WS 50Hz no dolby mainstream MD1.2E	1.07.1998Basic TV	TELEVISION
28PW6301/02	710228i WS 50Hz no dolby mainstream MD1.1E	1.06.1996Basic TV	TELEVISION
28PW6301/58	710228i WS 100Hz MD1.1E	1.10.1996Basic TV	TELEVISION
28PW6302/00	710228i WS 50Hz no dolby mainstream MD1.2E	1.03.1997Basic TV	TELEVISION
28PW6302/15	710228i WS 50Hz no dolby mainstream MD1.2E	1.05.1997Basic TV	TELEVISION
28PW6302/58	710224i WS 50Hz no dolby mainstream MD1.2E	1.11.1997Basic TV	TELEVISION
28PW6304/00R	710228i WS 50Hz no dolby mainstream A8.0E	1.05.1999Basic TV	TELEVISION
28PW6305/01	710228i WS 50Hz no dolby mainstream A10E	1.10.2000Basic TV	TELEVISION
28PW6305/05	710228i WS 50Hz no dolby mainstream A10E	1.09.2000Basic TV	TELEVISION
28PW6305/58	710228i WS 50Hz no dolby mainstream A10E	1.11.2000Basic TV	TELEVISION
28PW630A/00	710224i WS 50Hz no dolby mainstream GR2.3	1.07.1993Basic TV	TELEVISION
28PW630A/01	710224i WS 50Hz no dolby mainstream GR2.3	1.10.1993Basic TV	TELEVISION
28PW630B/00	710224i WS 50Hz no dolby mainstream GR2.4	1.02.1995Basic TV	TELEVISION
28PW6312/00	710228i WS 50Hz dolby mainstream MD1.2E	1.05.1997Basic TV	TELEVISION
28PW6315/01	710228i WS 50Hz dolby mainstream A10E	1.04.2001Basic TV	TELEVISION
28PW6315/05	710228i WS 50Hz dolby mainstream A10E	1.12.2000Basic TV	TELEVISION
28PW6321/01	710224i WS 50Hz no dolby mainstream MD1.1E	1.08.1996Basic TV	TELEVISION
28PW6321/12	710224i WS 50Hz no dolby mainstream MD1.1E	1.06.1996Basic TV	TELEVISION
28PW6321/13	710224i WS 50Hz no dolby mainstream MD1.1E	1.11.1996Basic TV	TELEVISION
28PW6321/16	710224i WS 50Hz no dolby mainstream MD1.1E	1.06.1996Basic TV	TELEVISION
28PW6322/01	710228i WS 50Hz no dolby mainstream MD1.2E	1.03.1997Basic TV	TELEVISION
28PW6322/05	710228i WS 50Hz no dolby mainstream MD1.2E	1.10.1997Basic TV	TELEVISION
28PW6322/11	710228i WS 50Hz no dolby mainstream MD1.2E	1.01.1998Basic TV	TELEVISION
28PW6322/13	710228i WS 50Hz no dolby mainstream MD1.2E	1.03.1997Basic TV	TELEVISION
28PW6322/16	710228i WS 50Hz no dolby mainstream MD1.2E	1.04.1997Basic TV	TELEVISION
28PW6322/58	710228i WS 50Hz no dolby mainstream MD1.2E	1.06.1997Basic TV	TELEVISION
28PW6324/01R	710228i WS 50Hz no dolby mainstream A8.0E	1.05.1999Basic TV	TELEVISION

28PW6324/05R	710228i WS 50Hz no dolby mainstream A8.0E	1.06.1999Basic TV	TELEVISION
28PW6324/11R	710228i WS 50Hz no dolby mainstream A8.0E	Basic TV	TELEVISION
28PW6324/58R	710228i WS 50Hz no dolby mainstream A8.0E	1.06.1999Basic TV	TELEVISION
28PW632A/05	710224i WS 50Hz no dolby mainstream GR2.3	1.01.1994Basic TV	TELEVISION
28PW632A/11	710224i WS 50Hz no dolby mainstream GR2.3	1.12.1993Basic TV	TELEVISION
28PW632A/13	710224i WS 50Hz no dolby mainstream GR2.3	1.01.1994Basic TV	TELEVISION
28PW632B/01	710224i WS 50Hz no dolby mainstream GR2.4	1.11.1994Basic TV	TELEVISION
28PW632B/05	710224i WS 50Hz no dolby mainstream GR2.4	1.01.1995Basic TV	TELEVISION
28PW6332/01	710228i WS 50Hz dolby mainstream MD1.2E	1.03.1997Basic TV	TELEVISION
28PW6332/05	710228i WS 50Hz dolby mainstream MD1.2E	1.04.1997Basic TV	TELEVISION
28PW6332/11	710228i WS 50Hz dolby mainstream MD1.2E	1.11.1998Basic TV	TELEVISION
28PW6515/01	710228i WS 50Hz dolby mainstream A10E	1.10.2000Basic TV	TELEVISION
28PW6515/05	710228i WS 50Hz dolby mainstream A10E	1.10.2000Basic TV	TELEVISION
28PW6516/79R	32i WS 50Hz dolby mainstream		TELEVISION
28PW6526/01	700228i WS 50Hz dolby mainstream A10E	1.07.2001Basic TV	TELEVISION
28PW6526/05	700228i WS 50Hz dolby mainstream A10E	1.07.2001Basic TV	TELEVISION
28PW660B/00	710224i WS 50Hz no dolby mainstream GR2.4	1.06.1995Basic TV	TELEVISION
28PW6615/05	710228i WS 50Hz dolby mainstream MG1.1E	1.02.2000Upmarket TV	TELEVISION
28PW6615/12	710228i WS 50Hz dolby mainstream MG1.1E	Upmarket TV	TELEVISION
28PW6615/19	710228i WS 50Hz dolby mainstream MG1.1E	Upmarket TV	TELEVISION
28PW662B/01	710228i WS 50Hz dolby mainstream GR2.4	1.08.1995Basic TV	TELEVISION
28PW662B/05	710228i WS 50Hz dolby mainstream GR2.4	1.06.1995Basic TV	TELEVISION
28PW6816/01	201428i WS 50Hz dolby mainstream A10E	1.05.2001Basic TV	TELEVISION
28PW6816/05	201428i WS 50Hz dolby mainstream A10E	1.06.2001Basic TV	TELEVISION
28PW6826/01	201428i WS 50Hz dolby mainstream A10E	1.09.2001Basic TV	TELEVISION
28PW6826/05	201428i WS 50Hz dolby mainstream A10E	1.09.2001Basic TV	TELEVISION
28PW756A/90	720228i WS 100Hz GFL2.00A	1.03.1996Upmarket TV	TELEVISION
28PW757A/57	720228i WS 100Hz GFL2.00A	1.03.1996Upmarket TV	TELEVISION
28PW757A/69	720228i WS 100Hz GFL2.00A	1.02.1996Upmarket TV	TELEVISION
28PW757A/75	720228i WS 100Hz GFL2.00A	1.03.1996Upmarket TV	TELEVISION
28PW757A/79	720228i WS 100Hz GFL2.00A	1.06.1996Upmarket TV	TELEVISION
28PW757B/57	720228i WS 100Hz GFL2.00A	1.09.1996Upmarket TV	TELEVISION
28PW757B/69	720228i WS 100Hz GFL2.00A	1.07.1996Upmarket TV	TELEVISION
28PW758A/97	720228i WS 100Hz GFL2.00A	1.03.1996Upmarket TV	TELEVISION
28PW769B/61	720228i WS 100Hz GFL2.00A	Upmarket TV	TELEVISION
28PW777A/93	720228i WS 100Hz GFL2.00A	1.03.1996Upmarket TV	TELEVISION
28PW778B/78	720228i WS 100Hz GFL2.00A	1.07.1998Upmarket TV	TELEVISION
28PW778B/78R	720228i WS 100Hz GFL2.00A	Upmarket TV	TELEVISION
28PW787C/69	720228i WS 100Hz GFL2.00A	1.01.1997Upmarket TV	TELEVISION
28PW787C/79	720228i WS 100Hz GFL2.00A	1.04.1997Upmarket TV	TELEVISION
28PW787C/93	720228i WS 100Hz GFL2.00A	1.04.1997Upmarket TV	TELEVISION
28PW789C/61R	700228i WS 100Hz		TELEVISION

28PW8206/12	720228i WS 100Hz	EM2E	1.08.2000Upmarket TV	TELEVISION
28PW8206/12R	720228i WS 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
28PW8504/12	720228i WS 100Hz	MG2.1E	1.09.1998Upmarket TV	TELEVISION
28PW8504/19	720228i WS 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
28PW8505/12	720228i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
28PW8505/12S	720228i WS 100Hz	MG2.1E	1.11.1999Upmarket TV	TELEVISION
28PW8505/19	720228i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
28PW8505/58	720228i WS 100Hz	MG2.1E	1.11.1999Upmarket TV	TELEVISION
28PW8506/12	720228i WS 100Hz	EM2E	1.08.2000Upmarket TV	TELEVISION
28PW8506/12R	720228i WS 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
28PW8506/19	720228i WS 100Hz	EM2E	1.09.2000Upmarket TV	TELEVISION
28PW8506/19R	720228i WS 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
28PW8506/58	720228i WS 100Hz	EM2E	1.09.2000Upmarket TV	TELEVISION
28PW8506/58R	720228i WS 100Hz	EM2E	1.02.2001Upmarket TV	TELEVISION
28PW8707/12	720228i WS 100Hz	EM2E	1.05.2001Upmarket TV	TELEVISION
28PW8707/19	28i WS 100Hz			TELEVISION
28PW8707/58	720228i WS 100Hz	EM2E	1.09.2001Upmarket TV	TELEVISION
28PW8717/12	720228i WS 100Hz	EM2E	1.11.2001Upmarket TV	TELEVISION
28PW8806/12	720228i WS 100Hz	MG2.1E	1.08.2000Upmarket TV	TELEVISION
28PW8806/12R	720228i WS 100Hz	MG2.1E	1.12.2000Upmarket TV	TELEVISION
28PW8806/19	720228i WS 100Hz	MG2.1E	1.08.2000Upmarket TV	TELEVISION
28PW8806/19R	720228i WS 100Hz	MG2.1E	1.12.2000Upmarket TV	TELEVISION
28PW8806/58	720228i WS 100Hz	MG2.1E	1.09.2000Upmarket TV	TELEVISION
28PW8806/58R	720228i WS 100Hz	MG2.1E	1.12.2000Upmarket TV	TELEVISION
28PW8807/12	720228i WS 100Hz	EM3E	1.09.2001Upmarket TV	TELEVISION
28PW8807/19	720228i WS 100Hz	EM3E	1.09.2001Upmarket TV	TELEVISION
28PW9501/01	720228i WS 100Hz	GFL2.20E	1.06.1995Upmarket TV	TELEVISION
28PW9502/12	720228i WS 100Hz	MD2.12E	1.08.1996Upmarket TV	TELEVISION
28PW9502/19	720228i WS 100Hz	MD2.12E	1.08.1996Upmarket TV	TELEVISION
28PW9503/12	720228i WS 100Hz	MD2.22E	1.05.1997Upmarket TV	TELEVISION
28PW9503/19	720228i WS 100Hz	MD2.22E	1.06.1997Upmarket TV	TELEVISION
28PW9505/12	720228i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
28PW9505/19	720228i WS 100Hz	MG2.1E	1.10.1999Upmarket TV	TELEVISION
28PW9512/05	720228i WS 100Hz	MD2.12E	1.09.1996Upmarket TV	TELEVISION
28PW9513/05	720228i WS 100Hz	MD2.22E	1.05.1997Upmarket TV	TELEVISION
28PW9513/12	720228i WS 100Hz	MD2.22E	1.04.1997Upmarket TV	TELEVISION
28PW9513/19	720228i WS 100Hz	MD2.22E	1.05.1997Upmarket TV	TELEVISION
28PW9513/32	720228i WS 100Hz	MD2.22E	1.07.1998Upmarket TV	TELEVISION
28PW9513/39	720228i WS 100Hz	MD2.22E	1.09.1998Upmarket TV	TELEVISION
28PW9515/05	720228i WS 100Hz	MG2.1E	1.06.1999Upmarket TV	TELEVISION
28PW9515/12	720228i WS 100Hz	MG2.1E	1.03.1999Upmarket TV	TELEVISION
28PW9515/19	720228i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION

28PW9515/58	720228i WS 100Hz	MG2.1E	1.10.1999Upmarket TV	TELEVISION
28PW9521/05	720228i WS 100Hz	GFL2.20E	Upmarket TV	TELEVISION
28PW9521/12	720228i WS 100Hz	GFL2.20E	1.06.1995Upmarket TV	TELEVISION
28PW9521/19	720228i WS 100Hz	GFL2.20E	1.05.1995Upmarket TV	TELEVISION
28PW9525/05	720228i WS 100Hz	MG3.1E	1.06.2000Upmarket TV	TELEVISION
28PW9525/05L	720228i WS 100Hz	MG3.1E	1.09.2000Upmarket TV	TELEVISION
28PW9525/05R	720228i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
28PW9525/12	720228i WS 100Hz	MG3.1E	1.06.2000Upmarket TV	TELEVISION
28PW9525/12L	720228i WS 100Hz	MG3.1E	1.09.2000Upmarket TV	TELEVISION
28PW9525/12R	720228i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
28PW9525/19	720228i WS 100Hz	MG3.1E	1.06.2000Upmarket TV	TELEVISION
28PW9525/19L	720228i WS 100Hz	MG3.1E	1.09.2000Upmarket TV	TELEVISION
28PW9525/19R	28i WS 100Hz			TELEVISION
28PW9525/58L	720228i WS 100Hz	MG3.1E	1.09.2000Upmarket TV	TELEVISION
28PW9525/58R	720228i WS 100Hz	MG7.1E	1.04.2001Upmarket TV	TELEVISION
28PW9535/05	720228i WS 100Hz	MG2.1E	1.05.2000Upmarket TV	TELEVISION
28PW9535/12	720228i WS 100Hz	MG2.1E	1.03.2000Upmarket TV	TELEVISION
28PW9535/19	720228i WS 100Hz	MG2.1E	Upmarket TV	TELEVISION
28PW9536/05	720228i WS 100Hz	MG7.1E	1.10.2000Upmarket TV	TELEVISION
28PW9536/05R	720228i WS 100Hz	MG7.1E	1.02.2001Upmarket TV	TELEVISION
28PW9536/12	720228i WS 100Hz	MG7.1E	1.08.2000Upmarket TV	TELEVISION
28PW9536/12R	720228i WS 100Hz	MG7.1E	1.01.2001Upmarket TV	TELEVISION
28PW9536/19	28i WS 100Hz			TELEVISION
28PW9545/05	720228i WS 100Hz	MG2.1E	1.03.2000Upmarket TV	TELEVISION
28PW9545/12	720228i WS 100Hz	MG2.1E	1.03.2000Upmarket TV	TELEVISION
28PW9545/19	720228i WS 100Hz	MG2.1E	1.04.2000Upmarket TV	TELEVISION
28PW960A/01	720228i WS 100Hz	FL*.14	1.07.1993Upmarket TV	TELEVISION
28PW960A/19	720228i WS 100Hz	FL*.14	1.08.1993Upmarket TV	TELEVISION
28PW960B/01	720228i WS 100Hz	FL*.24	1.04.1994Upmarket TV	TELEVISION
28PW960B/19	720228i WS 100Hz	FL*.24	1.04.1994Upmarket TV	TELEVISION
28PW960B/42	720228i WS 100Hz	FL*.24	1.12.1994Upmarket TV	TELEVISION
28PW960B/58	720228i WS 100Hz	FL*.24	1.08.1994Upmarket TV	TELEVISION
28PW9611/01	720228i WS 100Hz	GFL2.30E	1.08.1995Upmarket TV	TELEVISION
28PW9611/58	720228i WS 100Hz	GFL2.30E	1.11.1995Upmarket TV	TELEVISION
28PW9615/01	720228i WS 100Hz	MG3.1E	1.11.1999Upmarket TV	TELEVISION
28PW9615/05	720228i WS 100Hz	MG3.1E	1.07.1999Upmarket TV	TELEVISION
28PW9615/12	720228i WS 100Hz	MG3.1E	1.08.1999Upmarket TV	TELEVISION
28PW9615/19	720228i WS 100Hz	MG3.1E	1.09.1999Upmarket TV	TELEVISION
28PW9616/01	700228i WS 100Hz			TELEVISION
28PW9616/01R	720228i WS 100Hz	MG3.1E	1.11.2000Upmarket TV	TELEVISION
28PW9616/05	720228i WS 100Hz	MG3.1E	1.06.2000Upmarket TV	TELEVISION
28PW9616/05R	720228i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION

28PW9616/12	720228i WS 100Hz	MG3.1E	1.06.2000Upmarket TV	TELEVISION
28PW9616/12R	720228i WS 100Hz	MG3.1E	1.11.2000Upmarket TV	TELEVISION
28PW9616/58	720228i WS 100Hz	MG3.1E	Upmarket TV	TELEVISION
28PW9617/01	28i WS 100Hz			TELEVISION
28PW9617/05	28i WS 100Hz			TELEVISION
28PW9617/12	28i WS 100Hz			TELEVISION
28PW9617/19	28i WS 100Hz			TELEVISION
28PW9623/05	720228i WS 100Hz	MD2.22E	1.06.1998Upmarket TV	TELEVISION
28PW9623/12	720228i WS 100Hz	MD2.22E	1.07.1998Upmarket TV	TELEVISION
28PW9623/19	720228i WS 100Hz	MD2.22E	1.08.1998Upmarket TV	TELEVISION
28PW9623/58	720228i WS 100Hz	MD2.22E	1.07.1998Upmarket TV	TELEVISION
28PW962A/12	720228i WS 100Hz	FL*.14	1.09.1993Upmarket TV	TELEVISION
28PW962B/12	720228i WS 100Hz	FL*.24	1.04.1994Upmarket TV	TELEVISION
28PW962B/19	720228i WS 100Hz	FL*.24	1.09.1994Upmarket TV	TELEVISION
28PW9631/05	720228i WS 100Hz	GFL2.30E	1.10.1995Upmarket TV	TELEVISION
28PW9631/12	720228i WS 100Hz	GFL2.30E	1.10.1995Upmarket TV	TELEVISION
28PW9631/19	720228i WS 100Hz	GFL2.30E	1.10.1995Upmarket TV	TELEVISION
28PW9631/25	720228i WS 100Hz	GFL2.30E	1.11.1996Upmarket TV	TELEVISION
28PW9671/69	720228i WS 100Hz	GFL2.20E	1.06.1995Upmarket TV	TELEVISION
28PW9761/01	720228i WS 100Hz	GFL2.30E	1.02.1996Upmarket TV	TELEVISION
28PW9763/12	720228i WS 100Hz	MD2.22E	1.07.1997Upmarket TV	TELEVISION
28PW9763/19	720228i WS 100Hz	MD2.22E	1.01.1998Upmarket TV	TELEVISION
28PW9763/32	720228i WS 100Hz	MD2.22E	1.07.1998Upmarket TV	TELEVISION
28PW9763/58	720228i WS 100Hz	MD2.22E	1.09.1997Upmarket TV	TELEVISION
28PW9781/12	720228i WS 100Hz	GFL2.30E	1.02.1996Upmarket TV	TELEVISION
28SA01/05	700228i (27v) stereo large 50Hz	L9.1E	Basic TV	TELEVISION
28SL5770/00B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5770/02B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5770/20B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5770/20S	720225i stereo large 50Hz	FL1.0	1.05.1992Upmarket TV	TELEVISION
28SL5770/22B	720225i stereo large 50Hz	FL1.0	1.04.1993Upmarket TV	TELEVISION
28SL5770/25B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5770/25S	700228i (27v) stereo large 50Hz			TELEVISION
28SL5776/00B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/10B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/13B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/16B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/19B	720225i stereo large 50Hz	FL1.0	1.04.1992Upmarket TV	TELEVISION
28SL5776/20B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/20S	720225i stereo large 50Hz	FL1.0	1.04.1992Upmarket TV	TELEVISION
28SL5776/30B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/30S	720225i stereo large 50Hz	FL1.0	1.06.1992Upmarket TV	TELEVISION

28SL5776/33B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/36B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/36S	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28SL5776/39B	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
28SL5776/39S	720225i stereo large 50Hz	FL1.0	1.05.1992Upmarket TV	TELEVISION
28SL5800/00B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28SL5800/20	720225i stereo large 50Hz	FL1.0	1.07.1993Upmarket TV	TELEVISION
28SL5801/00B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28SL5801/07B	720225i stereo large 50Hz	FL1.0	1.10.1992Upmarket TV	TELEVISION
28SL5801/10B	720225i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
28SL5801/13B	720225i stereo large 50Hz	FL1.0	1.02.1993Upmarket TV	TELEVISION
28SL5801/19B	720225i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
28SL5801/39	720225i stereo large 50Hz	FL1.0	1.09.1993Upmarket TV	TELEVISION
28ST1181/02B	710225i stereo large 50Hz	GR2.1	1.04.1992Basic TV	TELEVISION
28ST1281/02B	710225i stereo large 50Hz	GR2.1	1.04.1992Basic TV	TELEVISION
28ST1414/13R	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1414/33R	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1617/19B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1617/39B	710225i stereo large 50Hz	GR2.1	1.04.1992Basic TV	TELEVISION
28ST1637/19B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1637/39B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1686/19B	710225i stereo large 50Hz	GR2.1	1.04.1992Basic TV	TELEVISION
28ST1686/39B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1687/39B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1712/02B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1712/10B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1712/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/02B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/08B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/10B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/10V	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/13B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/16B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/28B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/30B	710225i stereo large 50Hz	GR2.1	1.05.1992Basic TV	TELEVISION
28ST1714/30V	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1714/33B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1717/10B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1717/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1734/02B	710225i stereo large 50Hz	GR2.1	1.08.1992Basic TV	TELEVISION
28ST1734/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION

28ST1734/28B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1770/25B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/02B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/08B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/10B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/12B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/13B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/16B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/28B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/32B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/33B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1780/36B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1781/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1781/25B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1781/28B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1781/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1781/33B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1781/36B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1786/30B	710225i stereo large 50Hz	GR2.1	1.04.1992Basic TV	TELEVISION
28ST1787/30B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1789/22Z	710225i stereo large 50Hz	GR2.1	1.05.1992Basic TV	TELEVISION
28ST1789/30Z	710225i stereo large 50Hz	GR2.1	1.05.1992Basic TV	TELEVISION
28ST1814/12B	710225i stereo large 50Hz	GR2.1	1.04.1992Basic TV	TELEVISION
28ST1814/32B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST1881/32B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
28ST2181/10B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
28ST2181/19B	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28ST2281/10B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
28ST2281/16B	710225i stereo large 50Hz	GR2.2	1.04.1993Basic TV	TELEVISION
28ST2287/19B	710225i stereo large 50Hz	GR2.2	1.12.1992Basic TV	TELEVISION
28ST2471/02B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
28ST2471/08B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2471/10B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
28ST2471/12B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2471/13B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
28ST2471/16B	710225i stereo large 50Hz	GR2.2	1.12.1992Basic TV	TELEVISION
28ST2477/10B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
28ST2477/42B	710225i stereo large 50Hz	GR2.2	1.03.1993Basic TV	TELEVISION
28ST2674/19B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
28ST2686/19B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION

28ST2686/39B	710225i stereo large 50Hz	GR2.2	1.09.1993Basic TV	TELEVISION
28ST2687/19B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2687/42B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
28ST2780/08B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
28ST2780/10B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2780/13B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2780/16B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
28ST2781/02B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
28ST2781/05B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
28ST2781/08B	710225i stereo large 50Hz	GR2.2	1.10.1992Basic TV	TELEVISION
28ST2781/10B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
28ST2781/13B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2781/16B	710225i stereo large 50Hz	GR2.2	1.05.1992Basic TV	TELEVISION
28ST2781/22B	710225i stereo large 50Hz	GR2.2	1.02.1993Basic TV	TELEVISION
28ST2784/13B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
28ST2786/10B	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
28ST2787/10B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2787/42B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2789/02Z	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
28ST2789/10Z	710225i stereo large 50Hz	GR2.2	1.07.1992Basic TV	TELEVISION
28ST2880/12B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
28ST2884/12B	710225i stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
28ST2981/10B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
28ST2981/16B	710225i stereo large 50Hz	GR2.2	1.09.1992Basic TV	TELEVISION
28ST2987/19B	710225i stereo large 50Hz	GR2.2	1.10.1992Basic TV	TELEVISION
29AJ2694/99	1041Clock radio		1.09.1993	CLOCKRADIO
29AJ2695/99	1041Clock radio		1.09.1993	CLOCKRADIO
29AK641/99	1049CD		1.10.1993	CD PLAYERS
29AK721/99	1049CD		1.10.1993	CD PLAYERS
29AL454/99	1041Radio + Cassette		1.03.1992	PERSONAL STEREO
29AQ4008/99	1041Radio cassette recorders - mono		1.09.1994	RADIO MONO + STEREO
29AQ8609/99	1041Radio cassette recorders - mono		1.03.1992	RADIO MONO + STEREO
29AQ8610/99	1041Radio cassette recorders - mono		1.03.1992	RADIO MONO + STEREO
29AS9010/99	1049		1.05.1993	MIDISYSTEMS
29AW8627/99	1041Radio cassette recorders - mono		1.06.1993	RADIO MONO + STEREO
29D2680/99	1041Clock radio		1.03.1992	CLOCKRADIO
29D2688/99	1041Clock radio		1.03.1992	CLOCKRADIO
29D6685/99	1041Radio + Cassette		1.06.1992	PERSONAL STEREO
29D7007/99	1041Radio cassette recorders - mono		1.03.1992	RADIO MONO + STEREO
29D7008/99	1041Radio cassette recorders - mono		1.06.1993	RADIO MONO + STEREO
29D7181/99	1041Radio cassette recorders - mono		1.07.1992	RADIO MONO + STEREO
29D8605/99	1041Radio cassette recorders - mono		1.03.1992	RADIO MONO + STEREO

29D8625/99	1041Radio cassette recorders - mono		1.03.1992	RADIO MONO + STEREO
29DS100/93	720225i stereo large 100Hz	MG2.1E	1.02.1999Upmarket TV	TELEVISION
29F1909/99	1049		1.05.1993	MIDISYSTEMS
29F1914/99	1049		1.06.1993	MIDISYSTEMS
29F1916/99	1049		1.12.1993	MIDISYSTEMS
29F202/99	1049		1.05.1993	MIDISYSTEMS
29FL1770/56R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
29FL1770/57R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
29FL1770/62R	720225i stereo large 50Hz	FL1.0S	1.12.1992Upmarket TV	TELEVISION
29FL1770/69R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
29FL1770/73R	720225i stereo large 50Hz	FL1.0S	1.11.1992Upmarket TV	TELEVISION
29FL1770/75R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
29FL1770/79R	720225i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
29FL1770/93R	720225i stereo large 50Hz	FL1.0S	1.07.1993Upmarket TV	TELEVISION
29FL1775/77R	720225i mono	FL1.0S	1.03.1992Upmarket TV	TELEVISION
29FL1775/78R	720225i mono	FL1.0S	1.04.1992Upmarket TV	TELEVISION
29FL1775/85R	720225i mono	FL1.0S	1.06.1992Upmarket TV	TELEVISION
29FL1775/97R	720225i mono	FL1.0S	1.03.1992Upmarket TV	TELEVISION
29FT5515/01	700229i stereo large 50Hz			TELEVISION
29FT5515/58	700229i stereo large 50Hz			TELEVISION
29GX1890/57R	700225i stereo large 50Hz	ANUBIS_S	1.11.1994Basic TV	TELEVISION
29GX1890/71R	700225i stereo large 50Hz	ANUBIS_S	1.06.1995Basic TV	TELEVISION
29GX1890/75R	700225i stereo large 50Hz	ANUBIS_S	1.02.1995Basic TV	TELEVISION
29GX1890/77B	700225i stereo large 50Hz	ANUBIS_S	1.06.1996Basic TV	TELEVISION
29GX1890/93R	700225i stereo large 50Hz	ANUBIS_S	1.01.1995Basic TV	TELEVISION
29GX1890/97R	700225i stereo large 50Hz	ANUBIS_S	1.01.1995Basic TV	TELEVISION
29GX1891/00R	700225i stereo large 50Hz	ANUBIS_S	1.10.1996Basic TV	TELEVISION
29GX1891/56H	700225i stereo large 50Hz	ANUBIS_S	1.05.1996Basic TV	TELEVISION
29GX1891/56R	700225i stereo large 50Hz	ANUBIS_S	1.03.1995Basic TV	TELEVISION
29GX1891/58H	700225i stereo large 50Hz	ANUBIS_S	1.05.1995Basic TV	TELEVISION
29GX1891/75R	700225i stereo large 50Hz	ANUBIS_S	1.02.1995Basic TV	TELEVISION
29GX1891/93R	700225i stereo large 50Hz	ANUBIS_S	1.06.1995Basic TV	TELEVISION
29GX1892/54R	700225i stereo large 50Hz			TELEVISION
29GX1893/57R	700225i stereo large 50Hz	ANUBIS_S	1.09.1995Basic TV	TELEVISION
29GX1893/75R	700225i stereo large 50Hz	ANUBIS_S	1.10.1995Basic TV	TELEVISION
29GX1893/93S	700225i stereo large 50Hz	ANUBIS_S	1.04.1996Basic TV	TELEVISION
29GX1895/78R	700225i stereo large 50Hz			TELEVISION
29GX1896/00R	700225i stereo large 50Hz	ANUBIS_S	1.10.1996Basic TV	TELEVISION
29GX1896/56H	700225i stereo large 50Hz	ANUBIS_S	1.04.1996Basic TV	TELEVISION
29GX1896/56R	700225i stereo large 50Hz	ANUBIS_S	1.05.1996Basic TV	TELEVISION
29GX1896/58H	700225i stereo large 50Hz	ANUBIS_S	1.11.1995Basic TV	TELEVISION
29GX1896/75R	700225i stereo large 50Hz	ANUBIS_S	1.11.1995Basic TV	TELEVISION

29GX1897/71R	700225i stereo large 50Hz	ANUBIS_S	1.03.1996Basic TV	TELEVISION
29GX1897/97R	700225i stereo large 50Hz	ANUBIS_S	1.10.1995Basic TV	TELEVISION
29GX1898/78R	700225i stereo large 50Hz		1.01.1997	TELEVISION
29GX1899/78R	700225i stereo large 50Hz		1.02.1997	TELEVISION
29GX1990/69R	700225i stereo large 50Hz	ANUBIS_S	1.12.1994Basic TV	TELEVISION
29GX1990/75R	700225i stereo large 50Hz	ANUBIS_S	1.04.1995Basic TV	TELEVISION
29GX1990/79R	700225i stereo large 50Hz	ANUBIS_S	1.02.1995Basic TV	TELEVISION
29GX1995/68R	700225i stereo large 50Hz	ANUBIS_S	1.02.1997Basic TV	TELEVISION
29GX1995/69R	700225i stereo large 50Hz	ANUBIS_S	1.12.1995Basic TV	TELEVISION
29GX1995/75R	700225i stereo large 50Hz	ANUBIS_S	1.11.1995Basic TV	TELEVISION
29GX1995/79R	700225i stereo large 50Hz	ANUBIS_S	1.11.1995Basic TV	TELEVISION
29HT2011/93Z	29i (27v) Stereo ITV			INSTITUTIONAL TV
29HT2217/69Y	29i (27v) Stereo ITV			INSTITUTIONAL TV
29HT4677/69Y	201329i (27v) Stereo ITV	L9H.1A	1.09.2000Institutional TV	INSTITUTIONAL TV
29MMTV/57V	710221i Multimedia	MD1.0A	1.11.1996Basic TV	TELEVISION
29MMTV/61V	710221i Multimedia	MD1.0A	Basic TV	TELEVISION
29MMTV/69V	710229i Multimedia	MD1.0A	1.09.1996Basic TV	TELEVISION
29MMTV/75V	710221i Multimedia	MD1.0A	1.10.1996Basic TV	TELEVISION
29MMTV/79V	710221i Multimedia	MD1.0A	1.11.1996Basic TV	TELEVISION
29PT2152/56A	700229i stereo large 50Hz	L01.1A	1.09.2001Basic TV	TELEVISION
29PT2152/68R	700229i stereo large 50Hz	L01.1A	1.10.2001Basic TV	TELEVISION
29PT2152/69R	700229i stereo large 50Hz	L01.1A	1.07.2001Basic TV	TELEVISION
29PT2152/71R	29i stereo large 50Hz			TELEVISION
29PT2152/79R	700229i stereo large 50Hz	L01.1A	1.11.2001Basic TV	TELEVISION
29PT2252/56A	700229i stereo large 50Hz	L01.1A	1.11.2001Basic TV	TELEVISION
29PT2252/57R	700229i stereo large 50Hz	L01.1A	1.09.2001Basic TV	TELEVISION
29PT2252/68R	700229i stereo large 50Hz	L01.1A	1.09.2001Basic TV	TELEVISION
29PT2252/69R	700229i stereo large 50Hz	L01.1A	1.09.2001Basic TV	TELEVISION
29PT2252/71R	29i stereo large 50Hz			TELEVISION
29PT2252/79R	700229i stereo large 50Hz	L01.1A	1.10.2001Basic TV	TELEVISION
29PT2252/97R	29i stereo large 50Hz			TELEVISION
29PT4223/59C	700229i stereo large 50Hz	L9.1A	1.06.1999Basic TV	TELEVISION
29PT4273/75R	700229i stereo large 50Hz	L9.1A	1.07.1999Basic TV	TELEVISION
29PT4423/68R	700229i stereo large 50Hz	L7.3A	1.06.1998Basic TV	TELEVISION
29PT4423/79R	700229i stereo large 50Hz	L7.3A	1.06.1998Basic TV	TELEVISION
29PT442A/56H	710229i stereo large 50Hz	MD1.0A	1.09.1996Basic TV	TELEVISION
29PT442A/56R	710229i stereo large 50Hz	MD1.0A	1.12.1996Basic TV	TELEVISION
29PT442A/75R	710229i stereo large 50Hz	MD1.0A	1.09.1996Basic TV	TELEVISION
29PT4473/75R	700229i stereo large 50Hz	L7.3A	1.07.1998Basic TV	TELEVISION
29PT4473/79R	700229i stereo large 50Hz	L7.3A	1.04.1998Basic TV	TELEVISION
29PT448A/68R	710229i stereo large 50Hz	MD1.0A	1.02.1997Basic TV	TELEVISION
29PT449A/79R	710229i stereo large 50Hz	MD1.0A	1.08.1996Basic TV	TELEVISION

29PT461A/97R	710229i stereo large 50Hz	MD1.0A	1.02.1997Basic TV	TELEVISION
29PT4622/71R	700229i stereo large 50Hz	L7.3A	1.07.1998Basic TV	TELEVISION
29PT4622/97R	700229i stereo large 50Hz	L7.3A	1.11.1998Basic TV	TELEVISION
29PT462A/69R	710229i stereo large 50Hz	MD1.0A	1.12.1997Basic TV	TELEVISION
29PT462A/73R	710229i stereo large 50Hz	MD1.0A	Basic TV	TELEVISION
29PT463A/61R	710229i stereo large 50Hz	MD1.0A	Basic TV	TELEVISION
29PT463A/71R	710229i stereo large 50Hz	MD1.0A	1.10.1996Basic TV	TELEVISION
29PT463A/97R	710229i stereo large 50Hz	MD1.0A	1.02.1997Basic TV	TELEVISION
29PT4663/56A	700229i stereo large 50Hz	L7.3A	Basic TV	TELEVISION
29PT4663/56R	700229i stereo large 50Hz	L7.3A	1.06.1998Basic TV	TELEVISION
29PT4663/57R	700229i stereo large 50Hz	L7.3A	1.07.1998Basic TV	TELEVISION
29PT4663/73R	700229i stereo large 50Hz	L7.3A	Basic TV	TELEVISION
29PT4666/57Y	700229i stereo large 50Hz	L7.3A	1.11.1998Basic TV	TELEVISION
29PT4673/68R	700229i stereo large 50Hz	L7.3A	1.01.1999Basic TV	TELEVISION
29PT4673/69R	700229i stereo large 50Hz	L7.3A	1.05.1998Basic TV	TELEVISION
29PT4673/75R	700229i stereo large 50Hz	L7.3A	1.07.1998Basic TV	TELEVISION
29PT4676/57Y	700229i stereo large 50Hz	L7.3A	Basic TV	TELEVISION
29PT4676/69R	700229i stereo large 50Hz	L7.3A	Basic TV	TELEVISION
29PT4676/69W	700229i stereo large 50Hz	L7.3A	1.07.1999Basic TV	TELEVISION
29PT468A/57R	710229i stereo large 50Hz	MD1.0A	1.08.1996Basic TV	TELEVISION
29PT468A/75R	710225i stereo large 50Hz	MD1.0A	1.08.1996Basic TV	TELEVISION
29PT469A/68R	710229i stereo large 50Hz	MD1.0A	1.02.1997Basic TV	TELEVISION
29PT469A/69R	710229i stereo large 50Hz	MD1.0A	1.06.1996Basic TV	TELEVISION
29PT469A/75R	710229i stereo large 50Hz	MD1.0A	1.09.1996Basic TV	TELEVISION
29PT469A/79R	710229i stereo large 50Hz	MD1.0A	1.08.1996Basic TV	TELEVISION
29PT4822/71R	700229i stereo large 50Hz	L9.1A	1.08.1999Basic TV	TELEVISION
29PT4822/97R	700229i stereo large 50Hz	L9.1A	1.09.1999Basic TV	TELEVISION
29PT4823/57R	700229i stereo large 50Hz	L9.1A	1.08.1999Basic TV	TELEVISION
29PT4873/56A	700229i stereo large 50Hz	L9.1A	1.09.1999Basic TV	TELEVISION
29PT4873/57R	700229i stereo large 50Hz	L9.1A	1.09.2000Basic TV	TELEVISION
29PT4873/68R	700229i stereo large 50Hz	L9.1A	1.12.2000Basic TV	TELEVISION
29PT4873/69R	700229i stereo large 50Hz	L9.1A	1.04.1999Basic TV	TELEVISION
29PT4873/79R	700229i stereo large 50Hz	L9.1A	1.08.1999Basic TV	TELEVISION
29PT4922/71R	700229i stereo large 50Hz	L9.1A	Basic TV	TELEVISION
29PT4922/97R	700229i stereo large 50Hz	L9.1A	Basic TV	TELEVISION
29PT4973/56A	700229i stereo large 50Hz	L9.1A	Basic TV	TELEVISION
29PT4973/57R	700229i stereo large 50Hz	L9.1A	Basic TV	TELEVISION
29PT4973/68R	700229i stereo large 50Hz	L9.1A	Basic TV	TELEVISION
29PT4973/69R	700229i stereo large 50Hz	L9.1A	Basic TV	TELEVISION
29PT4973/79R	700229i stereo large 50Hz	L9.1A	1.08.2000Basic TV	TELEVISION
29PT5105/00	700229i stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
29PT5105/01	700229i stereo large 50Hz	L9.1E	Basic TV	TELEVISION

29PT5123/16	710229i stereo large 50Hz	MD1.2E	1.02.1997Basic TV	TELEVISION
29PT5124/01	710229i stereo large 50Hz	A8.0E	1.03.1999Basic TV	TELEVISION
29PT5301/00	710225i stereo large 50Hz	GR2.4	1.07.1995Basic TV	TELEVISION
29PT5301/01	710225i stereo large 50Hz	GR2.4	1.08.1995Basic TV	TELEVISION
29PT5301/15	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
29PT5301/58	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
29PT5302/00	710229i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5302/15	710229i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5302/58	710229i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5304/00R	710229i stereo large 50Hz	A8.0E	1.10.1998Basic TV	TELEVISION
29PT5305/00	700229i stereo large 50Hz	L9.1E	1.07.2000Basic TV	TELEVISION
29PT5305/00P	700229i stereo large 50Hz	L9.1E	1.03.2001Basic TV	TELEVISION
29PT5305/01	700229i stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
29PT5305/58	700229i stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
29PT5321/01	710225i stereo large 50Hz	GR2.4	1.07.1995Basic TV	TELEVISION
29PT5321/11	710225i stereo large 50Hz	GR2.4	1.08.1995Basic TV	TELEVISION
29PT5321/13	710225i stereo large 50Hz	GR2.4	1.08.1995Basic TV	TELEVISION
29PT5322/01	710229i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5322/11	710229i stereo large 50Hz	MD1.2E	1.12.1997Basic TV	TELEVISION
29PT5322/13	710229i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5322/16	710229i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5322/58	710229i stereo large 50Hz	MD1.2E	1.05.1997Basic TV	TELEVISION
29PT5324/01R	710229i stereo large 50Hz	A8.0E	1.11.1998Basic TV	TELEVISION
29PT5324/05R	710229i stereo large 50Hz	A8.0E	Basic TV	TELEVISION
29PT5324/58R	710229i stereo large 50Hz	A8.0E	1.03.1999Basic TV	TELEVISION
29PT5402/00	710225i stereo large 50Hz	GR2.4	1.08.1996Basic TV	TELEVISION
29PT5403/00	710229i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5405/00	710229i stereo large 50Hz	A8.0E	1.01.1999Basic TV	TELEVISION
29PT5423/13	710229i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5423/16	710225i stereo large 50Hz	MD1.2E	1.03.1997Basic TV	TELEVISION
29PT5424/01	710229i stereo large 50Hz	MD1.2E	1.03.1998Basic TV	TELEVISION
29PT5424/11	710229i stereo large 50Hz	MD1.2E	1.12.1997Basic TV	TELEVISION
29PT5424/16	710229i stereo large 50Hz	MD1.2E	1.07.1997Basic TV	TELEVISION
29PT5425/01	710229i stereo large 50Hz	A8.0E	1.01.1999Basic TV	TELEVISION
29PT5506/01	700229i stereo large 50Hz	L01.1E	1.08.2001Basic TV	TELEVISION
29PT5506/01E	700229i stereo large 50Hz	L01.1E	1.09.2001Basic TV	TELEVISION
29PT5506/58	700229i stereo large 50Hz	L01.1E	1.09.2001Basic TV	TELEVISION
29PT5515/01	710229i stereo large 50Hz	A10E	1.09.2000Basic TV	TELEVISION
29PT5515/01E	710229i stereo large 50Hz	A10E	1.08.2001Basic TV	TELEVISION
29PT5515/58	710229i stereo large 50Hz	A10E	1.10.2000Basic TV	TELEVISION
29PT5516/01	710229i stereo large 50Hz	A10E	1.07.2001Basic TV	TELEVISION
29PT5516/58	710229i stereo large 50Hz	A10E	1.11.2001Basic TV	TELEVISION

29PT5621/13	710225i stereo large 50Hz	GR2.4	1.11.1995Basic TV	TELEVISION
29PT5633/71R	710229i stereo large 50Hz	A8.0A	1.01.1999Basic TV	TELEVISION
29PT5663/57R	710229i stereo large 50Hz	A8.0A	1.09.1998Basic TV	TELEVISION
29PT5673/69R	710229i stereo large 50Hz	A8.0A	1.08.1998Basic TV	TELEVISION
29PT5673/79R	710229i stereo large 50Hz	A8.0A	1.11.1998Basic TV	TELEVISION
29PT5683/56A	700229i stereo large 50Hz			TELEVISION
29PT5683/69R	710229i stereo large 50Hz	A8.0A	1.10.1998Basic TV	TELEVISION
29PT5683/79R	710229i stereo large 50Hz	A8.0A	1.01.1999Basic TV	TELEVISION
29PT5783/56A	710229i stereo large 50Hz	A8.0A	Basic TV	TELEVISION
29PT5783/57R	710229i stereo large 50Hz	A8.0A	1.06.1999Basic TV	TELEVISION
29PT5783/69R	710229i stereo large 50Hz	A8.0A	1.04.1999Basic TV	TELEVISION
29PT5783/79R	710229i stereo large 50Hz	A8.0A	1.07.1999Basic TV	TELEVISION
29PT600A/00	710225i stereo large 50Hz	GR2.3	1.05.1994Basic TV	TELEVISION
29PT600A/01	710225i stereo large 50Hz	GR2.3	1.05.1994Basic TV	TELEVISION
29PT600B/00	710225i stereo large 50Hz	GR2.4	1.12.1994Basic TV	TELEVISION
29PT600B/01	710225i stereo large 50Hz	GR2.4	1.12.1994Basic TV	TELEVISION
29PT6011/69R	29i stereo large 50Hz			TELEVISION
29PT6011/79R	29i stereo large 50Hz			TELEVISION
29PT6021/56A	710229i stereo large 50Hz	A10A	1.12.2000Basic TV	TELEVISION
29PT6021/57R	710229i stereo large 50Hz	A10A	1.09.2000Basic TV	TELEVISION
29PT6021/61R	710229i stereo large 50Hz	A10A	1.08.2001Basic TV	TELEVISION
29PT6021/68R	29i stereo large 50Hz			TELEVISION
29PT6021/69R	710229i stereo large 50Hz	A10A	1.10.2000Basic TV	TELEVISION
29PT6021/71R	710229i stereo large 50Hz	A10A	1.11.2000Basic TV	TELEVISION
29PT6021/73R	29i stereo large 50Hz			TELEVISION
29PT6021/79R	710229i stereo large 50Hz	A10A	1.10.2000Basic TV	TELEVISION
29PT602A/11	710225i stereo large 50Hz	GR2.3	1.08.1994Basic TV	TELEVISION
29PT602B/11	710225i stereo large 50Hz	GR2.4	1.12.1994Basic TV	TELEVISION
29PT6031/61R	710229i stereo large 50Hz	A8.0A	Basic TV	TELEVISION
29PT6031/71R	710229i stereo large 50Hz	A8.0A	1.09.1999Basic TV	TELEVISION
29PT6231/57R	710229i stereo large 50Hz	A8.0A	1.09.1999Basic TV	TELEVISION
29PT6231/69R	710229i stereo large 50Hz	A8.0A	1.08.1999Basic TV	TELEVISION
29PT6231/79B	710229i stereo large 50Hz	A8.0A	1.07.2000Basic TV	TELEVISION
29PT6231/79R	710229i stereo large 50Hz	A8.0A	1.09.1999Basic TV	TELEVISION
29PT630A/00	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
29PT632A/05	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
29PT632A/13	710225i stereo large 50Hz	GR2.4	1.09.1995Basic TV	TELEVISION
29PT6341/56A	29i stereo large 50Hz		1.12.2001	TELEVISION
29PT6341/57R	29i stereo large 50Hz			TELEVISION
29PT6341/61R	710229i stereo large 50Hz	A10A	1.09.2001Basic TV	TELEVISION
29PT6341/69R	710229i stereo large 50Hz	A10A	1.10.2001Basic TV	TELEVISION
29PT6341/71R	710229i stereo large 50Hz	A10A	1.10.2001Basic TV	TELEVISION

29PT6341/79R	29i stereo large 50Hz			TELEVISION
29PT6361/56A	710229i stereo large 50Hz	A8.0A	1.12.2000Basic TV	TELEVISION
29PT6361/57R	710229i stereo large 50Hz	A8.0A	1.10.2000Basic TV	TELEVISION
29PT6361/61R	710229i stereo large 50Hz	A8.0A	1.08.2001Basic TV	TELEVISION
29PT6361/69R	710229i stereo large 50Hz	A8.0A	1.10.2000Basic TV	TELEVISION
29PT6361/71R	710229i stereo large 50Hz	A8.0A	1.03.2001Basic TV	TELEVISION
29PT6361/79B	710229i stereo large 50Hz	A10A	1.03.2001Basic TV	TELEVISION
29PT6361/79R	710229i stereo large 50Hz	A8.0A	1.10.2000Basic TV	TELEVISION
29PT6413/00	710229i stereo large 50Hz	MD1.2E	1.06.1997Basic TV	TELEVISION
29PT6415/05	700229i stereo large 50Hz			TELEVISION
29PT6415/12	700229i stereo large 50Hz			TELEVISION
29PT6415/19	700229i stereo large 50Hz			TELEVISION
29PT6433/01	710229i stereo large 50Hz	MD1.2E	1.06.1997Basic TV	TELEVISION
29PT6433/05	710229i stereo large 50Hz	MD1.2E	1.06.1997Basic TV	TELEVISION
29PT6433/11	710229i stereo large 50Hz	MD1.2E	1.12.1997Basic TV	TELEVISION
29PT6433/13	710229i stereo large 50Hz	MD1.2E	1.06.1997Basic TV	TELEVISION
29PT6433/16	710229i stereo large 50Hz	MD1.2E	1.06.1997Basic TV	TELEVISION
29PT6773/05	710229i stereo large 50Hz	MD1.2E	1.04.1997Basic TV	TELEVISION
29PT6961/57R	710229i stereo large 50Hz	A10A	1.11.2000Basic TV	TELEVISION
29PT6961/69R	710229i stereo large 50Hz	A10A	1.01.2001Basic TV	TELEVISION
29PT6961/79R	710229i stereo large 50Hz	A10A	1.01.2001Basic TV	TELEVISION
29PT700A/00	710225i stereo large 50Hz	GR2.3	1.05.1994Basic TV	TELEVISION
29PT700A/01	710225i stereo large 50Hz	GR2.3	1.06.1994Basic TV	TELEVISION
29PT700B/00	710225i stereo large 50Hz	GR2.4	1.12.1994Basic TV	TELEVISION
29PT702A/11	710225i stereo large 50Hz	GR2.3	1.09.1994Basic TV	TELEVISION
29PT702B/01	710225i stereo large 50Hz	GR2.4	1.11.1994Basic TV	TELEVISION
29PT702B/11	710225i stereo large 50Hz	GR2.4	1.12.1994Basic TV	TELEVISION
29PT702B/13	710225i stereo large 50Hz	GR2.4	1.05.1995Basic TV	TELEVISION
29PT720B/00	710225i stereo large 50Hz	GR2.4	1.06.1995Basic TV	TELEVISION
29PT722B/01	710229i stereo large 50Hz	GR2.4	1.06.1995Basic TV	TELEVISION
29PT722B/11	710225i stereo large 50Hz	GR2.4	1.01.1996Basic TV	TELEVISION
29PT722B/13	710225i stereo large 50Hz	GR2.4	1.08.1995Basic TV	TELEVISION
29PT727B/05	710225i stereo large 50Hz	GR2.4	1.06.1995Basic TV	TELEVISION
29PT727B/25	710225i stereo large 50Hz	GR2.4	1.11.1996Basic TV	TELEVISION
29PT740A/56H	710225i stereo large 50Hz	G88	Basic TV	TELEVISION
29PT740A/56R	710229i stereo large 50Hz	G88	Basic TV	TELEVISION
29PT742A/56R	710225i stereo large 50Hz	G88	1.03.1996Basic TV	TELEVISION
29PT745A/93R	710225i stereo large 50Hz	G88	1.11.1995Basic TV	TELEVISION
29PT745C/93R	710225i stereo large 50Hz	G88	1.09.1996Basic TV	TELEVISION
29PT746A/56R	710225i stereo large 50Hz	G88	1.06.1996Basic TV	TELEVISION
29PT746C/56H	710225i stereo large 50Hz	G88	Basic TV	TELEVISION
29PT746C/56R	710229i stereo large 50Hz	G88	1.04.1997Basic TV	TELEVISION

29PT760A/57R	710225i stereo large 50Hz	G88	1.08.1995Basic TV	TELEVISION
29PT760C/57R	710229i stereo large 50Hz	G88	1.11.1996Basic TV	TELEVISION
29PT762A/69R	710225i stereo large 50Hz	G88	1.06.1995Basic TV	TELEVISION
29PT762C/68R	710225i stereo large 50Hz	G88	1.02.1997Basic TV	TELEVISION
29PT762C/69R	710225i stereo large 50Hz	G88	1.07.1996Basic TV	TELEVISION
29PT763A/97R	710225i stereo large 50Hz	G88	1.11.1995Basic TV	TELEVISION
29PT763B/97R	700225i stereo large 50Hz		1.03.1996	TELEVISION
29PT780A/57R	710225i stereo large 50Hz	G88	1.08.1995Basic TV	TELEVISION
29PT780A/67R	710229i stereo large 50Hz	G88	1.11.1995Basic TV	TELEVISION
29PT780A/73R	710225i stereo large 50Hz	G88	Basic TV	TELEVISION
29PT780A/93R	710225i stereo large 50Hz	G88	1.11.1995Basic TV	TELEVISION
29PT780C/57R	710225i stereo large 50Hz	G88	1.11.1996Basic TV	TELEVISION
29PT780C/67R	710229i stereo large 50Hz	G88	1.12.1996Basic TV	TELEVISION
29PT780C/93R	710225i stereo large 50Hz	G88	1.10.1996Basic TV	TELEVISION
29PT785A/54R	710225i stereo large 50Hz	G88	1.04.1996Basic TV	TELEVISION
29PT785A/61R	710225i stereo large 50Hz	G88	Basic TV	TELEVISION
29PT785A/78R	710225i stereo large 50Hz	G88	1.01.1997Basic TV	TELEVISION
29PT785A/85R	710225i stereo large 50Hz	G88	1.01.1996Basic TV	TELEVISION
29PT785C/54R	710225i stereo large 50Hz	G88	1.07.1998Basic TV	TELEVISION
29PT785C/61R	710229i stereo large 50Hz	G88	Basic TV	TELEVISION
29PT785C/85R	710225i stereo large 50Hz	G88	1.05.1997Basic TV	TELEVISION
29PT786A/75R	710225i stereo large 50Hz	G88	1.09.1995Basic TV	TELEVISION
29PT786A/79R	710225i stereo large 50Hz	G88	1.10.1995Basic TV	TELEVISION
29PT786C/69R	710229i stereo large 50Hz	G88	1.01.1997Basic TV	TELEVISION
29PT786C/75R	710225i stereo large 50Hz	G88	1.09.1996Basic TV	TELEVISION
29PT786C/79R	710225i stereo large 50Hz	G88	1.10.1996Basic TV	TELEVISION
29PT8001/12	720229i stereo large 100HZ	MG2.1E	1.05.1999Upmarket TV	TELEVISION
29PT8004/12	720229i stereo large 100HZ	MG2.1E	1.10.1998Upmarket TV	TELEVISION
29PT8005/12	720229i stereo large 100HZ	MG2.1E	1.07.1999Upmarket TV	TELEVISION
29PT8006/12	720229i stereo large 100HZ	EM2E	1.06.2000Upmarket TV	TELEVISION
29PT8006/12R	720229i stereo large 100HZ	EM2E	1.12.2000Upmarket TV	TELEVISION
29PT805B/00	720225i stereo large 100Hz	FL*.17	1.05.1994Upmarket TV	TELEVISION
29PT805B/01	720225i stereo large 100Hz	FL*.17	1.06.1994Upmarket TV	TELEVISION
29PT8103/12	720229i stereo large 100HZ	MD2.22E	1.07.1998Upmarket TV	TELEVISION
29PT820B/00	720225i stereo large 100Hz	FL*.27	1.04.1994Upmarket TV	TELEVISION
29PT820B/01	720225i stereo large 100Hz	FL*.27	1.05.1994Upmarket TV	TELEVISION
29PT820B/19	720225i stereo large 100Hz	FL*.27	1.04.1994Upmarket TV	TELEVISION
29PT820B/58	720225i stereo large 100Hz	FL*.27	1.12.1994Upmarket TV	TELEVISION
29PT822B/05	720225i stereo large 100Hz	FL*.27	1.05.1994Upmarket TV	TELEVISION
29PT822B/07	720225i stereo large 100Hz	FL*.27	1.09.1994Upmarket TV	TELEVISION
29PT822B/12	720225i stereo large 100Hz	FL*.27	1.04.1994Upmarket TV	TELEVISION
29PT822B/13	720225i stereo large 100Hz	FL*.27	1.06.1994Upmarket TV	TELEVISION

29PT822B/19	720225i stereo large 100Hz	FL*.27	1.11.1994Upmarket TV	TELEVISION
29PT825B/00	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
29PT825B/01	720225i stereo large 100Hz	FL*.26	1.12.1994Upmarket TV	TELEVISION
29PT826C/01	720225i stereo large 100Hz	GFL2.20E	1.02.1995Upmarket TV	TELEVISION
29PT826C/58	720225i stereo large 100Hz	GFL2.20E	1.05.1995Upmarket TV	TELEVISION
29PT827B/12	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
29PT827B/13	720225i stereo large 100Hz	FL*.26	1.06.1995Upmarket TV	TELEVISION
29PT828C/05	720229i stereo large 100HZ	GFL2.20E	1.03.1995Upmarket TV	TELEVISION
29PT828C/12	720229i stereo large 100HZ	GFL2.20E	1.03.1995Upmarket TV	TELEVISION
29PT828C/19	720225i stereo large 100Hz	GFL2.20E	1.03.1995Upmarket TV	TELEVISION
29PT828C/25	720229i stereo large 100HZ	GFL2.20E	1.10.1996Upmarket TV	TELEVISION
29PT8302/12	720229i stereo large 100HZ	MD2.12E	1.04.1996Upmarket TV	TELEVISION
29PT8302/19	720229i stereo large 100HZ	MD2.12E	1.04.1996Upmarket TV	TELEVISION
29PT8302/58	720225i stereo large 100Hz	MD2.12E	1.08.1996Upmarket TV	TELEVISION
29PT8303/12	720229i stereo large 100HZ	MD2.22E	1.03.1997Upmarket TV	TELEVISION
29PT8303/19	720229i stereo large 100HZ	MD2.22E	1.03.1997Upmarket TV	TELEVISION
29PT8303/58	720229i stereo large 100HZ	MD2.22E	1.04.1997Upmarket TV	TELEVISION
29PT8304/12	720229i stereo large 100HZ	MG2.1E	1.09.1998Upmarket TV	TELEVISION
29PT8304/19	720229i stereo large 100HZ	MG2.1E	1.10.1998Upmarket TV	TELEVISION
29PT8304/58	720229i stereo large 100HZ	MG2.1E	1.11.1998Upmarket TV	TELEVISION
29PT8306/12	720229i stereo large 100HZ	EM2E	1.06.2000Upmarket TV	TELEVISION
29PT8306/12R	720229i stereo large 100HZ	EM2E	1.12.2000Upmarket TV	TELEVISION
29PT8306/58	720229i stereo large 100HZ	EM2E	1.06.2000Upmarket TV	TELEVISION
29PT8306/58R	720229i stereo large 100HZ	EM2E	1.12.2000Upmarket TV	TELEVISION
29PT8319/57R	720229i stereo large 100HZ	EM1A	1.01.2001Upmarket TV	TELEVISION
29PT8333/12	720229i stereo large 100HZ	MD2.22E	1.12.1997Upmarket TV	TELEVISION
29PT8344/12	720229i stereo large 100HZ	MG2.1E	1.10.1998Upmarket TV	TELEVISION
29PT8346/12	720229i stereo large 100HZ	EM2E	1.06.2000Upmarket TV	TELEVISION
29PT8346/12R	720229i stereo large 100HZ	EM2E	1.12.2000Upmarket TV	TELEVISION
29PT8402/12	720229i stereo large 100HZ	MD2.12E	1.10.1996Upmarket TV	TELEVISION
29PT8402/19	720229i stereo large 100HZ	MD2.12E	1.10.1996Upmarket TV	TELEVISION
29PT8402/58	720229i stereo large 100HZ	MD2.12E	1.11.1996Upmarket TV	TELEVISION
29PT8403/12	720229i stereo large 100HZ	MD2.22E	1.05.1997Upmarket TV	TELEVISION
29PT8403/19	720229i stereo large 100HZ	MD2.22E	1.06.1997Upmarket TV	TELEVISION
29PT8403/32	720229i stereo large 100HZ	MD2.22E	1.08.1998Upmarket TV	TELEVISION
29PT8403/39	720229i stereo large 100HZ	MD2.22E	1.08.1998Upmarket TV	TELEVISION
29PT8403/58	720229i stereo large 100HZ	MD2.22E	1.06.1998Upmarket TV	TELEVISION
29PT8412/05	720229i stereo large 100HZ	MD2.12E	1.10.1996Upmarket TV	TELEVISION
29PT8413/05	720229i stereo large 100HZ	MD2.22E	1.04.1997Upmarket TV	TELEVISION
29PT8413/25	720229i stereo large 100HZ	MD2.22E	1.07.1998Upmarket TV	TELEVISION
29PT8419/44	29i stereo large 100HZ			TELEVISION
29PT8419/55	29i stereo large 100HZ			TELEVISION

29PT8419/56R	720229i stereo large 100HZ	EM1A	1.05.2001Upmarket TV	TELEVISION
29PT8419/57R	29i stereo large 100HZ			TELEVISION
29PT8419/61R	29i stereo large 100HZ		1.12.2001	TELEVISION
29PT8419/69R	720229i stereo large 100HZ	EM1A	1.03.2001Upmarket TV	TELEVISION
29PT8419/71R	720229i stereo large 100HZ	EM1A	1.09.2001Upmarket TV	TELEVISION
29PT8419/77	29i stereo large 100HZ			TELEVISION
29PT8419/78	29i stereo large 100HZ			TELEVISION
29PT8419/79R	720229i stereo large 100HZ	EM1A	1.05.2001Upmarket TV	TELEVISION
29PT8423/12	720229i stereo large 100HZ	MD2.22E	1.10.1997Upmarket TV	TELEVISION
29PT8424/12	720229i stereo large 100HZ	MD2.22E	1.02.1999Upmarket TV	TELEVISION
29PT8434/12	720229i stereo large 100HZ	MD2.22E	1.02.1999Upmarket TV	TELEVISION
29PT8444/12	720229i stereo large 100HZ	MD2.22E	1.02.1999Upmarket TV	TELEVISION
29PT8444/58	720229i stereo large 100HZ	MD2.22E	1.11.1999Upmarket TV	TELEVISION
29PT8600/57R	710229i stereo large 50Hz upmarket	MD1.1A	1.02.1999Basic TV	TELEVISION
29PT8606/12	710229i stereo large 100HZ	EM2E	1.09.2001Upmarket TV	TELEVISION
29PT860A/57R	700229i stereo large 50Hz		1.09.1997	TELEVISION
29PT8620/69R	710229i stereo large 50Hz upmarket	MD1.1A	1.12.1998Basic TV	TELEVISION
29PT862A/68R	700229i stereo large 50Hz	MD1.1A	1.10.1997Basic TV	TELEVISION
29PT862A/69R	700229i stereo large 50Hz	MD1.1A	1.07.1997Basic TV	TELEVISION
29PT8630/97R	710229i stereo large 50Hz upmarket	MD1.1A	1.02.1999Basic TV	TELEVISION
29PT863A/97R	700229i stereo large 50Hz	MD1.1A	1.01.1998Basic TV	TELEVISION
29PT8702/12	720229i stereo large 100HZ	MD2.12E	1.04.1996Upmarket TV	TELEVISION
29PT8703/12	720229i stereo large 100HZ	MD2.22E	1.04.1997Upmarket TV	TELEVISION
29PT8703/32	720229i stereo large 100HZ	MD2.22E	1.07.1998Upmarket TV	TELEVISION
29PT8703/58	720229i stereo large 100HZ	MD2.22E	1.08.1998Upmarket TV	TELEVISION
29PT8800/57R	710229i stereo large 50Hz upmarket	MD1.1A	1.02.1999Basic TV	TELEVISION
29PT880A/57R	700229i stereo large 50Hz	MD1.1A	1.09.1997Basic TV	TELEVISION
29PT880A/93R	700229i stereo large 50Hz	MD1.1A	1.01.1998Basic TV	TELEVISION
29PT8860/75R	710229i stereo large 50Hz upmarket	MD1.1A	1.02.1999Basic TV	TELEVISION
29PT8860/79R	710229i stereo large 50Hz upmarket	MD1.1A	1.03.1999Basic TV	TELEVISION
29PT886A/75R	710229i stereo large 50Hz	MD1.1A	1.09.1997Basic TV	TELEVISION
29PT886A/79R	710229i stereo large 50Hz	MD1.1A	1.09.1997Basic TV	TELEVISION
29PT8880/93R	710229i stereo large 50Hz upmarket	MD1.1A	Basic TV	TELEVISION
29PT888A/93R	700229i stereo large 50Hz	MD1.1A	1.01.1998Basic TV	TELEVISION
29PT8890/56H	710229i stereo large 50Hz upmarket	MD1.1A	Basic TV	TELEVISION
29PT8890/68R	710229i stereo large 50Hz upmarket	MD1.1A	1.02.1999Basic TV	TELEVISION
29PT8890/69R	710229i stereo large 50Hz upmarket	MD1.1A	1.12.1998Basic TV	TELEVISION
29PT889A/56H	700229i stereo large 50Hz			TELEVISION
29PT889A/69R	700229i stereo large 50Hz		1.07.1997	TELEVISION
29PT9001/01	720229i stereo large 100HZ	GFL2.20E	1.04.1995Upmarket TV	TELEVISION
29PT9005/12	720229i stereo large 100HZ	MG2.1E	1.09.1999Upmarket TV	TELEVISION
29PT9005/19	720229i stereo large 100HZ	MG2.1E	1.09.1999Upmarket TV	TELEVISION

29PT9005/58	720229i stereo large 100HZ	MG2.1E	1.10.1999Upmarket TV	TELEVISION
29PT9006/12	720229i stereo large 100HZ	MG2.1E	1.07.2000Upmarket TV	TELEVISION
29PT9006/12B	720229i stereo large 100HZ	MG2.1E	1.03.2001Upmarket TV	TELEVISION
29PT9006/12R	720229i stereo large 100HZ	MG2.1E	1.12.2000Upmarket TV	TELEVISION
29PT9006/19	720229i stereo large 100HZ	MG2.1E	1.08.2000Upmarket TV	TELEVISION
29PT9006/19R	720229i stereo large 100HZ	MG2.1E	1.01.2001Upmarket TV	TELEVISION
29PT9006/58	720229i stereo large 100HZ	MG2.1E	1.08.2000Upmarket TV	TELEVISION
29PT9006/58R	720229i stereo large 100HZ	MG2.1E	1.02.2001Upmarket TV	TELEVISION
29PT9007/12	720229i stereo large 100HZ	EM2E	1.07.2001Upmarket TV	TELEVISION
29PT9007/19	720229i stereo large 100HZ	EM2E	1.08.2001Upmarket TV	TELEVISION
29PT9007/58	720229i stereo large 100HZ	EM2E	1.07.2001Upmarket TV	TELEVISION
29PT900B/01	720225i stereo large 100Hz	FL*.26	1.04.1994Upmarket TV	TELEVISION
29PT9015/05	720229i stereo large 100HZ	MG2.1E	Upmarket TV	TELEVISION
29PT9015/12	720229i stereo large 100HZ	MG2.1E	1.03.1999Upmarket TV	TELEVISION
29PT9015/58	720229i stereo large 100HZ	MG2.1E	1.08.1999Upmarket TV	TELEVISION
29PT9021/05	720229i stereo large 100HZ	GFL2.20E	1.05.1995Upmarket TV	TELEVISION
29PT9021/12	720225i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
29PT9021/19	720225i stereo large 100Hz	GFL2.20E	1.05.1995Upmarket TV	TELEVISION
29PT902B/12	720225i stereo large 100Hz	FL*.26	1.05.1994Upmarket TV	TELEVISION
29PT902B/19	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
29PT9046/12	720229i stereo large 100HZ	MG2.1E	1.10.2000Upmarket TV	TELEVISION
29PT9046/12R	720229i stereo large 100HZ	MG2.1E	1.12.2000Upmarket TV	TELEVISION
29PT9046/58	720229i stereo large 100HZ	MG2.1E	1.11.2000Upmarket TV	TELEVISION
29PT9046/58R	720229i stereo large 100HZ	MG2.1E	1.12.2000Upmarket TV	TELEVISION
29PT9047/12	29i stereo large 100HZ			TELEVISION
29PT9047/58	29i stereo large 100HZ			TELEVISION
29PT9055/12	720229i stereo large 100HZ	MG2.1E	1.11.1999Upmarket TV	TELEVISION
29PT9101/01	720225i stereo large 100Hz	GFL2.20E	1.04.1995Upmarket TV	TELEVISION
29PT9101/58	720225i stereo large 100Hz	GFL2.20E	1.06.1995Upmarket TV	TELEVISION
29PT910A/01	720225i stereo large 100Hz	FL*.16	1.10.1993Upmarket TV	TELEVISION
29PT910A/19	720225i stereo large 100Hz	FL*.16	1.10.1993Upmarket TV	TELEVISION
29PT910B/01	720225i stereo large 100Hz	FL*.26	1.03.1994Upmarket TV	TELEVISION
29PT910B/19	720225i stereo large 100Hz	FL*.26	1.04.1994Upmarket TV	TELEVISION
29PT910B/42	720225i stereo large 100Hz	FL*.26	1.06.1994Upmarket TV	TELEVISION
29PT910B/58	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
29PT9111/01	720229i stereo large 100HZ	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
29PT9111/58	720229i stereo large 100HZ	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
29PT9113/05	720229i stereo large 100HZ	MD2.22E	1.04.1997Upmarket TV	TELEVISION
29PT9113/12	720229i stereo large 100HZ	MD2.22E	1.05.1997Upmarket TV	TELEVISION
29PT9113/19	720229i stereo large 100HZ	MD2.22E	1.05.1997Upmarket TV	TELEVISION
29PT9113/58	720229i stereo large 100HZ	MD2.22E	1.05.1997Upmarket TV	TELEVISION
29PT9121/12	720225i stereo large 100Hz	GFL2.20E	1.06.1995Upmarket TV	TELEVISION

29PT9121/19	720225i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
29PT912A/12	720225i stereo large 100Hz	FL*.16	1.10.1993Upmarket TV	TELEVISION
29PT912A/13	720225i stereo large 100Hz	FL*.16	1.12.1993Upmarket TV	TELEVISION
29PT912B/12	720225i stereo large 100Hz	FL*.26	1.04.1994Upmarket TV	TELEVISION
29PT912B/13	720225i stereo large 100Hz	FL*.26	1.04.1994Upmarket TV	TELEVISION
29PT912B/19	720225i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
29PT9131/12	720229i stereo large 100HZ	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
29PT9131/19	720225i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
29PT9413/05	720229i stereo large 100HZ	MD2.22E	1.06.1998Upmarket TV	TELEVISION
29PT9413/12	720229i stereo large 100HZ	MD2.22E	1.06.1998Upmarket TV	TELEVISION
29PT9413/19	700229i stereo large 100HZ			TELEVISION
29PT9413/58	720229i stereo large 100HZ	MD2.22E	1.08.1998Upmarket TV	TELEVISION
29PT9415/05	720229i stereo large 100HZ	MG3.1E	Upmarket TV	TELEVISION
29PT9415/12	720229i stereo large 100HZ	MG3.1E	1.08.1999Upmarket TV	TELEVISION
29PT9415/19	720229i stereo large 100HZ	MG3.1E	Upmarket TV	TELEVISION
29PT9415/58	720229i stereo large 100HZ	MG3.1E	1.08.1999Upmarket TV	TELEVISION
29PT9416/12	720229i stereo large 100HZ	MG3.1E	1.05.2000Upmarket TV	TELEVISION
29PT9416/12B	720229i stereo large 100HZ	MG3.1E	1.05.2001Upmarket TV	TELEVISION
29PT9416/12R	720229i stereo large 100HZ	MG3.1E	1.11.2000Upmarket TV	TELEVISION
29PT9416/58	720229i stereo large 100HZ	MG3.1E	1.05.2000Upmarket TV	TELEVISION
29PT9416/58R	720229i stereo large 100HZ	MG3.1E	1.12.2000Upmarket TV	TELEVISION
29PT9418/56G	720229i stereo large 100HZ	MG3.1A	1.08.2001Upmarket TV	TELEVISION
29PT9418/56R	720229i stereo large 100HZ	MG3.1A	1.04.2000Upmarket TV	TELEVISION
29PT9418/56T	720229i stereo large 100HZ	MG3.1A	1.09.2000Upmarket TV	TELEVISION
29PT9418/57G	720229i stereo large 100HZ	MG3.1A	1.06.2001Upmarket TV	TELEVISION
29PT9418/57R	720229i stereo large 100HZ	MG3.1A	1.11.1999Upmarket TV	TELEVISION
29PT9418/57T	720229i stereo large 100HZ	MG3.1A	1.07.2000Upmarket TV	TELEVISION
29PT9418/69G	720229i stereo large 100HZ	MG3.1A	1.06.2001Upmarket TV	TELEVISION
29PT9418/69R	720229i stereo large 100HZ	MG3.1A	1.11.1999Upmarket TV	TELEVISION
29PT9418/69T	720229i stereo large 100HZ	MG3.1A	1.06.2000Upmarket TV	TELEVISION
29PT9418/79G	720229i stereo large 100HZ	MG3.1A	1.08.2001Upmarket TV	TELEVISION
29PT9418/79R	720229i stereo large 100HZ	MG3.1A	1.02.2000Upmarket TV	TELEVISION
29PT9418/79T	720229i stereo large 100HZ	MG3.1A	1.07.2000Upmarket TV	TELEVISION
29PT9418/93R	720229i stereo large 100HZ	MG3.1A	1.01.2000Upmarket TV	TELEVISION
29PX8001/01	720229i Multimedia	GFL2.20E	1.07.1995Upmarket TV	TELEVISION
29PX8001/05	720229i Multimedia	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
29PX8001/19	720229i Multimedia	GFL2.20E	1.03.1996Upmarket TV	TELEVISION
29PX8001/58	720221i Multimedia	GFL2.20E	1.06.1996Upmarket TV	TELEVISION
29PX8011/17	700221i Multimedia		1.06.1996	TELEVISION
29PX8031/01	720229i Multimedia	GFL2.20E	1.09.1996Upmarket TV	TELEVISION
29PX8031/05	720229i Multimedia	GFL2.20E	1.09.1996Upmarket TV	TELEVISION
29PX8031/19	720229i Multimedia	GFL2.20E	1.09.1996Upmarket TV	TELEVISION

29SP1698/56R	710225i mono	G112	1.05.1992Basic TV	TELEVISION
29SP1698/56S	710225i mono	G112	1.06.1992Basic TV	TELEVISION
29SP1698/57R	710225i mono	G112	1.05.1992Basic TV	TELEVISION
29SP1698/57T	710225i mono	G112	1.09.1992Basic TV	TELEVISION
29SP1698/70T	710225i mono	G112	1.08.1993Basic TV	TELEVISION
29SP1698/75R	710225i mono	G112	1.03.1992Basic TV	TELEVISION
29SP1698/79R	710225i mono	G112	1.04.1992Basic TV	TELEVISION
29SP1698/80	710225i mono	G112	1.10.1993Basic TV	TELEVISION
29SP1698L/80	700225i stereo large 50Hz		1.05.1992	TELEVISION
29SP1798/68R	710225i stereo large 50Hz	G112	1.05.1992Basic TV	TELEVISION
29SP1798/69R	710225i stereo large 50Hz	G112	1.05.1992Basic TV	TELEVISION
29SP1798/75R	710225i stereo large 50Hz	G112	1.03.1992Basic TV	TELEVISION
29SP1798/79R	710225i stereo large 50Hz	G112	1.09.1992Basic TV	TELEVISION
29SX8671/56R	710225i stereo large 50Hz	G8	1.01.1994Upmarket TV	TELEVISION
29SX8671/75R	710225i stereo large 50Hz	G8	1.08.1993Upmarket TV	TELEVISION
29SX8671/93R	710225i stereo large 50Hz	G8	1.05.1994Upmarket TV	TELEVISION
29SX8671/93T	710225i stereo large 50Hz	G8	1.12.1994Upmarket TV	TELEVISION
29SX8672/97R	710225i stereo large 50Hz	G8	1.12.1993Upmarket TV	TELEVISION
29SX8674/54R	710225i stereo large 50Hz	G8	1.12.1993Upmarket TV	TELEVISION
29SX8674/78G	710225i stereo large 50Hz	G8	1.04.1994Upmarket TV	TELEVISION
29SX8674/78R	700229i stereo large 50Hz			TELEVISION
29SX8674/85R	710225i stereo large 50Hz	G8	1.01.1994Upmarket TV	TELEVISION
29SX8676/00R	710225i stereo large 50Hz	G8.1	1.10.1996Upmarket TV	TELEVISION
29SX8676/56R	710225i stereo large 50Hz	G8.1	1.03.1995Upmarket TV	TELEVISION
29SX8676/57R	710225i stereo large 50Hz	G8.1	1.08.1994Upmarket TV	TELEVISION
29SX8676/67R	710225i stereo large 50Hz	G8.1	1.03.1995Upmarket TV	TELEVISION
29SX8676/75R	710225i stereo large 50Hz	G8.1	1.09.1994Upmarket TV	TELEVISION
29SX8677/97R	710225i stereo large 50Hz	G8.1	1.12.1994Upmarket TV	TELEVISION
29SX8771/56H	710225i stereo large 50Hz	G8	1.11.1993Upmarket TV	TELEVISION
29SX8771/57R	710225i stereo large 50Hz	G8	1.07.1993Upmarket TV	TELEVISION
29SX8771/67R	710225i stereo large 50Hz	G8	1.10.1993Upmarket TV	TELEVISION
29SX8771/69R	710225i stereo large 50Hz	G8	1.07.1993Upmarket TV	TELEVISION
29SX8771/75R	710225i stereo large 50Hz	G8	1.09.1993Upmarket TV	TELEVISION
29SX8771/79R	710225i stereo large 50Hz	G8	1.09.1993Upmarket TV	TELEVISION
29SX8771/89B	710225i stereo large 50Hz	G8	1.12.1993Upmarket TV	TELEVISION
29SX8776/69R	710225i stereo large 50Hz	G8.1	1.09.1994Upmarket TV	TELEVISION
29SX8876/57R	710225i stereo large 50Hz	G8.1	1.08.1994Upmarket TV	TELEVISION
29SX8876/73R	710225i stereo large 50Hz	G8.1	1.10.1995Upmarket TV	TELEVISION
29SX8876/93B	710225i stereo large 50Hz	G8.1	1.03.1996Upmarket TV	TELEVISION
29SX8876/93R	710225i stereo large 50Hz	G8.1	1.01.1995Upmarket TV	TELEVISION
29SX8876/93T	710225i stereo large 50Hz	G8.1	1.01.1995Upmarket TV	TELEVISION
29SX8879/54R	710225i stereo large 50Hz	G8.1	1.03.1996Upmarket TV	TELEVISION

29SX8879/78R	700229i stereo large 50Hz			TELEVISION
29SX8879/85R	710225i stereo large 50Hz	G8.1	1.10.1995Upmarket TV	TELEVISION
29SX8976/75R	710225i stereo large 50Hz	G8.1	1.09.1994Upmarket TV	TELEVISION
29SX8976/79R	710225i stereo large 50Hz	G8.1	1.10.1994Upmarket TV	TELEVISION
2SB11/07	1021Leader	KATE _STN	1.01.1994Standard	VCR
2SB11/16	1021Leader	KATE _STN	1.01.1994Standard	VCR
2SB31/08	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
2SB31/16	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
2SB32/03	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
2SB33/03	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
2SB41/03	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB41/07	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB41/08	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB41/11	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB41/16	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB410/18	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB419/38	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB42/03	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB42/11W	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB469/38	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB47/02	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB47/03	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB47/08	1021Leader	NORA _STN	1.03.1995Standard	VCR
2SB47/11	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB47/11W	1021Leader	NORA _STN	1.11.1994Standard	VCR
2SB51/03	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
2SB51/16	1021Leader	OLIVIA_STN	1.02.1996Standard	VCR
2SB52/11	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
2SB56/08	1021Leader	OLIVIA_STN	1.12.1995Standard	VCR
2SB56/38	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
2SB56/38M	1021Leader	OLIVIA_STN	1.01.1996Standard	VCR
2SB57/02	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
2SB57/03	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
2SB57/11	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
30PW8859/17	32i WS 100Hz			TELEVISION
30PW8869/17	32i WS 100Hz			TELEVISION
30PW8879/17	32i WS 100Hz			TELEVISION
30PW9815/17	700332i WS 100Hz			TELEVISION
30PW9817/17	32i WS 100Hz			TELEVISION
31DV1/08	1021Leader	KATE _STN	1.03.1994Standard	VCR
31DV3/05	1021Leader	KATE _STN	1.01.1994Standard	VCR
31K371L/76	200648i rear-PTV 4:3		1.03.1992	PROJECTION TV

32DW6715/05	7103Digital CRT DVB 50/60Hz 28i WS			DIGITAL TV
32DW6834/05	7103Digital CRT DVB 50/60Hz 28i WSMD1.2E		1.05.1999Basic TV	DIGITAL TV
32DW6834/25	7103Digital CRT DVB 50/60Hz 28i WSMD1.2E		1.11.1999Basic TV	DIGITAL TV
32DW8957/05	Digital CRT DVB 100Hz 32i WS			DIGITAL TV
32DW9625/05	7203Digital CRT DVB 50/60Hz 28i WS			DIGITAL TV
32DW9625/05R	7203Digital CRT DVB 100Hz 32i WS	MG4.1E	1.05.2001Upmarket TV	DIGITAL TV
32FD9944/01S	2001Flat TV	FM23	1.11.2001Flat TV	FLAT TV
32FD9944/69S	2001Flat TV	FM23	1.11.2001Flat TV	FLAT TV
32FD9954/69S	Flat TV			FLAT TV
32FL2881/56R	720328i WS 100Hz	FL2-G	1.03.1995Upmarket TV	TELEVISION
32FL2881/57R	720328i WS 100Hz	FL2-G	1.02.1994Upmarket TV	TELEVISION
32FL2881/69R	720328i WS 100Hz	FL2-G	1.01.1994Upmarket TV	TELEVISION
32FL2881/75R	720328i WS 100Hz	FL2-G	1.07.1994Upmarket TV	TELEVISION
32FL2881/79R	720328i WS 100Hz	FL2-G	1.06.1994Upmarket TV	TELEVISION
32FL2881/93R	720328i WS 100Hz	FL2-G	1.05.1994Upmarket TV	TELEVISION
32FL2882/97R	720328i WS 100Hz	FL2G	1.06.1994Upmarket TV	TELEVISION
32FL2883/61R	720328i WS 100Hz	FL2G	Upmarket TV	TELEVISION
32FL2884/54R	720328i WS 100Hz	FL2G	1.08.1994Upmarket TV	TELEVISION
32FL2884/78R	720328i WS 100Hz	FL2G	1.03.1996Upmarket TV	TELEVISION
32FL2884/85R	720328i WS 100Hz	FL2G	1.08.1994Upmarket TV	TELEVISION
32PF9964/12S	2001Flat TV	FM23	1.10.2001Flat TV	FLAT TV
32PN977A/69	720328i WS 100Hz	GFL2.20A	1.03.1996Upmarket TV	TELEVISION
32PT8419/17	33i stereo large 100Hz			TELEVISION
32PW5405/01	710332i WS 50Hz no dolby mainstream A10E		1.08.2000Basic TV	TELEVISION
32PW5406/01	710332i WS 50Hz no dolby mainstream A10E		1.11.2000Basic TV	TELEVISION
32PW5407/01	700332i WS 50Hz no dolby mainstream L01.1E		1.09.2001Basic TV	TELEVISION
32PW5407/05	32i WS 50Hz no dolby mainstream			TELEVISION
32PW5407/21	700332i WS 50Hz no dolby mainstream L01.1E		1.09.2001Basic TV	TELEVISION
32PW5407/25	32i WS 50Hz no dolby mainstream			TELEVISION
32PW6005/01	710332i WS 50Hz no dolby mainstream A10E		1.06.2000Basic TV	TELEVISION
32PW6005/05	710332i WS 50Hz no dolby mainstream A10E		1.06.2000Basic TV	TELEVISION
32PW6006/01	700332i WS 50Hz no dolby mainstream L01.1E		1.09.2001Basic TV	TELEVISION
32PW6006/05	32i WS 50Hz no dolby mainstream			TELEVISION
32PW6006/21	700332i WS 50Hz no dolby mainstream L01.1E		1.08.2001Basic TV	TELEVISION
32PW6006/25	700332i WS 50Hz no dolby mainstream L01.1E		1.08.2001Basic TV	TELEVISION
32PW6006/48	700332i WS 50Hz no dolby mainstream L01.1E		1.10.2001Basic TV	TELEVISION
32PW6006/58	700332i WS 50Hz no dolby mainstream L01.1E		1.11.2001Basic TV	TELEVISION
32PW6302/00	710332i WS 50Hz no dolby mainstream MD1.2E		1.05.1997Basic TV	TELEVISION
32PW6302/20	710324i WS 50Hz no dolby mainstream MD1.2E		1.03.1999Basic TV	TELEVISION
32PW6304/00	710332i WS 50Hz no dolby mainstream A8.0E		1.07.1999Basic TV	TELEVISION
32PW6304/20	710332i WS 50Hz no dolby mainstream A8.0E		1.02.2000Basic TV	TELEVISION
32PW6305/01	710332i WS 50Hz no dolby mainstream A10E		1.09.2000Basic TV	TELEVISION

32PW6305/05	710332i WS 50Hz no dolby mainstream A10E	1.09.2000Basic TV	TELEVISION
32PW6305/21	710332i WS 50Hz no dolby mainstream A10E	1.03.2001Basic TV	TELEVISION
32PW6305/25	710332i WS 50Hz no dolby mainstream A10E	1.03.2001Basic TV	TELEVISION
32PW6305/58	710332i WS 50Hz no dolby mainstream A10E	1.12.2000Basic TV	TELEVISION
32PW6312/00	710332i WS 50Hz dolby mainstream MD1.2E	1.04.1997Basic TV	TELEVISION
32PW6312/20	710332i WS 50Hz dolby mainstream MD1.2E	Basic TV	TELEVISION
32PW6315/01	710332i WS 50Hz dolby mainstream A10E	1.06.2001Basic TV	TELEVISION
32PW6315/05	710332i WS 50Hz dolby mainstream A10E	1.12.2000Basic TV	TELEVISION
32PW6315/21	710332i WS 50Hz dolby mainstream A10E	1.07.2001Basic TV	TELEVISION
32PW6315/25	710332i WS 50Hz dolby mainstream A10E	1.08.2001Basic TV	TELEVISION
32PW6322/01	710332i WS 50Hz no dolby mainstream MD1.2E	1.05.1997Basic TV	TELEVISION
32PW6322/05	710332i WS 50Hz no dolby mainstream MD1.2E	1.10.1997Basic TV	TELEVISION
32PW6322/11	710332i WS 50Hz no dolby mainstream MD1.2E	1.01.1998Basic TV	TELEVISION
32PW6322/13	710332i WS 50Hz no dolby mainstream MD1.2E	1.05.1997Basic TV	TELEVISION
32PW6322/16	710332i WS 50Hz no dolby mainstream MD1.2E	1.05.1997Basic TV	TELEVISION
32PW6322/21	710324i WS 50Hz no dolby mainstream MD1.2E	1.04.1999Basic TV	TELEVISION
32PW6322/25	710332i WS 50Hz no dolby mainstream MD1.2E	1.03.1999Basic TV	TELEVISION
32PW6322/31	710332i WS 50Hz no dolby mainstream MD1.2E	1.03.1999Basic TV	TELEVISION
32PW6322/P01	710332i WS 50Hz no dolby mainstream MD1.2E	Basic TV	TELEVISION
32PW6324/01	710332i WS 50Hz no dolby mainstream A8.0E	1.07.1999Basic TV	TELEVISION
32PW6324/05	710332i WS 50Hz no dolby mainstream A8.0E	1.07.1999Basic TV	TELEVISION
32PW6324/21	710332i WS 50Hz no dolby mainstream A8.0E	1.02.2000Basic TV	TELEVISION
32PW6324/25	710332i WS 50Hz no dolby mainstream A8.0E	1.03.2000Basic TV	TELEVISION
32PW6332/01	710332i WS 50Hz dolby mainstream MD1.2E	1.03.1997Basic TV	TELEVISION
32PW6332/05	710332i WS 50Hz dolby mainstream MD1.2E	1.04.1997Basic TV	TELEVISION
32PW6332/11	710332i WS 50Hz dolby mainstream MD1.2E	Basic TV	TELEVISION
32PW6332/16	710332i WS 50Hz dolby mainstream MD1.2E	1.04.1997Basic TV	TELEVISION
32PW6332/21	710332i WS 50Hz dolby mainstream MD1.2E	Basic TV	TELEVISION
32PW6332/25	710332i WS 50Hz dolby mainstream MD1.2E	1.03.1999Basic TV	TELEVISION
32PW6515/01	710332i WS 50Hz dolby mainstream A10E	1.09.2000Basic TV	TELEVISION
32PW6515/05	710332i WS 50Hz dolby mainstream A10E	1.11.2000Basic TV	TELEVISION
32PW6515/58	710332i WS 50Hz dolby mainstream A10E	1.12.2000Basic TV	TELEVISION
32PW6516/79R	710332i WS 50Hz dolby mainstream A10A	1.11.2001Basic TV	TELEVISION
32PW6526/01	710332i WS 50Hz dolby mainstream A10E	1.07.2001Basic TV	TELEVISION
32PW6526/05	710332i WS 50Hz dolby mainstream A10E	1.08.2001Basic TV	TELEVISION
32PW6615/05	710332i WS 50Hz dolby mainstream MG1.1E	Upmarket TV	TELEVISION
32PW6615/12	710332i WS 50Hz dolby mainstream MG1.1E	Upmarket TV	TELEVISION
32PW6615/19	710332i WS 50Hz dolby mainstream MG1.1E	Upmarket TV	TELEVISION
32PW6615/25	710332i WS 50Hz dolby mainstream MG1.1E	1.02.2000Upmarket TV	TELEVISION
32PW6826/01	201432i WS 50Hz dolby mainstream A10E	1.09.2001Basic TV	TELEVISION
32PW6826/05	201432i WS 50Hz dolby mainstream A10E	1.09.2001Basic TV	TELEVISION
32PW6826/58	201432i WS 50Hz dolby mainstream A10E	1.11.2001Basic TV	TELEVISION

32PW8206/12	720332i WS 100Hz	EM2E	1.09.2000Upmarket TV	TELEVISION
32PW8206/12R	720332i WS 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
32PW8406/12	720332i WS 100Hz	EM2E	1.09.2000Upmarket TV	TELEVISION
32PW8406/12R	720332i WS 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
32PW8504/12	720332i WS 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
32PW8504/19	720332i WS 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
32PW8504/58	720332i WS 100Hz	MG2.1E	1.12.1998Upmarket TV	TELEVISION
32PW8505/12	720332i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
32PW8505/12S	720332i WS 100Hz	MG2.1E	1.11.1999Upmarket TV	TELEVISION
32PW8505/19	720332i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
32PW8505/58	720332i WS 100Hz	MG2.1E	1.10.1999Upmarket TV	TELEVISION
32PW8506/12	720332i WS 100Hz	EM2E	1.08.2000Upmarket TV	TELEVISION
32PW8506/12R	720332i WS 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
32PW8506/19	720332i WS 100Hz	EM2E	1.08.2000Upmarket TV	TELEVISION
32PW8506/19R	720332i WS 100Hz	EM2E	1.01.2001Upmarket TV	TELEVISION
32PW8506/58	720332i WS 100Hz	EM2E	1.09.2000Upmarket TV	TELEVISION
32PW8506/58R	720332i WS 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
32PW8604/12	720332i WS 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
32PW8707/12	720332i WS 100Hz	EM2E	1.05.2001Upmarket TV	TELEVISION
32PW8707/58	720332i WS 100Hz	EM2E	1.05.2001Upmarket TV	TELEVISION
32PW8717/12	720332i WS 100Hz	EM2E	1.11.2001Upmarket TV	TELEVISION
32PW8717/19	720332i WS 100Hz	EM2E	1.11.2001Upmarket TV	TELEVISION
32PW8806/12	720332i WS 100Hz	MG2.1E	1.01.2000Upmarket TV	TELEVISION
32PW8806/12R	720332i WS 100Hz	MG2.1E	1.11.2000Upmarket TV	TELEVISION
32PW8806/19	720332i WS 100Hz	MG2.1E	1.08.2000Upmarket TV	TELEVISION
32PW8806/19R	720332i WS 100Hz	MG2.1E	1.11.2000Upmarket TV	TELEVISION
32PW8806/58	720332i WS 100Hz	MG2.1E	1.09.2000Upmarket TV	TELEVISION
32PW8806/58R	720332i WS 100Hz	MG2.1E	1.02.2001Upmarket TV	TELEVISION
32PW8806/79R	720332i WS 100Hz	MG2.1E	1.03.2001Upmarket TV	TELEVISION
32PW8807/12	720332i WS 100Hz	EM3E	1.08.2001Upmarket TV	TELEVISION
32PW8807/19	720332i WS 100Hz	EM3E	1.09.2001Upmarket TV	TELEVISION
32PW8807/58	720332i WS 100Hz	EM3E	1.09.2001Upmarket TV	TELEVISION
32PW8807/79	32i WS 100Hz		1.12.2001	TELEVISION
32PW8906/19	720332i WS 100Hz	MG7.1E	1.03.2000Upmarket TV	TELEVISION
32PW9403/12	720332i WS 100Hz	MD2.22E	1.09.1997Upmarket TV	TELEVISION
32PW9501/01	720328i WS 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
32PW9502/12	720332i WS 100Hz	MD2.12E	1.09.1996Upmarket TV	TELEVISION
32PW9502/19	720332i WS 100Hz	MD2.12E	1.09.1996Upmarket TV	TELEVISION
32PW9503/12	720332i WS 100Hz	MD2.22E	1.05.1997Upmarket TV	TELEVISION
32PW9503/19	720332i WS 100Hz	MD2.22E	1.06.1997Upmarket TV	TELEVISION
32PW9503/58	720332i WS 100Hz	MD2.22E	1.07.1997Upmarket TV	TELEVISION
32PW9505/12	720332i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION

32PW9505/19	720332i WS 100Hz	MG2.1E	Upmarket TV	TELEVISION
32PW9505/58	720332i WS 100Hz	MG2.1E	Upmarket TV	TELEVISION
32PW9513/12	720332i WS 100Hz	MD2.22E	1.07.1998Upmarket TV	TELEVISION
32PW9513/19	720332i WS 100Hz	MD2.22E	1.08.1998Upmarket TV	TELEVISION
32PW9515/05	720332i WS 100Hz	MG2.1E	1.06.1999Upmarket TV	TELEVISION
32PW9515/12	720332i WS 100Hz	MG2.1E	1.03.1999Upmarket TV	TELEVISION
32PW9515/19	720332i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
32PW9521/12	720332i WS 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
32PW9521/19	720332i WS 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
32PW9523/05	720332i WS 100Hz	MD2.22E	1.12.1997Upmarket TV	TELEVISION
32PW9523/05M	720332i WS 100Hz	MD2.22E	1.10.1999Upmarket TV	TELEVISION
32PW9523/05R	720332i WS 100Hz	MD2.22E	1.02.2001Upmarket TV	TELEVISION
32PW9523/12	720332i WS 100Hz	MD2.22E	1.11.1997Upmarket TV	TELEVISION
32PW9523/12M	720332i WS 100Hz	MD2.22E	1.10.1999Upmarket TV	TELEVISION
32PW9523/12R	720332i WS 100Hz	MD2.22E	1.02.2001Upmarket TV	TELEVISION
32PW9523/19	720332i WS 100Hz	MD2.22E	1.12.1997Upmarket TV	TELEVISION
32PW9523/19M	720332i WS 100Hz	MD2.22E	1.10.1999Upmarket TV	TELEVISION
32PW9523/25	720332i WS 100Hz	MD2.22E	1.07.1998Upmarket TV	TELEVISION
32PW9523/32	720332i WS 100Hz	MD2.22E	1.07.1998Upmarket TV	TELEVISION
32PW9523/39	720332i WS 100Hz	MD2.22E	1.08.1998Upmarket TV	TELEVISION
32PW9523/58	720332i WS 100Hz	MD2.22E	1.03.1998Upmarket TV	TELEVISION
32PW9523/58M	720332i WS 100Hz	MD2.22E	1.11.1999Upmarket TV	TELEVISION
32PW9523/75	720332i WS 100Hz	MD2.22E	1.08.1999Upmarket TV	TELEVISION
32PW9523/75M	720332i WS 100Hz	MD2.22E	1.11.1999Upmarket TV	TELEVISION
32PW9523/95	720332i WS 100Hz	MD2.22E	1.08.1998Upmarket TV	TELEVISION
32PW9525/05	720332i WS 100Hz	MG3.1E	1.11.1999Upmarket TV	TELEVISION
32PW9525/05L	720332i WS 100Hz	MG3.1E	1.09.2000Upmarket TV	TELEVISION
32PW9525/05R	720332i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
32PW9525/12	720332i WS 100Hz	MG3.1E	1.11.1999Upmarket TV	TELEVISION
32PW9525/12L	720332i WS 100Hz	MG3.1E	1.08.2000Upmarket TV	TELEVISION
32PW9525/12R	720332i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
32PW9525/19	720332i WS 100Hz	MG3.1E	1.11.1999Upmarket TV	TELEVISION
32PW9525/19L	32i WS 100Hz			TELEVISION
32PW9525/19R	32i WS 100Hz			TELEVISION
32PW9525/58	720332i WS 100Hz	MG3.1E	1.12.1999Upmarket TV	TELEVISION
32PW9525/58L	720332i WS 100Hz	MG3.1E	1.09.2000Upmarket TV	TELEVISION
32PW9525/58R	720332i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
32PW9534/05	720332i WS 100Hz	MD2.22E	1.03.1999Upmarket TV	TELEVISION
32PW9534/05M	720332i WS 100Hz	MD2.22E	1.10.1999Upmarket TV	TELEVISION
32PW9534/05R	720332i WS 100Hz	MD2.22E	1.02.2001Upmarket TV	TELEVISION
32PW9534/12	720332i WS 100Hz	MD2.22E	1.09.1998Upmarket TV	TELEVISION
32PW9534/12M	720332i WS 100Hz	MD2.22E	1.11.1999Upmarket TV	TELEVISION

32PW9534/12R	720332i WS 100Hz	MD2.22E	1.02.2001Upmarket TV	TELEVISION
32PW9534/19	720332i WS 100Hz	MD2.22E	1.03.1999Upmarket TV	TELEVISION
32PW9534/19M	720332i WS 100Hz	MD2.22E	1.11.1999Upmarket TV	TELEVISION
32PW9534/75	720332i WS 100Hz	MD2.22E	1.10.1999Upmarket TV	TELEVISION
32PW9534/75M	720332i WS 100Hz	MD2.22E	1.11.1999Upmarket TV	TELEVISION
32PW9535/05	720332i WS 100Hz	MG2.1E	1.01.2000Upmarket TV	TELEVISION
32PW9535/12	720332i WS 100Hz	MG2.1E	1.12.1999Upmarket TV	TELEVISION
32PW9535/19	720332i WS 100Hz	MG2.1E	Upmarket TV	TELEVISION
32PW9535/58	720332i WS 100Hz	MG2.1E	1.04.2000Upmarket TV	TELEVISION
32PW9536/05	720332i WS 100Hz	MG7.1E	1.07.2000Upmarket TV	TELEVISION
32PW9536/05M	32i WS 100Hz			TELEVISION
32PW9536/05R	720332i WS 100Hz	MG7.1E	1.12.2000Upmarket TV	TELEVISION
32PW9536/12	720332i WS 100Hz	MG7.1E	1.08.2000Upmarket TV	TELEVISION
32PW9536/12R	720332i WS 100Hz	MG7.1E	1.12.2000Upmarket TV	TELEVISION
32PW9536/19	720332i WS 100Hz	MG7.1E	1.11.2000Upmarket TV	TELEVISION
32PW9536/19R	720332i WS 100Hz	MG7.1E	1.01.2001Upmarket TV	TELEVISION
32PW9536/58	720332i WS 100Hz	MG7.1E	1.09.2000Upmarket TV	TELEVISION
32PW9536/58R	720332i WS 100Hz	MG7.1E	1.01.2001Upmarket TV	TELEVISION
32PW9544/05	720332i WS 100Hz	MD2.22E	1.03.1999Upmarket TV	TELEVISION
32PW9544/05M	720332i WS 100Hz	MD2.22E	1.10.1999Upmarket TV	TELEVISION
32PW9544/05R	720332i WS 100Hz	MD2.22E	1.02.2001Upmarket TV	TELEVISION
32PW9544/12	720332i WS 100Hz	MD2.22E	1.09.1998Upmarket TV	TELEVISION
32PW9544/12M	720332i WS 100Hz	MD2.22E	1.10.1999Upmarket TV	TELEVISION
32PW9544/12R	720332i WS 100Hz	MD2.22E	1.01.2001Upmarket TV	TELEVISION
32PW9544/19	720332i WS 100Hz	MD2.22E	1.03.1999Upmarket TV	TELEVISION
32PW9544/19M	720332i WS 100Hz	MD2.22E	1.11.1999Upmarket TV	TELEVISION
32PW9544/58M	720332i WS 100Hz	MD2.22E	1.05.2000Upmarket TV	TELEVISION
32PW9544/75M	720332i WS 100Hz	MD2.22E	1.11.1999Upmarket TV	TELEVISION
32PW9545/05	720332i WS 100Hz	MG2.1E	1.10.1999Upmarket TV	TELEVISION
32PW9545/12	720332i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
32PW9545/19	720332i WS 100Hz	MG2.1E	1.09.1999Upmarket TV	TELEVISION
32PW9545/58	720332i WS 100Hz	MG2.1E	1.11.1999Upmarket TV	TELEVISION
32PW9546/05	720332i WS 100Hz	MG7.1E	1.07.2000Upmarket TV	TELEVISION
32PW9546/05R	720332i WS 100Hz	MG7.1E	1.12.2000Upmarket TV	TELEVISION
32PW9546/12	720332i WS 100Hz	MG7.1E	1.08.2000Upmarket TV	TELEVISION
32PW9546/12R	720332i WS 100Hz	MG7.1E	1.12.2000Upmarket TV	TELEVISION
32PW9546/19	720332i WS 100Hz	MG7.1E	1.10.2000Upmarket TV	TELEVISION
32PW9546/19R	720332i WS 100Hz	MG7.1E	1.04.2001Upmarket TV	TELEVISION
32PW9546/58	720332i WS 100Hz	MG7.1E	1.09.2000Upmarket TV	TELEVISION
32PW9546/58R	720332i WS 100Hz	MG7.1E	1.02.2001Upmarket TV	TELEVISION
32PW9556/05E	720332i WS 100Hz	MG2.1E	1.11.2001Upmarket TV	TELEVISION
32PW9556/05R	720332i WS 100Hz	MG2.1E	1.12.2000Upmarket TV	TELEVISION

32PW9556/12E	720332i WS 100Hz	MG2.1E	1.09.2001Upmarket TV	TELEVISION
32PW9556/12R	720332i WS 100Hz	MG2.1E	1.12.2000Upmarket TV	TELEVISION
32PW9556/19E	720332i WS 100Hz	MG2.1E	1.10.2001Upmarket TV	TELEVISION
32PW9556/19R	720332i WS 100Hz	MG2.1E	1.02.2001Upmarket TV	TELEVISION
32PW9556/57E	32i WS 100Hz			TELEVISION
32PW9556/57R	720332i WS 100Hz	MG2.1E	1.04.2001Upmarket TV	TELEVISION
32PW9556/58E	720332i WS 100Hz	MG2.1E	1.09.2001Upmarket TV	TELEVISION
32PW9556/58R	720332i WS 100Hz	MG2.1E	1.01.2001Upmarket TV	TELEVISION
32PW9556/69E	32i WS 100Hz			TELEVISION
32PW9556/69R	720332i WS 100Hz	MG2.1E	1.04.2001Upmarket TV	TELEVISION
32PW9556/79E	32i WS 100Hz			TELEVISION
32PW9556/79R	720332i WS 100Hz	MG2.1E	1.03.2001Upmarket TV	TELEVISION
32PW9566/05E	720332i WS 100Hz	MG2.1E	1.10.2001Upmarket TV	TELEVISION
32PW9566/05R	720332i WS 100Hz	MG2.1E	1.12.2000Upmarket TV	TELEVISION
32PW9566/12E	720332i WS 100Hz	MG2.1E	1.09.2001Upmarket TV	TELEVISION
32PW9566/12R	720332i WS 100Hz	MG2.1E	1.12.2000Upmarket TV	TELEVISION
32PW9566/19E	720332i WS 100Hz	MG2.1E	1.10.2001Upmarket TV	TELEVISION
32PW9566/19R	720332i WS 100Hz	MG2.1E	1.03.2001Upmarket TV	TELEVISION
32PW9566/57E	32i WS 100Hz			TELEVISION
32PW9566/57R	720332i WS 100Hz	MG2.1E	1.04.2001Upmarket TV	TELEVISION
32PW9566/58E	32i WS 100Hz		1.12.2001	TELEVISION
32PW9566/58R	720332i WS 100Hz	MG2.1E	1.12.2000Upmarket TV	TELEVISION
32PW9566/69E	32i WS 100Hz			TELEVISION
32PW9566/69R	720332i WS 100Hz	MG2.1E	1.04.2001Upmarket TV	TELEVISION
32PW9566/79E	32i WS 100Hz			TELEVISION
32PW9566/79R	700332i WS 100Hz	MG2.1E	1.04.2001Upmarket TV	TELEVISION
32PW956A/90	720328i WS 100Hz	GFL2.20A	1.03.1996Upmarket TV	TELEVISION
32PW9576/05E	720332i WS 100Hz	MG2.1E	1.10.2001Upmarket TV	TELEVISION
32PW9576/05R	720332i WS 100Hz	MG2.1E	1.03.2001Upmarket TV	TELEVISION
32PW9576/12E	720332i WS 100Hz	MG2.1E	1.09.2001Upmarket TV	TELEVISION
32PW9576/12R	720332i WS 100Hz	MG2.1E	1.04.2001Upmarket TV	TELEVISION
32PW9576/19E	700332i WS 100Hz	MG2.1E	1.09.2001Upmarket TV	TELEVISION
32PW9576/19R	720332i WS 100Hz	MG2.1E	1.06.2001Upmarket TV	TELEVISION
32PW9576/58E	720332i WS 100Hz	MG2.1E	1.09.2001Upmarket TV	TELEVISION
32PW9576/58R	700332i WS 100Hz	MG2.1E	1.07.2001Upmarket TV	TELEVISION
32PW960A/01	720328i WS 100Hz	FL*.14	1.07.1993Upmarket TV	TELEVISION
32PW960A/19	720328i WS 100Hz	FL*.14	1.06.1993Upmarket TV	TELEVISION
32PW960B/01	720328i WS 100Hz	FL*.24	1.03.1994Upmarket TV	TELEVISION
32PW960B/19	720328i WS 100Hz	FL*.24	1.03.1994Upmarket TV	TELEVISION
32PW960B/42	720328i WS 100Hz	FL*.24	1.12.1994Upmarket TV	TELEVISION
32PW960B/58	720328i WS 100Hz	FL*.24	1.09.1994Upmarket TV	TELEVISION
32PW9611/01	720332i WS 100Hz	GFL2.30E	1.09.1995Upmarket TV	TELEVISION

32PW9611/58	720332i WS 100Hz	GFL2.30E	1.10.1995Upmarket TV	TELEVISION
32PW9615/01	720332i WS 100Hz	MG3.1E	1.09.1999Upmarket TV	TELEVISION
32PW9615/05	720332i WS 100Hz	MG3.1E	1.08.1999Upmarket TV	TELEVISION
32PW9615/12	720332i WS 100Hz	MG3.1E	1.08.1999Upmarket TV	TELEVISION
32PW9615/19	720332i WS 100Hz	MG3.1E	1.09.1999Upmarket TV	TELEVISION
32PW9615/58	720332i WS 100Hz	MG3.1E	1.11.1999Upmarket TV	TELEVISION
32PW9616/01	720332i WS 100Hz	MG3.1E	1.05.2000Upmarket TV	TELEVISION
32PW9616/01M	720332i WS 100Hz	MG3.1E	1.11.2001Upmarket TV	TELEVISION
32PW9616/01R	720332i WS 100Hz	MG3.1E	1.11.2000Upmarket TV	TELEVISION
32PW9616/05	720332i WS 100Hz	MG3.1E	1.05.2000Upmarket TV	TELEVISION
32PW9616/05M	720332i WS 100Hz	MG3.1E	1.10.2001Upmarket TV	TELEVISION
32PW9616/05R	720332i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
32PW9616/12	720332i WS 100Hz	MG3.1E	1.04.2000Upmarket TV	TELEVISION
32PW9616/12M	720332i WS 100Hz	MG3.1E	1.10.2001Upmarket TV	TELEVISION
32PW9616/12R	720332i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
32PW9616/19	720332i WS 100Hz	MG3.1E	1.04.2000Upmarket TV	TELEVISION
32PW9616/19M	720332i WS 100Hz	MG3.1E	1.11.2001Upmarket TV	TELEVISION
32PW9616/19R	720332i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
32PW9616/58M	720332i WS 100Hz	MG3.1E	1.11.2001Upmarket TV	TELEVISION
32PW9616/58R	720332i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
32PW9617/01	32i WS 100Hz			TELEVISION
32PW9617/05	32i WS 100Hz			TELEVISION
32PW9617/12	32i WS 100Hz			TELEVISION
32PW9617/19	32i WS 100Hz			TELEVISION
32PW962A/05	720328i WS 100Hz	FL*.14	1.10.1993Upmarket TV	TELEVISION
32PW962A/12	720328i WS 100Hz	FL*.14	1.06.1993Upmarket TV	TELEVISION
32PW962A/13	720328i WS 100Hz	FL*.14	1.09.1993Upmarket TV	TELEVISION
32PW962B/05	720328i WS 100Hz	FL*.24	1.04.1994Upmarket TV	TELEVISION
32PW962B/12	720328i WS 100Hz	FL*.24	1.04.1994Upmarket TV	TELEVISION
32PW962B/13	720328i WS 100Hz	FL*.24	1.06.1994Upmarket TV	TELEVISION
32PW962B/19	720328i WS 100Hz	FL*.24	1.09.1994Upmarket TV	TELEVISION
32PW9631/05	720328i WS 100Hz	GFL2.30E	1.11.1995Upmarket TV	TELEVISION
32PW9631/12	720332i WS 100Hz	GFL2.30E	1.10.1995Upmarket TV	TELEVISION
32PW9631/19	720332i WS 100Hz	GFL2.30E	1.10.1995Upmarket TV	TELEVISION
32PW9631/25	720332i WS 100Hz	GFL2.30E	1.10.1996Upmarket TV	TELEVISION
32PW967A/57	720328i WS 100Hz	GFL2.20A	1.08.1996Upmarket TV	TELEVISION
32PW968A/97	720328i WS 100Hz	GFL2.20A	1.03.1996Upmarket TV	TELEVISION
32PW968B/97	720328i WS 100Hz	GFL2.20A	1.09.1996Upmarket TV	TELEVISION
32PW9713/05	720332i WS 100Hz	MD2.22E	1.05.1997Upmarket TV	TELEVISION
32PW9713/12	720332i WS 100Hz	MD2.22E	1.04.1997Upmarket TV	TELEVISION
32PW9713/19	720332i WS 100Hz	MD2.22E	1.05.1997Upmarket TV	TELEVISION
32PW9723/05	720332i WS 100Hz	MD2.22E	1.06.1998Upmarket TV	TELEVISION

32PW9723/12	720332i WS 100Hz	MD2.22E	1.06.1998Upmarket TV	TELEVISION
32PW9723/19	720332i WS 100Hz	MD2.22E	1.09.1998Upmarket TV	TELEVISION
32PW9723/32	720332i WS 100Hz	MD2.22E	1.09.1998Upmarket TV	TELEVISION
32PW975A/01	720328i WS 100Hz	FL*.24	1.02.1995Upmarket TV	TELEVISION
32PW9761/01	720332i WS 100Hz	GFL2.30E	1.11.1995Upmarket TV	TELEVISION
32PW9763/05	720332i WS 100Hz	MD2.22E	1.06.1997Upmarket TV	TELEVISION
32PW9763/12	720332i WS 100Hz	MD2.22E	1.06.1997Upmarket TV	TELEVISION
32PW9763/19	720332i WS 100Hz	MD2.22E	1.07.1997Upmarket TV	TELEVISION
32PW9763/25	720332i WS 100Hz	MD2.22E	1.06.1998Upmarket TV	TELEVISION
32PW9763/32	720332i WS 100Hz	MD2.22E	1.06.1998Upmarket TV	TELEVISION
32PW9763/39	720332i WS 100Hz	MD2.22E	1.08.1998Upmarket TV	TELEVISION
32PW9763/58	720332i WS 100Hz	MD2.22E	1.09.1997Upmarket TV	TELEVISION
32PW9763/95	720332i WS 100Hz	MD2.22E	1.07.1998Upmarket TV	TELEVISION
32PW9765/01	720332i WS 100Hz	MG3.1E	1.04.2000Upmarket TV	TELEVISION
32PW9765/01M	720332i WS 100Hz	MG3.1E	1.11.2001Upmarket TV	TELEVISION
32PW9765/01R	720332i WS 100Hz	MG3.1E	1.11.2000Upmarket TV	TELEVISION
32PW9765/05	720332i WS 100Hz	MG3.1E	Upmarket TV	TELEVISION
32PW9765/12	720332i WS 100Hz	MG3.1E	1.04.2000Upmarket TV	TELEVISION
32PW9765/12M	720332i WS 100Hz	MG3.1E	1.10.2001Upmarket TV	TELEVISION
32PW9765/12R	720332i WS 100Hz	MG3.1E	1.11.2000Upmarket TV	TELEVISION
32PW9765/19	720332i WS 100Hz	MG3.1E	1.04.2000Upmarket TV	TELEVISION
32PW9765/19R	32i WS 100Hz	MG3.1E	Upmarket TV	TELEVISION
32PW9765/58	720332i WS 100Hz	MG3.1E	1.04.2000Upmarket TV	TELEVISION
32PW9765/58M	720332i WS 100Hz	MG3.1E	1.10.2001Upmarket TV	TELEVISION
32PW9765/58R	720332i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
32PW9767/01	32i WS 100Hz			TELEVISION
32PW9767/12	32i WS 100Hz		1.12.2001	TELEVISION
32PW9767/19	32i WS 100Hz			TELEVISION
32PW9767/58	32i WS 100Hz			TELEVISION
32PW977A/05	720328i WS 100Hz	FL*.24	1.05.1995Upmarket TV	TELEVISION
32PW977A/12	720328i WS 100Hz	FL*.24	1.03.1995Upmarket TV	TELEVISION
32PW977A/19	720328i WS 100Hz	FL*.24	1.05.1995Upmarket TV	TELEVISION
32PW977A/57	720328i WS 100Hz	FL*.24	1.03.1996Upmarket TV	TELEVISION
32PW977A/69	720328i WS 100Hz	FL*.24	1.02.1996Upmarket TV	TELEVISION
32PW977A/75	720328i WS 100Hz	FL*.24	1.03.1996Upmarket TV	TELEVISION
32PW977A/79	720328i WS 100Hz	FL*.24	1.02.1996Upmarket TV	TELEVISION
32PW977A/93	720328i WS 100Hz	FL*.24	1.09.1996Upmarket TV	TELEVISION
32PW977B/56	720332i WS 100Hz	GFL2.20A	Upmarket TV	TELEVISION
32PW977B/69	720332i WS 100Hz	GFL2.20A	1.05.1996Upmarket TV	TELEVISION
32PW9781/12	720332i WS 100Hz	GFL2.30E	1.12.1995Upmarket TV	TELEVISION
32PW9781/19	720328i WS 100Hz	GFL2.30E	1.06.1996Upmarket TV	TELEVISION
32PW978B/78	720328i WS 100Hz	GFL2.20A	1.07.1998Upmarket TV	TELEVISION

32PW978B/78R	720328i WS 100Hz	GFL2.20A	1.01.1997Upmarket TV	TELEVISION
32PW978B/85	720328i WS 100Hz	GFL2.20A	1.09.1996Upmarket TV	TELEVISION
32PW979B/61	720332i WS 100Hz	GFL2.20A	Upmarket TV	TELEVISION
32PW987C/57	720332i WS 100Hz	GFL2.20A	1.12.1996Upmarket TV	TELEVISION
32PW987C/69	720332i WS 100Hz	GFL2.20A	1.12.1996Upmarket TV	TELEVISION
32PW987C/75	720328i WS 100Hz	GFL2.20A	1.03.1997Upmarket TV	TELEVISION
32PW987C/79	720328i WS 100Hz	GFL2.20A	1.04.1997Upmarket TV	TELEVISION
32PW987C/93	720328i WS 100Hz	GFL2.20A	1.03.1997Upmarket TV	TELEVISION
32PW988C/71	720328i WS 100Hz	GFL2.20A	1.04.1997Upmarket TV	TELEVISION
32PW989C/61	720332i WS 100Hz	GFL2.20A	Upmarket TV	TELEVISION
32PW989C/61R	700332i WS 100Hz			TELEVISION
32PX977A/57	720328i WS 100Hz	GFL2.20A	1.12.1996Upmarket TV	TELEVISION
32PX977A/69	720328i WS 100Hz	GFL2.20A	1.02.1996Upmarket TV	TELEVISION
32PX977A/75	720328i WS 100Hz	GFL2.20A	1.03.1996Upmarket TV	TELEVISION
32PX979B/61	720328i WS 100Hz	GFL2.20A	Upmarket TV	TELEVISION
330T5601/00M	2012PAL/SECAM terminal		1.08.1996	SATELLITE
330T5805/00M	2012PAL/SECAM terminal		1.11.1996	SATELLITE
330U2801/00M	2012PAL/SECAM terminal			SATELLITE
333T6601/00P	2012PAL/SECAM terminal			SATELLITE
33AS501/99	1049		1.02.1993	MIDISYSTEMS
33AS9303/99	1049		1.05.1992	MIDISYSTEMS
33AW7694/99	1041Radio cassette recorders - mono		1.03.1992	RADIO MONO + STEREO
33CE7533/33R	720325i stereo large 100Hz	3A	1.03.1992Upmarket TV	TELEVISION
33CE7533/36R	720325i stereo large 100Hz	3A	1.05.1992Upmarket TV	TELEVISION
33CE7533/45R	720325i stereo large 100Hz	3A	1.03.1992Upmarket TV	TELEVISION
33CE7535/39B	720325i stereo large 100Hz	3A	1.03.1992Upmarket TV	TELEVISION
33CE7536/30R	720325i stereo large 100Hz	3A	1.04.1992Upmarket TV	TELEVISION
33CE7536/33R	720325i stereo large 100Hz	3A	1.02.1994Upmarket TV	TELEVISION
33CE7536/42R	720325i stereo large 100Hz	3A	1.04.1992Upmarket TV	TELEVISION
33CE7537/21R	720325i stereo large 100Hz	3A	1.01.1993Upmarket TV	TELEVISION
33CE7537/39R	720325i stereo large 100Hz	3A	1.03.1992Upmarket TV	TELEVISION
33CE7538/30R	720325i stereo large 100Hz	3A	1.03.1992Upmarket TV	TELEVISION
33CE7538/42R	720325i stereo large 100Hz	3A	1.03.1992Upmarket TV	TELEVISION
33CE7539/10R	720325i stereo large 100Hz	3A	1.06.1992Upmarket TV	TELEVISION
33CE7539/19R	720325i stereo large 100Hz	3A	1.03.1992Upmarket TV	TELEVISION
33CE7539/30R	720325i stereo large 100Hz	3A	1.03.1992Upmarket TV	TELEVISION
33DC2080/20R	720325i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
33DC2080/25R	720325i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
33DC2080/32R	720325i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
33DC2080/33R	720325i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
33DC2080/36R	720325i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
33DC2080/39R	720325i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION

33DC2080/42R	720325i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
33DC2080/80	720325i stereo large 100Hz	D16	1.07.1993Upmarket TV	TELEVISION
33DC2080L/80	700325i stereo large 50Hz		1.03.1992	TELEVISION
33DC2085/39R	720325i stereo large 100Hz	D16	1.03.1992Upmarket TV	TELEVISION
33DV1/08	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
33DV1/10	1021Leader	MICHEL_STN	1.02.1995Standard	VCR
33DV2/08	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
33FL1780/56R	720325i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
33FL1780/57R	720325i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
33FL1780/62R	720325i stereo large 50Hz	FL1.0S	1.12.1992Upmarket TV	TELEVISION
33FL1780/73R	720325i stereo large 50Hz	FL1.0S	1.11.1992Upmarket TV	TELEVISION
33FL1780/75R	720325i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
33FL1785/76R	720325i stereo large 50Hz	FL1.0S	1.12.1992Upmarket TV	TELEVISION
33FL1785/77R	720325i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
33FL1785/78R	720325i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
33FL1785/97R	720325i stereo large 50Hz	FL1.0S	1.03.1992Upmarket TV	TELEVISION
33FL1880/56R	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33FL1880/57R	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33FL1880/75R	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33FL1880/79R	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33FL1880L/80	700325i stereo large 50Hz		1.06.1992	TELEVISION
33ML0996L/80	700325i stereo large 50Hz		1.05.1992	TELEVISION
33ML8905/00B	720325i stereo large 100Hz	FL1.6	1.05.1992Upmarket TV	TELEVISION
33ML8905/02B	720325i stereo large 100Hz	FL1.6	1.05.1992Upmarket TV	TELEVISION
33ML8905/06B	720325i stereo large 100Hz	FL1.6	1.05.1992Upmarket TV	TELEVISION
33ML8905/08B	720325i stereo large 100Hz	FL1.6	1.07.1992Upmarket TV	TELEVISION
33ML8905/10B	720325i stereo large 100Hz	FL1.6	1.05.1992Upmarket TV	TELEVISION
33ML8905/13B	720325i stereo large 100Hz	FL1.6	1.06.1992Upmarket TV	TELEVISION
33ML8905/16B	720325i stereo large 100Hz	FL1.6	1.06.1992Upmarket TV	TELEVISION
33ML8905/19B	720325i stereo large 100Hz	FL1.6	1.05.1992Upmarket TV	TELEVISION
33ML8905/21	720333i stereo large 100Hz	FL1.6	1.06.1993Upmarket TV	TELEVISION
33ML8905/32	720325i stereo large 100Hz	FL1.6	1.06.1993Upmarket TV	TELEVISION
33ML8905/33	720325i stereo large 100Hz	FL1.6	1.10.1993Upmarket TV	TELEVISION
33ML8905/39	720325i stereo large 100Hz	FL1.6	1.07.1993Upmarket TV	TELEVISION
33ML8905/42	720325i stereo large 100Hz	FL1.6	1.05.1994Upmarket TV	TELEVISION
33ML8905/80	720325i stereo large 100Hz	FL1.6	1.05.1993Upmarket TV	TELEVISION
33ML8905L/80	700325i stereo large 50Hz		1.09.1992	TELEVISION
33ML8990/05B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33ML8996/00B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33ML8996/02B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33ML8996/06B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33ML8996/08B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION

33ML8996/10B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33ML8996/13B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33ML8996/16B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33ML8996/19B	720325i stereo large 100Hz	FL1.7	1.03.1992Upmarket TV	TELEVISION
33PT700A/00	720325i stereo large 50Hz	FL*.10	1.09.1993Upmarket TV	TELEVISION
33PT700A/19	720325i stereo large 50Hz	FL*.10	1.09.1993Upmarket TV	TELEVISION
33PT700B/00	720325i stereo large 50Hz	FL*.10	1.04.1994Upmarket TV	TELEVISION
33PT700B/19	720325i stereo large 50Hz	FL*.10	1.03.1994Upmarket TV	TELEVISION
33PT700C/00	720325i stereo large 50Hz	FL*.20	1.05.1995Upmarket TV	TELEVISION
33PT702A/07	720325i stereo large 50Hz	FL*.10	1.02.1994Upmarket TV	TELEVISION
33PT702A/13	720325i stereo large 50Hz	FL*.10	1.09.1993Upmarket TV	TELEVISION
33PT702B/07	720325i stereo large 50Hz	FL*.10	1.03.1994Upmarket TV	TELEVISION
33PT702B/13	720325i stereo large 50Hz	FL*.10	1.04.1994Upmarket TV	TELEVISION
33PT702B/19	720325i stereo large 50Hz	FL*.10	1.09.1994Upmarket TV	TELEVISION
33PT702C/07	720325i stereo large 50Hz	FL*.20	1.05.1996Upmarket TV	TELEVISION
33PT702C/12	720333i (32v) stereo large 50Hz	FL*.20	1.06.1995Upmarket TV	TELEVISION
33PT702C/13	720333i (32v) stereo large 50Hz	FL*.20	1.06.1995Upmarket TV	TELEVISION
33PT702C/19	720325i stereo large 50Hz	FL*.20	1.05.1995Upmarket TV	TELEVISION
33PT710A/01	720325i stereo large 50Hz	FL*.10	1.09.1993Upmarket TV	TELEVISION
33PT710B/01	720325i stereo large 50Hz	FL*.10	1.06.1994Upmarket TV	TELEVISION
33PT710C/01	720325i stereo large 50Hz	FL*.20	1.10.1995Upmarket TV	TELEVISION
33PT712A/12	720325i stereo large 50Hz	FL*.10	1.09.1993Upmarket TV	TELEVISION
33PT712B/12	720325i stereo large 50Hz	FL*.10	1.04.1994Upmarket TV	TELEVISION
33PT9101/01	720333i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
33PT9101/58	720333i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
33PT910B/01	720325i stereo large 100Hz	FL*.26	1.07.1994Upmarket TV	TELEVISION
33PT910B/19	720325i stereo large 100Hz	FL*.26	1.07.1994Upmarket TV	TELEVISION
33PT910B/58	720325i stereo large 100Hz	FL*.26	1.10.1994Upmarket TV	TELEVISION
33PT9121/12	720333i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
33PT9121/19	720333i stereo large 100Hz	GFL2.20E	1.09.1995Upmarket TV	TELEVISION
33PT912B/12	720325i stereo large 100Hz	FL*.26	1.06.1994Upmarket TV	TELEVISION
33PT912B/13	720325i stereo large 100Hz	FL*.26	1.07.1994Upmarket TV	TELEVISION
33PT912B/19	720325i stereo large 100Hz	FL*.26	1.09.1994Upmarket TV	TELEVISION
33PV7906/00B	720325i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
33PV7906/10B	720325i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
33PV7990/00B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33PV7996/00B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33PV7996/19B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33PX8001/01	720333i Multimedia	GFL2.20E	1.06.1996Upmarket TV	TELEVISION
33PX8001/05	720333i Multimedia	GFL2.20E	1.06.1996Upmarket TV	TELEVISION
33SL5790/00B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33SL5790/02B	720325i stereo large 50Hz	FL1.0	1.07.1992Upmarket TV	TELEVISION

33SL5796/00B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33SL5796/10B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33SL5796/13B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33SL5796/16B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33SL5796/19B	720325i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
33SL5900/00B	720325i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
33SL5901/07B	720325i stereo large 50Hz	FL1.0	1.11.1992Upmarket TV	TELEVISION
33SL5901/10B	720325i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
33SL5901/13B	720325i stereo large 50Hz	FL1.0	1.08.1992Upmarket TV	TELEVISION
33SL5901/19B	720325i stereo large 50Hz	FL1.0	1.09.1992Upmarket TV	TELEVISION
34DV19/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
34DV2/08	1021Leader	NORA _STN	1.03.1995Standard	VCR
34DV69/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
34PH9915/17	7203Digital CRT TV ATSC			DIGITAL TV
34PT2152/69R	33i (32v) stereo large 50Hz			TELEVISION
34PT2152/79R	33i (32v) stereo large 50Hz			TELEVISION
34PT4822/71R	720333i (32v) stereo large 50Hz	MG3.1E	1.03.2001Upmarket TV	TELEVISION
34PT4873/56A	720333i (32v) stereo large 50Hz	MG3.1E	1.11.2000Upmarket TV	TELEVISION
34PT4873/57R	720333i (32v) stereo large 50Hz	MG3.1E	Upmarket TV	TELEVISION
34PT4873/69R	720333i (32v) stereo large 50Hz	MG3.1E	1.07.2000Upmarket TV	TELEVISION
34PT4873/79R	720333i (32v) stereo large 50Hz	MG3.1E	1.09.2000Upmarket TV	TELEVISION
34PT5633/61R	700333i (32v) stereo large 50Hz			TELEVISION
34PT5633/71R	710333i (32v) stereo large 50Hz	A8.0A	1.01.1999Basic TV	TELEVISION
34PT5693/56A	710333i (32v) stereo large 50Hz	A8.0A	1.03.1999Basic TV	TELEVISION
34PT5693/57R	710333i (32v) stereo large 50Hz	A8.0A	1.11.1998Basic TV	TELEVISION
34PT5693/69R	710333i (32v) stereo large 50Hz	A8.0A	1.10.1998Basic TV	TELEVISION
34PT5693/75R	710333i (32v) stereo large 50Hz	A8.0A	1.12.1998Basic TV	TELEVISION
34PT5693/79R	710333i (32v) stereo large 50Hz	A8.0A	1.11.1998Basic TV	TELEVISION
34PT5793/56A	710333i (32v) stereo large 50Hz	A8.0A	1.06.1999Basic TV	TELEVISION
34PT5793/57R	710333i (32v) stereo large 50Hz	A8.0A	1.05.1999Basic TV	TELEVISION
34PT5793/69R	710333i (32v) stereo large 50Hz	A8.0A	1.04.1999Basic TV	TELEVISION
34PT5793/79R	710333i (32v) stereo large 50Hz	A8.0A	1.07.1999Basic TV	TELEVISION
34PT6361/56A	710333i (32v) stereo large 50Hz	A8.0A	1.05.2001Basic TV	TELEVISION
34PT6361/57R	710333i (32v) stereo large 50Hz	A8.0A	1.11.2000Basic TV	TELEVISION
34PT6361/61R	710333i (32v) stereo large 50Hz	A8.0A	1.08.2001Basic TV	TELEVISION
34PT6361/69R	710333i (32v) stereo large 50Hz	A8.0A	1.10.2000Basic TV	TELEVISION
34PT6361/71R	710333i (32v) stereo large 50Hz	A8.0A	1.04.2001Basic TV	TELEVISION
34PT6361/79R	710333i (32v) stereo large 50Hz	A8.0A	1.12.2000Basic TV	TELEVISION
34PT6361/97R	710333i (32v) stereo large 50Hz	A8.0A	1.04.2001Basic TV	TELEVISION
34PT8419/44	33i stereo large 100Hz			TELEVISION
34PT8419/55	33i stereo large 100Hz			TELEVISION
34PT8419/56R	33i stereo large 100Hz			TELEVISION

34PT8419/57R	33i stereo large 100Hz			TELEVISION
34PT8419/61R	33i stereo large 100Hz			TELEVISION
34PT8419/69R	33i stereo large 100Hz			TELEVISION
34PT8419/71R	33i stereo large 100Hz			TELEVISION
34PT8419/77	33i stereo large 100Hz			TELEVISION
34PT8419/78	33i stereo large 100Hz			TELEVISION
34PT8419/79R	33i stereo large 100Hz			TELEVISION
34PW9815/17	700336i WS 100Hz			TELEVISION
34PW9815/97R	720336i WS 100Hz	MG3.1U	1.12.2000Upmarket TV	TELEVISION
34PW9817/17	36i WS 100Hz			TELEVISION
34PW9817/97R	720336i WS 100Hz	MG3.1U	1.06.2001Upmarket TV	TELEVISION
34PW9846/17	36i WS 100Hz			TELEVISION
34PW9847/17	36i WS 100Hz			TELEVISION
35DV2/08	1021Leader	OLIVIA_STN	1.02.1996Standard	VCR
35DV6/39	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
36D8061/99	1041Radio cassette recorders - mono		1.06.1992	RADIO MONO + STEREO
36D8089/99	1041Radio cassette recorders - mono		1.03.1992	RADIO MONO + STEREO
36FL1890/56R	720328i WS 100Hz	FL1.2S	1.10.1992Upmarket TV	TELEVISION
36FL1890/57R	720328i WS 100Hz	FL1.2S	1.10.1992Upmarket TV	TELEVISION
36FL1890/79R	720328i WS 100Hz	FL1.2S	1.05.1993Upmarket TV	TELEVISION
36ML8906/00B	720328i WS 100Hz	FL1.2	1.03.1992Upmarket TV	TELEVISION
36ML8906/05B	720328i WS 100Hz	FL1.2	1.03.1992Upmarket TV	TELEVISION
36ML8906/10B	720328i WS 100Hz	FL1.2	1.03.1992Upmarket TV	TELEVISION
36ML8906/13B	720328i WS 100Hz	FL1.2	1.03.1992Upmarket TV	TELEVISION
36ML8906/19B	720328i WS 100Hz	FL1.2	1.03.1992Upmarket TV	TELEVISION
36ML8906/30B	720328i WS 100Hz	FL1.2	1.03.1992Upmarket TV	TELEVISION
36ML8906L/80	200648i rear-PTV 4:3		1.09.1992	PROJECTION TV
36ML8908/20B	720328i WS 100Hz	FL1.2 AB	1.05.1992Upmarket TV	TELEVISION
36ML8908/30B	720328i WS 100Hz	FL1.2 AB	1.05.1992Upmarket TV	TELEVISION
36ML8908/39B	700336i WS 100Hz			TELEVISION
36ML8965/39B	720328i WS 100Hz	FL1.2 AB	1.11.1992Upmarket TV	TELEVISION
36ML8985/00B	720328i WS 100Hz	FL1.2 AB	1.01.1994Upmarket TV	TELEVISION
36PW9525/05	720336i WS 100Hz	MG3.1E	1.01.2000Upmarket TV	TELEVISION
36PW9525/05R	720336i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
36PW9525/12	720336i WS 100Hz	MG3.1E	1.12.1999Upmarket TV	TELEVISION
36PW9525/12R	720336i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
36PW9525/19	720336i WS 100Hz	MG3.1E	1.12.1999Upmarket TV	TELEVISION
36PW9525/19R	720336i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
36PW9525/57R	720336i WS 100Hz	MG3.1E	1.06.2000Upmarket TV	TELEVISION
36PW9525/58	720336i WS 100Hz	MG3.1E	1.06.2000Upmarket TV	TELEVISION
36PW9525/58R	720336i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
36PW9525/69R	720336i WS 100Hz	MG3.1E	1.06.2000Upmarket TV	TELEVISION

36PW9525/79R	720336i WS 100Hz	MG3.1E	1.07.2000Upmarket TV	TELEVISION
36PW9765/01	720336i WS 100Hz	MG3.1E	1.05.2000Upmarket TV	TELEVISION
36PW9765/01R	720336i WS 100Hz	MG3.1E	1.11.2000Upmarket TV	TELEVISION
36PW9765/05	720336i WS 100Hz	MG3.1E	Upmarket TV	TELEVISION
36PW9765/12	720336i WS 100Hz	MG3.1E	1.03.2000Upmarket TV	TELEVISION
36PW9765/12R	720336i WS 100Hz	MG3.1E	1.11.2000Upmarket TV	TELEVISION
36PW9765/19	720336i WS 100Hz	MG3.1E	1.04.2000Upmarket TV	TELEVISION
36PW9765/19R	720336i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
36PW9765/58	720336i WS 100Hz	MG3.1E	1.04.2000Upmarket TV	TELEVISION
36PW9765/58R	720336i WS 100Hz	MG3.1E	1.12.2000Upmarket TV	TELEVISION
36PW9767/01	36i WS 100Hz			TELEVISION
36PW9767/05	36i WS 100Hz			TELEVISION
36PW9767/12	36i WS 100Hz			TELEVISION
36PW9767/19	36i WS 100Hz			TELEVISION
36PW9767/58	36i WS 100Hz			TELEVISION
37CS5600/08S	200648i rear-PTV 4:3	K40	1.04.1992Basic TV	PROJECTION TV
37DC2090/08R	700125i stereo large 50Hz	CUC	1.03.1992	TELEVISION
37DC2090/10R	700125i stereo large 50Hz	CUC	1.03.1992	TELEVISION
37DC2090/13R	700125i stereo large 50Hz	CUC	1.03.1992	TELEVISION
37DC2090/19R	700133i (32v) stereo large 50Hz			TELEVISION
37KV1212/02B	700114i (13v) stereo	GR1AX	1.08.1992Basic TV	TELEVISION
37KV1212/05B	700114i (13v) stereo	GR1AX	1.11.1994Basic TV	TELEVISION
37KV1212/05W	700114i (13v) stereo	GR1AX	1.07.1995Basic TV	TELEVISION
37KV1212/07B	700114i (13v) stereo	GR1AX	1.04.1993Basic TV	TELEVISION
37KV1212/16B	700114i (13v) stereo	GR1AX	1.11.1994Basic TV	TELEVISION
37KV1212/33B	700114i (13v) stereo	GR1AX	1.09.1992Basic TV	TELEVISION
37KV1230/16B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
37KV1232/16B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
37KV1232/22B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
37KV1232/33B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
37KV1232/44B	700114i (13v) stereo	GR1AX	1.10.1992Basic TV	TELEVISION
37KV1240/16B	700114i (13v) stereo	GR1AX	1.05.1992Basic TV	TELEVISION
37KV1242/05B	700114i (13v) stereo	GR1AX	1.11.1994Basic TV	TELEVISION
37KV1242/10B	700114i (13v) stereo	GR1AX	1.03.1992Basic TV	TELEVISION
37KV1242/15B	700114i (13v) stereo	GR1AX	1.05.1992Basic TV	TELEVISION
37KV1242/16B	700114i (13v) stereo	GR1AX	1.04.1992Basic TV	TELEVISION
37TA1030/16	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV
37TA1040/08	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV
37TA1040/16	700114i (13v) mono ITV	CTT-H	1.01.1995Basic TV	INSTITUTIONAL TV
37TA1040/36	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV
37TA1050/16	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV
37TA1050/36B	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV

37TA1060/08	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV
37TA1070/05	700114i (13v) mono ITV	CTT-H	1.02.1995Basic TV	INSTITUTIONAL TV
37TA1070/14	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV
37TA1070/16	700114i (13v) mono ITV	CTT-H	1.01.1996Basic TV	INSTITUTIONAL TV
37TA1071/14	700114i (13v) mono	CTT-H	1.07.1997Basic TV	TELEVISION
37TA1071/16	700114i (13v) mono	CTT-H	1.06.1997Basic TV	TELEVISION
37TA1080/08	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV
37TA1080/16	700114i (13v) mono ITV	CTT-H	1.02.1995Basic TV	INSTITUTIONAL TV
37TA1090/36	700114i (13v) mono ITV	CTT-H	1.05.1996Basic TV	INSTITUTIONAL TV
37TA1171/00	700114i (13v) mono	AA5	1.06.1996Basic TV	TELEVISION
37TA1171/03	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TA1171/05	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
37TA1171/08	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TA1171/11	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TA1171/18	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TA1171/25	700114i (13v) stereo	AA5	1.02.1996Basic TV	TELEVISION
37TA1220/58	700114i (13v) mono	L6.1	1.03.2000Basic TV	TELEVISION
37TA1232/03	700114i (13v) mono	L6.1	1.06.1997Basic TV	TELEVISION
37TA1242/08	700114i (13v) mono	CTT-H	1.03.1997Basic TV	TELEVISION
37TA1242/16	700114i (13v) mono	CTT-H	1.02.1997Basic TV	TELEVISION
37TA1262/18	700114i (13v) mono	L6.1	1.07.1996Basic TV	TELEVISION
37TA1262/38	700114i (13v) mono	L6.1	1.11.1997Basic TV	TELEVISION
37TA1263/03	700114i (13v) mono	L6.1	1.02.1999Basic TV	TELEVISION
37TA1263/08	700114i (13v) mono	L6.1	1.02.1999Basic TV	TELEVISION
37TA1263/16	700114i (13v) mono	L6.1	1.12.1998Basic TV	TELEVISION
37TA1263/58	700114i (13v) mono	L6.1	1.05.1999Basic TV	TELEVISION
37TA1264/18	700114i (13v) mono	L9.2E	Basic TV	TELEVISION
37TA1266/18	14i (13v) mono			TELEVISION
37TA1266/58	14i (13v) mono			TELEVISION
37TA1271/02	700114i (13v) stereo	AA5	1.07.1995Basic TV	TELEVISION
37TA1271/18	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TA1273/03	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
37TA1273/08	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
37TA1273/11	700114i (13v) mono	L6.1	1.02.1997Basic TV	TELEVISION
37TA1273/16	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
37TA1274/03	700114i (13v) mono	L9.2E	1.09.1999Basic TV	TELEVISION
37TA1274/05	700114i (13v) mono	L9.2E	Basic TV	TELEVISION
37TA1274/08	700114i (13v) mono	L9.2E	1.05.2000Basic TV	TELEVISION
37TA1274/11	700114i (13v) mono	L9.2E	1.09.1999Basic TV	TELEVISION
37TA1274/16	700114i (13v) mono	L9.2E	1.09.1999Basic TV	TELEVISION
37TA1276/03	14i (13v) mono			TELEVISION
37TA1276/08	14i (13v) mono			TELEVISION

37TA1276/11	14i (13v) mono			TELEVISION
37TA1276/16	14i (13v) mono			TELEVISION
37TA1432/03	700114i (13v) mono	L6.1	1.06.1997Basic TV	TELEVISION
37TA1442/08	700114i (13v) mono	CTT-H	1.07.1997Basic TV	TELEVISION
37TA1442/16	700114i (13v) mono	CTT-H	1.03.1997Basic TV	TELEVISION
37TA1462/03	700114i (13v) mono	L6.1	1.04.1998Basic TV	TELEVISION
37TA1462/18	700114i (13v) mono	L6.1	1.07.1997Basic TV	TELEVISION
37TA1463/03	700114i (13v) mono	L6.1	1.02.1999Basic TV	TELEVISION
37TA1463/16	700114i (13v) mono	L6.1	1.12.1998Basic TV	TELEVISION
37TA1471/03	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TA1471/05	700114i (13v) stereo	AA5	1.06.1995Basic TV	TELEVISION
37TA1471/08	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TA1471/18	700114i (13v) mono	AA5	1.07.1996Basic TV	TELEVISION
37TA1471/25	700114i (13v) stereo	AA5	1.03.1996Basic TV	TELEVISION
37TA1473/03	700114i (13v) mono	L6.1	1.04.1998Basic TV	TELEVISION
37TA1473/16	700114i (13v) mono	L6.1	1.03.1998Basic TV	TELEVISION
37TA1473/18	700114i (13v) mono	L6.1	1.04.1998Basic TV	TELEVISION
37TA1474/03	700114i (13v) mono	L9.2E	1.09.1999Basic TV	TELEVISION
37TA1474/05	700114i (13v) mono	L9.2E	Basic TV	TELEVISION
37TA1474/16	700114i (13v) mono	L9.2E	1.10.1999Basic TV	TELEVISION
37TA1474/18	700114i (13v) mono	L9.2E	1.09.1999Basic TV	TELEVISION
37TA1476/03	14i (13v) mono			TELEVISION
37TA1476/16	14i (13v) mono			TELEVISION
37TA1476/18	14i (13v) mono			TELEVISION
37TB1151/19	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TB1191/19	700114i (13v) stereo	AA5	1.05.1996Basic TV	TELEVISION
37TB1252/19	700114i (13v) mono	L6.1	1.06.1996Basic TV	TELEVISION
37TB1252/39	700114i (13v) mono	L6.1	1.12.1997Basic TV	TELEVISION
37TB1256/19	14i (13v) mono			TELEVISION
37TR100/39	1022Leader	TVCR-B	1.07.1998	TVCR
37TR105/39	1022Leader	TVCR-D	1.04.2000	TVCR
37TR120/01	1022Leader	TVCR-B	1.02.1997	TVCR
37TR120/08	1022Leader	TVCR-B	1.09.1996	TVCR
37TR125/01	1022Leader	TVCR-A	1.10.1995	TVCR
37TR125/38N	1022Leader	TVCR-A	1.11.1996	TVCR
37TR125/39	1022Leader	TVCR-A	1.09.1995	TVCR
37TR126/03	1022Leader	TVCR-B	1.07.1996	TVCR
37TR126/38	1022Leader	TVCR-B	1.07.1996	TVCR
37TR127/03	1022Leader	TVCR-B	1.04.1998	TVCR
37TR127/39	1022Leader	TVCR-B	1.07.1998	TVCR
37TR210/39	1022Leader	TVCR-E	1.04.2001	TVCR
37TR215/03	1022Leader	TVCR-D	1.09.1999	TVCR

37TR215/39	1022Leader	TVCR-D	1.10.1999	TVCR
37TR216/03	1022Leader	TVCR-D	1.06.2000	TVCR
37TR216/39	1022Leader	TVCR-D	1.06.2000	TVCR
37TR220/03	1022Leader	TVCR-E	1.04.2001	TVCR
37TVB10/39	1022Leader	TVCR-A	1.02.1996	TVCR
37TVB10/39N	1022Leader	TVCR-A	1.10.1996	TVCR
37TVB11/39	1022Leader	TVCR-B	1.08.1998	TVCR
37TVB50/39	1022Leader	TVCR-D	1.11.1999	TVCR
37TVB51/39	1022Leader	TVCR-D	1.07.2000	TVCR
37TVB60/39	1022Leader	TVCR-E	1.04.2001	TVCR
37ZZ3223/22B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
37ZZ3223/32B	700114i (13v) stereo	ANUBIS_A	1.03.1992Basic TV	TELEVISION
37ZZ3233/22B	700114i (13v) stereo	ANUBIS_A	1.07.1992Basic TV	TELEVISION
38KV2323/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
38KV2325/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
38KV2325/22B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
38MS205T/,,	2010			OBSERVATION SYSTEMS
38TA1271/08	700115i mono	AA5	1.05.1996Basic TV	TELEVISION
38TA1271/18	700115i mono	AA5	1.05.1996Basic TV	TELEVISION
38TB1191/19	700115i mono	AA5	1.05.1996Basic TV	TELEVISION
38ZZ3253/22B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
3SB12/16	1021Leader	KATE _STN	1.01.1994Standard	VCR
3SB32/03	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
3SB32/11	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
3SB32/16	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
3SB37/11	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
3SB419/38	1021Leader	NORA _STN	1.11.1994Standard	VCR
3SB42/08	1021Leader	NORA _STN	1.11.1994Standard	VCR
3SB42/16	1021Leader	NORA _STN	1.10.1994Standard	VCR
3SB469/38	1021Leader	NORA _STN	1.11.1994Standard	VCR
3SB47/03	1021Leader	NORA _STN	1.11.1994Standard	VCR
3SB47/08	1021Leader	NORA _STN	1.02.1995Standard	VCR
3SB47/11	1021Leader	NORA _STN	1.11.1994Standard	VCR
3SB47/11W	1021Leader	NORA _STN	1.11.1994Standard	VCR
3SB51/08	1021Leader	OLIVIA_STN	1.12.1995Standard	VCR
3SB52/16	1021Leader	OLIVIA_STN	1.02.1996Standard	VCR
3SB56/08	1021Leader	OLIVIA_STN	1.01.1996Standard	VCR
3SB56/38	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
3SB57/03	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
3SB57/11	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
41CE8745/16B	200648i rear-PTV 4:3	3A-PTV	1.04.1993Projection TV	PROJECTION TV
41CE8745/19B	200648i rear-PTV 4:3	3A-PTV	1.03.1992Projection TV	PROJECTION TV

41CE8746/10B	200648i rear-PTV 4:3	3A-PTV	1.06.1992Projection TV	PROJECTION TV
41DV2/05	1021Leader	KATE _STN	1.02.1994Standard	VCR
41GR8840/02B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8840/06B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8840/08B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8840/10B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8840/19B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8840/75B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8841/05B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8841/13B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8841/16B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41GR8841/32B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
41ML0955/00B	200648i rear-PTV 4:3	FL1-PTV	1.10.1992Projection TV	PROJECTION TV
41ML0955/10B	200648i rear-PTV 4:3	FL1-PTV	1.10.1992Projection TV	PROJECTION TV
41ML0955/19B	200648i rear-PTV 4:3	FL1-PTV	1.10.1992Projection TV	PROJECTION TV
41ML0955/75B	200648i rear-PTV 4:3	FL1-PTV	1.05.1994Projection TV	PROJECTION TV
42FD9910/01B	2001Flat TV			FLAT TV
42FD9930/01	Flat TV			FLAT TV
42FD9932/01G	2001Flat TV	FTV1.9	1.12.1999Flat TV	FLAT TV
42FD9932/01S	2001Flat TV	FTV1.9	1.04.2000Flat TV	FLAT TV
42FD9932/17G	2001Flat TV	FTV1.9	Flat TV	FLAT TV
42FD9932/69G	2001Flat TV	FTV1.9	1.12.1999Flat TV	FLAT TV
42FD9932/69S	2001Flat TV	FTV1.9	1.10.2000Flat TV	FLAT TV
42MS405T/.,	2010	VM4		OBSERVATION SYSTEMS
42PF9952/12	2001Flat TV	FTV1.9	Flat TV	FLAT TV
42PF9952/12S	2001Flat TV	FTV1.9	1.09.1999Flat TV	FLAT TV
42PF9952/19S	2001Flat TV	FTV1.9	1.09.1999Flat TV	FLAT TV
42PF9952/32S	2001Flat TV	FTV1.9	1.09.2000Flat TV	FLAT TV
42PF9952/39S	2001Flat TV	FTV1.9	1.09.2000Flat TV	FLAT TV
42PF9952/58S	2001Flat TV	FTV1.9	1.09.2000Flat TV	FLAT TV
42PW9962/17	2001Flat TV		1.04.1998	FLAT TV
42PW9980/12	2001Flat TV			FLAT TV
42PW9980/19	2001Flat TV			FLAT TV
42PW9982/12	2000Flat TV	FTV1.5E	1.10.1997Flat TV	FLAT TV
42PW9982/19	2000Flat TV	FTV1.5E	1.11.1997Flat TV	FLAT TV
42PW9982/58	2000Flat TV	FTV1.5E	1.03.1999Flat TV	FLAT TV
42PW9982/69	2000Flat TV	FTV1.5E	1.10.1998Flat TV	FLAT TV
43DV2/08	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
43KV2423/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
43KV2425/02B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
43KV2425/22B	700115i mono	G90AE	1.03.1992Basic TV	TELEVISION
43PP925/57	200642i rear-PTV Table Top	A10PTV	1.04.2001Projection TV	PROJECTION TV

43PP925/61	200642i rear-PTV Table Top	A10PTV	1.08.2001Projection TV	PROJECTION TV
43PP925/69	200642i rear-PTV Table Top	A10PTV	1.03.2001Projection TV	PROJECTION TV
43PP925/79	200642i rear-PTV Table Top	A10PTV	1.05.2001Projection TV	PROJECTION TV
43PP925/97	200642i rear-PTV Table Top	A10PTV	1.07.2001Projection TV	PROJECTION TV
43TA1271/08	700115i mono	AA5	1.05.1996Basic TV	TELEVISION
43TA1271/16	700115i mono	AA5	1.05.1996Basic TV	TELEVISION
43TA1271/18	700115i mono	AA5	1.05.1996Basic TV	TELEVISION
43TB1191/19	700115i mono	AA5	1.05.1996Basic TV	TELEVISION
43ZZ3453/16B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
43ZZ3453/22B	700115i mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
43ZZ3483/16B	700115i mono	ANUBIS_A	1.07.1993Basic TV	TELEVISION
44DV2/01	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
44DV69/39	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
45DV1/39	1021Leader show view	OLIVIA_ECNI	1.09.1995Economy	VCR
45DV2/01	1021Leader show view	OLIVIA_STN	1.11.1995Standard	VCR
45DV20/39	1021Leader show view	APOLLO12	1.06.2000	VCR
45DV30/39	Leader show view			VCR
45DV6/07	1021Leader show view	OLIVIA_STN	1.10.1996Standard	VCR
45DV6/39	1021Leader show view	OLIVIA_STN	1.09.1995Standard	VCR
45DV7/39	1021Leader show view	QUEEN _VL	1.06.1997Volume Line	VCR
45DV9/39	1021Leader show view	APOLLO11	1.08.1999	VCR
46CE8766/10B	200648i rear-PTV 4:3	3A-PTV	1.07.1992Projection TV	PROJECTION TV
46CE8766/99	200648i rear-PTV 4:3	3A-PTV	1.04.1992Projection TV	PROJECTION TV
46GR8850/02B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46GR8850/06B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46GR8850/08B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46GR8850/10B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46GR8850/19B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46GR8850/75B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46GR8850/80	200648i rear-PTV 4:3	G110-PTV	1.06.1993Projection TV	PROJECTION TV
46GR8850L/80	200648i rear-PTV 4:3		1.03.1992	PROJECTION TV
46GR8851/13B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46GR8851/16B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46GR8851/32B	200648i rear-PTV 4:3	G110-PTV	1.03.1992Projection TV	PROJECTION TV
46ML0985/00B	200648i rear-PTV 4:3	FL1-PTV	1.09.1992Projection TV	PROJECTION TV
46ML0985/05B	200648i rear-PTV 4:3	FL1-PTV	1.12.1992Projection TV	PROJECTION TV
46ML0985/10B	200648i rear-PTV 4:3	FL1-PTV	1.11.1992Projection TV	PROJECTION TV
46ML0985/19B	200648i rear-PTV 4:3	FL1-PTV	1.12.1992Projection TV	PROJECTION TV
46ML0985/49B	200648i rear-PTV 4:3	FL1-PTV	Projection TV	PROJECTION TV
46NP41/76	200648i rear-PTV 4:3		1.05.1993	PROJECTION TV
46PA9030/16	200646i rear-PTV 4:3	FL1-PTV	1.06.1995Projection TV	PROJECTION TV
46PP910A/01	200646i rear-PTV 4:3	FL1-PTV	1.09.1993Projection TV	PROJECTION TV

46PP910A/58	200646i rear-PTV 4:3	FL1-PTV	1.05.1995Projection TV	PROJECTION TV
46PP912A/05	200646i rear-PTV 4:3	FL1-PTV	1.10.1993Projection TV	PROJECTION TV
46PP912A/07	200646i rear-PTV 4:3	FL1-PTV	1.03.1994Projection TV	PROJECTION TV
46PP912A/12	200646i rear-PTV 4:3	FL1-PTV	1.09.1993Projection TV	PROJECTION TV
46PP912A/13	200646i rear-PTV 4:3	FL1-PTV	1.10.1993Projection TV	PROJECTION TV
46PP9501/05	200646i rear-PTV WS	MG5.1E	1.10.1999Projection TV	PROJECTION TV
46PP9501/12	200646i rear-PTV WS	MG5.1E	1.09.1999Projection TV	PROJECTION TV
46PP9501/58	200646i rear-PTV WS	MG5.1E	Projection TV	PROJECTION TV
46PP960A/01	200646i rear-PTV WS	FL1-PTV	1.10.1993Projection TV	PROJECTION TV
46PP960A/19	200648i rear-PTV 4:3	FL1-PTV	1.01.1994Projection TV	PROJECTION TV
46PP960A/49	200648i rear-PTV 4:3	FL1-PTV	Projection TV	PROJECTION TV
46PP960A/58	200646i rear-PTV WS	FL1-PTV	1.05.1995Projection TV	PROJECTION TV
46PP960A/75	200646i rear-PTV WS	FL1-PTV	1.09.1995Projection TV	PROJECTION TV
46PP962A/19	200646i rear-PTV WS	FL1-PTV	1.10.1994Projection TV	PROJECTION TV
48P915/57	200646i rear-PTV WS	GFL7D	1.04.1999Projection TV	PROJECTION TV
48P915/69	200646i rear-PTV WS	GFL7D	1.11.1998Projection TV	PROJECTION TV
48P915/75	200646i rear-PTV WS	GFL7D	1.12.1998Projection TV	PROJECTION TV
48P915/79	200646i rear-PTV WS	GFL7D	1.11.1998Projection TV	PROJECTION TV
48P915/93	200646i rear-PTV WS	GFL7D	1.12.1998Projection TV	PROJECTION TV
48P977/57	200648i rear-PTV 4:3	GFL7D	1.03.1997Projection TV	PROJECTION TV
48P977/69	200648i rear-PTV 4:3	GFL7D	1.12.1996Projection TV	PROJECTION TV
48P977/75	200648i rear-PTV 4:3	GFL7D	1.04.1997Projection TV	PROJECTION TV
48P977/79	200648i rear-PTV 4:3	GFL7D	1.04.1997Projection TV	PROJECTION TV
48P977/93	200648i rear-PTV 4:3	GFL7D	1.06.1997Projection TV	PROJECTION TV
48PP9103/05	200648i rear-PTV 4:3	GFL7D	1.12.1997Projection TV	PROJECTION TV
48PP9103/12	200648i rear-PTV 4:3	GFL7D	1.01.1998Projection TV	PROJECTION TV
48PP9103/58	200648i rear-PTV 4:3	GFL7D	1.04.1998Projection TV	PROJECTION TV
48WP44C/37R	200646i rear-PTV WS			PROJECTION TV
48XP43C/37	200646i rear-PTV WS		1.11.1998	PROJECTION TV
48XP44C/37	200646i rear-PTV WS		1.09.2001	PROJECTION TV
4SB42/01	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
4SB42/16	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
4SB469/38	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
4SB47/11W	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
4SB51/08	1021Leader show view	OLIVIA_ECN	1.02.1996Economy	VCR
4SB51/16	1021Leader show view	OLIVIA_ECN	1.12.1995Economy	VCR
4SB51/38	1021Leader show view	OLIVIA_ECN	1.09.1995Economy	VCR
4SB52/01	1021Leader show view	OLIVIA_STN	1.11.1995Standard	VCR
4SB57/11	1021Leader show view	OLIVIA_STN	1.10.1995Standard	VCR
4SB57/38	1021Leader show view	OLIVIA_STN	1.09.1995Standard	VCR
50PP925/57	50i rear-PTV 4:3			PROJECTION TV
50PP925/69	200650i rear-PTV 4:3	A10PTV	1.06.2001Projection TV	PROJECTION TV

50PP925/79	200650i rear-PTV 4:3		1.07.2001	PROJECTION TV
50YP43C/85	200646i rear-PTV WS		1.11.1999	PROJECTION TV
50YP44C/61	200650i rear-PTV 4:3		1.08.2001	PROJECTION TV
50YP45C/87	200646i rear-PTV WS		1.12.1999	PROJECTION TV
515/AH	1049CD			CD PLAYERS
515/C	1049CD			CD PLAYERS
51AS300/99	1049		1.10.1992	MIDISYSTEMS
51AS500/99	1049		1.01.1995	MIDISYSTEMS
51KV1056/16B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
51KV1256/15B	700120i (19v) mono	GR1AX	1.05.1992Basic TV	TELEVISION
51KV1256/27V	700120i (19v) mono	GR1AX	1.12.1992Basic TV	TELEVISION
51KV1256/35B	700120i (19v) mono	GR1AX	1.12.1992Basic TV	TELEVISION
51KV1256/36B	700120i (19v) mono	GR1AX	1.07.1993Basic TV	TELEVISION
51TA1131/05	700120i (19v) mono			TELEVISION
51TA1171/05	700120i (19v) mono	AA5	1.06.1995Basic TV	TELEVISION
51TA1171/18	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
51TA1171/25	700120i (19v) mono	AA5	1.11.1995Basic TV	TELEVISION
51TA1232/18	700120i (19v) mono	L6.1	1.02.1999Basic TV	TELEVISION
51TA1260/16	700120i (19v) mono	ANUBIS_A	1.05.1994Basic TV	TELEVISION
51TA1262/18	700120i (19v) mono	L6.1	1.07.2000Basic TV	TELEVISION
51TA1266/18	20i (19v) mono			TELEVISION
51TA1431/05	700120i (19v) mono			TELEVISION
51TA1462/03	700120i (19v) mono	L6.1	1.09.2000Basic TV	TELEVISION
51TA1471/03	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
51TA1471/05	700120i (19v) mono	AA5	1.06.1995Basic TV	TELEVISION
51TA1471/08	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
51TA1471/11	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
51TA1471/16	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
51TA1471/25	700120i (19v) mono	AA5	1.11.1995Basic TV	TELEVISION
51TA1472/03	700120i (19v) mono	L6.1	1.10.1996Basic TV	TELEVISION
51TA1472/08	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
51TA1472/11	700120i (19v) mono	L6.1	1.11.1996Basic TV	TELEVISION
51TA1472/16	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
51TA1472/18	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
51TA1473/03	700120i (19v) mono	L6.2	1.03.1998Basic TV	TELEVISION
51TA1473/11	700120i (19v) mono	L6.2	1.03.1998Basic TV	TELEVISION
51TA1473/16	700120i (19v) mono	L6.2	1.03.1998Basic TV	TELEVISION
51TA1473/18	700120i (19v) mono	L6.2	1.03.1998Basic TV	TELEVISION
51TA1474/03	700120i (19v) mono	L9.2E	Basic TV	TELEVISION
51TA1474/05	700120i (19v) mono	L9.2E	Basic TV	TELEVISION
51TA1474/11	700120i (19v) mono	L9.2E	Basic TV	TELEVISION
51TA1474/16	700120i (19v) mono	L9.2E	Basic TV	TELEVISION

51TA1474/18	700120i (19v) mono	L9.2E	Basic TV	TELEVISION
51TA1476/03	20i (19v) mono			TELEVISION
51TA1476/11	20i (19v) mono			TELEVISION
51TA1476/16	20i (19v) mono			TELEVISION
51TB1151/19	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
51TB1222/19	700120i (19v) mono	L6.1	1.09.1998Basic TV	TELEVISION
51TB1252/19	700120i (19v) mono	L6.1	1.08.1996Basic TV	TELEVISION
51TB1256/19	20i (19v) mono			TELEVISION
51TB1452/19	700120i (19v) mono	L6.1	1.09.1998Basic TV	TELEVISION
51TR225/03	1022Core	TVCR-D	1.08.1999	TVCR
51TR225/39	1022Core	TVCR-D	1.09.1999	TVCR
51TR226/03	1022Leader	TVCR-D	1.06.2000	TVCR
51TR226/39	1022Leader	TVCR-D	1.06.2000	TVCR
51TR300/03	1022Leader	TVCR-E	1.07.2001	TVCR
51TR300/39	1022Leader	TVCR-E	1.07.2001	TVCR
51TR426/03	1022Leader	TVCR-B	1.07.1996	TVCR
51TR426/08	1022Leader	TVCR-B	1.07.1996	TVCR
51TR426/38	1022Core	TVCR-B	1.07.1996	TVCR
51TR427/03	1022Core	TVCR-B	1.05.1998	TVCR
51TR427/39	1022Core	TVCR-B	1.07.1998	TVCR
51TVB20/39	1022Leader	TVCR-B	1.07.1996	TVCR
51TVB31/39	1022Leader	TVCR-B	1.07.1998	TVCR
51TVB60/39	1022Core	TVCR-D	1.09.1999	TVCR
51TVB61/39	1022Leader	TVCR-D	1.06.2000	TVCR
51TVB70/39	1022Leader	TVCR-E	1.07.2001	TVCR
52KP56L/76	200648i rear-PTV 4:3		1.03.1992	PROJECTION TV
52KV1528/05B	700120i (19v) mono	GR1AX	1.12.1994Basic TV	TELEVISION
52KV1528/15B	700120i (19v) mono	GR1AX	1.06.1992Basic TV	TELEVISION
52KV1528/16B	700120i (19v) mono	GR1AX	1.03.1992Basic TV	TELEVISION
52KV1592/16B	700120i (19v) mono	GR1AX	1.11.1992Basic TV	TELEVISION
52KV2523/02B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
52KV2523/05B	700120i (19v) mono	G90AE	1.11.1992Basic TV	TELEVISION
52KV2523/17B	700120i (19v) mono	G90AE	1.03.1993Basic TV	TELEVISION
52KV2523/22B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
52KV2525/02B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
52KV2525/05B	700120i (19v) mono	G90AE	1.12.1992Basic TV	TELEVISION
52KV2525/22B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
52KV2529/05B	700120i (19v) mono	G90AE-SAT	1.01.1995Basic TV	TELEVISION
52KV2565/05B	700120i (19v) mono	G90AE	1.02.1995Basic TV	TELEVISION
52KV2565/22B	700120i (19v) mono	G90AE	1.03.1992Basic TV	TELEVISION
52LP50/87	200648i rear-PTV 4:3		1.03.1992	PROJECTION TV
52LP50L/84	200648i rear-PTV 4:3		1.03.1992	PROJECTION TV

52RP53B/76	200648i rear-PTV 4:3		1.11.1993	PROJECTION TV
52RP53B/84	200648i rear-PTV 4:3		1.03.1994	PROJECTION TV
52RP53B/87	200648i rear-PTV 4:3		1.11.1993	PROJECTION TV
52RP53B/99	200648i rear-PTV 4:3		1.03.1994	PROJECTION TV
52TA1071/18	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
52TA1171/08	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
52TA1171/16	700120i (19v) mono	AA5	1.09.1995Basic TV	TELEVISION
52TA1262/07	700121i (20v) mono	L6.1	1.03.1998Basic TV	TELEVISION
52TA1262/18	700121i (20v) mono	L6.1	1.09.1996Basic TV	TELEVISION
52TA1271/18	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
52TA1420/43	700121i (20v) mono	L9.2E	Basic TV	TELEVISION
52TA1420/58	700121i (20v) mono	L9.2E	1.07.2000Basic TV	TELEVISION
52TA1462/18	700121i (20v) mono	L6.1	1.03.1998Basic TV	TELEVISION
52TA1464/18	700121i (20v) stereo medium	L9.2E	Basic TV	TELEVISION
52TA1471/03	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
52TA1471/08	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
52TA1471/11	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
52TA1471/16	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
52TA1472/03	700121i (20v) mono	L6.1	1.09.1996Basic TV	TELEVISION
52TA1472/08	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
52TA1472/11	700121i (20v) mono	L6.1	1.09.1996Basic TV	TELEVISION
52TA1472/16	700121i (20v) mono	L6.1	1.09.1996Basic TV	TELEVISION
52TA1472/18	700121i (20v) mono	L6.1	1.08.1996Basic TV	TELEVISION
52TA1474/03	700121i (20v) mono	L9.2E	1.03.2000Basic TV	TELEVISION
52TA1474/11	700121i (20v) mono	L9.2E	1.02.2000Basic TV	TELEVISION
52TA1474/16	700121i (20v) mono	L9.2E	1.03.2000Basic TV	TELEVISION
52TA1474/18	700121i (20v) mono	L9.2E	1.06.2000Basic TV	TELEVISION
52TA1474/23	700121i (20v) mono	L9.2E	1.09.2000Basic TV	TELEVISION
52TA1474/31	700121i (20v) mono	L9.2E	1.09.2000Basic TV	TELEVISION
52TA1474/36	700121i (20v) mono	L9.2E	1.10.2000Basic TV	TELEVISION
52TA2472/18	700121i (20v) stereo medium	L6.1	1.05.1997Basic TV	TELEVISION
52TA4311/03	710120i (19i) stereo medium	MD1.1E	1.05.1996Basic TV	TELEVISION
52TA4311/03B	710121i (20v) stereo medium	MD1.1E	1.04.1997Basic TV	TELEVISION
52TA4311/11	710120i (19i) stereo medium	MD1.1E	1.05.1996Basic TV	TELEVISION
52TA4311/18	710120i (19i) stereo medium	MD1.1E	1.05.1996Basic TV	TELEVISION
52TA4314/03	700121i (20v) stereo medium	L6.2	1.12.1997Basic TV	TELEVISION
52TA4314/11	700121i (20v) stereo medium	L6.2	1.12.1997Basic TV	TELEVISION
52TA4315/03	700121i (20v) stereo medium	L7.2E	1.06.1998Basic TV	TELEVISION
52TA4315/11	700121i (20v) stereo medium	L7.2E	1.08.1998Basic TV	TELEVISION
52TA4415/03	700121i (20v) stereo medium	L9.2E	1.07.1999Basic TV	TELEVISION
52TA4415/05	700121i (20v) stereo medium	L9.2E	Basic TV	TELEVISION
52TA4415/11	700121i (20v) stereo medium	L9.2E	1.09.1999Basic TV	TELEVISION

52TA4415/18	700121i (20v) stereo medium	L9.2E	1.08.1999Basic TV	TELEVISION
52TA5211/16	710120i (19i) stereo medium	GR2.2	1.05.1996Basic TV	TELEVISION
52TA5213/03	710120i (19i) stereo medium	GR2.4	1.05.1996Basic TV	TELEVISION
52TA5213/18	710120i (19i) stereo medium	GR2.4	1.05.1996Basic TV	TELEVISION
52TA5214/03	710121i (20v) stereo medium	MD1.2E	1.01.1997Basic TV	TELEVISION
52TA5214/18	710121i (20v) stereo medium	MD1.2E	1.01.1997Basic TV	TELEVISION
52TA5215/03R	710121i (20v) stereo medium	A8.0E	Basic TV	TELEVISION
52TA5215/18R	710121i (20v) stereo medium	A8.0E	1.04.1999Basic TV	TELEVISION
52TA5216/18	700121i (20v) stereo medium			TELEVISION
52TB1051/19	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
52TB1252/19	700121i (20v) mono	L6.1	1.09.1996Basic TV	TELEVISION
52TB1452/19	700121i (20v) mono	L6.1	1.03.1998Basic TV	TELEVISION
52TB1454/19	700121i (20v) stereo medium	L9.2E	Basic TV	TELEVISION
52TB2452/19	700121i (20v) stereo medium	L6.1	1.12.1996Basic TV	TELEVISION
52TB4291/19	710120i (19i) stereo medium	MD1.1E	1.05.1996Basic TV	TELEVISION
52TB4395/19	700121i (20v) stereo medium	L9.2E	1.08.1999Basic TV	TELEVISION
52TB5193/19	710125i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
52ZY3535/22B	700120i (19v) mono	ANUBIS_B	1.05.1992Basic TV	TELEVISION
52ZY3535/25G	700120i (19v) mono	ANUBIS_B	1.07.1992Basic TV	TELEVISION
52ZZ3523/16B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
52ZZ3523/22B	700120i (19v) mono	ANUBIS_A	1.03.1992Basic TV	TELEVISION
52ZZ3523/25G	700120i (19v) mono	ANUBIS_A	1.09.1992Basic TV	TELEVISION
52ZZ3583/16B	700120i (19v) mono	ANUBIS_A	1.12.1994Basic TV	TELEVISION
54P915/57	200646i rear-PTV WS	GFL7D	1.12.1997Projection TV	PROJECTION TV
54P915/69	200646i rear-PTV WS	GFL7D	1.12.1997Projection TV	PROJECTION TV
54P915/75	200646i rear-PTV WS	GFL7D	1.03.1998Projection TV	PROJECTION TV
54P915/79	200646i rear-PTV WS	GFL7D	1.07.1998Projection TV	PROJECTION TV
54P915/93	200646i rear-PTV WS	GFL7D	1.12.1997Projection TV	PROJECTION TV
54WP44C/37R	200646i rear-PTV WS			PROJECTION TV
54XP43C/37	200646i rear-PTV WS		1.11.1998	PROJECTION TV
54XP44C/37	200646i rear-PTV WS			PROJECTION TV
55PP925/61	200655i rear-PTV 4:3	A10PTV	1.09.2001Projection TV	PROJECTION TV
55PP925/69	200655i rear-PTV 4:3	A10PTV	1.06.2001Projection TV	PROJECTION TV
55PP925/79	55i rear-PTV 4:3			PROJECTION TV
55PP925/97	200655i rear-PTV 4:3		1.07.2001	PROJECTION TV
55PP9501/05	200655i rear-PTV WS	MG5.1E	1.11.1999Projection TV	PROJECTION TV
55PP9501/12	200655i rear-PTV WS	MG5.1E	1.09.1999Projection TV	PROJECTION TV
55PP9501/58	200655i rear-PTV WS	MG5.1E	1.11.1999Projection TV	PROJECTION TV
55PP9501/69	200655i rear-PTV WS	MG5.1E	1.06.2000Projection TV	PROJECTION TV
55PP9501/79	200655i rear-PTV WS	MG5.1A	1.08.2000Projection TV	PROJECTION TV
55YP43C/85	200655i rear-PTV 4:3		1.01.2000	PROJECTION TV
55YP44C/61	200655i rear-PTV 4:3		1.08.2001	PROJECTION TV

55YP45C/87	200655i rear-PTV 4:3		1.01.2000	PROJECTION TV
59KE3785/05M	710225i mono	CP110	1.11.1992Basic TV	TELEVISION
5SB22/16	1021Leader show view	LUCY _STU	1.06.1995Step-up	VCR
60P915/57	200646i rear-PTV WS		1.12.1998	PROJECTION TV
60P915/69	200646i rear-PTV WS		1.12.1998	PROJECTION TV
60P915/79	200646i rear-PTV WS		1.12.1998	PROJECTION TV
60P915/93	200646i rear-PTV WS		1.12.1998	PROJECTION TV
61NP61/76	200648i rear-PTV 4:3		1.02.1993	PROJECTION TV
63CA1503/37B	710225i mono	GR2.1	1.07.1993Basic TV	TELEVISION
63CA1595/25Z	710225i mono	GR2.2	1.12.1994Basic TV	TELEVISION
63KE6722/14M	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
63KV9616/37R	710225i stereo large 50Hz	G110	1.04.1994Basic TV	TELEVISION
63KV9617/22M	710225i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
63KV9817/22M	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
63NA1047/02B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
63NA1047/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
63NA1617/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
63NA2514/16B	710225i stereo large 50Hz	GR2.2	1.04.1993Basic TV	TELEVISION
63RK5687/22R	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
63TA3911/08	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
63TA3911/11	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
63TA3913/16	700225i mono	L6.1	Basic TV	TELEVISION
63TA3913/18	700225i mono	L6.1	1.07.1997Basic TV	TELEVISION
63TA3961/18	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
63TA4011/08	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
63TA4011/16	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
63TA4013/07	700225i mono	L6.2	Basic TV	TELEVISION
63TA4013/16	700225i mono	L6.2	1.07.1997Basic TV	TELEVISION
63TA4311/03	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
63TA4412/23	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
63TA4412/28	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
63TA4412/31	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
63TA4412/36	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
63TA4412/38	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
63TA4413/03	700225i stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
63TA4413/08	700225i stereo large 50Hz	L6.2	1.07.1997Basic TV	TELEVISION
63TA4413/11	700225i stereo large 50Hz	L6.2	1.07.1997Basic TV	TELEVISION
63TA4413/16	700225i stereo large 50Hz	L6.2	1.07.1997Basic TV	TELEVISION
63TA4413/18	700225i stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
63TA4415/03	700225i stereo large 50Hz	L9.1E	1.06.1999Basic TV	TELEVISION
63TA4415/11	700225i stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
63TA4415/18	700225i stereo large 50Hz	L9.1E	1.07.1999Basic TV	TELEVISION

63TA4415/38	700225i stereo large 50Hz	L9.1E	1.09.2000Basic TV	TELEVISION
63TA5212/03	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
63TA5212/11	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
63TA5212/16	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
63TA5212/18	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
63TA5213/03	710225i stereo large 50Hz	MD1.2E	1.09.1996Basic TV	TELEVISION
63TA5213/11	710225i stereo large 50Hz	MD1.2E	1.09.1996Basic TV	TELEVISION
63TA5213/16	710225i stereo large 50Hz	MD1.2E	1.09.1996Basic TV	TELEVISION
63TA5213/18	710225i stereo large 50Hz	MD1.2E	1.09.1996Basic TV	TELEVISION
63TA5214/03R	710225i stereo large 50Hz	A8.0E	1.01.1999Basic TV	TELEVISION
63TA5214/11R	710225i stereo large 50Hz	A8.0E	1.05.1999Basic TV	TELEVISION
63TA5214/18R	710225i stereo large 50Hz	A8.0E	1.06.1999Basic TV	TELEVISION
63TA5215/03	700225i stereo large 50Hz	L9.1E	1.08.2000Basic TV	TELEVISION
63TA5215/11	700225i stereo large 50Hz	L9.1E	1.07.2000Basic TV	TELEVISION
63TA5215/18	700225i stereo large 50Hz	L9.1E	1.06.2000Basic TV	TELEVISION
63TA5216/03	25i stereo large 50Hz			TELEVISION
63TA5216/11	25i stereo large 50Hz			TELEVISION
63TA5216/18	25i stereo large 50Hz			TELEVISION
63TA7111/03	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
63TA7912/03	720225i stereo large 100Hz	FL*.16	1.06.1995Upmarket TV	TELEVISION
63TA7932/16	720225i stereo large 100Hz	FL*.16	1.11.1995Upmarket TV	TELEVISION
63TB3890/16	710225i mono	GR2.2	1.06.1995Basic TV	TELEVISION
63TB3891/19	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
63TB3893/19	700225i mono	L6.1	1.07.1997Basic TV	TELEVISION
63TB4392/39	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
63TB4393/39	710225i stereo large 50Hz	MD1.1E	1.09.1996Basic TV	TELEVISION
63TB4394/19	700225i stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
63TB4395/19	700225i stereo large 100Hz	L9.1E	Basic TV	TELEVISION
63TB5192/19	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
64VP9021/99	1021Leader		1.08.1992	VCR
64VP9025/99	1021Leader		1.04.1992	VCR
64VP9030R/99	1021Leader		1.12.1992	VCR
64VP9040/99	1021Leader		1.03.1992	VCR
64VR6385/99	1021Leader		1.04.1992	VCR
64VR6585/99	1021Leader		1.12.1992	VCR
64VR9625/99	1021Leader		1.04.1992	VCR
64VR9642/99	1021Leader		1.03.1992	VCR
64VR9645/99	1021Leader		1.12.1992	VCR
64VR9664/99	1021Leader		1.06.1992	VCR
65DV20/05	1021Leader	APOLLO12		VCR
65DV20/39	1021Leader	APOLLO12	1.07.2000	VCR
65DV30/39	1021Leader	APOLLO13	1.07.2001	VCR

65DV5/39	1021Leader	OLIVIA_STU	1.11.1995Step-up	VCR
65DV7/39	1021Leader	QUEEN_VLH	1.09.1997Volume Line Hifi	VCR
65DV9/39	1021Leader	APOLLO11	1.08.1999	VCR
68MC305R/.,	2010			OBSERVATION SYSTEMS
6SB47/03	1021Leader	NORA _STU	1.11.1994Step-up	VCR
6SB47/11W	1021Leader	NORA _STU	1.11.1994Step-up	VCR
6SB57/03	1021Leader	OLIVIA_STU	1.12.1995Step-up	VCR
6SB57/11	1021Leader	OLIVIA_STU	1.11.1995Step-up	VCR
6SB57/38	1021Leader	OLIVIA_STU	1.11.1995Step-up	VCR
70CD162/00	1049CD		1.11.1992	CD PLAYERS
70CD162/00R	1049CD		1.08.1992	CD PLAYERS
70CD162/00T	1049CD		1.06.1993	CD PLAYERS
70CD162/05	1049CD		1.06.1993	CD PLAYERS
70CD164/00	1049CD		1.12.1992	CD PLAYERS
70CD164/00R	1049CD		1.09.1992	CD PLAYERS
70CD164/00T	1049CD		1.09.1993	CD PLAYERS
70CD164/01	1049CD		1.03.1993	CD PLAYERS
70CD164/01B	1049CD		1.07.1993	CD PLAYERS
70CD164/01R	1049CD		1.10.1992	CD PLAYERS
70CD164/05	1049CD		1.06.1993	CD PLAYERS
70CD690/05B	1049CD		1.10.1992	CD PLAYERS
70CD690/20B	1049CD		1.07.1992	CD PLAYERS
70CD690/21B	1049CD		1.01.1993	CD PLAYERS
70CD690/25B	1049CD		1.11.1992	CD PLAYERS
70CD690/37B	1049CD		1.09.1992	CD PLAYERS
70CD692/00B	1049CD		1.07.1992	CD PLAYERS
70CD692/05B	1049CD		1.09.1992	CD PLAYERS
70CD692/20B	1049CD		1.09.1992	CD PLAYERS
70CD692/21B	1049CD		1.10.1992	CD PLAYERS
70CD692/25B	1049CD		1.11.1992	CD PLAYERS
70CD692/37B	1049CD		1.07.1992	CD PLAYERS
70CD730/00B	1049CD		1.08.1993	CD PLAYERS
70CD732/00B	1049CD		1.08.1993	CD PLAYERS
70CD732/05B	1049CD		1.09.1993	CD PLAYERS
70CD910/00S	1049CD		1.05.1992	CD PLAYERS
70CD910/01S	1049CD		1.07.1993	CD PLAYERS
70CD910/05S	1049CD		1.08.1992	CD PLAYERS
70CD910/17S	1049CD		1.07.1992	CD PLAYERS
70CD920/00S	1049CD		1.06.1992	CD PLAYERS
70CD920/01S	1049CD		1.08.1992	CD PLAYERS
70CD920/05S	1049CD		1.08.1992	CD PLAYERS
70CD920/17S	1049CD		1.07.1992	CD PLAYERS

70CD930/00S	1049CD	1.04.1992	CD PLAYERS
70CD930/01S	1049CD	1.09.1992	CD PLAYERS
70CD930/05S	1049CD	1.08.1992	CD PLAYERS
70CD930/06S	1049CD	1.07.1993	CD PLAYERS
70CD930/20S	1049CD	1.09.1993	CD PLAYERS
70CD930/21S	1049CD	1.10.1993	CD PLAYERS
70CD930/26S	1049CD	1.03.1994	CD PLAYERS
70CD940/00S	1049CD	1.05.1992	CD PLAYERS
70CD940/05S	1049CD	1.08.1992	CD PLAYERS
70CD940/06S	1049CD	1.12.1992	CD PLAYERS
70CD950/00S	1049CD	1.06.1992	CD PLAYERS
70CD950/01S	1049CD	1.08.1992	CD PLAYERS
70CD950/05S	1049CD	1.08.1992	CD PLAYERS
70CD950/06S	1049CD	1.12.1992	CD PLAYERS
70CD950/17S	1049CD	1.07.1992	CD PLAYERS
70CD950/20S	1049CD	1.10.1993	CD PLAYERS
70CD950/21S	1049CD	1.11.1992	CD PLAYERS
70CD950/26S	1049CD	1.12.1993	CD PLAYERS
70CD950/41S	1049CD	1.11.1993	CD PLAYERS
70DCC130/00	1041Miscellaneous	1.09.1993	PORTABLE OTHER
70DCC130/01	1041Miscellaneous	1.10.1993	PORTABLE OTHER
70DCC130/05	1041Miscellaneous	1.09.1993	PORTABLE OTHER
70DCC130/06	1041Miscellaneous	1.06.1993	PORTABLE OTHER
70DCC130/10	1041Miscellaneous	1.12.1993	PORTABLE OTHER
70DCC130/17	1041Miscellaneous	1.12.1993	PORTABLE OTHER
70DCC134/00	1041Miscellaneous	1.09.1994	PORTABLE OTHER
70DCC134/01	1041Miscellaneous	1.07.1994	PORTABLE OTHER
70DCC134/05	1041Miscellaneous	1.12.1994	PORTABLE OTHER
70DCC134/06	1041Miscellaneous	1.12.1994	PORTABLE OTHER
70DSC950/00S	1049	1.09.1992	CASSETTEDECKS
70DSC950/05S	1049	1.11.1992	CASSETTEDECKS
70DSC950/06S	1049	1.07.1993	CASSETTEDECKS
70DSC950/17S	1049	1.10.1992	CASSETTEDECKS
70DSS930/00B	1058	1.09.1992	SPEAKER BOXES
70DSS930/00S	1058	1.09.1993	SPEAKER BOXES
70DSS930/05B	1058	1.12.1992	SPEAKER BOXES
70DSS930/06B	1058	1.06.1993	SPEAKER BOXES
70DSS930/06S	1058	1.09.1993	SPEAKER BOXES
70DSS930/16B	1058	1.12.1992	SPEAKER BOXES
70DSS930/17B	1058	1.10.1992	SPEAKER BOXES
70FA910/00S	1049Amplifiers	1.05.1992	AMPLIFIERS
70FA910/01S	1049Amplifiers	1.04.1993	AMPLIFIERS

70FA920/00S	1049Amplifiers	1.04.1992	AMPLIFIERS
70FA920/01S	1049Amplifiers	1.08.1992	AMPLIFIERS
70FA920/05S	1049Amplifiers	1.08.1992	AMPLIFIERS
70FA930/00S	1049Amplifiers	1.04.1992	AMPLIFIERS
70FA930/01S	1049Amplifiers	1.08.1992	AMPLIFIERS
70FA930/05S	1049Amplifiers	1.08.1992	AMPLIFIERS
70FA950/00S	1049Amplifiers	1.07.1992	AMPLIFIERS
70FA950/06S	1049Amplifiers	1.12.1992	AMPLIFIERS
70FA950/17S	1049Amplifiers	1.08.1992	AMPLIFIERS
70FB305/00G	1058	1.03.1992	MIDISYSTEMS
70FB310/00G	1058	1.03.1992	SPEAKER BOXES
70FB320/00G	1058	1.03.1992	SPEAKER BOXES
70FB330/00G	1058	1.03.1992	SPEAKER BOXES
70FB650/00L	1058	1.03.1992	SPEAKER BOXES
70FB650/17L	1058	1.03.1992	SPEAKER BOXES
70FB670/00L	1058	1.03.1992	SPEAKER BOXES
70FB670/17L	1058	1.03.1992	SPEAKER BOXES
70FB690/00L	1058	1.03.1992	SPEAKER BOXES
70FB690/17L	1058	1.03.1992	SPEAKER BOXES
70FB695/00L	1058	1.03.1992	SPEAKER BOXES
70FB695/17L	1058	1.03.1992	SPEAKER BOXES
70FB710/00B	1058	1.06.1993	SPEAKER BOXES
70FB710/04B	1058	1.07.1993	SPEAKER BOXES
70FB710/06B	1058	1.08.1993	SPEAKER BOXES
70FB720/00B	1058	1.10.1992	SPEAKER BOXES
70FB720/04B	1058	1.02.1993	SPEAKER BOXES
70FB720/06B	1058	1.01.1995	SPEAKER BOXES
70FB815/00	1058	1.03.1992	SPEAKER BOXES
70FB815/00B	1058	1.03.1992	SPEAKER BOXES
70FB815/04	1058	1.03.1992	SPEAKER BOXES
70FB815/17	1058	1.03.1992	SPEAKER BOXES
70FB815/20	1058	1.10.1992	SPEAKER BOXES
70FB815/30B	1058	1.06.1992	SPEAKER BOXES
70FB815/34B	1058	1.07.1992	SPEAKER BOXES
70FB820/00	1058	1.03.1992	SPEAKER BOXES
70FB820/04	1058	1.03.1992	SPEAKER BOXES
70FB820/17	1058	1.03.1992	SPEAKER BOXES
70FB820/30B	1058	1.06.1992	SPEAKER BOXES
70FB820/34B	1058	1.08.1992	SPEAKER BOXES
70FB821/00	1058	1.03.1992	SPEAKER BOXES
70FB821/17	1058	1.03.1992	SPEAKER BOXES
70FB821/30B	1058	1.06.1992	SPEAKER BOXES

70FB821/34B	1058	1.11.1992	SPEAKER BOXES
70FB825/00	1058	1.03.1992	SPEAKER BOXES
70FB825/04R	1058	1.03.1992	SPEAKER BOXES
70FB825/17	1058	1.03.1992	SPEAKER BOXES
70FB825/30B	1058	1.06.1992	SPEAKER BOXES
70FB830/00B	1058	1.09.1993	SPEAKER BOXES
70FB830/01B	1058	1.06.1995	SPEAKER BOXES
70FB830/04B	1058	1.09.1993	SPEAKER BOXES
70FB830/06B	1058	1.04.1994	SPEAKER BOXES
70FB830/17B	1058	1.02.1995	SPEAKER BOXES
70FB840/00B	1058	1.09.1993	SPEAKER BOXES
70FB840/01B	1058	1.06.1995	SPEAKER BOXES
70FB840/04B	1058	1.09.1993	SPEAKER BOXES
70FB850/00B	1058	1.09.1993	SPEAKER BOXES
70FB850/00L	1058	1.10.1993	SPEAKER BOXES
70FB850/01B	1058	1.06.1995	SPEAKER BOXES
70FB850/04B	1058	1.10.1993	SPEAKER BOXES
70FB850/06L	1058	1.04.1994	SPEAKER BOXES
70FB850/17B	1058	1.02.1995	SPEAKER BOXES
70FB860/00B	1058	1.09.1993	SPEAKER BOXES
70FB860/01B	1058	1.06.1995	SPEAKER BOXES
70FB860/04B	1058	1.09.1993	SPEAKER BOXES
70FB900/00G	1058	1.03.1992	MIDISYSTEMS
70FC330/00G	1049	1.03.1992	MIDISYSTEMS
70FC910/00S	1049	1.04.1992	CASSETTEDECKS
70FC910/17S	1049	1.07.1992	CASSETTEDECKS
70FC910/20S	1049	1.06.1992	CASSETTEDECKS
70FC920/00S	1049	1.09.1992	CASSETTEDECKS
70FC920/05S	1049	1.10.1992	CASSETTEDECKS
70FC930/00S	1049	1.04.1992	CASSETTEDECKS
70FC930/01S	1049	1.08.1992	CASSETTEDECKS
70FC930/17S	1049	1.07.1992	CASSETTEDECKS
70FC930/20S	1049	1.06.1992	CASSETTEDECKS
70FC930/25S	1049	1.08.1992	CASSETTEDECKS
70FC940/00S	1049	1.07.1992	CASSETTEDECKS
70FC950/00S	1049	1.06.1992	CASSETTEDECKS
70FC950/06S	1049	1.12.1992	CASSETTEDECKS
70FC950/17S	1049	1.08.1992	CASSETTEDECKS
70FP320/00G	1049	1.03.1992	MIDISYSTEMS
70FP320/00R	1049	1.11.1992	MIDISYSTEMS
70FP320/00S	1049	1.02.1993	MIDISYSTEMS
70FP320/05R	1049	1.03.1992	MIDISYSTEMS

70FP930/00S	1049	1.01.1993	PHONO
70FR330/00G	1049	1.03.1992	MIDISYSTEMS
70FR330/02G	1049	1.03.1992	MIDISYSTEMS
70FR330/08G	1049	1.03.1992	MIDISYSTEMS
70FR910/00S	1049Receivers	1.11.1992	RECEIVERS
70FR910/01S	1049Receivers	1.07.1993	RECEIVERS
70FR910/17S	1049Receivers	1.07.1992	RECEIVERS
70FR920/00S	1049Receivers	1.11.1992	RECEIVERS
70FR920/17S	1049Receivers	1.07.1992	RECEIVERS
70FR930/00S	1049Receivers	1.12.1992	RECEIVERS
70FR930/01S	1049Receivers	1.01.1993	RECEIVERS
70FR930/17S	1049Receivers	1.09.1992	RECEIVERS
70FR930/37S	1049Receivers	1.07.1993	RECEIVERS
70FR940/00S	1049Receivers	1.01.1993	RECEIVERS
70FR940/05S	1049Receivers	1.11.1993	RECEIVERS
70FR940/17S	1049Receivers	1.10.1992	RECEIVERS
70FR940/37S	1049Receivers	1.10.1993	RECEIVERS
70FS310/00G	1049	1.03.1992	MIDISYSTEMS
70FS310/02G	1049	1.03.1992	MIDISYSTEMS
70FS310/08G	1049	1.03.1992	MIDISYSTEMS
70FS320/00G	1049	1.03.1992	MIDISYSTEMS
70FS320/02G	1049	1.03.1992	MIDISYSTEMS
70FS320/08G	1049	1.03.1992	MIDISYSTEMS
70FS340/00B	1049	1.10.1992	MIDISYSTEMS
70FS340/02B	1049	1.11.1992	MIDISYSTEMS
70FS360/00B	1049	1.02.1993	MIDISYSTEMS
70FS360/02B	1049	1.02.1993	MIDISYSTEMS
70FS360/05B	1049	1.03.1993	MIDISYSTEMS
70FS900/00G	1049	1.03.1992	MIDISYSTEMS
70FT920/00S	1049Tuners	1.04.1992	TUNERS
70FT920/01S	1049Tuners	1.08.1992	TUNERS
70FT920/05S	1049Tuners	1.08.1992	TUNERS
70FT920/17S	1049Tuners	1.08.1992	TUNERS
70FT920/20S	1049Tuners	1.10.1993	TUNERS
70FT920/21S	1049Tuners	1.12.1993	TUNERS
70FT920/37S	1049Tuners	1.04.1994	TUNERS
70FT930/00S	1049Tuners	1.05.1992	TUNERS
70FT930/05S	1049Tuners	1.08.1992	TUNERS
70FT930/06S	1049Tuners	1.02.1993	TUNERS
70FT930/20S	1049Tuners	1.09.1993	TUNERS
70FT950/00S	1049Tuners	1.01.1993	TUNERS
70FT990/00R	1049Tuners	1.03.1992	TUNERS

70FT990/00S	1049	Tuners	1.03.1992	TUNERS
70FV100/00	1058		1.03.1992	SPEAKER BOXES
70FV101/00	1058		1.03.1992	SPEAKER BOXES
70FV105/00B	1058		1.09.1992	SPEAKER BOXES
70FV106/00B	1058		1.09.1992	SPEAKER BOXES
70FV110/00B	1058		1.09.1992	SPEAKER BOXES
70FV115/00B	1058		1.11.1992	SPEAKER BOXES
70FV120/00B	1058		1.10.1992	SPEAKER BOXES
70FV311/00R	1049		1.03.1992	MIDISYSTEMS
70FV321/00G	1049		1.03.1992	MIDISYSTEMS
70FV815/00	1058		1.03.1992	SPEAKER BOXES
70FV815/00B	1058		1.09.1992	SPEAKER BOXES
70FV820/00	1058		1.03.1992	SPEAKER BOXES
70FV820/00B	1058		1.09.1992	SPEAKER BOXES
70FV930/00S	1049		1.07.1992	EQUALIZERS
70KD2726/02R	720225i stereo large 50Hz	D16	1.03.1992Upmarket TV	TELEVISION
70KD2726/42R	720225i stereo large 50Hz	D16	1.03.1992Upmarket TV	TELEVISION
70KE6922/14M	710225i mono	CP110	1.03.1992Basic TV	TELEVISION
70KV9717/22M	710225i stereo large 50Hz	G110	1.04.1992Basic TV	TELEVISION
70KV9917/22M	710225i stereo large 50Hz	G110	1.03.1992Basic TV	TELEVISION
70NA1147/02B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
70NA1147/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
70NA1817/22B	710225i stereo large 50Hz	GR2.1	1.03.1992Basic TV	TELEVISION
70NA2807/02B	710228i (27v) stereo large 50Hz	GR2.2	1.06.1992Basic TV	TELEVISION
70RK5787/22R	720225i stereo large 50Hz	FL1.0	1.03.1992Upmarket TV	TELEVISION
70TA3911/08	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
70TA3911/11	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
70TA3913/11	700225i mono	L6.2	1.07.1997Basic TV	TELEVISION
70TA3913/16	700228i (27v) mono	L6.2	Basic TV	TELEVISION
70TA3913/18	700228i (27v) mono	L6.2	1.06.1997Basic TV	TELEVISION
70TA3961/18	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
70TA4011/08	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
70TA4011/16	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
70TA4013/16	700225i mono	L6.2	1.07.1997Basic TV	TELEVISION
70TA4412/03	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
70TA4412/08	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
70TA4412/11	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
70TA4412/16	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
70TA4412/18	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
70TA4413/03	700228i (27v) stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
70TA4413/08	700225i stereo large 50Hz	L6.2	1.07.1997Basic TV	TELEVISION
70TA4413/11	700228i (27v) stereo large 50Hz	L6.2	1.07.1997Basic TV	TELEVISION

70TA4413/16	700228i (27v) stereo large 50Hz	L6.2	1.07.1997Basic TV	TELEVISION
70TA4413/18	700228i (27v) stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
70TA4415/03	700228i (27v) stereo large 50Hz	L9.1E	1.09.1999Basic TV	TELEVISION
70TA4415/11	700228i (27v) stereo large 50Hz	L9.1E	1.09.1999Basic TV	TELEVISION
70TA4415/18	700228i (27v) stereo large 50Hz	L9.1E	1.08.1999Basic TV	TELEVISION
70TA5212/03	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
70TA5212/11	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
70TA5212/16	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
70TA5212/18	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
70TA7212/03	720228i stereo large 100Hz	MD2.11E	1.03.1997Upmarket TV	TELEVISION
70TA7212/11	720228i stereo large 100Hz	MD2.11E	1.03.1997Upmarket TV	TELEVISION
70TA7212/18	720228i stereo large 100Hz	MD2.11E	1.06.1996Upmarket TV	TELEVISION
70TA7213/03	720228i stereo large 100Hz	MD2.21E	1.07.1997Upmarket TV	TELEVISION
70TA7213/11	720228i stereo large 100Hz	MD2.21E	1.07.1997Upmarket TV	TELEVISION
70TA7213/18	720228i stereo large 100Hz	MD2.21E	1.07.1997Upmarket TV	TELEVISION
70TA7214/03	720228i stereo large 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
70TA7214/11	720228i stereo large 100Hz	MG2.1E	1.10.1998Upmarket TV	TELEVISION
70TA7214/18	720228i stereo large 100Hz	MG2.1E	1.11.1998Upmarket TV	TELEVISION
70TA7216/03	720228i stereo large 100Hz	EM2E	1.09.2000Upmarket TV	TELEVISION
70TA7216/03R	720228i stereo large 100Hz	EM2E	1.01.2001Upmarket TV	TELEVISION
70TA7216/11	720228i stereo large 100Hz	EM2E	1.07.2000Upmarket TV	TELEVISION
70TA7216/11R	720228i stereo large 100Hz	EM2E	1.12.2000Upmarket TV	TELEVISION
70TA8331/11	720225i stereo large 100Hz	FL*.16	1.06.1995Upmarket TV	TELEVISION
70TA8331/18	720225i stereo large 100Hz	FL*.16	1.11.1995Upmarket TV	TELEVISION
70TB3891/19	700225i mono	AA5	1.05.1996Basic TV	TELEVISION
70TB3893/19	700225i mono	L6.1	1.07.1997Basic TV	TELEVISION
70TB4392/19	710225i stereo large 50Hz	MD1.1E	1.05.1996Basic TV	TELEVISION
70TB4393/19	710225i stereo large 50Hz	MD1.1E	1.09.1996Basic TV	TELEVISION
70TB4394/19	700228i (27v) stereo large 50Hz	L6.2	1.06.1997Basic TV	TELEVISION
70TB4395/19	700228i (27v) stereo large 50Hz	L9.1E	1.09.1999Basic TV	TELEVISION
70TB5192/19	710225i stereo large 50Hz	GR2.4	1.05.1996Basic TV	TELEVISION
70TB7192/19	720228i stereo large 100Hz	MD2.12E	1.06.1996Upmarket TV	TELEVISION
70WA5211/18	710224i WS 50Hz no dolby mainstream	GR2.4	1.06.1995Basic TV	TELEVISION
70WA6211/11	710224i WS 50Hz no dolby mainstream	GR2.4	1.06.1995Basic TV	TELEVISION
70WA6212/03	710224i WS 50Hz no dolby mainstream	MD1.1E	1.06.1996Basic TV	TELEVISION
70WA6212/11	710224i WS 50Hz no dolby mainstream	MD1.1E	1.06.1996Basic TV	TELEVISION
70WA6212/18	710224i WS 50Hz no dolby mainstream	MD1.1E	1.09.1996Basic TV	TELEVISION
70WA6213/03	710228i WS 50Hz no dolby mainstream	MD1.2E	1.03.1997Basic TV	TELEVISION
70WA6213/11	710228i WS 50Hz no dolby mainstream	MD1.2E	1.03.1997Basic TV	TELEVISION
70WA6213/16	710228i WS 50Hz no dolby mainstream	MD1.2E	1.09.1997Basic TV	TELEVISION
70WA6213/18	710228i WS 50Hz no dolby mainstream	MD1.2E	1.03.1997Basic TV	TELEVISION
70WA6214/03	710228i WS 50Hz no dolby mainstream	A8.0E	1.06.1999Basic TV	TELEVISION

70WA6214/11	710228i WS 50Hz no dolby mainstream A8.0E	1.07.1999Basic TV	TELEVISION
70WA6214/18	710228i WS 50Hz no dolby mainstream A8.0E	1.06.1999Basic TV	TELEVISION
70WA6215/03	710228i WS 50Hz no dolby mainstream A10E	1.07.2000Basic TV	TELEVISION
70WA6215/11	710228i WS 50Hz no dolby mainstream A10E	1.09.2000Basic TV	TELEVISION
70WA6215/18	710228i WS 50Hz no dolby mainstream A10E	1.09.2000Basic TV	TELEVISION
70WA6216/03	700228i WS 50Hz no dolby mainstream L01.1E	1.08.2001Basic TV	TELEVISION
70WA6216/11	28i WS 50Hz no dolby mainstream		TELEVISION
70WA6216/18	28i WS 50Hz no dolby mainstream		TELEVISION
70WA8414/03	720228i WS 100Hz MG2.1E	1.09.1998Upmarket TV	TELEVISION
70WA8414/11	720228i WS 100Hz MG2.1E	1.10.1998Upmarket TV	TELEVISION
70WA8414/18	720228i WS 100Hz MG2.1E	1.11.1998Upmarket TV	TELEVISION
70WA8416/03	720228i WS 100Hz EM2E	1.02.2001Upmarket TV	TELEVISION
70WA8416/11	720228i WS 100Hz EM2E	1.02.2001Upmarket TV	TELEVISION
70WA9410/03	720228i WS 100Hz GFL2.20E	1.09.1996Upmarket TV	TELEVISION
70WA9412/03	720228i WS 100Hz MD2.22E	1.05.1997Upmarket TV	TELEVISION
70WA9412/11	720228i WS 100Hz MD2.22E	1.06.1997Upmarket TV	TELEVISION
70WA9412/18	720228i WS 100Hz MD2.22E	1.12.1997Upmarket TV	TELEVISION
70WA9430/11	720228i WS 100Hz GFL2.30E	1.10.1995Upmarket TV	TELEVISION
70WB5191/19	710224i WS 50Hz no dolby mainstream GR2.4	1.10.1995Basic TV	TELEVISION
70WB6192/19	710224i WS 50Hz no dolby mainstream MD1.1E	1.10.1996Basic TV	TELEVISION
70WB6193/19	710228i WS 50Hz no dolby mainstream MD1.2E	1.04.1997Basic TV	TELEVISION
70WB6194/19	710228i WS 50Hz no dolby mainstream A8.0E	1.06.1999Basic TV	TELEVISION
72TA5213/03	710229i stereo large 50Hz MD1.2E	1.09.1996Basic TV	TELEVISION
72TA5213/11	710229i stereo large 50Hz MD1.2E	1.09.1996Basic TV	TELEVISION
72TA5213/16	710225i stereo large 50Hz MD1.2E	1.09.1996Basic TV	TELEVISION
72TA5213/18	710229i stereo large 50Hz MD1.2E	1.09.1996Basic TV	TELEVISION
72TA5214/03R	710229i stereo large 50Hz A8.0E	1.12.1998Basic TV	TELEVISION
72TA5214/11R	710229i stereo large 50Hz A8.0E	1.05.1999Basic TV	TELEVISION
72TA5214/18R	710229i stereo large 50Hz A8.0E	1.04.1999Basic TV	TELEVISION
72TA5215/03	700229i stereo large 50Hz L9.1E	1.08.2000Basic TV	TELEVISION
72TA5215/11	700229i stereo large 50Hz L9.1E	1.09.2000Basic TV	TELEVISION
72TA5215/18	700229i stereo large 50Hz L9.1E	1.09.2000Basic TV	TELEVISION
72TA6211/18	710225i stereo large 50Hz GR2.4	1.05.1996Basic TV	TELEVISION
72TA6931/11	710225i stereo large 50Hz GR2.4	1.05.1996Basic TV	TELEVISION
72TA7911/03	720225i stereo large 100Hz FL*.17	1.06.1995Upmarket TV	TELEVISION
72TA7912/03	720225i stereo large 100Hz FL*.16	1.06.1995Upmarket TV	TELEVISION
72TA7932/16	720225i stereo large 100Hz FL*.16	1.06.1995Upmarket TV	TELEVISION
72TA7932/18	720225i stereo large 100Hz FL*.16	1.06.1995Upmarket TV	TELEVISION
72TA8032/11	720225i stereo large 100Hz FL*.26	1.06.1995Upmarket TV	TELEVISION
72TB7912/19	720225i stereo large 100Hz FL*.16	1.06.1995Upmarket TV	TELEVISION
82WA6213/11	710332i WS 50Hz no dolby mainstream MD1.2E	1.10.1997Basic TV	TELEVISION
82WA6213/18	710332i WS 50Hz no dolby mainstream MD1.2E	1.12.1997Basic TV	TELEVISION

82WA6213/38	710332i WS 50Hz no dolby mainstream MD1.2E	1.06.1999	Basic TV	TELEVISION
82WA6214/18	710332i WS 50Hz no dolby mainstream A8.0E	1.09.1999	Basic TV	TELEVISION
82WA8414/03	720332i WS 100Hz MG2.1E	1.03.1999	Upmarket TV	TELEVISION
82WA8414/11	720332i WS 100Hz MG2.1E	1.10.1998	Upmarket TV	TELEVISION
82WA8414/18	720332i WS 100Hz MG2.1E	1.12.1998	Upmarket TV	TELEVISION
82WA8416/03	720332i WS 100Hz EM2E	1.02.2001	Upmarket TV	TELEVISION
82WA8416/11	720332i WS 100Hz EM2E	1.02.2001	Upmarket TV	TELEVISION
82WA9412/11	720332i WS 100Hz MD2.22E	1.06.1997	Upmarket TV	TELEVISION
82WA9412/18	720332i WS 100Hz MD2.22E	1.03.1998	Upmarket TV	TELEVISION
82WA9430/11	720332i WS 100Hz GFL2.20E	1.09.1995	Upmarket TV	TELEVISION
82WB6193/19	710332i WS 50Hz no dolby mainstream MD1.2E	1.04.1998	Basic TV	TELEVISION
82WB6193/39	710332i WS 50Hz no dolby mainstream MD1.2E		Basic TV	TELEVISION
85RK5987/02B	720325i stereo large 50Hz FL1.0	1.03.1992	Upmarket TV	TELEVISION
85TA6912/03	720325i stereo large 50Hz FL*.20	1.05.1996	Upmarket TV	TELEVISION
85TA6932/16	720333i (32v) stereo large 50Hz FL*.20	1.05.1996	Upmarket TV	TELEVISION
85TA7010/18	720333i (32v) stereo large 50Hz FL*.10		Upmarket TV	TELEVISION
900S2853/13M	2012MAC terminal	1.09.1996		SATELLITE
900U2803/13M	2012PAL/SECAM terminal	1.05.1997		SATELLITE
900U2853/13M	2012PAL/SECAM terminal	1.03.1997		SATELLITE
900U2853/33M	2012PAL/SECAM terminal	1.03.1997		SATELLITE
98MC255T/,,	2010 X9-B/W			OBSERVATION SYSTEMS
98MC350R/,,	6010 X9-B/W			OBSERVATION SYSTEMS
98MC355R/,,	2010 X9-B/W			OBSERVATION SYSTEMS
AC388/53	1021Step-up show view			VCR
AC457/78	1021Step-up show view			VCR
AC488/78	1021Leader show view			VCR
AC557/78	1021Leader show view			VCR
AC588/78	1021Leader show view			VCR
AC757/78	1021High-end			VCR
AC788/78	1021Leader			VCR
AC819/53	1021Leader			VCR
AC857/78	1021High-end			VCR
AC988/78	1021Leader			VCR
ACT6688/00	1041Radio + Cassette	1.05.1999		PERSONAL STEREO
ACT6688/01	1041Radio + Cassette	1.06.1999		PERSONAL STEREO
ACT6688/11	1041Radio + Cassette	1.08.1999		PERSONAL STEREO
ACT6688/14	1041Radio + Cassette	1.07.1999		PERSONAL STEREO
ACT6688/17Z	1041Radio + Cassette	1.06.1999		PERSONAL STEREO
ACT7580/17	1042CD personal	1.05.1999		PERSONAL CD
ACT7581/07	1042CD personal			PERSONAL CD
ACT7581/16	1042CD personal	1.02.2000		PERSONAL CD
ACT7581/17	1042CD personal	1.05.1999		PERSONAL CD

ACT7582/00	1042CD personal	1.05.1999	PERSONAL CD
ACT7582/01	1042CD personal	1.04.1999	PERSONAL CD
ACT7582/05	1042CD personal	1.07.1999	PERSONAL CD
ACT7582/09	1042CD personal	1.07.1999	PERSONAL CD
ACT7582/10	1042CD personal	1.07.1999	PERSONAL CD
ACT7582/14	1042CD personal	1.06.1999	PERSONAL CD
ACT7583/00	1042CD personal	1.05.2000	PERSONAL CD
ACT7583/01	1042CD personal	1.05.2000	PERSONAL CD
ACT7583/05	1042CD personal	1.05.2000	PERSONAL CD
ACT7583/09	1042CD personal	1.05.2000	PERSONAL CD
ACT7583/10	1042CD personal	1.06.2000	PERSONAL CD
ACT7583/17	1042CD personal	1.04.2000	PERSONAL CD
ACT7585/00	1042CD personal	1.05.2001	PERSONAL CD
ACT7585/01	1042CD personal	1.05.2001	PERSONAL CD
ACT7585/17	1042CD personal		PERSONAL CD
AE1000/00	1041Portable radio	1.03.2000	RADIO PORTABLE
AE1000/01	1041Portable radio	1.06.2000	RADIO PORTABLE
AE1000/04	1041Portable radio	1.05.2000	RADIO PORTABLE
AE1000/17	1041Portable radio	1.04.2000	RADIO PORTABLE
AE1490/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE1490/10	1041Portable radio	1.03.1992	RADIO PORTABLE
AE1492/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE1495/00	1041Portable radio	1.08.1994	RADIO PORTABLE
AE1495/00Z	1041Portable radio	1.06.1995	RADIO PORTABLE
AE1495/01Z	1041Portable radio	1.06.1995	RADIO PORTABLE
AE1495/04	1041Portable radio	1.09.1994	RADIO PORTABLE
AE1495/04Z	1041Portable radio	1.06.1995	RADIO PORTABLE
AE1505/00	1041Portable radio	1.06.2000	RADIO PORTABLE
AE1505/00Z	1041Portable radio	1.08.2000	RADIO PORTABLE
AE1505/01Z	1041Portable radio	1.06.2000	RADIO PORTABLE
AE1505/04	1041Portable radio	1.07.2000	RADIO PORTABLE
AE1505/04Z	1041Portable radio	1.07.2000	RADIO PORTABLE
AE1505/14	1041Portable radio	1.07.2000	RADIO PORTABLE
AE1505/17Z	1041Portable radio	1.05.2000	RADIO PORTABLE
AE1590/01	1041Portable radio	1.05.1998	RADIO PORTABLE
AE1595/00	1041Portable radio	1.09.1996	RADIO PORTABLE
AE1595/00S	1041Portable radio	1.06.1999	RADIO PORTABLE
AE1595/01	1041Portable radio	1.08.1997	RADIO PORTABLE
AE1595/01Z	1041Portable radio	1.04.1997	RADIO PORTABLE
AE1595/04	1041Portable radio	1.09.1996	RADIO PORTABLE
AE1595/04S	1041Portable radio	1.06.1999	RADIO PORTABLE
AE1595/04Z	1041Portable radio	1.06.1999	RADIO PORTABLE

AE1595/11	1041Portable radio	1.11.1996	RADIO PORTABLE
AE1595/14	1041Portable radio	1.03.1997	RADIO PORTABLE
AE1595/17Z	1041Portable radio	1.03.1997	RADIO PORTABLE
AE1605/00	1041Portable radio	1.03.2001	RADIO PORTABLE
AE1605/04	1041Portable radio	1.02.2001	RADIO PORTABLE
AE1605/14	1041Portable radio	1.03.2001	RADIO PORTABLE
AE1695/00	1041Portable radio	1.08.1996	RADIO PORTABLE
AE1695/00S	1041Portable radio	1.06.1999	RADIO PORTABLE
AE1695/01	1041Portable radio		RADIO PORTABLE
AE1695/04	1041Portable radio	1.08.1996	RADIO PORTABLE
AE1695/04S	1041Portable radio	1.06.1999	RADIO PORTABLE
AE1695/11	1041Portable radio	1.09.1997	RADIO PORTABLE
AE1695/14	1041Portable radio	1.02.1997	RADIO PORTABLE
AE2045/17	1041Portable radio	1.06.1997	RADIO PORTABLE
AE2100/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2100/10	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2100/17	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2102/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2102/18	1041Portable radio	1.08.1993	RADIO PORTABLE
AE2110/11	1041Portable radio	1.08.2001	RADIO PORTABLE
AE2130/00	1041Portable radio	1.08.1993	RADIO PORTABLE
AE2130/00Z	1041Portable radio	1.10.1994	RADIO PORTABLE
AE2130/01	1041Portable radio	1.09.1993	RADIO PORTABLE
AE2130/04	1041Portable radio	1.08.1993	RADIO PORTABLE
AE2130/05	1041Portable radio	1.03.1994	RADIO PORTABLE
AE2130/10	1041Portable radio	1.12.1993	RADIO PORTABLE
AE2130/17	1041Portable radio	1.06.1994	RADIO PORTABLE
AE2140/00	1041Portable radio	1.08.1996	RADIO PORTABLE
AE2140/01	1041Portable radio	1.09.1996	RADIO PORTABLE
AE2140/04	1041Portable radio	1.07.1996	RADIO PORTABLE
AE2140/05	1041Portable radio	1.05.1997	RADIO PORTABLE
AE2140/10	1041Portable radio	1.09.1996	RADIO PORTABLE
AE2140/11	1041Portable radio	1.09.1996	RADIO PORTABLE
AE2140/14	1041Portable radio	1.12.1996	RADIO PORTABLE
AE2140/17	1041Portable radio	1.09.1996	RADIO PORTABLE
AE2145/17	1041Portable radio	1.07.1996	RADIO PORTABLE
AE2150/00	1041Portable radio	1.03.1999	RADIO PORTABLE
AE2150/01	1041Portable radio	1.05.1999	RADIO PORTABLE
AE2150/04	1041Portable radio	1.03.1999	RADIO PORTABLE
AE2150/05	1041Portable radio	1.05.1999	RADIO PORTABLE
AE2150/09	1041Portable radio	1.06.1999	RADIO PORTABLE
AE2150/11	1041Portable radio	1.05.1999	RADIO PORTABLE

AE2150/14	1041Portable radio	1.05.1999	RADIO PORTABLE
AE2155/17	1041Portable radio	1.05.1999	RADIO PORTABLE
AE2170/00	1041Portable radio	1.03.1999	RADIO PORTABLE
AE2170/04	1041Portable radio	1.04.1999	RADIO PORTABLE
AE2170/14	1041Portable radio	1.05.1999	RADIO PORTABLE
AE2180/00	1041Portable radio	1.08.1999	RADIO PORTABLE
AE2180/01	Portable radio		RADIO PORTABLE
AE2180/04	1041Portable radio	1.07.1999	RADIO PORTABLE
AE2180/17	1041Portable radio	1.04.1999	RADIO PORTABLE
AE2300/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2300/05	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2300/06	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2302/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2306/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2340/00	1041Portable radio	1.03.1995	RADIO PORTABLE
AE2340/14	1041Portable radio	1.07.1997	RADIO PORTABLE
AE2380/00	1041Portable radio	1.03.2000	RADIO PORTABLE
AE2380/05	1041Portable radio	1.04.2000	RADIO PORTABLE
AE2402/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE2630/00	1041Portable radio	1.07.1993	RADIO PORTABLE
AE2630/05	1041Portable radio	1.03.1994	RADIO PORTABLE
AE2630/08	1041Portable radio	1.09.1993	RADIO PORTABLE
AE3205/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3205/01	1041Portable radio	1.09.1992	RADIO PORTABLE
AE3350/00	1041Portable radio	1.07.1995	RADIO PORTABLE
AE3350/14	1041Portable radio	1.03.1997	RADIO PORTABLE
AE3350/15	1041Portable radio	1.12.1995	RADIO PORTABLE
AE3405/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3405/01	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3405/20	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3405/21	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3405/23	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3405/37	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3625/00	1041Portable radio	1.09.1992	RADIO PORTABLE
AE3625/17	1041Portable radio	1.08.1992	RADIO PORTABLE
AE3625/18	1041Portable radio	1.03.1993	RADIO PORTABLE
AE3650/00	1041Portable radio	1.11.1995	RADIO PORTABLE
AE3650/03	1041Portable radio	1.03.1996	RADIO PORTABLE
AE3650/14	1041Portable radio	1.02.1997	RADIO PORTABLE
AE3750/00	1041Portable radio	1.10.1996	RADIO PORTABLE
AE3805/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3805/03	1041Portable radio	1.03.1992	RADIO PORTABLE

AE3805/08	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3805/17	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3905/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE3905/08	1041Portable radio	1.05.1992	RADIO PORTABLE
AE4130/03	1041Portable radio	1.02.1993	RADIO PORTABLE
AE4200/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE4200/20	1041Portable radio	1.05.1992	RADIO PORTABLE
AE4200/23	1041Portable radio	1.03.1992	RADIO PORTABLE
AE4200/37	1041Portable radio	1.04.1992	RADIO PORTABLE
AE4230/00	1041Portable radio	1.01.1994	RADIO PORTABLE
AE4230/03	1041Portable radio	1.10.1993	RADIO PORTABLE
AE4230/17	1041Portable radio	1.01.1995	RADIO PORTABLE
AE6203/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE6206/17	1041Portable radio	1.03.1992	RADIO PORTABLE
AE6209/00	1041Portable radio	1.03.1992	RADIO PORTABLE
AE6360/00	1041Portable radio	1.05.1997	RADIO PORTABLE
AE6360/00S	1041Portable radio	1.06.1999	RADIO PORTABLE
AE6360/01	1041Portable radio	1.12.1996	RADIO PORTABLE
AE6360/06	1041Portable radio	1.07.1997	RADIO PORTABLE
AE6360/11	1041Portable radio	1.05.1997	RADIO PORTABLE
AE6360/14	1041Portable radio	1.04.1997	RADIO PORTABLE
AE6360/17Z	1041Portable radio	1.07.1997	RADIO PORTABLE
AE6370/00	1041Portable radio	1.02.2001	RADIO PORTABLE
AE6370/00Z	1041Portable radio	1.03.2001	RADIO PORTABLE
AE6370/14	1041Portable radio	1.03.2001	RADIO PORTABLE
AE6545/00	1041Portable radio	1.08.1996	RADIO PORTABLE
AE6545/00S	1041Portable radio	1.06.1999	RADIO PORTABLE
AE6545/01	1041Portable radio	1.10.1996	RADIO PORTABLE
AE6545/11	1041Portable radio	1.09.1997	RADIO PORTABLE
AE6545/11H	1041Portable radio	1.11.1996	RADIO PORTABLE
AE6545/14P	1041Portable radio	1.03.1997	RADIO PORTABLE
AE6545/17	1041Portable radio	1.10.1996	RADIO PORTABLE
AE6550/00	1041Portable radio	1.09.1996	RADIO PORTABLE
AE6550/00S	1041Portable radio	1.06.1999	RADIO PORTABLE
AE6550/01	1041Portable radio	1.10.1996	RADIO PORTABLE
AE6550/06P	1041Portable radio	1.12.1996	RADIO PORTABLE
AE6550/11	1041Portable radio	1.10.1996	RADIO PORTABLE
AE6550/14P	1041Portable radio	1.07.1997	RADIO PORTABLE
AE6565/00	1041Portable radio	1.02.2000	RADIO PORTABLE
AE6565/00Z	1041Portable radio	1.05.2000	RADIO PORTABLE
AE6565/01	1041Portable radio	1.06.2000	RADIO PORTABLE
AE6570/00	1041Portable radio	1.03.2000	RADIO PORTABLE

AE6570/00Z	1041Portable radio		RADIO PORTABLE
AE6570/01	1041Portable radio	1.11.2000	RADIO PORTABLE
AE6690/17	1041Portable radio	1.03.1992	RADIO PORTABLE
AE6691/01	1041Portable radio	1.07.1993	RADIO PORTABLE
AE6691/17	1041Portable radio	1.03.1992	RADIO PORTABLE
AE6695/00	1041Portable radio	1.09.1994	RADIO PORTABLE
AE6695/00Z	1041Portable radio	1.06.1995	RADIO PORTABLE
AE6695/01	1041Portable radio	1.08.1994	RADIO PORTABLE
AE6695/01Z	1041Portable radio	1.09.1995	RADIO PORTABLE
AE6695/17	1041Portable radio	1.01.1995	RADIO PORTABLE
AE6740/17Z	1041Portable radio	1.04.1997	RADIO PORTABLE
AE6745/00	1041Portable radio	1.08.1996	RADIO PORTABLE
AE6745/01	1041Portable radio	1.05.1997	RADIO PORTABLE
AE6745/11	1041Portable radio	1.06.1997	RADIO PORTABLE
AE6745/14P	1041Portable radio	1.03.1997	RADIO PORTABLE
AE6745/17	1041Portable radio	1.10.1996	RADIO PORTABLE
AE6750/00	1041Portable radio	1.03.1995	RADIO PORTABLE
AE6750/00Z	1041Portable radio	1.06.1995	RADIO PORTABLE
AE6750/11	1041Portable radio	1.12.1995	RADIO PORTABLE
AE6775/00	1041Portable radio	1.06.1999	RADIO PORTABLE
AE6780/00	1041Portable radio	1.07.1999	RADIO PORTABLE
AE6780/14	1041Portable radio	1.08.1999	RADIO PORTABLE
AE6780/17Z	1041Portable radio	1.09.1999	RADIO PORTABLE
AH194/37	1049	1.05.1992	MIDISYSTEMS
AH198/37	1049	1.03.1992	MIDISYSTEMS
AH307/37	1049	1.08.1992	MIDISYSTEMS
AH829/17R	1049	1.09.1992	MIDISYSTEMS
AJ3000/01	1041Clock radio	1.06.1999	CLOCKRADIO
AJ3000/11	1041Clock radio	1.04.1999	CLOCKRADIO
AJ3000/14	1041Clock radio	1.06.1999	CLOCKRADIO
AJ3005/00	1041Clock radio	1.03.1999	CLOCKRADIO
AJ3005/04	1041Clock radio	1.04.1999	CLOCKRADIO
AJ3005/05	1041Clock radio	1.05.1999	CLOCKRADIO
AJ3010/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3010/00W	1041Clock radio	1.06.1992	CLOCKRADIO
AJ3010/00Z	1041Clock radio	1.09.1994	CLOCKRADIO
AJ3010/01	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3010/04	1041Clock radio	1.02.2001	CLOCKRADIO
AJ3010/05	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3010/09	1041Clock radio	1.06.2001	CLOCKRADIO
AJ3010/10	1041Clock radio	1.07.1992	CLOCKRADIO
AJ3010/17	1041Clock radio	1.03.1992	CLOCKRADIO

AJ3010/19	1041Clock radio	1.04.1992	CLOCKRADIO
AJ3012/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3012/00W	1041Clock radio	1.09.1993	CLOCKRADIO
AJ3012/18	1041Clock radio	1.12.1992	CLOCKRADIO
AJ3015/00	1041Clock radio	1.08.1993	CLOCKRADIO
AJ3015/04	1041Clock radio	1.09.1993	CLOCKRADIO
AJ3015/19	1041Clock radio	1.02.1994	CLOCKRADIO
AJ3016/00	1041Clock radio	1.10.1999	CLOCKRADIO
AJ3016/04	1041Clock radio	1.02.2000	CLOCKRADIO
AJ3016/05	1041Clock radio	1.05.2000	CLOCKRADIO
AJ3017/00	1041Clock radio	1.10.1999	CLOCKRADIO
AJ3017/04	1041Clock radio	1.02.2000	CLOCKRADIO
AJ3017/05	1041Clock radio	1.05.2000	CLOCKRADIO
AJ3018/00	1041Clock radio	1.10.1999	CLOCKRADIO
AJ3018/04	1041Clock radio	1.02.2000	CLOCKRADIO
AJ3018/05	1041Clock radio		CLOCKRADIO
AJ3019/00	1041Clock radio	1.11.1999	CLOCKRADIO
AJ3019/04	1041Clock radio	1.02.2000	CLOCKRADIO
AJ3019/05	1041Clock radio		CLOCKRADIO
AJ3030/17	1041Clock radio	1.01.1995	CLOCKRADIO
AJ3040/00	1041Clock radio	1.05.1995	CLOCKRADIO
AJ3040/00P	1041Clock radio	1.10.1996	CLOCKRADIO
AJ3040/00Z	1041Clock radio	1.10.1995	CLOCKRADIO
AJ3040/04	1041Clock radio	1.09.1996	CLOCKRADIO
AJ3040/04P	1041Clock radio	1.11.1996	CLOCKRADIO
AJ3040/04Z	1041Clock radio	1.09.1995	CLOCKRADIO
AJ3040/05B	1041Clock radio	1.01.1997	CLOCKRADIO
AJ3040/05W	1041Clock radio	1.06.1995	CLOCKRADIO
AJ3040/10	1041Clock radio	1.10.1997	CLOCKRADIO
AJ3040/10W	1041Clock radio	1.10.1997	CLOCKRADIO
AJ3040/17	1041Clock radio	1.03.1995	CLOCKRADIO
AJ3050/00C	Clock radio		CLOCKRADIO
AJ3050/04	Clock radio		CLOCKRADIO
AJ3050/05	Clock radio		CLOCKRADIO
AJ3051/00C	Clock radio		CLOCKRADIO
AJ3051/04	Clock radio		CLOCKRADIO
AJ3051/05	Clock radio		CLOCKRADIO
AJ3052/00	Clock radio		CLOCKRADIO
AJ3052/04	Clock radio		CLOCKRADIO
AJ3080/00	1041Clock radio	1.07.1998	CLOCKRADIO
AJ3080/00P	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3080/00Z	1041Clock radio	1.08.1999	CLOCKRADIO

AJ3080/01	1041Clock radio	1.12.1998	CLOCKRADIO
AJ3080/04	1041Clock radio	1.08.1998	CLOCKRADIO
AJ3080/04Z	1041Clock radio	1.08.1998	CLOCKRADIO
AJ3080/05	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3080/05W	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3080/07	1041Clock radio		CLOCKRADIO
AJ3080/10	1041Clock radio	1.10.1998	CLOCKRADIO
AJ3080/17	1041Clock radio	1.05.1998	CLOCKRADIO
AJ3081/17	1041Clock radio	1.04.2000	CLOCKRADIO
AJ3120/00	1041Clock radio	1.01.2001	CLOCKRADIO
AJ3120/00Z	1041Clock radio	1.02.2001	CLOCKRADIO
AJ3120/04	1041Clock radio	1.02.2001	CLOCKRADIO
AJ3120/04Z	1041Clock radio	1.02.2001	CLOCKRADIO
AJ3120/05	1041Clock radio	1.03.2001	CLOCKRADIO
AJ3120/09	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3120/17	1041Clock radio	1.05.2001	CLOCKRADIO
AJ3120/19	Clock radio		CLOCKRADIO
AJ3120/19E	Clock radio		CLOCKRADIO
AJ3125/00	1041Clock radio	1.05.2001	CLOCKRADIO
AJ3125/04	1041Clock radio	1.05.2001	CLOCKRADIO
AJ3125/05	1041Clock radio	1.06.2001	CLOCKRADIO
AJ3125/14	1041Clock radio	1.05.2001	CLOCKRADIO
AJ3125/17	Clock radio		CLOCKRADIO
AJ3130/00	1041Clock radio	1.02.2000	CLOCKRADIO
AJ3130/04	1041Clock radio	1.04.2000	CLOCKRADIO
AJ3130/05	1041Clock radio	1.05.2000	CLOCKRADIO
AJ3130/17	1041Clock radio	1.03.1993	CLOCKRADIO
AJ3131/00	1041Clock radio	1.09.2000	CLOCKRADIO
AJ3131/04	1041Clock radio	1.09.2000	CLOCKRADIO
AJ3131/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3132/00	1041Clock radio	1.09.2000	CLOCKRADIO
AJ3132/04	1041Clock radio	1.09.2000	CLOCKRADIO
AJ3132/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3133/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3135/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3140/00	1041Clock radio	1.08.1996	CLOCKRADIO
AJ3140/00S	1041Clock radio	1.08.1997	CLOCKRADIO
AJ3140/00W	1041Clock radio	1.10.1996	CLOCKRADIO
AJ3140/01	1041Clock radio	1.10.1996	CLOCKRADIO
AJ3140/04	1041Clock radio	1.08.1996	CLOCKRADIO
AJ3140/04S	1041Clock radio	1.09.1997	CLOCKRADIO
AJ3140/04W	1041Clock radio	1.11.1996	CLOCKRADIO

AJ3140/05	1041Clock radio	1.08.1996	CLOCKRADIO
AJ3140/05S	1041Clock radio	1.09.1997	CLOCKRADIO
AJ3140/05W	1041Clock radio	1.03.1997	CLOCKRADIO
AJ3140/06	1041Clock radio	1.10.1996	CLOCKRADIO
AJ3140/06W	1041Clock radio	1.11.1996	CLOCKRADIO
AJ3140/09	1041Clock radio	1.01.1999	CLOCKRADIO
AJ3140/10	1041Clock radio	1.07.1997	CLOCKRADIO
AJ3140/10W	1041Clock radio	1.10.1996	CLOCKRADIO
AJ3140/11	1041Clock radio	1.10.1996	CLOCKRADIO
AJ3140/11W	1041Clock radio	1.12.1997	CLOCKRADIO
AJ3140/13	1041Clock radio		CLOCKRADIO
AJ3140/14	1041Clock radio	1.09.1996	CLOCKRADIO
AJ3140/17	1041Clock radio	1.06.1996	CLOCKRADIO
AJ3140/17W	1041Clock radio	1.06.1996	CLOCKRADIO
AJ3140/19	1041Clock radio	1.08.1998	CLOCKRADIO
AJ3140/19B	1041Clock radio	1.08.1998	CLOCKRADIO
AJ3140/19S	1041Clock radio	1.02.1998	CLOCKRADIO
AJ3140/19W	1041Clock radio	1.08.1998	CLOCKRADIO
AJ3141/00	1041Clock radio	1.04.1999	CLOCKRADIO
AJ3141/07	1041Clock radio		CLOCKRADIO
AJ3141/17	1041Clock radio	1.06.1998	CLOCKRADIO
AJ3142/00	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3143/00	1041Clock radio	1.09.1999	CLOCKRADIO
AJ3143/04	1041Clock radio	1.08.1999	CLOCKRADIO
AJ3143/07	1041Clock radio		CLOCKRADIO
AJ3143/17	1041Clock radio	1.06.1998	CLOCKRADIO
AJ3144/04	1041Clock radio	1.05.1999	CLOCKRADIO
AJ3144/17	1041Clock radio	1.09.1999	CLOCKRADIO
AJ3145/00	1041Clock radio	1.04.1999	CLOCKRADIO
AJ3145/04	1041Clock radio	1.04.1999	CLOCKRADIO
AJ3145/05	1041Clock radio	1.07.1999	CLOCKRADIO
AJ3145/07	1041Clock radio		CLOCKRADIO
AJ3145/14	1041Clock radio	1.03.2001	CLOCKRADIO
AJ3145/16	1041Clock radio	1.06.2000	CLOCKRADIO
AJ3145/17	1041Clock radio	1.06.1998	CLOCKRADIO
AJ3150/00	1041Clock radio	1.01.1995	CLOCKRADIO
AJ3150/00W	1041Clock radio	1.06.1995	CLOCKRADIO
AJ3150/04	1041Clock radio	1.02.1995	CLOCKRADIO
AJ3150/04W	1041Clock radio	1.06.1995	CLOCKRADIO
AJ3150/05W	1041Clock radio	1.03.1995	CLOCKRADIO
AJ3150/10	1041Clock radio	1.09.1995	CLOCKRADIO
AJ3150/10P	1041Clock radio	1.10.1996	CLOCKRADIO

AJ3150/10W	1041Clock radio	1.09.1995	CLOCKRADIO
AJ3150/11	1041Clock radio	1.06.1995	CLOCKRADIO
AJ3150/11W	1041Clock radio	1.11.1997	CLOCKRADIO
AJ3150/12	1041Clock radio	1.03.1996	CLOCKRADIO
AJ3150/13	1041Clock radio		CLOCKRADIO
AJ3150/14	1041Clock radio	1.03.1997	CLOCKRADIO
AJ3150/19	1041Clock radio	1.07.1995	CLOCKRADIO
AJ3150/19W	1041Clock radio	1.10.1995	CLOCKRADIO
AJ3150/20	1041Clock radio	1.08.1995	CLOCKRADIO
AJ3150/24	1041Clock radio	1.12.1995	CLOCKRADIO
AJ3150/39	1041Clock radio	1.10.1995	CLOCKRADIO
AJ3150CL/15	1041Clock radio		CLOCKRADIO
AJ3160/00C	Clock radio		CLOCKRADIO
AJ3160/04	Clock radio		CLOCKRADIO
AJ3180/17	Clock radio		CLOCKRADIO
AJ3180/21	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3182/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3190/00	1041Clock radio	1.07.1998	CLOCKRADIO
AJ3190/01	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3190/04	1041Clock radio	1.08.1998	CLOCKRADIO
AJ3190/05	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3190/09	1041Clock radio	1.12.1998	CLOCKRADIO
AJ3190/11	1041Clock radio		CLOCKRADIO
AJ3190/13	1041Clock radio		CLOCKRADIO
AJ3190/14	1041Clock radio		CLOCKRADIO
AJ3190/19	1041Clock radio	1.11.1998	CLOCKRADIO
AJ3195/11	1041Clock radio	1.02.1999	CLOCKRADIO
AJ3195/14	1041Clock radio	1.10.1998	CLOCKRADIO
AJ3220/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3220/01	1041Clock radio	1.04.1992	CLOCKRADIO
AJ3220/04	Clock radio		CLOCKRADIO
AJ3220/09	1041Clock radio	1.07.2001	CLOCKRADIO
AJ3220/10	1041Clock radio	1.06.1992	CLOCKRADIO
AJ3220/17	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3222/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3225/00	1041Clock radio	1.03.2001	CLOCKRADIO
AJ3225/04	1041Clock radio	1.04.2001	CLOCKRADIO
AJ3225/05	1041Clock radio	1.06.2001	CLOCKRADIO
AJ3225/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3230/00	1041Clock radio	1.06.2001	CLOCKRADIO
AJ3230/04	1041Clock radio	1.06.2001	CLOCKRADIO
AJ3230/05	1041Clock radio	1.06.2001	CLOCKRADIO

AJ3230/17	1041Clock radio	1.03.1993	CLOCKRADIO
AJ3240/00	1041Clock radio	1.08.1995	CLOCKRADIO
AJ3240/17	1041Clock radio	1.04.1995	CLOCKRADIO
AJ3241/17	1041Clock radio	1.09.2001	CLOCKRADIO
AJ3242/17	1041Clock radio	1.09.2001	CLOCKRADIO
AJ3250/00	1041Clock radio	1.03.1995	CLOCKRADIO
AJ3250/00W	1041Clock radio	1.07.1995	CLOCKRADIO
AJ3250/04	1041Clock radio	1.03.1995	CLOCKRADIO
AJ3250/04W	1041Clock radio	1.06.1995	CLOCKRADIO
AJ3250/05W	1041Clock radio	1.04.1995	CLOCKRADIO
AJ3250/06	1041Clock radio	1.09.1995	CLOCKRADIO
AJ3250/10	1041Clock radio	1.10.1996	CLOCKRADIO
AJ3250/11	1041Clock radio		CLOCKRADIO
AJ3260/00C	Clock radio	1.12.2001	CLOCKRADIO
AJ3260/04	Clock radio		CLOCKRADIO
AJ3260/05	Clock radio		CLOCKRADIO
AJ3260/17	Clock radio		CLOCKRADIO
AJ3280/00	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3280/07	1041Clock radio		CLOCKRADIO
AJ3280/17	1041Clock radio	1.05.1998	CLOCKRADIO
AJ3290/00	1041Clock radio	1.08.1998	CLOCKRADIO
AJ3290/01	1041Clock radio	1.10.1998	CLOCKRADIO
AJ3290/04	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3290/05	1041Clock radio	1.09.1998	CLOCKRADIO
AJ3290/09	1041Clock radio	1.03.1999	CLOCKRADIO
AJ3290/10	1041Clock radio		CLOCKRADIO
AJ3290/11	1041Clock radio		CLOCKRADIO
AJ3290/14	1041Clock radio		CLOCKRADIO
AJ3320/00	Clock radio		CLOCKRADIO
AJ3330/17	Clock radio		CLOCKRADIO
AJ3340/10	1041Clock radio	1.11.1996	CLOCKRADIO
AJ3340/17	1041Clock radio	1.06.1995	CLOCKRADIO
AJ3380/00	1041Clock radio	1.06.1998	CLOCKRADIO
AJ3380/01	1041Clock radio		CLOCKRADIO
AJ3380/04	1041Clock radio	1.07.1998	CLOCKRADIO
AJ3380/10	1041Clock radio	1.10.1998	CLOCKRADIO
AJ3380/11	1041Clock radio		CLOCKRADIO
AJ3380/17	1041Clock radio	1.06.1998	CLOCKRADIO
AJ3430/00	1041Clock radio	1.08.2000	CLOCKRADIO
AJ3430/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3440/17	1041Clock radio	1.05.1995	CLOCKRADIO
AJ3450/17	1041Clock radio	1.05.1997	CLOCKRADIO

AJ3470/00	Clock radio		CLOCKRADIO
AJ3475/00	Clock radio		CLOCKRADIO
AJ3480/16	1041Clock radio	1.10.1999	CLOCKRADIO
AJ3480/17	1041Clock radio	1.05.1998	CLOCKRADIO
AJ3490/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3510/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3510/05	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3510/06	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3512/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3600/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3600/10	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3602/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3602/05	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3630/00	1041Clock radio	1.02.1994	CLOCKRADIO
AJ3630/04	1041Clock radio	1.03.1994	CLOCKRADIO
AJ3630/05	1041Clock radio	1.09.1994	CLOCKRADIO
AJ3710/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3710/01	1041Clock radio	1.05.1992	CLOCKRADIO
AJ3710/05	1041Clock radio	1.06.1992	CLOCKRADIO
AJ3710/10	1041Clock radio	1.07.1992	CLOCKRADIO
AJ3710/17	1041Clock radio	1.06.1992	CLOCKRADIO
AJ3712/00	1041Clock radio	1.06.1992	CLOCKRADIO
AJ3720/00	1041Clock radio	1.09.1997	CLOCKRADIO
AJ3720/00S	1041Clock radio	1.05.1999	CLOCKRADIO
AJ3720/01	1041Clock radio	1.07.1998	CLOCKRADIO
AJ3720/17	1041Clock radio	1.07.1998	CLOCKRADIO
AJ3740/00	1041Clock radio	1.08.1997	CLOCKRADIO
AJ3740/00S	1041Clock radio	1.04.1999	CLOCKRADIO
AJ3800/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3800/10	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3802/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3802/05	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3840/00	1041Clock radio	1.09.1995	CLOCKRADIO
AJ3840/00M	1041Clock radio	1.06.1997	CLOCKRADIO
AJ3840/10	1041Clock radio	1.11.1995	CLOCKRADIO
AJ3840/10M	1041Clock radio	1.11.1997	CLOCKRADIO
AJ3840/17	1041Clock radio	1.11.1995	CLOCKRADIO
AJ3840/17M	1041Clock radio	1.02.1997	CLOCKRADIO
AJ3900/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3900/17	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3902/00	1041Clock radio	1.03.1992	CLOCKRADIO
AJ3920/00	1041Clock radio	1.09.1995	CLOCKRADIO

AJ3920/01	1041Clock radio	1.10.1995	CLOCKRADIO
AJ3920/01H	1041Clock radio	1.06.1996	CLOCKRADIO
AJ3920/06	1041Clock radio	1.05.1996	CLOCKRADIO
AJ3920/10	1041Clock radio	1.04.1996	CLOCKRADIO
AJ3920/14	1041Clock radio	1.03.1997	CLOCKRADIO
AJ3920/17	1041Clock radio	1.08.1995	CLOCKRADIO
AJ3925/00	1041Clock radio	1.08.1997	CLOCKRADIO
AJ3925/01	1041Clock radio	1.12.1996	CLOCKRADIO
AJ3925/10	1041Clock radio	1.08.1997	CLOCKRADIO
AJ3925/13	1041Clock radio		CLOCKRADIO
AJ3925/14	1041Clock radio	1.09.1997	CLOCKRADIO
AJ3925/17	1041Clock radio	1.04.1997	CLOCKRADIO
AJ3930/00	1041Clock radio	1.02.1994	CLOCKRADIO
AJ3930/01	1041Clock radio	1.11.1993	CLOCKRADIO
AJ3930/04	1041Clock radio	1.11.1993	CLOCKRADIO
AJ3930/05	1041Clock radio	1.12.1993	CLOCKRADIO
AJ3930/06	1041Clock radio	1.02.1994	CLOCKRADIO
AJ3930/17	1041Clock radio	1.06.1994	CLOCKRADIO
AJ3930/26	1041Clock radio	1.05.1995	CLOCKRADIO
AJ3935/00	1041Clock radio	1.06.1999	CLOCKRADIO
AJ3935/10	1041Clock radio	1.08.1999	CLOCKRADIO
AJ3935/17	1041Clock radio	1.05.1999	CLOCKRADIO
AJ3936/00	1041Clock radio	1.06.2000	CLOCKRADIO
AJ3936/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3940/00	1041Clock radio	1.06.1998	CLOCKRADIO
AJ3940/01	1041Clock radio	1.08.1998	CLOCKRADIO
AJ3940/10	1041Clock radio		CLOCKRADIO
AJ3940/14	1041Clock radio	1.10.1998	CLOCKRADIO
AJ3940/17	1041Clock radio	1.05.1998	CLOCKRADIO
AJ3941/17	1041Clock radio		CLOCKRADIO
AJ3950/00	1041Clock radio	1.06.2001	CLOCKRADIO
AJ3950/05	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3950/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3951/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3952/17	1041Clock radio	1.08.2001	CLOCKRADIO
AJ3953/17	1041Clock radio	1.11.2001	CLOCKRADIO
AJ3965/00	1041Clock radio	1.08.2000	CLOCKRADIO
AJ3965/01	1041Clock radio	1.07.2000	CLOCKRADIO
AJ3965/05	1041Clock radio	1.08.2000	CLOCKRADIO
AJ3965/17	1041Clock radio	1.05.2000	CLOCKRADIO
AJ3970/00	Clock radio		CLOCKRADIO
AJ3970/05	Clock radio		CLOCKRADIO

AJ3970/17	Clock radio		CLOCKRADIO
AK271/00	1049	1.03.1992	MIDISYSTEMS
AK281/80	1049	1.07.1992	MIDISYSTEMS
AK281/80R	1049	1.01.1993	MIDISYSTEMS
AK530/00	1049	1.04.1992	MIDISYSTEMS
AK530/00S	1049	1.02.1993	MIDISYSTEMS
AK540/00	1049Tuners	1.06.1993	TUNERS
AK600/45	1049CD	1.07.1992	CD PLAYERS
AK630/00	1049	1.03.1992	MIDISYSTEMS
AK630/00B	1049	1.10.1992	MIDISYSTEMS
AK630/00R	1049	1.08.1992	MIDISYSTEMS
AK630/00T	1049	1.08.1993	MIDISYSTEMS
AK630/01	1049	1.04.1992	MIDISYSTEMS
AK630/01B	1049	1.06.1992	MIDISYSTEMS
AK630/05	1049	1.06.1992	MIDISYSTEMS
AK630/05R	1049	1.09.1992	MIDISYSTEMS
AK630/10B	1049	1.06.1992	MIDISYSTEMS
AK630/17B	1049	1.08.1992	MIDISYSTEMS
AK640/00	1049	1.08.1993	MIDISYSTEMS
AK640/01	1049	1.07.1993	MIDISYSTEMS
AK640/10	1049	1.09.1993	MIDISYSTEMS
AK640CL/15	1049CD		CD PLAYERS
AK691CL/15	1049CD		CD PLAYERS
AK729/17	1049	1.12.1992	MIDISYSTEMS
AK729/17H	1049	1.08.1993	MIDISYSTEMS
AK729/17M	1049	1.05.1992	MIDISYSTEMS
AK730/00	1049	1.04.1992	MIDISYSTEMS
AK730/00H	1049	1.06.1993	MIDISYSTEMS
AK730/01	1049	1.04.1992	MIDISYSTEMS
AK730/01Z	1049	1.08.1993	MIDISYSTEMS
AK730/05	1049	1.05.1992	MIDISYSTEMS
AK730/10	1049	1.07.1992	MIDISYSTEMS
AK730/17	1049	1.12.1992	MIDISYSTEMS
AK730/17M	1049	1.06.1992	MIDISYSTEMS
AL244/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
AM140/00I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO
AM160/00I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO
AMARYS165/B	1003		TELEPHONES CORDLESS
AMARYSA/355	1003		TELEPHONES CORDLESS
AMARYSP/355	1003		TELEPHONES CORDLESS
AQ4010/00	1041Radio cassette recorders - mono	1.02.1993	RADIO MONO + STEREO
AQ4010/05	1041Radio cassette recorders - mono	1.08.1993	RADIO MONO + STEREO

AQ4030/01	1041Radio cassette recorders - mono	1.02.1994	RADIO MONO + STEREO
AQ4050/05	1041Radio cassette recorders - mono	1.07.1996	RADIO MONO + STEREO
AQ4050/10	1041Radio cassette recorders - mono	1.08.1996	RADIO MONO + STEREO
AQ4050/11	1041Radio cassette recorders - mono	1.05.1998	RADIO MONO + STEREO
AQ4050/17	1041Radio cassette recorders - mono	1.08.1996	RADIO MONO + STEREO
AQ4150/00	1041Radio cassette recorders - mono	1.09.1995	RADIO MONO + STEREO
AQ4150/00M	1041Radio cassette recorders - mono	1.03.1996	RADIO MONO + STEREO
AQ4150/00S	1041Radio cassette recorders - mono	1.05.1999	RADIO MONO + STEREO
AQ4150/01	1041Radio cassette recorders - mono	1.09.1995	RADIO MONO + STEREO
AQ4150/01S	1041Radio cassette recorders - mono	1.05.1999	RADIO MONO + STEREO
AQ4150/04	1041Radio cassette recorders - mono	1.09.1995	RADIO MONO + STEREO
AQ4150/04S	1041Radio cassette recorders - mono	1.05.1999	RADIO MONO + STEREO
AQ4150/05	1041Radio cassette recorders - mono	1.10.1995	RADIO MONO + STEREO
AQ4150/05S	1041Radio cassette recorders - mono	1.06.1999	RADIO MONO + STEREO
AQ4150/10	1041Radio cassette recorders - mono	1.09.1995	RADIO MONO + STEREO
AQ4150/11	1041Radio cassette recorders - mono	1.12.1995	RADIO MONO + STEREO
AQ4150/11S	1041Radio cassette recorders - mono	1.05.1999	RADIO MONO + STEREO
AQ4150/13	1041Radio cassette recorders - mono		RADIO MONO + STEREO
AQ4150/13S	1041Radio cassette recorders - mono		RADIO MONO + STEREO
AQ4150/14	1041Radio cassette recorders - mono	1.01.1996	RADIO MONO + STEREO
AQ4150/14S	1041Radio cassette recorders - mono	1.06.1999	RADIO MONO + STEREO
AQ4180CL/15	1041Radio cassette recorders - mono		RADIO MONO + STEREO
AQ4420/00	1041Radio cassette recorders - mono	1.02.1994	RADIO MONO + STEREO
AQ4420/00M	1041Radio cassette recorders - mono	1.10.1994	RADIO MONO + STEREO
AQ4420/01	1041Radio cassette recorders - mono	1.10.1993	RADIO MONO + STEREO
AQ4420/04	1041Radio cassette recorders - mono	1.02.1994	RADIO MONO + STEREO
AQ4420/04M	1041Radio cassette recorders - mono	1.10.1994	RADIO MONO + STEREO
AQ4420/05	1041Radio cassette recorders - mono	1.04.1994	RADIO MONO + STEREO
AQ4420/14	1041Radio cassette recorders - mono	1.01.1994	RADIO MONO + STEREO
AQ4420/14M	1041Radio cassette recorders - mono	1.09.1994	RADIO MONO + STEREO
AQ4460/11	1041Radio cassette recorders - stereo	1.07.1999	RADIO MONO + STEREO
AQ4460/13	1041Radio cassette recorders - stereo		RADIO MONO + STEREO
AQ5010/17	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5030/01	1041Radio cassette recorders - mono	1.03.1993	RADIO MONO + STEREO
AQ5040/00	1041Radio cassette recorders - mono	1.09.1993	RADIO MONO + STEREO
AQ5040/01	1041Radio cassette recorders - mono	1.10.1993	RADIO MONO + STEREO
AQ5040/04	1041Radio cassette recorders - mono	1.09.1993	RADIO MONO + STEREO
AQ5040/04M	1041Radio cassette recorders - mono	1.10.1994	RADIO MONO + STEREO
AQ5040/14	1041Radio cassette recorders - mono	1.11.1993	RADIO MONO + STEREO
AQ5040/14M	1041Radio cassette recorders - mono	1.11.1994	RADIO MONO + STEREO
AQ5040/20	1041Radio cassette recorders - mono	1.05.1994	RADIO MONO + STEREO
AQ5040/20M	1041Radio cassette recorders - mono	1.10.1994	RADIO MONO + STEREO

AQ5040CL/15	1041Radio cassette recorders - mono		RADIO MONO + STEREO
AQ5050/00	1041Radio cassette recorders - stereo	1.07.1996	RADIO MONO + STEREO
AQ5050/05	1041Radio cassette recorders - stereo	1.07.1995	RADIO MONO + STEREO
AQ5050/10Z	1041Radio cassette recorders - stereo	1.03.1997	RADIO MONO + STEREO
AQ5050/17	1041Radio cassette recorders - stereo	1.06.1995	RADIO MONO + STEREO
AQ5051/17	1041Radio cassette recorders - stereo	1.05.1995	RADIO MONO + STEREO
AQ5055/05	1041Radio cassette recorders - stereo	1.06.1996	RADIO MONO + STEREO
AQ5110/17	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5120/17	1041Radio cassette recorders - mono	1.08.1992	RADIO MONO + STEREO
AQ5130/01	1041Radio cassette recorders - mono	1.02.1994	RADIO MONO + STEREO
AQ5130/10	1041Radio cassette recorders - mono	1.08.1993	RADIO MONO + STEREO
AQ5130/17	1041Radio cassette recorders - mono	1.05.1993	RADIO MONO + STEREO
AQ5131/17	1041Radio cassette recorders - mono	1.04.1994	RADIO MONO + STEREO
AQ5150/00	1041Radio cassette recorders - stereo	1.09.1995	RADIO MONO + STEREO
AQ5150/00P	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AQ5150/00S	1041Radio cassette recorders - stereo	1.05.1999	RADIO MONO + STEREO
AQ5150/01	1041Radio cassette recorders - stereo	1.08.1995	RADIO MONO + STEREO
AQ5150/01P	1041Radio cassette recorders - stereo	1.05.1996	RADIO MONO + STEREO
AQ5150/01S	1041Radio cassette recorders - stereo	1.06.1999	RADIO MONO + STEREO
AQ5150/04	1041Radio cassette recorders - stereo	1.09.1995	RADIO MONO + STEREO
AQ5150/04P	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AQ5150/04S	1041Radio cassette recorders - stereo	1.06.1999	RADIO MONO + STEREO
AQ5150/05P	1041Radio cassette recorders - stereo	1.06.1998	RADIO MONO + STEREO
AQ5150/05S	1041Radio cassette recorders - stereo	1.08.1999	RADIO MONO + STEREO
AQ5150/11	1041Radio cassette recorders - stereo	1.12.1995	RADIO MONO + STEREO
AQ5150/11P	1041Radio cassette recorders - stereo	1.06.1996	RADIO MONO + STEREO
AQ5150/11S	1041Radio cassette recorders - stereo	1.06.1999	RADIO MONO + STEREO
AQ5150/13	1041Radio cassette recorders - stereo		RADIO MONO + STEREO
AQ5150/13S	1041Radio cassette recorders - stereo	1.08.2001	RADIO MONO + STEREO
AQ5150/14	1041Radio cassette recorders - stereo	1.11.1995	RADIO MONO + STEREO
AQ5150/14P	1041Radio cassette recorders - stereo	1.07.1996	RADIO MONO + STEREO
AQ5150/14S	1041Radio cassette recorders - stereo	1.07.1999	RADIO MONO + STEREO
AQ5160/01	1041Radio cassette recorders - stereo	1.09.1998	RADIO MONO + STEREO
AQ5160/11	1041Radio cassette recorders - stereo	1.01.1998	RADIO MONO + STEREO
AQ5190/20	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5190/30	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5191/21	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5192/20	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5210/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5210/20	1041Radio cassette recorders - mono	1.04.1992	RADIO MONO + STEREO
AQ5211/01	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5211CL/15	1041Radio cassette recorders - mono		RADIO MONO + STEREO

AQ5212/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5212/14	1041Radio cassette recorders - mono	1.06.1992	RADIO MONO + STEREO
AQ5310/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5310/17	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5311/01	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5312/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5312/05	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5315/17	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5410/06	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5414/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5414/05	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AQ5460/11	1041Radio cassette recorders - stereo	1.05.1999	RADIO MONO + STEREO
AQ5460/13	1041Radio cassette recorders - stereo		RADIO MONO + STEREO
AQ5520/01	1041Radio cassette recorders - mono	1.11.1992	RADIO MONO + STEREO
AQ5521/17Z	1041Radio + Cassette	1.07.1997	PERSONAL STEREO
AQ5550/01	1041Radio cassette recorders - stereo	1.08.1996	RADIO MONO + STEREO
AQ5550/11	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AQ5550/12	1041Radio cassette recorders - mono	1.11.1997	RADIO MONO + STEREO
AQ5850/01	1041Radio cassette recorders - stereo	1.08.1998	RADIO MONO + STEREO
AQ5850/11	1041Radio cassette recorders - stereo	1.08.1998	RADIO MONO + STEREO
AQ5850/12	1041Radio cassette recorders - mono	1.09.1998	RADIO MONO + STEREO
AQ6314/17	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6316/17	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6340/00	1041Cassette only	1.08.1996	PERSONAL STEREO
AQ6340/00Z	1041Cassette only	1.09.1996	PERSONAL STEREO
AQ6340/14Z	1041Cassette only	1.11.1996	PERSONAL STEREO
AQ6345/00	1041Radio + Cassette	1.06.2000	PERSONAL STEREO
AQ6345/01Z	1041Radio + Cassette	1.06.2000	PERSONAL STEREO
AQ6345/14	1041Radio + Cassette	1.04.2000	PERSONAL STEREO
AQ6346/37	1042Radio + Cassette		PERSONAL STEREO
AQ6350/00	1041Radio + Cassette	1.06.1993	PERSONAL STEREO
AQ6350/05	1041Radio + Cassette	1.06.1993	PERSONAL STEREO
AQ6355/00	1041Cassette only	1.10.1997	PERSONAL STEREO
AQ6355/05	1041Cassette only	1.10.1997	PERSONAL STEREO
AQ6355/17	1041Cassette only	1.07.1998	PERSONAL STEREO
AQ6355/17Z	1041Radio + Cassette	1.08.2001	PERSONAL STEREO
AQ6390/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6390/17	1041Cassette only	1.03.1992	PERSONAL STEREO
AQ6401/00	1041Cassette only	1.03.1992	PERSONAL STEREO
AQ6401/00Z	Cassette only		PERSONAL STEREO
AQ6404/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6404/00S	1041Radio + Cassette	1.03.1992	PERSONAL STEREO

AQ6408/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6411/00	1041Cassette only	1.03.1999	PERSONAL STEREO
AQ6413/00	1041Cassette only	1.03.1999	PERSONAL STEREO
AQ6414/00	1041Cassette only	1.09.1999	PERSONAL STEREO
AQ6421/00	1041Radio + Cassette	1.09.1992	PERSONAL STEREO
AQ6421/18	1041Radio + Cassette	1.12.1992	PERSONAL STEREO
AQ6422/00	1041Radio + Cassette	1.02.1993	PERSONAL STEREO
AQ6426/00	1041Radio + Cassette	1.10.1992	PERSONAL STEREO
AQ6426/06	1041Radio + Cassette	1.08.1994	PERSONAL STEREO
AQ6426/20	1041Radio + Cassette	1.04.1993	PERSONAL STEREO
AQ6439/12	1041Radio + Cassette	1.01.1996	PERSONAL STEREO
AQ6440/00	1041Radio + Cassette	1.08.1995	PERSONAL STEREO
AQ6440/12	1041Radio + Cassette	1.09.1995	PERSONAL STEREO
AQ6440/17	1041Radio + Cassette	1.06.1995	PERSONAL STEREO
AQ6441/00	1041Radio + Cassette	1.05.1995	PERSONAL STEREO
AQ6441/00M	1041Radio + Cassette	1.05.1996	PERSONAL STEREO
AQ6441/00Z	1041Radio + Cassette	1.07.1995	PERSONAL STEREO
AQ6441/12	1041Radio + Cassette	1.08.1995	PERSONAL STEREO
AQ6442/00	1041Radio + Cassette	1.07.1995	PERSONAL STEREO
AQ6442/00K	1041Radio + Cassette	1.04.1996	PERSONAL STEREO
AQ6443/00	1041Radio + Cassette	1.02.1995	PERSONAL STEREO
AQ6443/00K	1041Radio + Cassette	1.02.1996	PERSONAL STEREO
AQ6443/00Z	1041Radio + Cassette	1.06.1995	PERSONAL STEREO
AQ6443/01Z	1041Radio + Cassette	1.05.1995	PERSONAL STEREO
AQ6445/00	1041Radio + Cassette	1.07.1995	PERSONAL STEREO
AQ6445/00K	1041Radio + Cassette	1.04.1996	PERSONAL STEREO
AQ6446/00	1041Radio + Cassette	1.02.1995	PERSONAL STEREO
AQ6446/00K	1041Radio + Cassette	1.03.1996	PERSONAL STEREO
AQ6446/12	1041Radio + Cassette	1.10.1995	PERSONAL STEREO
AQ6455/00	1041Cassette only	1.11.1997	PERSONAL STEREO
AQ6455/05	1041Cassette only	1.03.1998	PERSONAL STEREO
AQ6463/00	1041Cassette only	1.09.1996	PERSONAL STEREO
AQ6463/00Z	1041Cassette only	1.01.1997	PERSONAL STEREO
AQ6463/11	1041Cassette only	1.11.1996	PERSONAL STEREO
AQ6463/14	1041Cassette only	1.01.1997	PERSONAL STEREO
AQ6481/00	1041Cassette only	1.08.1997	PERSONAL STEREO
AQ6481/01	1041Cassette only	1.03.1998	PERSONAL STEREO
AQ6481/12	1041Radio + Cassette	1.12.1997	PERSONAL STEREO
AQ6481/14	1041Cassette only	1.09.1997	PERSONAL STEREO
AQ6481/17Z	1041Cassette only	1.06.1997	PERSONAL STEREO
AQ6481/32	1041Radio + Cassette	1.09.1997	PERSONAL STEREO
AQ6482/00	1041Cassette only	1.08.1997	PERSONAL STEREO

AQ6482/00B	1041Cassette only	1.10.1997	PERSONAL STEREO
AQ6482/00G	1041Cassette only	1.05.1998	PERSONAL STEREO
AQ6482/00S	1041Cassette only	1.06.1998	PERSONAL STEREO
AQ6483/00	1041Cassette only	1.09.1997	PERSONAL STEREO
AQ6483/00Z	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6483/11	1041Radio + Cassette		PERSONAL STEREO
AQ6483/12	1041Radio + Cassette	1.01.1998	PERSONAL STEREO
AQ6483/32	1041Radio + Cassette	1.12.1997	PERSONAL STEREO
AQ6485/00	1041Cassette only	1.03.1998	PERSONAL STEREO
AQ6485/00Z	1041Cassette only	1.06.1998	PERSONAL STEREO
AQ6485/14	1041Cassette only	1.05.1998	PERSONAL STEREO
AQ6487/00	1041Radio + Cassette	1.09.1997	PERSONAL STEREO
AQ6487/00S	1041Cassette only	1.05.1998	PERSONAL STEREO
AQ6487/12	1041Radio + Cassette	1.11.1998	PERSONAL STEREO
AQ6487/14	1041Cassette only	1.10.1997	PERSONAL STEREO
AQ6487/14S	1041Cassette only	1.06.1998	PERSONAL STEREO
AQ6490/17	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6491/17Z	1041Cassette only	1.04.1999	PERSONAL STEREO
AQ6492/00	1041Cassette only	1.03.1999	PERSONAL STEREO
AQ6492/00Z	1041Cassette only	1.05.1999	PERSONAL STEREO
AQ6492/14	1041Cassette only	1.04.1999	PERSONAL STEREO
AQ6495/00	1041Radio + Cassette		PERSONAL STEREO
AQ6495/00C	1041Cassette only	1.09.2001	PERSONAL STEREO
AQ6495/00Z	1041Cassette only	1.10.2001	PERSONAL STEREO
AQ6495/14	1041Radio + Cassette		PERSONAL STEREO
AQ6507/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6508/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6511/00	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6511/01	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6511/01Z	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6511/17	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6511/17Z	1041Radio + Cassette	1.07.1999	PERSONAL STEREO
AQ6512/00	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6512/01	1041Radio + Cassette	1.10.1998	PERSONAL STEREO
AQ6512/01Z	1041Radio + Cassette	1.11.1998	PERSONAL STEREO
AQ6512/17Z	1041Radio + Cassette	1.07.1999	PERSONAL STEREO
AQ6513/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6513/01	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6513/01Z	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6513/17Z	1041Radio + Cassette	1.07.1999	PERSONAL STEREO
AQ6513/18	1041Radio + Cassette	1.12.1992	PERSONAL STEREO
AQ6513/20	1041Radio + Cassette	1.06.1992	PERSONAL STEREO

AQ6514/00	1041Radio + Cassette	1.03.1999	PERSONAL STEREO
AQ6514/01	1041Radio + Cassette	1.10.1998	PERSONAL STEREO
AQ6514/01Z	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6514/17	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6518/00S	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6519/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6519/17	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6521/00	1041Radio + Cassette	1.08.1993	PERSONAL STEREO
AQ6521/00Z	1041Radio + Cassette	1.11.1994	PERSONAL STEREO
AQ6521/09	1041Radio + Cassette	1.11.1994	PERSONAL STEREO
AQ6521/12	1041Radio + Cassette	1.11.1994	PERSONAL STEREO
AQ6521/17	1041Radio + Cassette	1.05.1993	PERSONAL STEREO
AQ6523/17	1041Radio + Cassette	1.08.1993	PERSONAL STEREO
AQ6524/00	1041Radio + Cassette	1.02.1993	PERSONAL STEREO
AQ6524/00Z	1041Radio + Cassette	1.04.1993	PERSONAL STEREO
AQ6524/11	1041Radio + Cassette	1.03.1993	PERSONAL STEREO
AQ6524/19	1041Radio + Cassette	1.08.1994	PERSONAL STEREO
AQ6525/00	1041Radio + Cassette	1.08.1993	PERSONAL STEREO
AQ6525/11	1041Radio + Cassette		PERSONAL STEREO
AQ6525/19	1041Radio + Cassette	1.08.1994	PERSONAL STEREO
AQ6525/20	1041Radio + Cassette	1.12.1994	PERSONAL STEREO
AQ6526/00	1041Radio + Cassette	1.02.1993	PERSONAL STEREO
AQ6527/00	1041Radio + Cassette	1.02.1994	PERSONAL STEREO
AQ6528/00	1041Radio + Cassette	1.09.1992	PERSONAL STEREO
AQ6528/11	1041Radio + Cassette	1.04.1993	PERSONAL STEREO
AQ6529/00	1041Radio + Cassette	1.02.1993	PERSONAL STEREO
AQ6529/01	1041Radio + Cassette	1.05.1993	PERSONAL STEREO
AQ6529/19	1041Radio + Cassette	1.10.1994	PERSONAL STEREO
AQ6529CL/15	1041Radio + Cassette		PERSONAL STEREO
AQ6540/00	1041Radio + Cassette	1.05.1995	PERSONAL STEREO
AQ6540/00Z	1041Radio + Cassette	1.06.1995	PERSONAL STEREO
AQ6540/12	1041Radio + Cassette	1.12.1995	PERSONAL STEREO
AQ6540/17	1041Radio + Cassette	1.05.1995	PERSONAL STEREO
AQ6542/00	1041Radio + Cassette	1.02.1995	PERSONAL STEREO
AQ6542/00K	1041Radio + Cassette	1.03.1996	PERSONAL STEREO
AQ6542/00Z	1041Radio + Cassette	1.07.1995	PERSONAL STEREO
AQ6542/01	1041Radio + Cassette	1.04.1996	PERSONAL STEREO
AQ6542/01Z	1041Radio + Cassette	1.05.1995	PERSONAL STEREO
AQ6542/11	1041Radio + Cassette	1.06.1995	PERSONAL STEREO
AQ6545/00	1041Radio + Cassette	1.05.1995	PERSONAL STEREO
AQ6545/00Z	1041Radio + Cassette	1.09.1995	PERSONAL STEREO
AQ6545/17	1041Radio + Cassette	1.05.1995	PERSONAL STEREO

AQ6546/00	1041Radio + Cassette	1.08.1995	PERSONAL STEREO
AQ6546/00K	1041Radio + Cassette	1.04.1996	PERSONAL STEREO
AQ6546/01Z	1041Radio + Cassette	1.09.1995	PERSONAL STEREO
AQ6546/11	1041Radio + Cassette	1.12.1996	PERSONAL STEREO
AQ6547/00	1041Radio + Cassette	1.09.1996	PERSONAL STEREO
AQ6547/00B	1041Radio + Cassette	1.02.1998	PERSONAL STEREO
AQ6547/00S	1041Radio + Cassette	1.02.1998	PERSONAL STEREO
AQ6547/01	1041Radio + Cassette	1.10.1996	PERSONAL STEREO
AQ6547/10	1041Radio + Cassette	1.12.1996	PERSONAL STEREO
AQ6547/10G	1041Radio + Cassette	1.11.1997	PERSONAL STEREO
AQ6547/10L	1041Radio + Cassette	1.11.1997	PERSONAL STEREO
AQ6547/10S	1041Radio + Cassette	1.11.1997	PERSONAL STEREO
AQ6547/14P	1041Radio + Cassette	1.03.1997	PERSONAL STEREO
AQ6548/00	1041Radio + Cassette	1.03.1995	PERSONAL STEREO
AQ6548/01Z	1041Radio + Cassette	1.07.1995	PERSONAL STEREO
AQ6549/00	1041Radio + Cassette	1.03.1995	PERSONAL STEREO
AQ6549/00G	1041Radio + Cassette	1.08.1996	PERSONAL STEREO
AQ6549/01Z	1041Radio + Cassette	1.06.1995	PERSONAL STEREO
AQ6560/00	1041Radio + Cassette	1.09.1996	PERSONAL STEREO
AQ6560/00B	1041Radio + Cassette	1.11.1997	PERSONAL STEREO
AQ6560/00G	1041Radio + Cassette	1.03.1998	PERSONAL STEREO
AQ6560/01	1041Radio + Cassette	1.08.1996	PERSONAL STEREO
AQ6560/01B	1041Radio + Cassette	1.12.1997	PERSONAL STEREO
AQ6560/01G	1041Radio + Cassette	1.12.1997	PERSONAL STEREO
AQ6560/01L	1041Radio + Cassette	1.12.1997	PERSONAL STEREO
AQ6560/01S	1041Radio + Cassette	1.12.1997	PERSONAL STEREO
AQ6560/01Z	1041Radio + Cassette	1.10.1996	PERSONAL STEREO
AQ6560/10	1041Radio + Cassette	1.09.1996	PERSONAL STEREO
AQ6560/10B	1041Radio + Cassette	1.11.1996	PERSONAL STEREO
AQ6560/10G	1041Radio + Cassette	1.08.1997	PERSONAL STEREO
AQ6560/10L	1041Radio + Cassette	1.08.1997	PERSONAL STEREO
AQ6560/10S	1041Radio + Cassette	1.08.1997	PERSONAL STEREO
AQ6560/12	1041Radio + Cassette	1.07.1997	PERSONAL STEREO
AQ6560/14P	1041Radio + Cassette	1.03.1997	PERSONAL STEREO
AQ6560/17	1041Radio + Cassette	1.06.1996	PERSONAL STEREO
AQ6560/21Z	1041Radio + Cassette	1.07.1998	PERSONAL STEREO
AQ6560/34K	1041Radio + Cassette	1.05.1998	PERSONAL STEREO
AQ6560/B10	1041Radio + Cassette	1.07.1997	PERSONAL STEREO
AQ6562/00	1041Radio + Cassette	1.08.1996	PERSONAL STEREO
AQ6562/00Z	1041Radio + Cassette	1.11.1996	PERSONAL STEREO
AQ6562/01	1041Radio + Cassette	1.10.1996	PERSONAL STEREO
AQ6562/01Z	1041Radio + Cassette	1.10.1996	PERSONAL STEREO

AQ6562/11	1041Radio + Cassette	1.09.1996	PERSONAL STEREO
AQ6562/11H	1041Radio + Cassette	1.09.1996	PERSONAL STEREO
AQ6562/14	1041Radio + Cassette	1.03.1997	PERSONAL STEREO
AQ6563/00	1041Radio + Cassette	1.09.1996	PERSONAL STEREO
AQ6563/01	1041Radio + Cassette	1.10.1996	PERSONAL STEREO
AQ6563/03	1041Radio + Cassette	1.10.1996	PERSONAL STEREO
AQ6563/11	1041Radio + Cassette	1.09.1996	PERSONAL STEREO
AQ6563/14P	1041Radio + Cassette	1.03.1997	PERSONAL STEREO
AQ6567/17	1041Radio + Cassette	1.11.1996	PERSONAL STEREO
AQ6570/17Z	1041Radio + Cassette	1.04.1998	PERSONAL STEREO
AQ6570/40	1041Radio + Cassette		PERSONAL STEREO
AQ6581/00	1041Radio + Cassette	1.03.1998	PERSONAL STEREO
AQ6581/00M	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6581/00Z	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6581/01	1041Radio + Cassette	1.05.1998	PERSONAL STEREO
AQ6581/01Z	1041Radio + Cassette	1.05.1998	PERSONAL STEREO
AQ6581/10	1041Radio + Cassette		PERSONAL STEREO
AQ6581/11	1041Radio + Cassette	1.07.1998	PERSONAL STEREO
AQ6581/12	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6581/14	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6581/14A	1041Radio + Cassette	1.04.1998	PERSONAL STEREO
AQ6581/17Z	1041Radio + Cassette	1.03.1998	PERSONAL STEREO
AQ6582/01	1041Radio + Cassette	1.02.1999	PERSONAL STEREO
AQ6582/17Z	1041Radio + Cassette	1.11.1999	PERSONAL STEREO
AQ6583/01	1041Radio + Cassette	1.08.1998	PERSONAL STEREO
AQ6583/01Z	1041Radio + Cassette	1.11.1998	PERSONAL STEREO
AQ6583/11	1041Radio + Cassette	1.02.1999	PERSONAL STEREO
AQ6585/00	1041Radio + Cassette	1.03.1998	PERSONAL STEREO
AQ6585/00Z	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6585/01	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6585/01Z	1041Radio + Cassette	1.08.1998	PERSONAL STEREO
AQ6585/11	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6585/14	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6587/00	1041Radio + Cassette	1.08.1997	PERSONAL STEREO
AQ6587/01	1041Radio + Cassette	1.09.1997	PERSONAL STEREO
AQ6587/01S	1041Radio + Cassette	1.08.1998	PERSONAL STEREO
AQ6587/14S	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6587/17Z	1041Radio + Cassette	1.05.1997	PERSONAL STEREO
AQ6588/00	1041Radio + Cassette	1.08.1997	PERSONAL STEREO
AQ6588/00S	1041Radio + Cassette	1.08.1998	PERSONAL STEREO
AQ6588/01	1041Radio + Cassette	1.08.1997	PERSONAL STEREO
AQ6588/01P	1041Radio + Cassette	1.12.1996	PERSONAL STEREO

AQ6588/11S	1041Radio + Cassette		PERSONAL STEREO
AQ6588/14	1041Radio + Cassette	1.09.1997	PERSONAL STEREO
AQ6588/14S	1041Radio + Cassette	1.05.1998	PERSONAL STEREO
AQ6591/00	1041Radio + Cassette	1.07.2000	PERSONAL STEREO
AQ6591/00Z	1041Radio + Cassette	1.08.2000	PERSONAL STEREO
AQ6591/01	1041Radio + Cassette	1.05.2000	PERSONAL STEREO
AQ6591/01Z	1041Radio + Cassette	1.05.2000	PERSONAL STEREO
AQ6591/14	1041Radio + Cassette	1.02.2001	PERSONAL STEREO
AQ6591/17Z	1041Radio + Cassette	1.04.2000	PERSONAL STEREO
AQ6591/19E	Radio + Cassette		PERSONAL STEREO
AQ6595/00	1041Radio + Cassette		PERSONAL STEREO
AQ6595/00C	1041Radio + Cassette	1.09.2001	PERSONAL STEREO
AQ6595/14	1041Radio + Cassette		PERSONAL STEREO
AQ6597/07Z	1041Radio + Cassette		PERSONAL STEREO
AQ6597/17Z	1041Radio + Cassette	1.05.1998	PERSONAL STEREO
AQ6598/00	1041Radio + Cassette	1.06.2000	PERSONAL STEREO
AQ6598/01	1041Radio + Cassette	1.06.2000	PERSONAL STEREO
AQ6598/01Z	1041Radio + Cassette	1.08.2000	PERSONAL STEREO
AQ6598/17Z	1041Radio + Cassette	1.08.2001	PERSONAL STEREO
AQ6601/00	1041Radio + Cassette		PERSONAL STEREO
AQ6601/00C	1041Radio + Cassette	1.09.2001	PERSONAL STEREO
AQ6601/14	1041Radio + Cassette		PERSONAL STEREO
AQ6603/17Z	1041Radio + Cassette	1.06.1997	PERSONAL STEREO
AQ6604/17Z	1041Radio + Cassette	1.06.1997	PERSONAL STEREO
AQ6605/17Z	1041Radio + Cassette	1.06.1997	PERSONAL STEREO
AQ6606/17Z	1041Radio + Cassette	1.06.1997	PERSONAL STEREO
AQ6613/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6613/01	1041Radio + Cassette	1.06.1992	PERSONAL STEREO
AQ6613/05	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6617/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6617/01	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6617/05	1041Radio + Cassette	1.05.1992	PERSONAL STEREO
AQ6619/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6619/01	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
AQ6619/05	1041Radio + Cassette	1.08.1992	PERSONAL STEREO
AQ6681/00	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6681/00Z	1041Radio + Cassette	1.08.1999	PERSONAL STEREO
AQ6681/01	1041Radio + Cassette	1.06.1998	PERSONAL STEREO
AQ6681/01Z	1041Radio + Cassette	1.02.1999	PERSONAL STEREO
AQ6681/07Z	1041Radio + Cassette		PERSONAL STEREO
AQ6681/11	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6681/12	1041Radio + Cassette	1.12.1998	PERSONAL STEREO

AQ6681/14	1041Radio + Cassette	1.05.1998	PERSONAL STEREO
AQ6681/17Z	1041Radio + Cassette	1.03.1998	PERSONAL STEREO
AQ6682/01	1041Radio + Cassette		PERSONAL STEREO
AQ6682/17Z	1041Radio + Cassette	1.05.1999	PERSONAL STEREO
AQ6688/00	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6688/01	1041Radio + Cassette	1.12.1996	PERSONAL STEREO
AQ6688/11	1041Radio + Cassette	1.12.1998	PERSONAL STEREO
AQ6688/14	1041Radio + Cassette	1.09.1998	PERSONAL STEREO
AQ6688/17Z	1041Radio + Cassette	1.08.1998	PERSONAL STEREO
AQ6689/01	1041Radio + Cassette	1.12.1996	PERSONAL STEREO
AQ6691/00	1041Radio + Cassette	1.06.2000	PERSONAL STEREO
AQ6691/00Z	1041Radio + Cassette	1.06.2000	PERSONAL STEREO
AQ6691/01	1041Radio + Cassette	1.06.2000	PERSONAL STEREO
AQ6691/01Z	1041Radio + Cassette	1.06.2000	PERSONAL STEREO
AQ6691/14	1041Radio + Cassette	1.02.2001	PERSONAL STEREO
AQ6691/17	Radio + Cassette		PERSONAL STEREO
AQ6691/17Z	1041Radio + Cassette	1.05.2000	PERSONAL STEREO
AQ6691/19	Radio + Cassette		PERSONAL STEREO
AQ6691/19E	Radio + Cassette		PERSONAL STEREO
AQ6720/01Z	1041Radio + Cassette	1.06.1997	PERSONAL STEREO
AQ6720/10Z	1041Radio + Cassette	1.11.1996	PERSONAL STEREO
AQ6820/00	1041Radio + Cassette	1.03.1997	PERSONAL STEREO
AQ6820/01	1041Radio + Cassette	1.08.1997	PERSONAL STEREO
AQ6840/00	1041Radio + Cassette	1.03.1997	PERSONAL STEREO
AQ6840/01	1041Radio + Cassette	1.01.1998	PERSONAL STEREO
AQ6840/11	1041Radio + Cassette		PERSONAL STEREO
AQ6860/00	1041Radio + Cassette	1.03.1997	PERSONAL STEREO
AQ6860/01	1041Radio + Cassette	1.01.1998	PERSONAL STEREO
AQ6860/11	1041Radio + Cassette		PERSONAL STEREO
AS130CL/15	1049		MIDISYSTEMS
AS135/21	1049	1.07.1993	MIDISYSTEMS
AS135/30	1049	1.09.1993	MIDISYSTEMS
AS135/34	1049	1.09.1993	MIDISYSTEMS
AS230/01	1049	1.08.1993	MIDISYSTEMS
AS230/22	1049	1.08.1993	MIDISYSTEMS
AS230CL/15	1049		MIDISYSTEMS
AS235/21	1049	1.08.1993	MIDISYSTEMS
AS301/20	1049	1.05.1992	MIDISYSTEMS
AS301/21	1049	1.06.1992	MIDISYSTEMS
AS301/22	1049	1.05.1992	MIDISYSTEMS
AS305/20	1049	1.03.1992	MIDISYSTEMS
AS305/20B	1049	1.09.1992	MIDISYSTEMS

AS305/21	1049	1.04.1992	MIDISYSTEMS
AS305/21B	1049	1.04.1992	MIDISYSTEMS
AS305/30	1049	1.06.1992	MIDISYSTEMS
AS305/34	1049	1.09.1992	MIDISYSTEMS
AS305/37	1049	1.06.1992	MIDISYSTEMS
AS305/37R	1049	1.06.1995	MIDISYSTEMS
AS400/37	1049	1.05.1992	MIDISYSTEMS
AS401/01	1049	1.06.1992	MIDISYSTEMS
AS401/17	1049	1.08.1992	MIDISYSTEMS
AS401/20	1049	1.05.1992	MIDISYSTEMS
AS401/20R	1049	1.09.1992	MIDISYSTEMS
AS401/21	1049	1.06.1992	MIDISYSTEMS
AS401/22	1049	1.05.1992	MIDISYSTEMS
AS401/22R	1049	1.10.1992	MIDISYSTEMS
AS401/37	1049	1.06.1992	MIDISYSTEMS
AS405/00	1049	1.06.1992	MIDISYSTEMS
AS405/00R	1049	1.08.1992	MIDISYSTEMS
AS405/10	1049	1.09.1992	MIDISYSTEMS
AS405/20	1049	1.04.1992	MIDISYSTEMS
AS405/20R	1049	1.05.1992	MIDISYSTEMS
AS405/21	1049	1.03.1992	MIDISYSTEMS
AS405/22	1049	1.08.1992	MIDISYSTEMS
AS405/22R	1049	1.12.1992	MIDISYSTEMS
AS405/25	1049	1.06.1992	MIDISYSTEMS
AS405/25R	1049	1.07.1992	MIDISYSTEMS
AS405/30	1049	1.06.1992	MIDISYSTEMS
AS405/37	1049	1.06.1992	MIDISYSTEMS
AS405/60	1049	1.09.1992	MIDISYSTEMS
AS440/20	1049	1.05.1993	MIDISYSTEMS
AS440/20G	1049	1.05.1994	MIDISYSTEMS
AS440/20H	1049	1.10.1993	MIDISYSTEMS
AS440/20P	1049	1.08.1993	MIDISYSTEMS
AS440/21	1049	1.07.1994	MIDISYSTEMS
AS440/21G	1049	1.12.1994	MIDISYSTEMS
AS440/22	1049	1.05.1993	MIDISYSTEMS
AS440/22G	1049	1.06.1994	MIDISYSTEMS
AS440/22H	1049	1.11.1993	MIDISYSTEMS
AS440/25	1049	1.07.1993	MIDISYSTEMS
AS440/25G	1049	1.09.1994	MIDISYSTEMS
AS440/25H	1049	1.01.1994	MIDISYSTEMS
AS440/37	1049	1.07.1993	MIDISYSTEMS
AS445/20	1049	1.08.1993	MIDISYSTEMS

AS445/20G	1049	1.06.1994	MIDISYSTEMS
AS445/21	1049	1.07.1993	MIDISYSTEMS
AS445/21G	1049	1.07.1994	MIDISYSTEMS
AS445/21R	1049	1.08.1994	MIDISYSTEMS
AS445/25	1049	1.09.1993	MIDISYSTEMS
AS445/30	1049	1.09.1993	MIDISYSTEMS
AS445/30G	1049	1.08.1994	MIDISYSTEMS
AS450/20	1049	1.02.1995	MIDISYSTEMS
AS450/21	1049	1.03.1995	MIDISYSTEMS
AS450/22	1049	1.02.1995	MIDISYSTEMS
AS455/20	1049	1.02.1995	MIDISYSTEMS
AS455/21	1049	1.03.1995	MIDISYSTEMS
AS455/22	1049	1.06.1995	MIDISYSTEMS
AS5000/37	1049Mini systems	1.08.1997	MINISYSTEMS
AS501/01	1049	1.07.1992	MIDISYSTEMS
AS501/20	1049	1.05.1992	MIDISYSTEMS
AS501/21	1049	1.05.1992	MIDISYSTEMS
AS501/22	1049	1.07.1992	MIDISYSTEMS
AS501/26	1049	1.09.1992	MIDISYSTEMS
AS501/30	1049	1.07.1992	MIDISYSTEMS
AS505/21	1049	1.05.1992	MIDISYSTEMS
AS505/26S	1049	1.03.1993	MIDISYSTEMS
AS540/20	1049	1.08.1993	MIDISYSTEMS
AS540/20B	1049	1.08.1993	MIDISYSTEMS
AS540/20G	1049	1.06.1994	MIDISYSTEMS
AS540/20R	1049	1.12.1994	MIDISYSTEMS
AS540/21	1049	1.10.1993	MIDISYSTEMS
AS540/21G	1049	1.07.1994	MIDISYSTEMS
AS540/22	1049	1.09.1993	MIDISYSTEMS
AS540/22G	1049	1.09.1994	MIDISYSTEMS
AS540/25	1049	1.09.1993	MIDISYSTEMS
AS545/21	1049	1.08.1993	MIDISYSTEMS
AS545/21G	1049	1.08.1994	MIDISYSTEMS
AS550/21	1049	1.03.1995	MIDISYSTEMS
AS601/01	1049	1.05.1992	MIDISYSTEMS
AS601/20	1049	1.09.1992	MIDISYSTEMS
AS601/28	1049	1.09.1992	MIDISYSTEMS
AS640/17	1049	1.10.1994	MIDISYSTEMS
AS640/20	1049	1.08.1993	MIDISYSTEMS
AS640/20B	1049	1.08.1993	MIDISYSTEMS
AS640/21	1049	1.10.1993	MIDISYSTEMS
AS640/22	1049	1.09.1993	MIDISYSTEMS

AS640/25	1049	1.09.1993	MIDISYSTEMS
AS640/37	1049	1.06.1993	MIDISYSTEMS
AS640CL/15	1049		MIDISYSTEMS
AS641/37	1049	1.09.1993	MIDISYSTEMS
AS642/37	1049	1.10.1993	MIDISYSTEMS
AS645/21	1049	1.07.1993	MIDISYSTEMS
AS645/30	1049	1.09.1993	MIDISYSTEMS
AS650/21	1049	1.02.1995	MIDISYSTEMS
AS655/21	1049	1.02.1995	MIDISYSTEMS
AS655/30	1049	1.04.1995	MIDISYSTEMS
AS660C/34	1049	1.03.1997	MIDISYSTEMS
AS660C/41	1049	1.02.1997	MIDISYSTEMS
AS665C/22	1049	1.04.1997	MIDISYSTEMS
AS665C/30	1049	1.01.1997	MIDISYSTEMS
AS665C/34	1049	1.05.1997	MIDISYSTEMS
AS665C/41	1049	1.12.1996	MIDISYSTEMS
AS665C/41B	1049	1.01.1998	MIDISYSTEMS
AS670C/34	1049	1.09.1998	MIDISYSTEMS
AS670C/41	1049	1.07.1997	MIDISYSTEMS
AS675C/34	1049	1.09.1998	MIDISYSTEMS
AS675C/41	1049	1.07.1997	MIDISYSTEMS
AS675C/41B	1049	1.04.1998	MIDISYSTEMS
AS680C/22	1049	1.02.1999	MIDISYSTEMS
AS680C/30	1049	1.04.1999	MIDISYSTEMS
AS680C/34	1049	1.04.1999	MIDISYSTEMS
AS701C/21	1049	1.03.1999	MIDISYSTEMS
AS740/37	1049	1.03.1995	MIDISYSTEMS
AS750C/37	1049	1.06.1996	MIDISYSTEMS
AS760C/41	1049	1.02.1997	MIDISYSTEMS
AS760C/41B	1049	1.01.1998	MIDISYSTEMS
AS765C/22S	1049	1.11.1997	MIDISYSTEMS
AS765C/41	1049	1.02.1997	MIDISYSTEMS
AS765C/41B	1049	1.01.1998	MIDISYSTEMS
AS770C/37	1049	1.08.1996	MIDISYSTEMS
AS780C/41	1049	1.08.1998	MIDISYSTEMS
AS785C/41	1049	1.07.1997	MIDISYSTEMS
AS9100/19	1049	1.03.1992	MIDISYSTEMS
AS9300/21	1049	1.03.1992	MIDISYSTEMS
AS9300/37	1049	1.03.1992	MIDISYSTEMS
AS9410/10	1049	1.03.1992	MIDISYSTEMS
AS9410/20R	1049	1.03.1992	MIDISYSTEMS
AS9410/21R	1049	1.03.1992	MIDISYSTEMS

AS9410/22R	1049	1.03.1992	MIDISYSTEMS
AS9410/28	1049	1.03.1992	MIDISYSTEMS
AS9510/21R	1049	1.03.1992	MIDISYSTEMS
AS9513/20	1049	1.03.1992	MIDISYSTEMS
AS9540/00I	1049	1.11.1996	MIDISYSTEMS
AS9604/19	1049	1.03.1992	MIDISYSTEMS
AV1000/75	1021High-end		VCR
AV7202/20G	1021Leader	1.03.1992	VCR
AV900/75	1021Leader	1.05.1997	VCR
AW434/00I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO
AW557/00I	1049	1.11.1996	MIDISYSTEMS
AW636/00I	1049	1.11.1996	MIDISYSTEMS
AW7010/00	1041Radio cassette recorders - mono	1.02.1993	RADIO MONO + STEREO
AW7010/05	1041Radio cassette recorders - mono	1.04.1993	RADIO MONO + STEREO
AW7030/01	1041Radio cassette recorders - mono	1.02.1994	RADIO MONO + STEREO
AW7030/10	1041Radio cassette recorders - mono	1.08.1993	RADIO MONO + STEREO
AW7030/17	1041Radio cassette recorders - mono	1.06.1993	RADIO MONO + STEREO
AW7035/01	1041Radio cassette recorders - mono	1.06.1994	RADIO MONO + STEREO
AW7035/17	1041Radio cassette recorders - mono	1.06.1993	RADIO MONO + STEREO
AW7050/00	1041Radio cassette recorders - mono	1.09.1996	RADIO MONO + STEREO
AW7050/05	1041Radio cassette recorders - stereo	1.08.1995	RADIO MONO + STEREO
AW7050/10	1041Radio cassette recorders - stereo	1.07.1996	RADIO MONO + STEREO
AW7050/17	1041Radio cassette recorders - stereo	1.08.1995	RADIO MONO + STEREO
AW7091/01	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7110/19S	1041Radio cassette recorders - mono	1.04.1992	RADIO MONO + STEREO
AW7140/00	1041Radio cassette recorders - mono	1.09.1993	RADIO MONO + STEREO
AW7140/00M	1041Radio cassette recorders - mono	1.10.1994	RADIO MONO + STEREO
AW7140/01	1041Radio cassette recorders - mono	1.09.1993	RADIO MONO + STEREO
AW7140/04	1041Radio cassette recorders - mono	1.09.1993	RADIO MONO + STEREO
AW7140/04M	1041Radio cassette recorders - mono	1.11.1994	RADIO MONO + STEREO
AW7140/14	1041Radio cassette recorders - mono	1.11.1993	RADIO MONO + STEREO
AW7140/14M	1041Radio cassette recorders - mono	1.09.1994	RADIO MONO + STEREO
AW7150/00	1041Radio cassette recorders - stereo	1.08.1995	RADIO MONO + STEREO
AW7150/00P	1041Radio cassette recorders - stereo	1.11.1996	RADIO MONO + STEREO
AW7150/00S	1041Radio cassette recorders - stereo	1.05.1999	RADIO MONO + STEREO
AW7150/01	1041Radio cassette recorders - stereo	1.09.1995	RADIO MONO + STEREO
AW7150/01P	1041Radio cassette recorders - stereo	1.06.1996	RADIO MONO + STEREO
AW7150/01S	1041Radio cassette recorders - stereo	1.06.1999	RADIO MONO + STEREO
AW7150/04	1041Radio cassette recorders - mono	1.09.1995	RADIO MONO + STEREO
AW7150/04S	1041Radio cassette recorders - stereo	1.06.1999	RADIO MONO + STEREO
AW7150/05P	1041Radio cassette recorders - stereo	1.06.1998	RADIO MONO + STEREO
AW7150/05S	1041Radio cassette recorders - stereo	1.07.1999	RADIO MONO + STEREO

AW7150/11	1041Radio cassette recorders - stereo	1.11.1995	RADIO MONO + STEREO
AW7150/11P	1041Radio cassette recorders - stereo	1.08.1996	RADIO MONO + STEREO
AW7150/11S	1041Radio cassette recorders - stereo	1.05.1999	RADIO MONO + STEREO
AW7150/14	1041Radio cassette recorders - stereo	1.09.1995	RADIO MONO + STEREO
AW7150/14P	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AW7150/14S	1041Radio cassette recorders - stereo	1.06.1999	RADIO MONO + STEREO
AW7150/20P	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AW7150/24P	1041Radio cassette recorders - stereo	1.10.1996	RADIO MONO + STEREO
AW7150/34P	1041Radio cassette recorders - stereo	1.10.1996	RADIO MONO + STEREO
AW7160/01	1041Radio cassette recorders - stereo	1.07.1998	RADIO MONO + STEREO
AW7160/11	1041Radio cassette recorders - stereo	1.01.1998	RADIO MONO + STEREO
AW7160CL/15	1041Radio cassette recorders - mono		RADIO MONO + STEREO
AW7220/10	1041Radio cassette recorders - mono	1.08.1992	RADIO MONO + STEREO
AW7223/01	1041Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AW7224/00	1041Radio cassette recorders - mono	1.04.1992	RADIO MONO + STEREO
AW7224/05	1041Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AW7224/14	1041Radio cassette recorders - mono	1.06.1992	RADIO MONO + STEREO
AW7225/17	1041Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AW7240/17	1041Radio cassette recorders - mono	1.08.1995	RADIO MONO + STEREO
AW7250/11	1041Radio cassette recorders - stereo	1.10.1995	RADIO MONO + STEREO
AW7250/11P	1041Radio cassette recorders - stereo	1.08.1996	RADIO MONO + STEREO
AW7250/14	1041Radio cassette recorders - mono	1.10.1995	RADIO MONO + STEREO
AW7250/14P	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AW7299/19S	1041Radio cassette recorders - mono	1.04.1992	RADIO MONO + STEREO
AW7301/01	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7301/19	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7304/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7320/10	1041Radio cassette recorders - mono	1.07.1992	RADIO MONO + STEREO
AW7323/01	1041Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AW7324/00	1041Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AW7324/05	1041Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AW7324/14	1041Radio cassette recorders - mono	1.07.1992	RADIO MONO + STEREO
AW7325/17	1041Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AW7390/01M	1041Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AW7391/19	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7392/00M	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7500/17	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7500/20	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7501/01	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7502/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7502/05	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7502/14	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO

AW7502/14R	1041Radio cassette recorders - mono	1.07.1992	RADIO MONO + STEREO
AW7502/20	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7505/17	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7509CL/15	1041Radio cassette recorders - mono		RADIO MONO + STEREO
AW7520/00	1041Radio cassette recorders - mono	1.04.1993	RADIO MONO + STEREO
AW7520/01	1041Radio cassette recorders - mono	1.01.1993	RADIO MONO + STEREO
AW7520/11	1041Radio cassette recorders - mono	1.03.1995	RADIO MONO + STEREO
AW7520/14	1041Radio cassette recorders - mono	1.05.1993	RADIO MONO + STEREO
AW7520/17	1041Radio cassette recorders - mono	1.04.1993	RADIO MONO + STEREO
AW7530/01	1041Radio cassette recorders - mono	1.09.1992	RADIO MONO + STEREO
AW7530/01R	1041Radio cassette recorders - mono	1.02.1993	RADIO MONO + STEREO
AW7530/13	1041Radio cassette recorders - mono		RADIO MONO + STEREO
AW7530/14R	1041Radio cassette recorders - mono	1.05.1993	RADIO MONO + STEREO
AW7550/01	1041Radio cassette recorders - stereo	1.06.1996	RADIO MONO + STEREO
AW7550/11	1041Radio cassette recorders - stereo	1.08.1996	RADIO MONO + STEREO
AW7550/12	1041Radio cassette recorders - mono	1.03.1997	RADIO MONO + STEREO
AW7550/14	1041Radio cassette recorders - stereo	1.08.1996	RADIO MONO + STEREO
AW7560/11	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AW7590/17	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7593/01	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7594/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7693/01	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7694/00	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7694/05	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7711/01	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7711/10	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7720/00	1041Radio cassette recorders - mono	1.09.1992	RADIO MONO + STEREO
AW7720/01	1041Radio cassette recorders - mono	1.06.1992	RADIO MONO + STEREO
AW7720/10	1041Radio cassette recorders - mono	1.08.1992	RADIO MONO + STEREO
AW7720/14	1041Radio cassette recorders - mono	1.11.1992	RADIO MONO + STEREO
AW7730/01	1041Radio cassette recorders - mono	1.01.1994	RADIO MONO + STEREO
AW7730/11	1041Radio cassette recorders - mono	1.06.1995	RADIO MONO + STEREO
AW7730/14	1041Radio cassette recorders - mono	1.07.1995	RADIO MONO + STEREO
AW7760/01	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AW7760/11	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AW7760/14	1041Radio cassette recorders - stereo	1.09.1996	RADIO MONO + STEREO
AW7790/07M	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7790/17M	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7791/01M	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7791/21M	1041Radio cassette recorders - mono	1.04.1992	RADIO MONO + STEREO
AW7792/20M	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AW7820/01	1041Radio cassette recorders - mono	1.02.1993	RADIO MONO + STEREO

AW7850/01	1041Radio cassette recorders - stereo	1.10.1998	RADIO MONO + STEREO
AW7850/11	1041Radio cassette recorders - stereo	1.07.1998	RADIO MONO + STEREO
AW7850/12	1041Radio cassette recorders - mono	1.10.1998	RADIO MONO + STEREO
AW7850/14	1041Radio cassette recorders - stereo	1.03.1999	RADIO MONO + STEREO
AW7860/11	1041Radio cassette recorders - stereo	1.07.1999	RADIO MONO + STEREO
AW7960/01	1041Radio cassette recorders - stereo	1.08.1998	RADIO MONO + STEREO
AW7960/11	1041Radio cassette recorders - stereo	1.07.1998	RADIO MONO + STEREO
AW7960/14	1041Radio cassette recorders - stereo		RADIO MONO + STEREO
AX1000/00	1042CD personal	1.01.2001	PERSONAL CD
AX1000/00Z	1042CD personal	1.02.2001	PERSONAL CD
AX1000/10	1042CD personal		PERSONAL CD
AX1000/11	1042CD personal	1.01.2001	PERSONAL CD
AX1000/13	1042CD personal		PERSONAL CD
AX1000/17	1042CD personal		PERSONAL CD
AX1000/19Z	1042CD personal	1.08.2001	PERSONAL CD
AX1001/00	1042CD personal	1.01.2001	PERSONAL CD
AX1001/00Z	1042CD personal	1.02.2001	PERSONAL CD
AX1001/01	1042CD personal	1.02.2001	PERSONAL CD
AX1001/10	1042CD personal	1.04.2001	PERSONAL CD
AX1001/18Z	1042CD personal	1.07.2001	PERSONAL CD
AX1001/19E	1042CD personal	1.06.2001	PERSONAL CD
AX1001/19Z	1042CD personal	1.05.2001	PERSONAL CD
AX1100/00	1042CD personal		PERSONAL CD
AX1100/00Z	1042CD personal		PERSONAL CD
AX1100/19Z	1042CD personal		PERSONAL CD
AX1101/00C	1042CD personal		PERSONAL CD
AX1101/00Z	1042CD personal		PERSONAL CD
AX1101/01	1042CD personal		PERSONAL CD
AX1101/10	1042CD personal		PERSONAL CD
AX2000/00	1042CD personal	1.01.2001	PERSONAL CD
AX2000/00Z	1042CD personal		PERSONAL CD
AX2001/00	1042CD personal	1.01.2001	PERSONAL CD
AX2001/05	1042CD personal		PERSONAL CD
AX2001/11	1042CD personal	1.01.2001	PERSONAL CD
AX2001/13	1042CD personal		PERSONAL CD
AX2002/00	1042CD personal	1.01.2001	PERSONAL CD
AX2002/05	1042CD personal	1.02.2001	PERSONAL CD
AX2003/01	1042CD personal	1.03.2001	PERSONAL CD
AX2003/10	1042CD personal	1.04.2001	PERSONAL CD
AX2003/18A	1042CD personal		PERSONAL CD
AX2003/19	1042CD personal		PERSONAL CD
AX2003/19E	1042CD personal		PERSONAL CD

AX2003/19Z	1042CD personal	1.09.2001	PERSONAL CD
AX2004/19Z	1042CD personal	1.10.2001	PERSONAL CD
AX2011/00	1042CD personal	1.02.2001	PERSONAL CD
AX2011/05	1042CD personal	1.03.2001	PERSONAL CD
AX2100/00C	1042CD personal		PERSONAL CD
AX2101/00C	1042CD personal	1.12.2001	PERSONAL CD
AX2102/00	1042CD personal		PERSONAL CD
AX2102/05	1042CD personal		PERSONAL CD
AX5000/00	1042CD personal	1.02.2001	PERSONAL CD
AX5000/00Z	1042CD personal		PERSONAL CD
AX5001/00	1042CD personal	1.01.2001	PERSONAL CD
AX5001/17	1042CD personal		PERSONAL CD
AX5002/00	1042CD personal	1.01.2001	PERSONAL CD
AX5002/05	1042CD personal	1.03.2001	PERSONAL CD
AX5002/11	1042CD personal		PERSONAL CD
AX5002/13	1042CD personal		PERSONAL CD
AX5003/10	1042CD personal	1.02.2001	PERSONAL CD
AX5003/17	1042CD personal		PERSONAL CD
AX5004/00	1042CD personal	1.02.2001	PERSONAL CD
AX5004/05	1042CD personal	1.07.2001	PERSONAL CD
AX5004/17	1042CD personal	1.08.2001	PERSONAL CD
AX5006/17	1042CD personal	1.08.2001	PERSONAL CD
AX5006/17P	1042CD personal	1.08.2001	PERSONAL CD
AX5011/17	1042CD personal	1.02.2001	PERSONAL CD
AX5011/17P	1042CD personal	1.08.2001	PERSONAL CD
AX5012/17	1042CD personal	1.08.2001	PERSONAL CD
AX5012/17P	1042CD personal	1.08.2001	PERSONAL CD
AX5013/00	1042CD personal	1.02.2001	PERSONAL CD
AX5013/17	1042CD personal	1.08.2001	PERSONAL CD
AX5014/17	1042CD personal	1.08.2001	PERSONAL CD
AX5015/17	1042CD personal	1.05.2001	PERSONAL CD
AX5016/17	1042CD personal	1.08.2001	PERSONAL CD
AX5017/17	1042CD personal	1.08.2001	PERSONAL CD
AX5018/17	1042CD personal	1.08.2001	PERSONAL CD
AX5018/17P	1042CD personal	1.08.2001	PERSONAL CD
AX5019/17	1042CD personal		PERSONAL CD
AX5021/17	1042CD personal	1.08.2001	PERSONAL CD
AX5022/17	1042CD personal	1.11.2001	PERSONAL CD
AX5023/17	1042CD personal	1.11.2001	PERSONAL CD
AX5024/17	1042CD personal	1.08.2001	PERSONAL CD
AX5025/17	1042CD personal	1.08.2001	PERSONAL CD
AX5026/17	1042CD personal	1.08.2001	PERSONAL CD

AX5027/17	1042CD personal	1.09.2001	PERSONAL CD
AX5100/00	1042CD personal		PERSONAL CD
AX5101/00C	1042CD personal	1.12.2001	PERSONAL CD
AX5101/11	1042CD personal	1.12.2001	PERSONAL CD
AX5102/00	1042CD personal		PERSONAL CD
AX5103/01	1042CD personal		PERSONAL CD
AX5103/10	1042CD personal		PERSONAL CD
AX5104/00C	1042CD personal		PERSONAL CD
AX5104/05	1042CD personal		PERSONAL CD
AX5111/17	1042CD personal		PERSONAL CD
AX5112/17	1042CD personal		PERSONAL CD
AX5113/00	1042CD personal		PERSONAL CD
AX5113/17	1042CD personal		PERSONAL CD
AX5114/17	1042CD personal		PERSONAL CD
AX5115/17	1042CD personal		PERSONAL CD
AX5116/17	1042CD personal		PERSONAL CD
AX5117/17	1042CD personal		PERSONAL CD
AX5118/17	1042CD personal		PERSONAL CD
AX5119/17	CD personal		PERSONAL CD
AX7101/17	1042CD personal		PERSONAL CD
AX7104/00C	1042CD personal		PERSONAL CD
AX7113/17	1042CD personal		PERSONAL CD
AZ1000/00	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ1000/01	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ1000/05	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ1000/10	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ1000/11	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1000/17	1042Single deck	1.02.1997	RADIORECORDERS + CD
AZ1001/17	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1002/17	1042Single deck	1.03.1998	RADIORECORDERS + CD
AZ1003/00C	Single deck		RADIORECORDERS + CD
AZ1003/01	Single deck		RADIORECORDERS + CD
AZ1003/05	Single deck		RADIORECORDERS + CD
AZ1003/10	Single deck		RADIORECORDERS + CD
AZ1003/13	Single deck		RADIORECORDERS + CD
AZ1003/17	Single deck		RADIORECORDERS + CD
AZ1003/19	Single deck		RADIORECORDERS + CD
AZ1005/00	1042Single deck	1.05.1999	RADIORECORDERS + CD
AZ1005/05	1042Single deck	1.06.1999	RADIORECORDERS + CD
AZ1005/11	1042Single deck	1.07.1999	RADIORECORDERS + CD
AZ1005/17	1042Single deck	1.05.1999	RADIORECORDERS + CD
AZ1007/00	1042Single deck	1.05.2000	RADIORECORDERS + CD

AZ1007/01	1042Single deck	1.04.2000	RADIORECORDERS + CD
AZ1007/05	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1007/10	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1007/11	1042Single deck	1.04.2000	RADIORECORDERS + CD
AZ1007/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1007/14	1042Single deck	1.03.2000	RADIORECORDERS + CD
AZ1007/17	1042Single deck	1.02.2000	RADIORECORDERS + CD
AZ1008/00	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ1008/01	1042Single deck	1.03.2001	RADIORECORDERS + CD
AZ1008/05	1042Single deck	1.03.2001	RADIORECORDERS + CD
AZ1008/08	Single deck		RADIORECORDERS + CD
AZ1008/10	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ1008/11	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1008/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1008/14	1042Single deck	1.03.2001	RADIORECORDERS + CD
AZ1008/16	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ1008/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1008/19	1042Single deck	1.07.2001	RADIORECORDERS + CD
AZ1008/19E	Single deck		RADIORECORDERS + CD
AZ1009/07	1042Single deck		RADIORECORDERS + CD
AZ1009/17	1042Single deck	1.11.1998	RADIORECORDERS + CD
AZ1010/00	1042Single deck	1.02.1998	RADIORECORDERS + CD
AZ1010/01	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1010/04	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1010/05	1042Single deck	1.03.1998	RADIORECORDERS + CD
AZ1010/10	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1010/11	1042Single deck	1.11.1997	RADIORECORDERS + CD
AZ1010/11H	1042Single deck	1.11.1998	RADIORECORDERS + CD
AZ1010/13	1042Single deck		RADIORECORDERS + CD
AZ1010/14	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1010/16	1042Single deck	1.09.1999	RADIORECORDERS + CD
AZ1010/17	1042Single deck	1.01.1998	RADIORECORDERS + CD
AZ1010/19	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1011/00	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1011/05	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1011/13	Single deck		RADIORECORDERS + CD
AZ1011/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1012/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1013/13	Single deck		RADIORECORDERS + CD
AZ1013/17	1042Single deck	1.11.2001	RADIORECORDERS + CD
AZ1015/00	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ1015/05	1042Single deck	1.06.1999	RADIORECORDERS + CD

AZ1015/14	1042Single deck	1.05.1999	RADIORECORDERS + CD
AZ1015/17	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1018/00	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1018/01	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1018/05	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1018/10	Single deck		RADIORECORDERS + CD
AZ1018/11	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1018/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1018/14	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1018/16	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ1018/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1018/19	Single deck		RADIORECORDERS + CD
AZ1020/00	1042Single deck	1.02.1999	RADIORECORDERS + CD
AZ1020/14	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1020/17	1042Single deck	1.02.1999	RADIORECORDERS + CD
AZ1025/00	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1025/05	1042Single deck	1.05.1999	RADIORECORDERS + CD
AZ1025/10	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ1025/11	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ1025/13	1042Single deck		RADIORECORDERS + CD
AZ1025/17	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1030/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1030/01	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1030/05	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1030/08	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ1030/10	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1030/11	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1030/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1030/14	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1030/16	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1030/17	1042Single deck	1.01.2000	RADIORECORDERS + CD
AZ1030/18	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ1030/19	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ1030/19E	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1035/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1035/05	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1035/11	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1035/14	1042Single deck	1.07.2000	RADIORECORDERS + CD
AZ1035/17	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1040/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1040/05	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1040/14	1042Single deck	1.06.2000	RADIORECORDERS + CD

AZ1040/17	1042Single deck	1.03.2000	RADIORECORDERS + CD
AZ1045/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1045/05	1042Single deck	1.07.2000	RADIORECORDERS + CD
AZ1045/17	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1050/00	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ1050/01	1042Single deck	1.05.2001	RADIORECORDERS + CD
AZ1050/05	1042Single deck	1.05.2001	RADIORECORDERS + CD
AZ1050/08	Single deck		RADIORECORDERS + CD
AZ1050/10	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ1050/11	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1050/14	1042Single deck	1.03.2001	RADIORECORDERS + CD
AZ1050/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1050/18	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1050/19	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ1050/19E	Single deck		RADIORECORDERS + CD
AZ1051/00	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1055/00	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ1055/08	Single deck		RADIORECORDERS + CD
AZ1055/11	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1055/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1055/14	1042Single deck	1.03.2001	RADIORECORDERS + CD
AZ1055/17	Single deck		RADIORECORDERS + CD
AZ1060/00	1042Single deck	1.03.2001	RADIORECORDERS + CD
AZ1060/05	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1060/14	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1060/17	Single deck		RADIORECORDERS + CD
AZ1061/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1065/00	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ1065/01	1042Single deck	1.03.2001	RADIORECORDERS + CD
AZ1065/05	1042Single deck	1.05.2001	RADIORECORDERS + CD
AZ1065/10	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1065/11	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1065/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1065/14	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ1065/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1080/00	Single deck		RADIORECORDERS + CD
AZ1080/01	Single deck		RADIORECORDERS + CD
AZ1080/05	Single deck		RADIORECORDERS + CD
AZ1080/13	Single deck		RADIORECORDERS + CD
AZ1080/14	Single deck		RADIORECORDERS + CD
AZ1081/00	Single deck		RADIORECORDERS + CD
AZ1081/01	Single deck		RADIORECORDERS + CD

AZ1081/13	Single deck		RADIORECORDERS + CD
AZ1100/00	1042Single deck	1.03.1997	RADIORECORDERS + CD
AZ1100/05	1042Single deck	1.05.1997	RADIORECORDERS + CD
AZ1100/13	1042Single deck		RADIORECORDERS + CD
AZ1101/00	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ1101/00R	1042Single deck	1.10.1997	RADIORECORDERS + CD
AZ1101/01	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ1101/05	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ1101/06	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ1101/07	1042Single deck	1.07.1996	RADIORECORDERS + CD
AZ1101/10	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1101/11	1042Single deck	1.04.1997	RADIORECORDERS + CD
AZ1101/11H	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ1101/13	1042Single deck		RADIORECORDERS + CD
AZ1101/14	1042Single deck	1.03.1997	RADIORECORDERS + CD
AZ1101/17	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ1102/00	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ1102/01	1042Single deck	1.04.1998	RADIORECORDERS + CD
AZ1102/05	1042Single deck	1.04.1997	RADIORECORDERS + CD
AZ1102/06	Single deck		RADIORECORDERS + CD
AZ1102/07	1042Single deck		RADIORECORDERS + CD
AZ1102/17	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ1103/00	1042Single deck	1.08.1997	RADIORECORDERS + CD
AZ1103/01	1042Single deck	1.09.1997	RADIORECORDERS + CD
AZ1103/07	1042Single deck		RADIORECORDERS + CD
AZ1103/10	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1103/11	1042Single deck	1.04.1998	RADIORECORDERS + CD
AZ1103/14	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1103/17	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1104/00	1042Single deck	1.04.1998	RADIORECORDERS + CD
AZ1104/01	1042Single deck	1.11.1997	RADIORECORDERS + CD
AZ1104/10	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1104/17	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1105/01	1042Single deck	1.11.1997	RADIORECORDERS + CD
AZ1105/10	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1105/17	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1106/17	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1108/17	1042Single deck		RADIORECORDERS + CD
AZ1109/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1110/00	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ1110/01	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ1110/05	1042Single deck	1.08.1998	RADIORECORDERS + CD

AZ1110/11	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ1110/11H	1042Single deck	1.11.1998	RADIORECORDERS + CD
AZ1110/13	1042Single deck		RADIORECORDERS + CD
AZ1110/14	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1110/16	1042Single deck	1.06.1999	RADIORECORDERS + CD
AZ1110/17	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1110/19	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ1111/00	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1111/05	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1111/06	1042Single deck		RADIORECORDERS + CD
AZ1111/10	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1111/11	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ1111/14	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1111/17	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1112/00	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1112/05	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1112/06	1042Single deck		RADIORECORDERS + CD
AZ1112/10	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1112/11	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ1112/14	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ1112/17	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1113/00	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1113/05	1042Single deck	1.05.1999	RADIORECORDERS + CD
AZ1113/06	1042Single deck		RADIORECORDERS + CD
AZ1113/10	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1113/11	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ1113/13	1042Single deck		RADIORECORDERS + CD
AZ1113/14	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ1113/17	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1114/00	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1114/05	1042Single deck	1.05.1999	RADIORECORDERS + CD
AZ1114/06	1042Single deck		RADIORECORDERS + CD
AZ1114/10	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1114/11	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ1114/14	1042Single deck	1.05.1999	RADIORECORDERS + CD
AZ1114/17	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ1116/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1116/10	1042Single deck	1.09.1999	RADIORECORDERS + CD
AZ1117/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1117/10	1042Single deck	1.09.1999	RADIORECORDERS + CD
AZ1118/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1118/10	1042Single deck	1.09.1999	RADIORECORDERS + CD

AZ1119/10	1042Single deck	1.09.1999	RADIORECORDERS + CD
AZ1120/00	1042Single deck	1.06.1999	RADIORECORDERS + CD
AZ1120/05	1042Single deck	1.07.1999	RADIORECORDERS + CD
AZ1120/11	1042Single deck	1.07.1999	RADIORECORDERS + CD
AZ1120/11H	1042Single deck	1.07.1999	RADIORECORDERS + CD
AZ1120/13	1042Single deck		RADIORECORDERS + CD
AZ1120/14	1042Single deck	1.10.1999	RADIORECORDERS + CD
AZ1120/17	1042Single deck	1.07.1999	RADIORECORDERS + CD
AZ1120/21	1042Single deck	1.02.2000	RADIORECORDERS + CD
AZ1138/00	1042Single deck	1.09.2001	RADIORECORDERS + CD
AZ1138/01	1042Single deck	1.10.2001	RADIORECORDERS + CD
AZ1138/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1140/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1140/05	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1140/06	Single deck		RADIORECORDERS + CD
AZ1140/11	1042Single deck		RADIORECORDERS + CD
AZ1140/16	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1140/17	1042Single deck	1.04.2000	RADIORECORDERS + CD
AZ1141/00	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ1141/05	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ1141/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1142/00	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ1142/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1143/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1145/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1145/01	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1145/10	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ1145/11	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1145/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1145/17	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1145/19	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ1145/19E	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1146/10	1042Single deck	1.10.2000	RADIORECORDERS + CD
AZ1146/11	1042Single deck	1.09.2000	RADIORECORDERS + CD
AZ1146/13	Single deck		RADIORECORDERS + CD
AZ1147/10	1042Single deck	1.10.2000	RADIORECORDERS + CD
AZ1147/11	1042Single deck	1.09.2000	RADIORECORDERS + CD
AZ1147/13	Single deck		RADIORECORDERS + CD
AZ1148/10	1042Single deck	1.10.2000	RADIORECORDERS + CD
AZ1148/11	1042Single deck	1.09.2000	RADIORECORDERS + CD
AZ1148/13	Single deck		RADIORECORDERS + CD
AZ1150/00	1042Single deck	1.10.2001	RADIORECORDERS + CD

AZ1150/05	1042Single deck	1.10.2001	RADIORECORDERS + CD
AZ1155/00	1042Single deck	1.09.2001	RADIORECORDERS + CD
AZ1155/01	1042Single deck	1.09.2001	RADIORECORDERS + CD
AZ1155/10	Single deck		RADIORECORDERS + CD
AZ1155/11	Single deck		RADIORECORDERS + CD
AZ1155/17	1042Single deck	1.09.2001	RADIORECORDERS + CD
AZ1155/19	Single deck		RADIORECORDERS + CD
AZ1200/00	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ1200/01	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1200/07	1042Single deck		RADIORECORDERS + CD
AZ1200/14	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1200/17	1042Single deck	1.04.1998	RADIORECORDERS + CD
AZ1201/14	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ1202/00	1042Single deck	1.12.1997	RADIORECORDERS + CD
AZ1202/01	1042Single deck	1.08.1997	RADIORECORDERS + CD
AZ1202/04	1042Single deck	1.12.1997	RADIORECORDERS + CD
AZ1202/05	1042Single deck	1.12.1997	RADIORECORDERS + CD
AZ1202/10	1042Single deck	1.01.1998	RADIORECORDERS + CD
AZ1202/11	1042Single deck	1.09.1997	RADIORECORDERS + CD
AZ1202/11H	1042Single deck		RADIORECORDERS + CD
AZ1202/13	1042Single deck		RADIORECORDERS + CD
AZ1202/14	1042Single deck	1.03.1998	RADIORECORDERS + CD
AZ1202/16	1042Single deck	1.08.1999	RADIORECORDERS + CD
AZ1202/17	1042Single deck	1.02.1998	RADIORECORDERS + CD
AZ1202/21	1042Single deck	1.01.1998	RADIORECORDERS + CD
AZ1202/60	1042Single deck	1.02.1998	RADIORECORDERS + CD
AZ1202/61	1042Single deck	1.01.1998	RADIORECORDERS + CD
AZ1202/61H	1042Single deck	1.11.1998	RADIORECORDERS + CD
AZ1202/63	1042Single deck		RADIORECORDERS + CD
AZ1203/00	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ1203/04	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ1203/17	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1205/01	1042Single deck		RADIORECORDERS + CD
AZ1205/17	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1207/00	1042Single deck	1.01.1998	RADIORECORDERS + CD
AZ1207/01	1042Single deck	1.12.1996	RADIORECORDERS + CD
AZ1207/04	1042Single deck	1.01.1998	RADIORECORDERS + CD
AZ1207/05	1042Single deck	1.01.1998	RADIORECORDERS + CD
AZ1207/07	1042Single deck		RADIORECORDERS + CD
AZ1207/11	1042Single deck	1.03.1998	RADIORECORDERS + CD
AZ1207/16	1042Single deck	1.10.1999	RADIORECORDERS + CD
AZ1207/17	1042Single deck	1.02.1998	RADIORECORDERS + CD

AZ1207/19	1042Single deck	1.03.1999	RADIORECORDERS + CD
AZ1208/00	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ1208/04	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ1208/05	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ1208/17	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1209/00	1042Single deck	1.11.1997	RADIORECORDERS + CD
AZ1209/01	1042Single deck	1.04.1998	RADIORECORDERS + CD
AZ1209/05	1042Single deck	1.02.1998	RADIORECORDERS + CD
AZ1209/11	1042Single deck		RADIORECORDERS + CD
AZ1209/14	1042Single deck	1.05.1998	RADIORECORDERS + CD
AZ1209/17	1042Single deck	1.10.1997	RADIORECORDERS + CD
AZ1210/17	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ1302/00	1042Single deck	1.02.1997	RADIORECORDERS + CD
AZ1302/05	1042Single deck	1.05.1997	RADIORECORDERS + CD
AZ1307/00	1042Single deck	1.02.1997	RADIORECORDERS + CD
AZ1307/05	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1307/17	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1308/01	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ1308/11	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ1402/00	1042Single deck	1.10.1997	RADIORECORDERS + CD
AZ1407/00	1042Single deck	1.07.1996	RADIORECORDERS + CD
AZ1407/05	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ1407/06	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ1407/17	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ1412/00	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1412/17	1042Single deck		RADIORECORDERS + CD
AZ1500/00	Single deck		RADIORECORDERS + CD
AZ1500/00C	Single deck		RADIORECORDERS + CD
AZ1500/01	Single deck		RADIORECORDERS + CD
AZ1500/05	Single deck		RADIORECORDERS + CD
AZ1500/10	Single deck		RADIORECORDERS + CD
AZ1500/13	Single deck		RADIORECORDERS + CD
AZ1500/17	Single deck		RADIORECORDERS + CD
AZ1500/19	Single deck		RADIORECORDERS + CD
AZ1505/00	Single deck		RADIORECORDERS + CD
AZ1505/01	Single deck		RADIORECORDERS + CD
AZ1505/10	Single deck		RADIORECORDERS + CD
AZ1505/13	Single deck		RADIORECORDERS + CD
AZ1505/14	Single deck		RADIORECORDERS + CD
AZ1505/17	Single deck		RADIORECORDERS + CD
AZ1508/00	1042Single deck	1.07.1996	RADIORECORDERS + CD
AZ1508/01	1042Single deck	1.08.1996	RADIORECORDERS + CD

AZ1508/05	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ1508/11	1042Single deck	1.05.1997	RADIORECORDERS + CD
AZ1508/13	1042Single deck		RADIORECORDERS + CD
AZ1508/14	1042Single deck	1.03.1997	RADIORECORDERS + CD
AZ1508/17	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ1509/17	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ1518/00	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1518/05	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ1518/14	1042Single deck		RADIORECORDERS + CD
AZ1518/17	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ1538/00C	Single deck		RADIORECORDERS + CD
AZ1538/01	Single deck		RADIORECORDERS + CD
AZ1538/13	Single deck		RADIORECORDERS + CD
AZ1538/19	Single deck		RADIORECORDERS + CD
AZ1550/00	1042Single deck	1.03.2000	RADIORECORDERS + CD
AZ1550/01	1042Single deck	1.04.2000	RADIORECORDERS + CD
AZ1550/05	1042Single deck	1.03.2000	RADIORECORDERS + CD
AZ1550/14	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1550/16	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1550/18	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ1550/19	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ1550/19E	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ1560/00	1042Single deck	1.01.2000	RADIORECORDERS + CD
AZ1560/05	1042Single deck	1.03.2000	RADIORECORDERS + CD
AZ1560/10	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ1560/11	1042Single deck	1.04.2000	RADIORECORDERS + CD
AZ1560/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1560/17	1042Single deck	1.02.2000	RADIORECORDERS + CD
AZ1564/17	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1565/00	1042Single deck	1.01.2000	RADIORECORDERS + CD
AZ1565/01	1042Single deck	1.04.2000	RADIORECORDERS + CD
AZ1565/05	1042Single deck	1.04.2000	RADIORECORDERS + CD
AZ1565/08	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ1565/10	1042Single deck	1.11.1999	RADIORECORDERS + CD
AZ1565/11	1042Single deck	1.11.1999	RADIORECORDERS + CD
AZ1565/13	1042Single deck		RADIORECORDERS + CD
AZ1565/14	1042Single deck	1.03.2000	RADIORECORDERS + CD
AZ1565/16	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ1565/17	1042Single deck	1.12.1999	RADIORECORDERS + CD
AZ1565/18	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ1565/19	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ1565/19E	1042Single deck	1.04.2001	RADIORECORDERS + CD

AZ1570/00	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ1570/01	1042Single deck		RADIORECORDERS + CD
AZ1570/05	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ1570/17	Single deck		RADIORECORDERS + CD
AZ1574/00	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1574/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1574/19	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1575/00	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ1575/01	1042Single deck	1.05.2001	RADIORECORDERS + CD
AZ1575/05	Single deck		RADIORECORDERS + CD
AZ1575/08	Single deck		RADIORECORDERS + CD
AZ1575/10	1042Single deck	1.05.2001	RADIORECORDERS + CD
AZ1575/11	1042Single deck	1.10.2000	RADIORECORDERS + CD
AZ1575/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1575/14	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ1575/16	1042Single deck	1.07.2001	RADIORECORDERS + CD
AZ1575/17	Single deck		RADIORECORDERS + CD
AZ1575/18	1042Single deck	1.10.2001	RADIORECORDERS + CD
AZ1575/19	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ1575/19E	Single deck		RADIORECORDERS + CD
AZ1602/00	1042Double deck	1.05.1997	RADIORECORDERS + CD
AZ1602/01	1042Double deck	1.06.1997	RADIORECORDERS + CD
AZ1602/05	1042Double deck	1.06.1997	RADIORECORDERS + CD
AZ1602/06	1042Double deck		RADIORECORDERS + CD
AZ1602/11	1042Double deck	1.09.1997	RADIORECORDERS + CD
AZ1602/11H	1042Double deck		RADIORECORDERS + CD
AZ1602/13	1042Double deck		RADIORECORDERS + CD
AZ1602/14	1042Double deck	1.09.1997	RADIORECORDERS + CD
AZ1602/16	1042Double deck	1.07.1999	RADIORECORDERS + CD
AZ1602/17	1042Double deck	1.06.1997	RADIORECORDERS + CD
AZ1605/00	1042Double deck	1.09.1999	RADIORECORDERS + CD
AZ1605/11	1042Double deck	1.09.1999	RADIORECORDERS + CD
AZ1605/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ1605/14	1042Double deck	1.10.1999	RADIORECORDERS + CD
AZ1605/17	1042Single deck	1.12.1999	RADIORECORDERS + CD
AZ2000/00	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ2000/01	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ2000/05	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ2000/07	1042Single deck		RADIORECORDERS + CD
AZ2000/10	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ2000/11	1042Single deck	1.09.1998	RADIORECORDERS + CD
AZ2000/11H	1042Single deck	1.09.1998	RADIORECORDERS + CD

AZ2000/13	1042Single deck		RADIORECORDERS + CD
AZ2000/14	1042Single deck	1.10.1998	RADIORECORDERS + CD
AZ2000/16	1042Single deck	1.08.1999	RADIORECORDERS + CD
AZ2000/17	1042Single deck	1.07.1998	RADIORECORDERS + CD
AZ2000/18	1042Single deck	1.01.2001	RADIORECORDERS + CD
AZ2000/19	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ2000/19E	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ2010/00	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ2010/05	1042Single deck	1.05.1999	RADIORECORDERS + CD
AZ2010/10	1042Single deck	1.11.1999	RADIORECORDERS + CD
AZ2010/11	1042Single deck	1.10.1999	RADIORECORDERS + CD
AZ2010/14	1042Single deck	1.06.1999	RADIORECORDERS + CD
AZ2010/17	1042Single deck	1.04.1999	RADIORECORDERS + CD
AZ2020/00	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ2020/05	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ2020/16	1042Single deck	1.09.2000	RADIORECORDERS + CD
AZ2025/00	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ2025/01	1042Single deck	1.12.2000	RADIORECORDERS + CD
AZ2025/05	1042Single deck		RADIORECORDERS + CD
AZ2025/10	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ2025/11	1042Single deck	1.07.2000	RADIORECORDERS + CD
AZ2025/13	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ2025/14	1042Single deck	1.08.2000	RADIORECORDERS + CD
AZ2025/17	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ2025/18	1042Single deck	1.11.2001	RADIORECORDERS + CD
AZ2025/19	1042Single deck	1.04.2001	RADIORECORDERS + CD
AZ2025/19E	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ2030/00	1042Single deck	1.05.2001	RADIORECORDERS + CD
AZ2030/05	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ2030/14	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ2030/16	Single deck		RADIORECORDERS + CD
AZ2035/10	1042Single deck	1.07.2001	RADIORECORDERS + CD
AZ2035/11	1042Single deck	1.05.2001	RADIORECORDERS + CD
AZ2035/13	Single deck		RADIORECORDERS + CD
AZ2035/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ2040/00	Single deck		RADIORECORDERS + CD
AZ2040/05	Single deck		RADIORECORDERS + CD
AZ2040/14	Single deck		RADIORECORDERS + CD
AZ2045/00	Single deck		RADIORECORDERS + CD
AZ2045/01	Single deck		RADIORECORDERS + CD
AZ2045/10	Single deck		RADIORECORDERS + CD
AZ2045/13	Single deck		RADIORECORDERS + CD

AZ2045/14	Single deck		RADIORECORDERS + CD
AZ2045/17	Single deck		RADIORECORDERS + CD
AZ2045/19	Single deck		RADIORECORDERS + CD
AZ2048/00	Single deck		RADIORECORDERS + CD
AZ2048/01	Single deck		RADIORECORDERS + CD
AZ2048/17	Single deck		RADIORECORDERS + CD
AZ2100/00	1042Compo's	1.08.1996	RADIORECORDERS + CD
AZ2100/01	1042Compo's	1.05.1996	RADIORECORDERS + CD
AZ2100/05	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ2100/10	1042Compo's	1.06.1996	RADIORECORDERS + CD
AZ2100/12	1042Single deck	1.04.1997	RADIORECORDERS + CD
AZ2100/17	1042Compo's	1.04.1996	RADIORECORDERS + CD
AZ2305/00	1042Compo's	1.05.1997	RADIORECORDERS + CD
AZ2305/05	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ2305/10	1042Single deck	1.10.1997	RADIORECORDERS + CD
AZ2305/13	1042Compo's		RADIORECORDERS + CD
AZ2402/00	1042Compo's	1.06.1998	RADIORECORDERS + CD
AZ2402/05	1042Compo's	1.06.1998	RADIORECORDERS + CD
AZ2402/10	1042Compo's	1.08.1998	RADIORECORDERS + CD
AZ2405/00	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ2405/01	1042Compo's	1.11.1996	RADIORECORDERS + CD
AZ2405/05	1042Single deck	1.03.1997	RADIORECORDERS + CD
AZ2405/11	1042Compo's	1.02.1997	RADIORECORDERS + CD
AZ2405/11H	1042Compo's	1.11.1996	RADIORECORDERS + CD
AZ2405/13	1042Compo's		RADIORECORDERS + CD
AZ2405/14	1042Compo's	1.03.1997	RADIORECORDERS + CD
AZ2405/17	1042Compo's	1.06.1997	RADIORECORDERS + CD
AZ2407/00	1042Compo's	1.04.1998	RADIORECORDERS + CD
AZ2407/01	1042Compo's	1.05.1998	RADIORECORDERS + CD
AZ2407/11	1042Compo's	1.05.1998	RADIORECORDERS + CD
AZ2407/11H	1042Compo's	1.04.1998	RADIORECORDERS + CD
AZ2407/12	1042Single deck	1.06.1998	RADIORECORDERS + CD
AZ2407/13	1042Compo's		RADIORECORDERS + CD
AZ2407/14	1042Compo's	1.04.1998	RADIORECORDERS + CD
AZ2407/16	1042Compo's	1.10.1999	RADIORECORDERS + CD
AZ2407/17	1042Compo's	1.06.1998	RADIORECORDERS + CD
AZ2407/19	1042Compo's	1.03.1999	RADIORECORDERS + CD
AZ2415/00	1042Compo's	1.09.1997	RADIORECORDERS + CD
AZ2415/01	1042Compo's	1.09.1997	RADIORECORDERS + CD
AZ2415/05	1042Compo's	1.09.1997	RADIORECORDERS + CD
AZ2415/11H	1042Compo's	1.10.1997	RADIORECORDERS + CD
AZ2415/12	1042Single deck	1.03.1998	RADIORECORDERS + CD

AZ2415/13	1042Compo's		RADIORECORDERS + CD
AZ2415/14	1042Compo's	1.06.1998	RADIORECORDERS + CD
AZ2415/17	1042Compo's	1.11.1997	RADIORECORDERS + CD
AZ2415/17S	1042Compo's	1.11.1999	RADIORECORDERS + CD
AZ2415/20	1042Compo's	1.07.1998	RADIORECORDERS + CD
AZ2415/21	1042Compo's	1.09.1998	RADIORECORDERS + CD
AZ2415/61	1042Compo's	1.07.1998	RADIORECORDERS + CD
AZ2415/61H	1042Compo's		RADIORECORDERS + CD
AZ2415/62	1042Single deck	1.08.1998	RADIORECORDERS + CD
AZ2415/64	1042Compo's	1.10.1998	RADIORECORDERS + CD
AZ2420/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ2425/00	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ2425/01	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ2425/11	1042Single deck		RADIORECORDERS + CD
AZ2425/14	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ2425/16	1042Single deck	1.06.2000	RADIORECORDERS + CD
AZ2425/17	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ2425/19	1042Single deck	1.02.2001	RADIORECORDERS + CD
AZ2600/01	1042Compo's	1.08.1996	RADIORECORDERS + CD
AZ2600/10	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ2600/14	1042Compo's	1.06.1997	RADIORECORDERS + CD
AZ2600/17	1042Compo's	1.05.1996	RADIORECORDERS + CD
AZ2605/01	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ2605/05	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ2605/10	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ2605/11	1042Compo's	1.11.1996	RADIORECORDERS + CD
AZ2605/14	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ2605/17	1042Compo's	1.08.1996	RADIORECORDERS + CD
AZ2615/17	1042Compo's	1.06.1996	RADIORECORDERS + CD
AZ2700/07	1042Compo's		RADIORECORDERS + CD
AZ2700/14	1042Compo's	1.05.1998	RADIORECORDERS + CD
AZ2700/17	1042Compo's	1.04.1998	RADIORECORDERS + CD
AZ2710/01	1042Compo's	1.05.1998	RADIORECORDERS + CD
AZ2710/10	1042Compo's	1.07.1998	RADIORECORDERS + CD
AZ2710/11	1042Compo's	1.07.1998	RADIORECORDERS + CD
AZ2710/14	1042Compo's	1.04.1998	RADIORECORDERS + CD
AZ2710/17	1042Compo's	1.06.1998	RADIORECORDERS + CD
AZ2725/17	1042Compo's	1.07.1998	RADIORECORDERS + CD
AZ2750/07	1042Compo's		RADIORECORDERS + CD
AZ2750/14	1042Compo's		RADIORECORDERS + CD
AZ2750/17	1042Compo's	1.03.1999	RADIORECORDERS + CD
AZ2755/00	1042Compo's	1.07.1999	RADIORECORDERS + CD

AZ2755/01	1042Compo's	1.05.1999	RADIORECORDERS + CD
AZ2755/10	1042Compo's	1.06.1999	RADIORECORDERS + CD
AZ2755/11	1042Compo's	1.05.1999	RADIORECORDERS + CD
AZ2755/14	1042Compo's	1.05.1999	RADIORECORDERS + CD
AZ2755/16	1042Compo's	1.06.1999	RADIORECORDERS + CD
AZ2755/17	1042Compo's	1.04.1999	RADIORECORDERS + CD
AZ2755/19	1042Compo's	1.02.2001	RADIORECORDERS + CD
AZ2760/17	1042Compo's	1.01.2000	RADIORECORDERS + CD
AZ2765/16	1042Single deck	1.05.2000	RADIORECORDERS + CD
AZ2765/17	1042Compo's	1.01.2000	RADIORECORDERS + CD
AZ2770/17	Single deck		RADIORECORDERS + CD
AZ2780/17	Single deck		RADIORECORDERS + CD
AZ2785/01	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ2785/16	1042Single deck	1.06.2001	RADIORECORDERS + CD
AZ2785/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ2804/17	1042Compo's	1.06.1997	RADIORECORDERS + CD
AZ2805/00	1042Compo's	1.08.1996	RADIORECORDERS + CD
AZ2805/05	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ2805/17	1042Compo's	1.06.1996	RADIORECORDERS + CD
AZ2808/01	1042Compo's	1.08.1996	RADIORECORDERS + CD
AZ2808/10	1042Single deck	1.07.1997	RADIORECORDERS + CD
AZ2808/11	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ2808/14	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ2808/17	1042Compo's	1.07.1996	RADIORECORDERS + CD
AZ2905/00	1042Compo's	1.07.1998	RADIORECORDERS + CD
AZ2905/17	1042Compo's	1.05.1998	RADIORECORDERS + CD
AZ2908/01	1042Compo's	1.06.1998	RADIORECORDERS + CD
AZ2908/14	1042Compo's		RADIORECORDERS + CD
AZ3000/00	Single deck		RADIORECORDERS + CD
AZ3000/11	Single deck		RADIORECORDERS + CD
AZ3000/17	Single deck		RADIORECORDERS + CD
AZ3010/00C	Single deck		RADIORECORDERS + CD
AZ3010/01	Single deck		RADIORECORDERS + CD
AZ3010/05	Single deck		RADIORECORDERS + CD
AZ3010/10	Single deck		RADIORECORDERS + CD
AZ3010/13	Single deck		RADIORECORDERS + CD
AZ3010/17	Single deck		RADIORECORDERS + CD
AZ3011/01	Single deck		RADIORECORDERS + CD
AZ3011/13	Single deck		RADIORECORDERS + CD
AZ3011/17	Single deck		RADIORECORDERS + CD
AZ3012/00C	Single deck		RADIORECORDERS + CD
AZ3012/01	Single deck		RADIORECORDERS + CD

AZ3012/05	Single deck		RADIORECORDERS + CD
AZ3012/10	Single deck		RADIORECORDERS + CD
AZ3012/17	Single deck		RADIORECORDERS + CD
AZ3038/00	Single deck		RADIORECORDERS + CD
AZ3038/01	Single deck		RADIORECORDERS + CD
AZ3038/17	Single deck		RADIORECORDERS + CD
AZ3141/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ3142/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ3143/17	1042Single deck	1.08.2001	RADIORECORDERS + CD
AZ3705/17	1042Compo's	1.07.1996	RADIORECORDERS + CD
AZ3708/01	1042Single deck	1.06.1996	RADIORECORDERS + CD
AZ3708/13	1042Single deck		RADIORECORDERS + CD
AZ3708/17	1042Compo's	1.09.1996	RADIORECORDERS + CD
AZ4000/00	Single deck		RADIORECORDERS + CD
AZ4000/05	Single deck		RADIORECORDERS + CD
AZ4000/11	Single deck		RADIORECORDERS + CD
AZ4000/17	Single deck		RADIORECORDERS + CD
AZ5050/01	1042Single deck	1.10.2001	RADIORECORDERS + CD
AZ5050/21	1042Single deck	1.10.2001	RADIORECORDERS + CD
AZ5150/01	Single deck		RADIORECORDERS + CD
AZ6806/00	1042CD personal	1.03.1992	PERSONAL CD
AZ6806/01	1042CD personal	1.04.1992	PERSONAL CD
AZ6806/17	1042CD personal	1.03.1992	PERSONAL CD
AZ6808/00	1042CD personal	1.03.1992	PERSONAL CD
AZ6808/01	1042CD personal	1.05.1992	PERSONAL CD
AZ6808/05	1042CD personal	1.03.1992	PERSONAL CD
AZ6808/06	1042CD personal	1.05.1992	PERSONAL CD
AZ6808/10	1042CD personal	1.06.1992	PERSONAL CD
AZ6808/17	1042CD personal	1.03.1992	PERSONAL CD
AZ6809/17	1042CD personal	1.12.1993	PERSONAL CD
AZ6810/00	1042CD personal	1.04.1992	PERSONAL CD
AZ6810/17	1042CD personal	1.06.1992	PERSONAL CD
AZ6811/00	1042CD personal	1.03.1992	PERSONAL CD
AZ6811/05	1042CD personal	1.03.1992	PERSONAL CD
AZ6811/17	1042CD personal	1.03.1992	PERSONAL CD
AZ6812/17	1042Radio + Cassette	1.03.1992	PERSONAL STEREO
AZ6813/00	1042CD personal	1.03.1992	PERSONAL CD
AZ6813/01	1042CD personal	1.03.1992	PERSONAL CD
AZ6813/05	1042CD personal	1.03.1992	PERSONAL CD
AZ6813/10	1042CD personal	1.05.1992	PERSONAL CD
AZ6813/17	1042CD personal	1.03.1992	PERSONAL CD
AZ6814/03	1042CD personal	1.07.1992	PERSONAL CD

AZ6815/00	1042CD personal	1.03.1992	PERSONAL CD
AZ6815/00H	1042CD personal	1.07.1992	PERSONAL CD
AZ6815/01	1042CD personal	1.05.1992	PERSONAL CD
AZ6815/05	1042CD personal	1.03.1992	PERSONAL CD
AZ6815/05H	1042CD personal	1.11.1992	PERSONAL CD
AZ6815/06	1042CD personal	1.04.1992	PERSONAL CD
AZ6815/10	1042CD personal	1.10.1992	PERSONAL CD
AZ6815/17	1042CD personal	1.03.1992	PERSONAL CD
AZ6815/19	1042CD personal	1.08.1992	PERSONAL CD
AZ6816/17	1042CD personal	1.08.1992	PERSONAL CD
AZ6817/00	1042CD personal	1.03.1992	PERSONAL CD
AZ6819/00	1042CD personal	1.03.1992	PERSONAL CD
AZ6819/01	1042CD personal	1.03.1992	PERSONAL CD
AZ6819/05	1042CD personal	1.03.1992	PERSONAL CD
AZ6819/13	1042CD personal		PERSONAL CD
AZ6819/17	1042CD personal	1.08.1992	PERSONAL CD
AZ6819/18	1042CD personal	1.03.1992	PERSONAL CD
AZ6820/17	1042CD personal	1.08.1993	PERSONAL CD
AZ6820/37	1042CD personal	1.07.1993	PERSONAL CD
AZ6821/00	1042CD personal	1.08.1993	PERSONAL CD
AZ6821/01	1042CD personal	1.07.1993	PERSONAL CD
AZ6821/05	1042CD personal	1.11.1993	PERSONAL CD
AZ6821/06	1042CD personal	1.07.1994	PERSONAL CD
AZ6821/20	1042CD personal	1.02.1993	PERSONAL CD
AZ6822/00	1042CD personal	1.09.1993	PERSONAL CD
AZ6822/05	1042CD personal	1.07.1993	PERSONAL CD
AZ6822/17	1042CD personal	1.05.1993	PERSONAL CD
AZ6823/00	1042CD personal	1.09.1993	PERSONAL CD
AZ6823/01	1042CD personal	1.09.1993	PERSONAL CD
AZ6823/05	1042CD personal	1.10.1993	PERSONAL CD
AZ6825/00	1042CD personal	1.09.1993	PERSONAL CD
AZ6825/01	1042CD personal	1.10.1993	PERSONAL CD
AZ6826/00	1042CD personal	1.01.1993	PERSONAL CD
AZ6826/01	1042CD personal	1.10.1992	PERSONAL CD
AZ6826/06	1042CD personal	1.01.1993	PERSONAL CD
AZ6827/00	1042CD personal	1.04.1994	PERSONAL CD
AZ6827/01	1042CD personal	1.10.1993	PERSONAL CD
AZ6827/06	1042CD personal	1.02.1994	PERSONAL CD
AZ6827/13	1042CD personal		PERSONAL CD
AZ6827/17	1042CD personal	1.10.1993	PERSONAL CD
AZ6828/17	1042CD personal	1.11.1995	PERSONAL CD
AZ6829/06	1042CD personal	1.06.1992	PERSONAL CD

AZ6830/00	1042CD personal	1.08.1995	PERSONAL CD
AZ6830/00B	1042CD personal	1.05.1996	PERSONAL CD
AZ6830/05	1042CD personal	1.06.1995	PERSONAL CD
AZ6830/11	1042CD personal	1.12.1995	PERSONAL CD
AZ6831/00	1042CD personal	1.07.1995	PERSONAL CD
AZ6831/17	1042CD personal	1.04.1995	PERSONAL CD
AZ6832/00	1042CD personal	1.05.1996	PERSONAL CD
AZ6832/05	1042CD personal	1.09.1995	PERSONAL CD
AZ6832/10	1042CD personal	1.12.1995	PERSONAL CD
AZ6832/17	1042CD personal	1.05.1995	PERSONAL CD
AZ6832/17H	1042CD personal	1.11.1996	PERSONAL CD
AZ6832CS/37	1042CD personal	1.10.1996	PERSONAL CD
AZ6833/07	1042CD personal	1.12.1995	PERSONAL CD
AZ6833/17	1042CD personal	1.07.1995	PERSONAL CD
AZ6834/00	1042CD personal	1.07.1995	PERSONAL CD
AZ6834/01	1042CD personal	1.06.1995	PERSONAL CD
AZ6834/01Z	1042CD personal	1.09.1995	PERSONAL CD
AZ6834/05	1042CD personal	1.08.1995	PERSONAL CD
AZ6835/00	1042CD personal	1.08.1995	PERSONAL CD
AZ6835/05	1042CD personal	1.08.1995	PERSONAL CD
AZ6835/06	1042CD personal	1.11.1995	PERSONAL CD
AZ6836/00	1042CD personal	1.07.1995	PERSONAL CD
AZ6836/05	1042CD personal	1.08.1995	PERSONAL CD
AZ6836/17	1042CD personal	1.06.1995	PERSONAL CD
AZ6837/01	1042CD personal	1.10.1995	PERSONAL CD
AZ6837/05	1042CD personal	1.09.1995	PERSONAL CD
AZ6837/10	1042CD personal	1.09.1995	PERSONAL CD
AZ6839/06	1042CD personal	1.08.1994	PERSONAL CD
AZ6839/17	1042CD personal	1.12.1994	PERSONAL CD
AZ6840/00	1042CD personal	1.04.1994	PERSONAL CD
AZ6840/01	1042CD personal	1.04.1994	PERSONAL CD
AZ6840/05	1042CD personal	1.06.1994	PERSONAL CD
AZ6840/17	1042CD personal	1.06.1994	PERSONAL CD
AZ6840/18	1042CD personal	1.08.1994	PERSONAL CD
AZ6841/00	1042CD personal	1.07.1995	PERSONAL CD
AZ6841/05	1042CD personal	1.04.1995	PERSONAL CD
AZ6841/10	1042CD personal	1.08.1994	PERSONAL CD
AZ6841/17	1042CD personal	1.06.1994	PERSONAL CD
AZ6843/00	1042CD personal	1.05.1995	PERSONAL CD
AZ6843/01	1042CD personal	1.07.1995	PERSONAL CD
AZ6843/06	1042CD personal	1.02.1995	PERSONAL CD
AZ6843/17	1042CD personal	1.05.1995	PERSONAL CD

AZ6844/00	1042CD personal	1.05.1995	PERSONAL CD
AZ6844/06	1042CD personal	1.06.1995	PERSONAL CD
AZ6844/17	1042CD personal	1.05.1995	PERSONAL CD
AZ6844/17H	1042CD personal	1.05.1996	PERSONAL CD
AZ6845/00	1042CD personal	1.06.1995	PERSONAL CD
AZ6845/01	1042CD personal	1.07.1995	PERSONAL CD
AZ6845/05	1042CD personal	1.08.1995	PERSONAL CD
AZ6846/00	1042CD personal	1.09.1994	PERSONAL CD
AZ6846/01	1042CD personal	1.11.1994	PERSONAL CD
AZ6846/06	1042CD personal	1.11.1994	PERSONAL CD
AZ6847/00	1042CD personal	1.10.1994	PERSONAL CD
AZ6847/01	1042CD personal	1.11.1994	PERSONAL CD
AZ6847/06	1042CD personal	1.11.1994	PERSONAL CD
AZ6848/00	1042CD personal	1.03.1995	PERSONAL CD
AZ6848/01	1042CD personal	1.12.1994	PERSONAL CD
AZ6848/17	1042CD personal	1.10.1994	PERSONAL CD
AZ6849/17	1042CD personal	1.04.1995	PERSONAL CD
AZ6850/00	1042CD personal	1.10.1995	PERSONAL CD
AZ6850/01	1042CD personal	1.12.1995	PERSONAL CD
AZ6856/07	1042CD personal	1.11.1996	PERSONAL CD
AZ6856/17	1042CD personal	1.03.1996	PERSONAL CD
AZ6856/17H	1042CD personal	1.05.1997	PERSONAL CD
AZ6858/17	1042CD personal	1.05.1996	PERSONAL CD
AZ6880/00	1042CD personal	1.07.1996	PERSONAL CD
AZ6880/01	1042CD personal	1.02.1996	PERSONAL CD
AZ6880/06	1042CD personal	1.02.1996	PERSONAL CD
AZ6890/03	1042CD personal	1.03.1992	PERSONAL CD
AZ7000/17	1042CD personal	1.12.1998	PERSONAL CD
AZ7161/11	1042CD personal	1.09.1996	PERSONAL CD
AZ7166/05	1042CD personal	1.09.1996	PERSONAL CD
AZ7166/10	1042CD personal	1.08.1996	PERSONAL CD
AZ7166/17	1042CD personal	1.03.1996	PERSONAL CD
AZ7166/17H	1042CD personal	1.10.1996	PERSONAL CD
AZ7167/00	1042CD personal	1.06.1996	PERSONAL CD
AZ7168/17	1042CD personal	1.05.1996	PERSONAL CD
AZ7180/00	1042CD personal	1.08.1998	PERSONAL CD
AZ7181/00	1042CD personal	1.05.1998	PERSONAL CD
AZ7181/01	1042CD personal	1.07.1998	PERSONAL CD
AZ7181/01Z	1042CD personal	1.09.1998	PERSONAL CD
AZ7181/05	1042CD personal	1.05.1998	PERSONAL CD
AZ7181/09Z	1042CD personal	1.12.1998	PERSONAL CD
AZ7181/11	1042CD personal	1.11.1998	PERSONAL CD

AZ7181/13	1042CD personal		PERSONAL CD
AZ7181/14	1042CD personal	1.09.1998	PERSONAL CD
AZ7181/17	1042CD personal	1.05.1998	PERSONAL CD
AZ7182/00	1042CD personal	1.05.1998	PERSONAL CD
AZ7182/10	1042CD personal	1.09.1998	PERSONAL CD
AZ7182/11	1042CD personal	1.06.1998	PERSONAL CD
AZ7188/01	1042CD personal	1.08.1998	PERSONAL CD
AZ7188/09	1042CD personal	1.11.1998	PERSONAL CD
AZ7260/00	1042CD personal	1.02.1997	PERSONAL CD
AZ7261/00	1042CD personal	1.09.1996	PERSONAL CD
AZ7261/01	1042CD personal	1.06.1996	PERSONAL CD
AZ7261/01Z	1042CD personal	1.10.1996	PERSONAL CD
AZ7261/05	1042CD personal	1.03.1997	PERSONAL CD
AZ7261/11	1042CD personal	1.09.1996	PERSONAL CD
AZ7261/11H	1042CD personal	1.09.1996	PERSONAL CD
AZ7261/13	1042CD personal		PERSONAL CD
AZ7261/14	1042CD personal	1.04.1997	PERSONAL CD
AZ7261/17	1042CD personal	1.10.1996	PERSONAL CD
AZ7261CS/37	1042CD personal	1.03.1997	PERSONAL CD
AZ7262/00	1042CD personal	1.09.1996	PERSONAL CD
AZ7262/10	1042CD personal	1.08.1997	PERSONAL CD
AZ7264/13	1042CD personal		PERSONAL CD
AZ7265/10	1042CD personal	1.08.1997	PERSONAL CD
AZ7265/10S	1042CD personal	1.08.1997	PERSONAL CD
AZ7265/17	1042CD personal	1.03.1997	PERSONAL CD
AZ7265CS/37	1042CD personal	1.02.1997	PERSONAL CD
AZ7266/17	1042CD personal	1.08.1996	PERSONAL CD
AZ7267/00	1042CD personal	1.10.1996	PERSONAL CD
AZ7267/06	1042CD personal	1.11.1996	PERSONAL CD
AZ7268/01	1042CD personal	1.09.1996	PERSONAL CD
AZ7268/05	1042CD personal	1.12.1996	PERSONAL CD
AZ7268/10	1042CD personal	1.09.1996	PERSONAL CD
AZ7268/10S	1042CD personal	1.11.1996	PERSONAL CD
AZ7268/17	1042CD personal	1.09.1997	PERSONAL CD
AZ7271/00	1042CD personal	1.04.1997	PERSONAL CD
AZ7271/00B	1042CD personal	1.08.1997	PERSONAL CD
AZ7271/00P	1042CD personal	1.04.1997	PERSONAL CD
AZ7271/00S	1042CD personal	1.04.1997	PERSONAL CD
AZ7271/01	1042CD personal	1.10.1997	PERSONAL CD
AZ7271/01Z	1042CD personal	1.11.1997	PERSONAL CD
AZ7271/11S	1042CD personal	1.10.1997	PERSONAL CD
AZ7271/14	1042CD personal	1.08.1997	PERSONAL CD

AZ7271/17	1042CD personal	1.02.1998	PERSONAL CD
AZ7271CS/37	1042CD personal		PERSONAL CD
AZ7272/00	1042CD personal	1.03.1997	PERSONAL CD
AZ7272/00R	1042CD personal	1.10.1997	PERSONAL CD
AZ7272/11S	1042CD personal	1.09.1997	PERSONAL CD
AZ7274/11	1042CD personal	1.05.1997	PERSONAL CD
AZ7275/00	1042CD personal	1.07.1997	PERSONAL CD
AZ7275/05	1042CD personal	1.05.1997	PERSONAL CD
AZ7275/17	1042CD personal	1.04.1998	PERSONAL CD
AZ7278/01	1042CD personal	1.09.1997	PERSONAL CD
AZ7278/11	1042CD personal		PERSONAL CD
AZ7331/17	1042CD personal	1.02.1998	PERSONAL CD
AZ7333/17	1042CD personal	1.04.1998	PERSONAL CD
AZ7337/17	1042CD personal	1.03.1998	PERSONAL CD
AZ7351/17Z	1042CD personal	1.05.1997	PERSONAL CD
AZ7356/17	1042CD personal	1.02.1997	PERSONAL CD
AZ7356/17Z	1042CD personal	1.02.1997	PERSONAL CD
AZ7360/00	1042CD personal	1.03.1997	PERSONAL CD
AZ7361/05	1042CD personal	1.09.1996	PERSONAL CD
AZ7362/00	1042CD personal	1.09.1996	PERSONAL CD
AZ7362/01	1042CD personal	1.10.1996	PERSONAL CD
AZ7362/11	1042CD personal	1.09.1996	PERSONAL CD
AZ7362/14	1042CD personal	1.04.1997	PERSONAL CD
AZ7363/17T	1042CD personal	1.06.1996	PERSONAL CD
AZ7363/19	1042CD personal	1.07.1997	PERSONAL CD
AZ7363CS/37	1042CD personal	1.04.1997	PERSONAL CD
AZ7364/00	1042CD personal	1.09.1996	PERSONAL CD
AZ7364/06	1042CD personal	1.11.1996	PERSONAL CD
AZ7365/11	1042CD personal	1.09.1996	PERSONAL CD
AZ7366/00	1042CD personal	1.09.1996	PERSONAL CD
AZ7366/01	1042CD personal	1.09.1996	PERSONAL CD
AZ7366/05	1042CD personal	1.09.1996	PERSONAL CD
AZ7366/10	1042CD personal	1.09.1996	PERSONAL CD
AZ7366/17	1042CD personal	1.06.1996	PERSONAL CD
AZ7368/10	1042CD personal		PERSONAL CD
AZ7368/10B	1042CD personal		PERSONAL CD
AZ7368/17	1042CD personal	1.08.1997	PERSONAL CD
AZ7372/00	1042CD personal	1.05.1997	PERSONAL CD
AZ7372/01	1042CD personal	1.08.1997	PERSONAL CD
AZ7372/14	1042CD personal	1.08.1997	PERSONAL CD
AZ7376/01	1042CD personal	1.08.1997	PERSONAL CD
AZ7381/00	1042CD personal	1.04.1998	PERSONAL CD

AZ7381/14	1042CD personal	1.08.1998	PERSONAL CD
AZ7382/00	1042CD personal	1.04.1998	PERSONAL CD
AZ7382/05	1042CD personal	1.04.1998	PERSONAL CD
AZ7382/11	1042CD personal	1.12.1997	PERSONAL CD
AZ7383/01	1042CD personal	1.06.1998	PERSONAL CD
AZ7383/05	1042CD personal	1.08.1998	PERSONAL CD
AZ7383/09	1042CD personal	1.11.1998	PERSONAL CD
AZ7383/11	1042CD personal	1.11.1998	PERSONAL CD
AZ7383/17	1042CD personal	1.03.1998	PERSONAL CD
AZ7384/00	1042CD personal	1.03.1999	PERSONAL CD
AZ7384/17	1042CD personal	1.05.1998	PERSONAL CD
AZ7385/00	1042CD personal	1.03.1999	PERSONAL CD
AZ7385/17	1042CD personal	1.06.1998	PERSONAL CD
AZ7386/00	1042CD personal	1.03.1999	PERSONAL CD
AZ7386/17	1042CD personal	1.06.1998	PERSONAL CD
AZ7387/00	1042CD personal	1.03.1999	PERSONAL CD
AZ7387/17	1042CD personal	1.09.1998	PERSONAL CD
AZ7388/00	1042CD personal	1.08.1998	PERSONAL CD
AZ7433/07	1042CD personal		PERSONAL CD
AZ7433/17	1042CD personal	1.12.1997	PERSONAL CD
AZ7433CS/17	1042CD personal		PERSONAL CD
AZ7433CS/37	1042CD personal		PERSONAL CD
AZ7443/17Z	1042CD personal	1.05.1997	PERSONAL CD
AZ7444/17Z	1042CD personal	1.06.1997	PERSONAL CD
AZ7445/17Z	1042CD personal	1.06.1997	PERSONAL CD
AZ7446/17Z	1042CD personal	1.06.1997	PERSONAL CD
AZ7453/17Z	1042CD personal	1.06.1997	PERSONAL CD
AZ7457/17	1042CD personal	1.06.1997	PERSONAL CD
AZ7460/00	1042CD personal	1.06.1997	PERSONAL CD
AZ7461/17	1042CD personal	1.09.1996	PERSONAL CD
AZ7462/00	1042CD personal	1.06.1997	PERSONAL CD
AZ7462/00R	1042CD personal	1.10.1997	PERSONAL CD
AZ7462/00S	1042CD personal	1.09.1997	PERSONAL CD
AZ7462/01	1042CD personal	1.02.1998	PERSONAL CD
AZ7462/05	1042CD personal	1.06.1997	PERSONAL CD
AZ7463/17	1042CD personal	1.03.1997	PERSONAL CD
AZ7463/17T	1042CD personal	1.06.1997	PERSONAL CD
AZ7464/00	1042CD personal	1.09.1996	PERSONAL CD
AZ7464/11	1042CD personal	1.09.1996	PERSONAL CD
AZ7464/14	1042CD personal	1.03.1997	PERSONAL CD
AZ7465/00	1042CD personal	1.09.1996	PERSONAL CD
AZ7465/00S	1042CD personal	1.10.1996	PERSONAL CD

AZ7465/06	1042CD personal	1.11.1996	PERSONAL CD
AZ7465/11	1042CD personal	1.09.1996	PERSONAL CD
AZ7466/10B	1042CD personal	1.11.1997	PERSONAL CD
AZ7466/10G	1042CD personal	1.11.1997	PERSONAL CD
AZ7466/10L	1042CD personal	1.11.1997	PERSONAL CD
AZ7466/10S	1042CD personal	1.11.1997	PERSONAL CD
AZ7466/17	1042CD personal	1.07.1996	PERSONAL CD
AZ7467/17	1042CD personal	1.06.1996	PERSONAL CD
AZ7474/00	1042CD personal	1.04.1997	PERSONAL CD
AZ7474/00S	1042CD personal	1.09.1997	PERSONAL CD
AZ7474/14	1042CD personal	1.08.1997	PERSONAL CD
AZ7476/00	1042CD personal	1.06.1997	PERSONAL CD
AZ7476/05	1042CD personal	1.06.1997	PERSONAL CD
AZ7481/00	1042CD personal	1.02.1998	PERSONAL CD
AZ7481/05	1042CD personal	1.07.1998	PERSONAL CD
AZ7482/00	1042CD personal	1.03.1998	PERSONAL CD
AZ7482/05	1042CD personal	1.04.1998	PERSONAL CD
AZ7483/00	1042CD personal	1.05.1998	PERSONAL CD
AZ7483/10	1042CD personal	1.07.1998	PERSONAL CD
AZ7483/17	1042CD personal	1.02.1998	PERSONAL CD
AZ7494/00	1042CD personal	1.09.1998	PERSONAL CD
AZ7495/11H	1042CD personal	1.10.1998	PERSONAL CD
AZ7562/00	1042CD personal	1.06.1997	PERSONAL CD
AZ7562/00S	1042CD personal	1.09.1997	PERSONAL CD
AZ7562/05	1042CD personal	1.06.1997	PERSONAL CD
AZ7565/00	1042CD personal	1.05.1997	PERSONAL CD
AZ7565/05	1042CD personal	1.06.1997	PERSONAL CD
AZ7566/10	1042CD personal	1.11.1997	PERSONAL CD
AZ7566/17	1042CD personal	1.05.1997	PERSONAL CD
AZ7566/17T	1042CD personal	1.06.1997	PERSONAL CD
AZ7566CS/37	1042CD personal	1.08.1997	PERSONAL CD
AZ7576/17	1042CD personal	1.10.1997	PERSONAL CD
AZ7582/00	1042CD personal	1.05.1998	PERSONAL CD
AZ7582/05	1042CD personal	1.06.1998	PERSONAL CD
AZ7583/17	1042CD personal	1.05.1998	PERSONAL CD
AZ7594/14	1042CD personal	1.12.1998	PERSONAL CD
AZ7594/17	1042CD personal	1.12.1998	PERSONAL CD
AZ7595/00	1042CD personal	1.12.1998	PERSONAL CD
AZ7595/10	1042CD personal	1.12.1998	PERSONAL CD
AZ7595/11	1042CD personal	1.11.1998	PERSONAL CD
AZ7595/11H	1042CD personal	1.09.1998	PERSONAL CD
AZ7680/00	1042CD personal	1.05.1999	PERSONAL CD

AZ7680/00Z	1042CD personal	1.08.1999	PERSONAL CD
AZ7681/00	1042CD personal	1.05.1999	PERSONAL CD
AZ7681/00Z	1042CD personal	1.08.1999	PERSONAL CD
AZ7681/01	1042CD personal	1.04.1999	PERSONAL CD
AZ7681/05	1042CD personal	1.06.1999	PERSONAL CD
AZ7681/09Z	1042CD personal	1.07.1999	PERSONAL CD
AZ7681/11	1042CD personal		PERSONAL CD
AZ7681/14	1042CD personal	1.06.1999	PERSONAL CD
AZ7681/16	1042CD personal	1.10.1999	PERSONAL CD
AZ7681/17	1042CD personal	1.03.1999	PERSONAL CD
AZ7682/00	1042CD personal	1.05.1999	PERSONAL CD
AZ7682/10	1042CD personal	1.06.1999	PERSONAL CD
AZ7682/11	1042CD personal	1.02.1999	PERSONAL CD
AZ7688/01	1042CD personal	1.06.1999	PERSONAL CD
AZ7688/09	1042CD personal	1.06.1999	PERSONAL CD
AZ7688/16	1042CD personal	1.08.1999	PERSONAL CD
AZ7779/17	1042CD personal	1.06.1999	PERSONAL CD
AZ7780/17	1042CD personal	1.06.1999	PERSONAL CD
AZ7781/00	1042CD personal	1.04.1999	PERSONAL CD
AZ7781/00Z	1042CD personal	1.09.1999	PERSONAL CD
AZ7781/05	1042CD personal	1.06.1999	PERSONAL CD
AZ7781/07	1042CD personal		PERSONAL CD
AZ7781/14	1042CD personal	1.06.1999	PERSONAL CD
AZ7781/17	1042CD personal	1.04.1999	PERSONAL CD
AZ7782/00	1042CD personal	1.05.1999	PERSONAL CD
AZ7782/05	1042CD personal	1.06.1999	PERSONAL CD
AZ7782/11	1042CD personal	1.03.1999	PERSONAL CD
AZ7782/17	1042CD personal	1.06.1999	PERSONAL CD
AZ7783/00	1042CD personal	1.06.1999	PERSONAL CD
AZ7783/01	1042CD personal	1.04.1999	PERSONAL CD
AZ7783/07	1042CD personal		PERSONAL CD
AZ7783/09	1042CD personal	1.08.1999	PERSONAL CD
AZ7783/10	1042CD personal	1.09.1999	PERSONAL CD
AZ7783/17	1042CD personal	1.02.1999	PERSONAL CD
AZ7784/00	1042CD personal	1.06.1999	PERSONAL CD
AZ7784/17	1042CD personal	1.07.1999	PERSONAL CD
AZ7785/17	1042CD personal	1.07.1999	PERSONAL CD
AZ7786/17	1042CD personal	1.07.1999	PERSONAL CD
AZ7787/17	1042CD personal	1.06.1999	PERSONAL CD
AZ7792/17	1042CD personal	1.07.1999	PERSONAL CD
AZ7793/17	1042CD personal	1.08.1999	PERSONAL CD
AZ7794/00	1042CD personal	1.05.1999	PERSONAL CD

AZ7795/17	1042CD personal	1.03.2000	PERSONAL CD
AZ7796/17	1042CD personal	1.04.2000	PERSONAL CD
AZ7798/17	1042CD personal	1.03.2000	PERSONAL CD
AZ7880/01	1042CD personal		PERSONAL CD
AZ7880/17	1042CD personal	1.03.1999	PERSONAL CD
AZ7881/00	1042CD personal	1.05.1999	PERSONAL CD
AZ7881/17	1042CD personal	1.04.1999	PERSONAL CD
AZ7882/00	1042CD personal	1.05.1999	PERSONAL CD
AZ7882/05	1042CD personal	1.06.1999	PERSONAL CD
AZ7882/14	1042CD personal	1.06.1999	PERSONAL CD
AZ7883/07	1042CD personal		PERSONAL CD
AZ7883/10	1042CD personal	1.07.1999	PERSONAL CD
AZ7883/16	1042CD personal		PERSONAL CD
AZ7883/17	1042CD personal	1.02.1999	PERSONAL CD
AZ7884/00	1042CD personal	1.05.1999	PERSONAL CD
AZ7884/05	1042CD personal	1.06.1999	PERSONAL CD
AZ7884/11	1042CD personal	1.03.1999	PERSONAL CD
AZ7884/17	1042CD personal	1.05.1999	PERSONAL CD
AZ7889/01	1042VCD personal	1.05.1997	PERSONAL CD
AZ7889/11H	1042VCD personal	1.06.1998	PERSONAL CD
AZ7894/00	1042CD personal	1.07.1999	PERSONAL CD
AZ7895/10	1042CD personal		PERSONAL CD
AZ7895/11	1042CD personal		PERSONAL CD
AZ7895/11H	1042CD personal		PERSONAL CD
AZ7900/00	1042CD personal	1.04.2000	PERSONAL CD
AZ7900/00Z	1042CD personal	1.05.2000	PERSONAL CD
AZ7900/17	1042CD personal		PERSONAL CD
AZ7901/00	1042CD personal	1.03.2000	PERSONAL CD
AZ7901/00T	1042CD personal		PERSONAL CD
AZ7901/00Z	1042CD personal	1.05.2000	PERSONAL CD
AZ7901/01	1042CD personal	1.04.2000	PERSONAL CD
AZ7901/05	1042CD personal	1.04.2000	PERSONAL CD
AZ7901/06	1042CD personal		PERSONAL CD
AZ7901/09Z	1042CD personal	1.06.2000	PERSONAL CD
AZ7901/10	1042CD personal	1.10.2000	PERSONAL CD
AZ7901/11	1042CD personal	1.03.2000	PERSONAL CD
AZ7901/13	1042CD personal		PERSONAL CD
AZ7901/16	1042CD personal		PERSONAL CD
AZ7901/19	1042CD personal	1.02.2001	PERSONAL CD
AZ7901/19E	1042CD personal	1.04.2001	PERSONAL CD
AZ7902/00	1042CD personal	1.04.2000	PERSONAL CD
AZ7911/00	1042CD personal	1.03.2000	PERSONAL CD

AZ8006/00	1042Single deck	1.08.1994	RADIORECORDERS + CD
AZ8006/10	1042Single deck	1.10.1994	RADIORECORDERS + CD
AZ8006/17	1042Single deck	1.09.1993	RADIORECORDERS + CD
AZ8010/17	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8012/00	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8020/01	1042Single deck	1.05.1992	RADIORECORDERS + CD
AZ8020/10	1042Single deck	1.05.1992	RADIORECORDERS + CD
AZ8020/17	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8020/37	1042Single deck	1.12.1993	RADIORECORDERS + CD
AZ8022/00	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8022/05	1042Single deck	1.04.1992	RADIORECORDERS + CD
AZ8022/14	1042Single deck	1.07.1992	RADIORECORDERS + CD
AZ8022/20	1042Single deck	1.05.1993	RADIORECORDERS + CD
AZ8025/17	1042Single deck	1.07.1992	RADIORECORDERS + CD
AZ8030/00	1042Single deck	1.03.1993	RADIORECORDERS + CD
AZ8030/01	1042Single deck	1.02.1993	RADIORECORDERS + CD
AZ8030/05	1042Single deck	1.04.1993	RADIORECORDERS + CD
AZ8030/10	1042Single deck	1.07.1993	RADIORECORDERS + CD
AZ8030/20	1042Single deck	1.06.1993	RADIORECORDERS + CD
AZ8030/21	1042Single deck	1.08.1993	RADIORECORDERS + CD
AZ8030/25	1042Single deck	1.09.1993	RADIORECORDERS + CD
AZ8035/17	1042Single deck	1.05.1993	RADIORECORDERS + CD
AZ8035/37	1042Single deck	1.09.1993	RADIORECORDERS + CD
AZ8040/00	1042Single deck	1.03.1994	RADIORECORDERS + CD
AZ8040/05	1042Single deck	1.05.1994	RADIORECORDERS + CD
AZ8040/10	1042Single deck	1.08.1994	RADIORECORDERS + CD
AZ8040/19	1042Single deck	1.03.1995	RADIORECORDERS + CD
AZ8040/20	1042Single deck	1.07.1994	RADIORECORDERS + CD
AZ8040/20M	1042Single deck	1.12.1994	RADIORECORDERS + CD
AZ8040/21	1042Single deck	1.04.1994	RADIORECORDERS + CD
AZ8040/41	1042Single deck	1.04.1995	RADIORECORDERS + CD
AZ8048/00	1042Single deck	1.06.1995	RADIORECORDERS + CD
AZ8048/01	1042Single deck	1.10.1995	RADIORECORDERS + CD
AZ8048/05	1042Single deck	1.06.1995	RADIORECORDERS + CD
AZ8048/17	1042Single deck	1.06.1995	RADIORECORDERS + CD
AZ8049/00	1042Single deck	1.11.1995	RADIORECORDERS + CD
AZ8049/05	1042Single deck	1.12.1996	RADIORECORDERS + CD
AZ8049/17	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8050/06	1042Single deck	1.10.1995	RADIORECORDERS + CD
AZ8050/10	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8050/10D	1042Single deck	1.11.1996	RADIORECORDERS + CD
AZ8050/10S	1042Single deck	1.11.1996	RADIORECORDERS + CD

AZ8050/17	1042Single deck	1.05.1995	RADIORECORDERS + CD
AZ8050/17D	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ8051/01	1042Single deck	1.05.1995	RADIORECORDERS + CD
AZ8051/01B	1042Single deck	1.03.1996	RADIORECORDERS + CD
AZ8051/01D	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ8051/10B	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ8051/11	1042Single deck	1.12.1995	RADIORECORDERS + CD
AZ8051/11D	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ8051/11H	1042Single deck	1.03.1996	RADIORECORDERS + CD
AZ8051/12	1042Single deck	1.04.1996	RADIORECORDERS + CD
AZ8051/12B	1042Single deck	1.12.1997	RADIORECORDERS + CD
AZ8051/13B	1042Single deck		RADIORECORDERS + CD
AZ8051/19	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ8052/00	1042Single deck	1.07.1995	RADIORECORDERS + CD
AZ8052/00B	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ8052/00D	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ8052/00R	1042Single deck	1.10.1997	RADIORECORDERS + CD
AZ8052/05	1042Single deck	1.09.1996	RADIORECORDERS + CD
AZ8052/14	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8055/17	1042Single deck	1.07.1995	RADIORECORDERS + CD
AZ8056/01	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8057/00	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ8057/05	1042Single deck	1.12.1995	RADIORECORDERS + CD
AZ8057/14	1042Single deck	1.10.1996	RADIORECORDERS + CD
AZ8061/00	1042Single deck	1.02.1996	RADIORECORDERS + CD
AZ8061/17	1042Single deck	1.03.1996	RADIORECORDERS + CD
AZ8061/17D	1042Single deck	1.12.1996	RADIORECORDERS + CD
AZ8068/17	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8070/00S	1042Single deck	1.02.1997	RADIORECORDERS + CD
AZ8070/01	1042Single deck	1.03.1997	RADIORECORDERS + CD
AZ8070/05S	1042Single deck	1.02.1997	RADIORECORDERS + CD
AZ8070/11	1042Single deck	1.01.1997	RADIORECORDERS + CD
AZ8070/14	1042Single deck	1.04.1997	RADIORECORDERS + CD
AZ8070/17	1042Single deck	1.04.1997	RADIORECORDERS + CD
AZ8070/17S	1042Single deck	1.07.1997	RADIORECORDERS + CD
AZ8075/00S	1042Single deck	1.02.1997	RADIORECORDERS + CD
AZ8075/01	1042Single deck	1.03.1997	RADIORECORDERS + CD
AZ8075/05S	1042Single deck	1.06.1997	RADIORECORDERS + CD
AZ8075/11	1042Single deck	1.04.1997	RADIORECORDERS + CD
AZ8084/16	1042Single deck		RADIORECORDERS + CD
AZ8084/17	1042Single deck	1.06.1999	RADIORECORDERS + CD
AZ8085/17	1042Single deck	1.06.1999	RADIORECORDERS + CD

AZ8086/16	1042Single deck		RADIORECORDERS + CD
AZ8086/17	1042Single deck	1.06.1999	RADIORECORDERS + CD
AZ8087/17	1042Single deck	1.06.1999	RADIORECORDERS + CD
AZ8110/17	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8114/00	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8140/00	1042Single deck	1.04.1994	RADIORECORDERS + CD
AZ8140/17	1042Single deck	1.06.1994	RADIORECORDERS + CD
AZ8140/53	1042Single deck		RADIORECORDERS + CD
AZ8150/17	1042Single deck	1.06.1995	RADIORECORDERS + CD
AZ8210/17	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8214/00	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8240/00	1042Single deck	1.05.1994	RADIORECORDERS + CD
AZ8240/05	1042Single deck	1.07.1994	RADIORECORDERS + CD
AZ8245/00	1042Single deck	1.01.1995	RADIORECORDERS + CD
AZ8250/00	1042Single deck	1.12.1994	RADIORECORDERS + CD
AZ8262/00	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ8262/05	1042Single deck	1.11.1995	RADIORECORDERS + CD
AZ8262/17	1042Single deck	1.05.1996	RADIORECORDERS + CD
AZ8267/00	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ8267/05	1042Single deck	1.12.1995	RADIORECORDERS + CD
AZ8267/17	1042Single deck	1.05.1996	RADIORECORDERS + CD
AZ8289/17	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8300/30	1042Single deck	1.05.1992	RADIORECORDERS + CD
AZ8300/37	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8301/01	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8301/19	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8301/21	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8304/05	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8304/20	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8304/25	1042Single deck	1.04.1992	RADIORECORDERS + CD
AZ8310/00	1042Single deck	1.11.1994	RADIORECORDERS + CD
AZ8310/10	1042Single deck	1.09.1993	RADIORECORDERS + CD
AZ8310/17	1042Single deck	1.08.1993	RADIORECORDERS + CD
AZ8320/00	1042Single deck	1.12.1992	RADIORECORDERS + CD
AZ8320/01	1042Single deck	1.04.1993	RADIORECORDERS + CD
AZ8320/05	1042Single deck	1.02.1993	RADIORECORDERS + CD
AZ8320/10	1042Single deck	1.06.1993	RADIORECORDERS + CD
AZ8340/00	1042Single deck	1.05.1994	RADIORECORDERS + CD
AZ8340/01	1042Single deck	1.06.1994	RADIORECORDERS + CD
AZ8340/05	1042Single deck	1.07.1994	RADIORECORDERS + CD
AZ8340/17	1042Single deck	1.06.1994	RADIORECORDERS + CD
AZ8340/19	1042Single deck	1.01.1995	RADIORECORDERS + CD

AZ8345/17	1042Single deck	1.07.1994	RADIORECORDERS + CD
AZ8348/00	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ8348/01	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8348/05	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8348/17	1042Single deck	1.05.1995	RADIORECORDERS + CD
AZ8349/00	1042Single deck	1.11.1995	RADIORECORDERS + CD
AZ8349/05	1042Single deck	1.05.1996	RADIORECORDERS + CD
AZ8350/17	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8351/01	1042Double deck	1.06.1995	RADIORECORDERS + CD
AZ8352/00	1042Single deck	1.06.1995	RADIORECORDERS + CD
AZ8352/05	1042Single deck	1.07.1995	RADIORECORDERS + CD
AZ8352/14	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8357/00	1042Single deck	1.07.1995	RADIORECORDERS + CD
AZ8357/05	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ8400/10	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8400/13R	1042Single deck		RADIORECORDERS + CD
AZ8400/17	1042Single deck	1.04.1992	RADIORECORDERS + CD
AZ8400/30	1042Single deck	1.04.1992	RADIORECORDERS + CD
AZ8400/37	1042Single deck	1.05.1992	RADIORECORDERS + CD
AZ8401/01	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8401/21	1042Single deck	1.05.1992	RADIORECORDERS + CD
AZ8404/00	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8404/05	1042Single deck	1.03.1992	RADIORECORDERS + CD
AZ8404/20	1042Single deck	1.04.1992	RADIORECORDERS + CD
AZ8404/25	1042Single deck	1.03.1993	RADIORECORDERS + CD
AZ8420/00	1042Single deck	1.08.1993	RADIORECORDERS + CD
AZ8440/00	1042Single deck	1.09.1994	RADIORECORDERS + CD
AZ8440/01	1042Single deck	1.09.1994	RADIORECORDERS + CD
AZ8440/17	1042Single deck	1.06.1994	RADIORECORDERS + CD
AZ8445/17	1042Single deck	1.09.1994	RADIORECORDERS + CD
AZ8540/00	1042Single deck	1.10.1994	RADIORECORDERS + CD
AZ8545/06	1042Single deck	1.10.1994	RADIORECORDERS + CD
AZ8562/00	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ8567/00	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ8567/05	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ8640/00	1042Double deck	1.09.1994	RADIORECORDERS + CD
AZ8640/02	1042Single deck	1.10.1994	RADIORECORDERS + CD
AZ8640/05	1042Single deck	1.10.1994	RADIORECORDERS + CD
AZ8700/17	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8700/19	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8704/00	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8900/01	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO

AZ8900/17	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8900/19	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8904/00	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ8904/02	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ9001/00	1042CD personal	1.04.2000	PERSONAL CD
AZ9001/00Z	1042CD personal	1.05.2000	PERSONAL CD
AZ9001/05	1042CD personal	1.05.2000	PERSONAL CD
AZ9001/11	1042CD personal	1.03.2000	PERSONAL CD
AZ9001/17	1042CD personal	1.03.2000	PERSONAL CD
AZ9002/00	1042CD personal	1.04.2000	PERSONAL CD
AZ9002/05	1042CD personal	1.05.2000	PERSONAL CD
AZ9003/00	1042CD personal		PERSONAL CD
AZ9003/01	1042CD personal	1.04.2000	PERSONAL CD
AZ9003/09	1042CD personal	1.05.2000	PERSONAL CD
AZ9003/10	1042CD personal	1.05.2000	PERSONAL CD
AZ9003/19	1042CD personal	1.02.2001	PERSONAL CD
AZ9011/00	1042CD personal	1.06.2000	PERSONAL CD
AZ9015/00	1042CD personal	1.06.2000	PERSONAL CD
AZ9020/00	1042Single deck	1.07.1992	RADIORECORDERS + CD
AZ9020/01	1042Single deck	1.08.1992	RADIORECORDERS + CD
AZ9020/05	1042Single deck	1.12.1992	RADIORECORDERS + CD
AZ9020/10	1042Single deck	1.09.1992	RADIORECORDERS + CD
AZ9020/17	1042Single deck	1.06.1992	RADIORECORDERS + CD
AZ9025/17	1042Single deck	1.09.1992	RADIORECORDERS + CD
AZ9040/00	1042Single deck	1.08.1994	RADIORECORDERS + CD
AZ9040/01	1042Single deck	1.07.1994	RADIORECORDERS + CD
AZ9040/05	1042Single deck	1.08.1994	RADIORECORDERS + CD
AZ9040/17	1042Compo's	1.05.1995	RADIORECORDERS + CD
AZ9055/00	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ9055/01	1042Single deck	1.10.1995	RADIORECORDERS + CD
AZ9055/05	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ9055/11	1042Single deck	1.06.1996	RADIORECORDERS + CD
AZ9055/11H	1042Single deck	1.08.1996	RADIORECORDERS + CD
AZ9055/17	1042Single deck	1.07.1995	RADIORECORDERS + CD
AZ9101/17	1042CD personal	1.01.2000	PERSONAL CD
AZ9102/17	1042CD personal	1.05.2000	PERSONAL CD
AZ9103/17	1042CD personal	1.02.2000	PERSONAL CD
AZ9104/16	1042CD personal	1.06.2000	PERSONAL CD
AZ9104/17	1042CD personal	1.01.2000	PERSONAL CD
AZ9106/17	1042CD personal	1.05.2000	PERSONAL CD
AZ9111/17	1042CD personal	1.03.2000	PERSONAL CD
AZ9113/17	1042CD personal	1.03.2000	PERSONAL CD

AZ9141/17	1042CD personal		PERSONAL CD
AZ9142/17	1042CD personal		PERSONAL CD
AZ9143/17	1042CD personal	1.09.2001	PERSONAL CD
AZ9201/00	1042CD personal	1.02.2000	PERSONAL CD
AZ9202/00	1042CD personal	1.03.2000	PERSONAL CD
AZ9202/05	1042CD personal	1.05.2000	PERSONAL CD
AZ9202/11	1042CD personal	1.01.2000	PERSONAL CD
AZ9202/13	1042CD personal		PERSONAL CD
AZ9203/10	1042CD personal	1.04.2000	PERSONAL CD
AZ9210/17	1042Radio cassette recorders - mono	1.05.1992	RADIO MONO + STEREO
AZ9211/00	1042CD personal		PERSONAL CD
AZ9213/17	1042CD personal	1.04.2000	PERSONAL CD
AZ9214/00	1042CD personal	1.05.2000	PERSONAL CD
AZ9214/17	1042CD personal		PERSONAL CD
AZ9217/17	1042CD personal		PERSONAL CD
AZ9218/17	1042CD personal		PERSONAL CD
AZ9225/00	1042CD personal	1.08.2000	PERSONAL CD
AZ9225/05	1042CD personal		PERSONAL CD
AZ9225/17	1042CD personal	1.08.2001	PERSONAL CD
AZ9235/00	1042CD personal	1.05.2001	PERSONAL CD
AZ9250/00	1042CD personal		PERSONAL CD
AZ9250/11	1042CD personal		PERSONAL CD
AZ9250/13	1042CD personal		PERSONAL CD
AZ9250/17	1042CD personal		PERSONAL CD
AZ9251/00	1042CD personal		PERSONAL CD
AZ9251/10	1042CD personal		PERSONAL CD
AZ9251/17	1042CD personal		PERSONAL CD
AZ9310/01	1042Single deck	1.08.1992	RADIORECORDERS + CD
AZ9338/17	1042Single deck	1.08.1994	RADIORECORDERS + CD
AZ9340/00	1042Single deck	1.08.1994	RADIORECORDERS + CD
AZ9340/01	1042Compo's	1.07.1994	RADIORECORDERS + CD
AZ9340/06	1042Compo's	1.03.1995	RADIORECORDERS + CD
AZ9340/10	1042Single deck	1.09.1994	RADIORECORDERS + CD
AZ9340/14	1042Single deck	1.10.1994	RADIORECORDERS + CD
AZ9340/17	1042Single deck	1.06.1994	RADIORECORDERS + CD
AZ9345/01	1042Single deck	1.04.1995	RADIORECORDERS + CD
AZ9345/17	1042Single deck	1.06.1994	RADIORECORDERS + CD
AZ9350/01	1042Single deck	1.06.1995	RADIORECORDERS + CD
AZ9350/05	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ9350/10	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ9350/14	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ9350/17	1042Compo's	1.07.1995	RADIORECORDERS + CD

AZ9355/00	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ9355/01	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ9430/01	1042Single deck	1.02.1993	RADIORECORDERS + CD
AZ9430/10	1042Single deck	1.08.1993	RADIORECORDERS + CD
AZ9430/17	1042Single deck	1.03.1993	RADIORECORDERS + CD
AZ9435/00	1042Single deck	1.04.1993	RADIORECORDERS + CD
AZ9435/05	1042Single deck	1.08.1993	RADIORECORDERS + CD
AZ9435/17	1042Single deck	1.04.1993	RADIORECORDERS + CD
AZ9440/00	1042Single deck	1.11.1994	RADIORECORDERS + CD
AZ9440/01	1042Single deck	1.10.1994	RADIORECORDERS + CD
AZ9440/17	1042Compo's	1.08.1994	RADIORECORDERS + CD
AZ9510/17	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ9555/00	1042Single deck	1.06.1995	RADIORECORDERS + CD
AZ9555/01	1042Single deck	1.08.1995	RADIORECORDERS + CD
AZ9555/17	1042Compo's	1.07.1995	RADIORECORDERS + CD
AZ9613/01	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ9614/00	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ9710/21	1042Single deck	1.05.1992	RADIORECORDERS + CD
AZ9710/39	1042Compo's	1.03.1992	RADIORECORDERS + CD
AZ9712/20	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ9712/22	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ9712/25	1042Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
AZ9855/01	1042Single deck	1.09.1995	RADIORECORDERS + CD
AZ9855/07	1042Single deck	1.12.1995	RADIORECORDERS + CD
AZ9855/17	1042Single deck	1.06.1995	RADIORECORDERS + CD
AZ9898/11	1042CD personal	1.08.1998	PERSONAL CD
AZ9898/11H	1042CD personal	1.08.1998	PERSONAL CD
AZ9898/31	1042CD personal	1.04.2000	PERSONAL CD
AZ9898/31H	1042CD personal	1.03.2000	PERSONAL CD
AZ9899/11	1042CD personal	1.10.1999	PERSONAL CD
AZ9899/11H	1042CD personal		PERSONAL CD
AZ9899/31	1042CD personal	1.03.2000	PERSONAL CD
AZ9955/17	1042Single deck	1.05.1995	RADIORECORDERS + CD
AZT9230/00	1042CD personal	1.06.2000	PERSONAL CD
AZT9230/01	1042CD personal	1.07.2000	PERSONAL CD
AZT9230/09Z	1042CD personal		PERSONAL CD
AZT9230/10	1042CD personal		PERSONAL CD
AZT9230/11	1042CD personal		PERSONAL CD
AZT9230/17	1042CD personal	1.08.2001	PERSONAL CD
AZT9230/19	1042CD personal	1.04.2001	PERSONAL CD
AZT9240/00	1042CD personal	1.04.2001	PERSONAL CD
AZT9240/01	1042CD personal	1.05.2001	PERSONAL CD

AZT9240/17	1042CD personal	1.10.2001	PERSONAL CD
AZT9240/17P	1042CD personal	1.08.2001	PERSONAL CD
AZT9240/19	1042CD personal		PERSONAL CD
AZT9500/00C	1042CD personal		PERSONAL CD
AZT9500/11	1042CD personal		PERSONAL CD
AZT9500/17	1042CD personal		PERSONAL CD
AZT9505/17	1042CD personal		PERSONAL CD
BDE353/00G	2012MAC terminal	1.11.1995	SATELLITE
BDE353/05G	2012PAL/SECAM terminal	1.12.1995	SATELLITE
BV225EGC	1021Leader	1.03.1996	VCR
BV230EC1	1021Leader	1.01.1995	VCR
BV230EC2	1021Leader	1.11.1994	VCR
BV230EGC	1021Leader	1.03.1995	VCR
BV230OIRT	1021Leader	1.03.1995	VCR
BV245EC	1021Leader	1.08.1995	VCR
BV245EC3	1021Leader	1.12.1995	VCR
BV245EGC	1021Leader	1.07.1995	VCR
BV245OIRT	1021Leader	1.08.1995	VCR
BV445EC	1021Leader show view	1.12.1995	VCR
BV445OIRT	1021Leader show view	1.08.1995	VCR
C1420VT/311	1022Leader		TVCR
CABLECRYP/2	2012Institutional analogue		SATELLITE
CALGARYB/92	1004		TELEPHONES ANSWERING
CC4000/F3B	2012Institutional analogue		SATELLITE
CC4000/K3B	2012Institutional analogue		SATELLITE
CC4000/U3B	2012Institutional analogue		SATELLITE
CD15/11	1042CD personal	1.08.1997	PERSONAL CD
CD163/00	1049CD	1.01.1995	CD PLAYERS
CD163/01	1049CD	1.09.1994	CD PLAYERS
CD163/05	1049CD	1.09.1994	CD PLAYERS
CD163CL/15	1049CD		CD PLAYERS
CD165/00	1049CD	1.03.1995	CD PLAYERS
CD165/01	1049CD	1.08.1994	CD PLAYERS
CD601/25	1049CD	1.09.1994	CD PLAYERS
CD602/25	1049CD	1.09.1994	CD PLAYERS
CD618/05B	1049CD	1.03.1992	CD PLAYERS
CD6660/00	1042Cassette only	1.06.1998	PERSONAL STEREO
CD710/00	1049CD	1.08.1995	CD PLAYERS
CD710/00B	1049CD	1.05.1994	CD PLAYERS
CD710/05	1049CD	1.09.1995	CD PLAYERS
CD710/05B	1049CD	1.07.1994	CD PLAYERS
CD711/00	1049CD	1.09.1995	CD PLAYERS

CD713/00	1049CD	1.08.1998	CD PLAYERS
CD713/20	1049CD	1.01.2000	CD PLAYERS
CD720/00	1049CD	1.08.1995	CD PLAYERS
CD720/00B	1049CD	1.05.1994	CD PLAYERS
CD720/01B	1049CD	1.06.1994	CD PLAYERS
CD720/05	1049CD	1.09.1995	CD PLAYERS
CD720/05B	1049CD	1.07.1994	CD PLAYERS
CD721/00	1049CD	1.08.1995	CD PLAYERS
CD721/01	1049CD	1.09.1995	CD PLAYERS
CD721/05	1049CD	1.09.1995	CD PLAYERS
CD721/17	1049CD	1.09.1996	CD PLAYERS
CD721/34	1049CD	1.04.1997	CD PLAYERS
CD722/00	1049CD	1.09.1997	CD PLAYERS
CD723/00	1049CD	1.07.1998	CD PLAYERS
CD723/01	1049CD	1.08.1998	CD PLAYERS
CD723/14	1049CD	1.09.1998	CD PLAYERS
CD723/20	1049CD	1.02.2000	CD PLAYERS
CD723/21	1049CD		CD PLAYERS
CD733/00	1049CD	1.09.1995	CD PLAYERS
CD733/00B	1049CD	1.04.1995	CD PLAYERS
CD740/00B	1049CD	1.06.1994	CD PLAYERS
CD740/01B	1049CD	1.09.1994	CD PLAYERS
CD740/05B	1049CD	1.07.1994	CD PLAYERS
CD750/00B	1049CD	1.06.1994	CD PLAYERS
CD750/01B	1049CD	1.08.1994	CD PLAYERS
CD750/05B	1049CD	1.07.1994	CD PLAYERS
CD750/06B	1049CD	1.10.1994	CD PLAYERS
CD751/00	1049CD	1.08.1996	CD PLAYERS
CD751/01	1049CD	1.09.1996	CD PLAYERS
CD751/34	1049CD	1.11.1997	CD PLAYERS
CD753/00	1049CD	1.08.1998	CD PLAYERS
CD753/01	1049CD	1.09.1998	CD PLAYERS
CD753/14	1049CD	1.10.1998	CD PLAYERS
CD753/20	1049CD	1.02.2000	CD PLAYERS
CD753/21	1049CD		CD PLAYERS
CD824/00B	1049CD	1.03.1992	CD PLAYERS
CD850/20B	1049CD	1.05.1993	CD PLAYERS
CD850/25B	1049CD	1.05.1993	CD PLAYERS
CD850II/20B	1049CD	1.03.1992	CD PLAYERS
CD850II/25B	1049CD	1.03.1992	CD PLAYERS
CD887V/00M	1049CD	1.08.1998	CD PLAYERS
CD911/00S	1049CD	1.08.1994	CD PLAYERS

CD921/17S	1049CD	1.08.1994	CD PLAYERS
CD931/00S	1049CD	1.06.1994	CD PLAYERS
CD931/01S	1049CD	1.05.1994	CD PLAYERS
CD951/00S	1049CD	1.08.1994	CD PLAYERS
CD951/01M	1049CD	1.10.1994	CD PLAYERS
CD951/01S	1049CD	1.07.1994	CD PLAYERS
CD951/06S	1049CD	1.07.1994	CD PLAYERS
CDC265/01	1049CD Video	1.05.1995	CDC / CDV
CDC345/00	1049	1.03.1992	MIDISYSTEMS
CDC552/30	1049CD Video	1.03.1992	CDC / CDV
CDC725/17	1049CD Video	1.09.1996	CDC / CDV
CDC735/17	1049CD Video	1.03.1998	CDC / CDV
CDC745/00	1049CD Video	1.04.1994	CDC / CDV
CDC745/05	1049CD Video	1.06.1994	CDC / CDV
CDC745/17	1049CD Video	1.06.1994	CDC / CDV
CDC748/17	1049CD Video	1.06.1995	CDC / CDV
CDC751/00B	1049CD Video	1.07.1995	CDC / CDV
CDC751/01B	1049CD Video	1.08.1995	CDC / CDV
CDC751/17	1049CD Video	1.09.1996	CDC / CDV
CDC752/00	1049CD Video	1.08.1997	CDC / CDV
CDC763V/01M	1049CD Video	1.01.1997	CDC / CDV
CDC771V/00	1049CD Video	1.05.1996	CDC / CDV
CDC771V/01	1049CD Video	1.11.1995	CDC / CDV
CDC771V/17	1049CD Video	1.07.1996	CDC / CDV
CDC775/00	1049CD	1.04.1999	CD PLAYERS
CDC775/00G	1049CD	1.01.2000	CD PLAYERS
CDC775/01	1049CD	1.05.1999	CD PLAYERS
CDC775/14	1049CD	1.06.1999	CD PLAYERS
CDC775/17	1049CD	1.04.1999	CD PLAYERS
CDC775/17G	1049CD		CD PLAYERS
CDC792/17	1049CD Video	1.07.1992	CDC / CDV
CDC792/17H	1049CD Video	1.06.1993	CDC / CDV
CDC792/17T	1049CD Video	1.01.1993	CDC / CDV
CDC794/17	1049CD Video	1.09.1993	CDC / CDV
CDC796/17	1049CD Video	1.06.1993	CDC / CDV
CDC828V/00M	1049CD Video	1.10.1998	CDC / CDV
CDC915/17S	1049CD Video	1.06.1993	CDC / CDV
CDC916/00S	1049CD Video	1.09.1994	CDC / CDV
CDC916/17S	1049CD Video	1.08.1994	CDC / CDV
CDC925/00S	1049CD Video	1.07.1992	CDC / CDV
CDC925/17S	1049CD Video	1.07.1992	CDC / CDV
CDC925/20S	1049CD Video	1.06.1993	CDC / CDV

CDC925/37S	1049CD Video	1.03.1993	CDC / CDV
CDC926/00S	1049CD Video	1.11.1994	CDC / CDV
CDC926/17S	1049CD Video	1.08.1994	CDC / CDV
CDC935/00S	1049CD Video	1.09.1992	CDC / CDV
CDC935/17S	1049CD Video	1.07.1992	CDC / CDV
CDC935/20S	1049CD Video	1.06.1993	CDC / CDV
CDC935/25S	1049CD Video	1.08.1993	CDC / CDV
CDC935/37S	1049CD Video	1.03.1993	CDC / CDV
CDC936/00S	1049CD Video	1.08.1995	CDC / CDV
CDC936/17S	1049CD Video	1.08.1995	CDC / CDV
CDC999V/35	1049CD Video		CDC / CDV
CDI200/17	1054CDI	1.09.1993	CDI
CDI200/37	1054CDI	1.05.1994	CDI
CDI205/00	1054CDI	1.03.1992	CDI
CDI205/05	1054CDI	1.04.1992	CDI
CDI205/11	1054CDI	1.03.1992	CDI
CDI210/00	1054CDI	1.09.1993	CDI
CDI210/05	1054CDI	1.08.1993	CDI
CDI210/20	1054CDI	1.09.1993	CDI
CDI210/25	1054CDI	1.11.1993	CDI
CDI210/28	1054CDI	1.02.1994	CDI
CDI210/33	1054CDI	1.07.1994	CDI
CDI210/40	1054CDI	1.09.1994	CDI
CDI210/45	1054CDI	1.09.1994	CDI
CDI210/48	1054CDI	1.10.1994	CDI
CDI210/53	1054CDI	1.06.1995	CDI
CDI210/56	1054CDI	1.03.1995	CDI
CDI210/60	1054CDI	1.09.1995	CDI
CDI210/68	1054CDI	1.10.1995	CDI
CDI220/00	1054CDI	1.08.1992	CDI
CDI220/20	1054CDI	1.11.1992	CDI
CDI220/25	1054CDI	1.11.1992	CDI
CDI220/37	1054CDI	1.12.1992	CDI
CDI220/39	1054CDI	1.11.1992	CDI
CDI220/40	1054CDI	1.01.1994	CDI
CDI220/57	1054CDI	1.11.1993	CDI
CDI220/60	1054CDI	1.09.1994	CDI
CDI220/60P	1054CDI	1.04.1996	CDI
CDI220/77	1054CDI	1.11.1994	CDI
CDI220/80	1054CDI	1.11.1995	CDI
CDI220/97	1054CDI	1.09.1995	CDI
CDI220/97C	1054CDI	1.04.1997	CDI

CDI450/00	1054CDI	1.08.1994	CDI
CDI450/03	1054CDI	1.10.1995	CDI
CDI450/05	1054CDI	1.08.1994	CDI
CDI450/11	1054CDI	1.12.1994	CDI
CDI450/17	1054CDI	1.06.1994	CDI
CDI470/00	1054CDI	1.07.1995	CDI
CDI470/05	1054CDI	1.07.1995	CDI
CDI470/20	1054CDI	1.09.1995	CDI
CDI470/80	1054CDI	1.09.1995	CDI
CDI470/81	1054CDI	1.12.1995	CDI
CDI470/83X	1054CDI		CDI
CDI490/00	1054CDI	1.02.1997	CDI
CDI550/00	1054CDI	1.03.1997	CDI
CDI550/03	1054CDI	1.10.1995	CDI
CDI550/05	1054CDI	1.03.1995	CDI
CDI550/11	1054CDI	1.06.1996	CDI
CDI550/17	1054CDI	1.09.1994	CDI
CDI550/28	1054CDI	1.11.1996	CDI
CDI740/00	1054CDI	1.02.1997	CDI
CDI910/13	1054CDI	1.09.1993	CDI
CDI910/17P	1054CDI	1.03.1992	CDI
CDJ500R/17	CDR-players		CDR
CDJ501R/01C	CDR-players		CDR
CDJ502R/00S	CDR-players		CDR
CDLFL/00	1049CD		CD PLAYERS
CDR200/17	2016CDR-players	1.08.1999	CDR
CDR300/17	2016CDR-players		CDR
CDR538/00S	2016CDR-players	1.09.1998	CDR
CDR560/00S	2016CDR-players	1.09.1998	CDR
CDR560/06S	2016CDR-players	1.10.1998	CDR
CDR560/11S	2016CDR-players	1.10.1998	CDR
CDR560/17S	2016CDR-players	1.12.1998	CDR
CDR570/00S	2016CDR-players	1.10.1999	CDR
CDR570/01S	2016CDR-players	1.10.1999	CDR
CDR570/06S	2016CDR-players		CDR
CDR570/10S	2016CDR-players	1.11.1999	CDR
CDR570/13S	2016CDR-players		CDR
CDR570/17S	2016CDR-players	1.11.1999	CDR
CDR570/19	2016CDR-players	1.04.2001	CDR
CDR570S/P00	2016CDR-players	1.02.2000	CDR
CDR600/00	2016CDR-players	1.06.2001	CDR
CDR600/17	2016CDR-players	1.08.2001	CDR

CDR602/00S	2016CDR-players	1.06.2001	CDR
CDR700/00	CDR-players		CDR
CDR700/17	2016CDR-players	1.08.2001	CDR
CDR715/17	CDR-players		CDR
CDR755/00	CDR-players		CDR
CDR755/17	CDR-players		CDR
CDR756/00S	CDR-players		CDR
CDR760/00	2016CDR-players	1.09.1998	CDR
CDR760/11S	2016CDR-players	1.10.1998	CDR
CDR760/17	2016CDR-players	1.09.1998	CDR
CDR765/00	2016CDR-players	1.10.1998	CDR
CDR765/06S	2016CDR-players	1.11.1998	CDR
CDR765/11S	2016CDR-players	1.11.1998	CDR
CDR765/13S	2016CDR-players		CDR
CDR765/17	2016CDR-players	1.10.1998	CDR
CDR770/00	2016CDR-players	1.10.1999	CDR
CDR770/01C	2016CDR-players		CDR
CDR770/06	2016CDR-players		CDR
CDR770/13	2016CDR-players		CDR
CDR770/17	2016CDR-players	1.11.1999	CDR
CDR770S/P00	CDR-players		CDR
CDR771/00S	2016CDR-players	1.08.2000	CDR
CDR772/00	2016CDR-players		CDR
CDR772/17	2016CDR-players		CDR
CDR775/00	2016CDR-players	1.04.2000	CDR
CDR775/01C	2016CDR-players	1.10.1999	CDR
CDR775/06	2016CDR-players		CDR
CDR775/13	2016CDR-players		CDR
CDR775/13C	2016CDR-players		CDR
CDR775/14	2016CDR-players		CDR
CDR775/17	2016CDR-players	1.04.2000	CDR
CDR776/00C	2016CDR-players		CDR
CDR777/00S	2016CDR-players	1.09.2000	CDR
CDR778/00	2016CDR-players		CDR
CDR778/01C	2016CDR-players	1.09.2000	CDR
CDR778/10C	2016CDR-players	1.09.2000	CDR
CDR778/13C	CDR-players		CDR
CDR778/17	2016CDR-players	1.08.2001	CDR
CDR779/00	2016CDR-players	1.01.2001	CDR
CDR785/00	2016CDR-players	1.06.2000	CDR
CDR785/01C	2016CDR-players	1.07.2000	CDR
CDR785/17	2016CDR-players	1.05.2000	CDR

CDR786/00	2016CDR-players	1.07.2000	CDR
CDR786/19S	CDR-players		CDR
CDR795/00	CDR-players		CDR
CDR795/17	CDR-players		CDR
CDR796/00S	CDR-players		CDR
CDR800/00	2016CDR-players	1.09.2001	CDR
CDR800/01	CDR-players		CDR
CDR800/17	2016CDR-players	1.11.2001	CDR
CDR801/00C	CDR-players		CDR
CDR801/01C	CDR-players		CDR
CDR802/00S	2016CDR-players	1.10.2001	CDR
CDR802/01S	CDR-players		CDR
CDR820/00	2016CDR-players	1.11.2001	CDR
CDR820/17	2016CDR-players	1.11.2001	CDR
CDR821/01C	CDR-players		CDR
CDR821/10C	CDR-players		CDR
CDR821/13C	CDR-players		CDR
CDR822/01S	CDR-players		CDR
CDR822/19	CDR-players		CDR
CDR850D/17	CDR-players		CDR
CDR852D/00S	CDR-players		CDR
CDR855M/00	CDR-players		CDR
CDR855M/17	CDR-players		CDR
CDR870/00	2016CDR-players	1.09.1997	CDR
CDR870/06	2016CDR-players	1.04.1998	CDR
CDR870/11	2016CDR-players	1.11.1997	CDR
CDR870/13	2016CDR-players		CDR
CDR870/17	2016CDR-players	1.06.1998	CDR
CDR880/00	2016CDR-players	1.05.1998	CDR
CDR880/00S	2016CDR-players	1.06.1998	CDR
CDR880/06S	2016CDR-players	1.08.1998	CDR
CDR880/11S	2016CDR-players	1.08.1998	CDR
CDR880/17	2016CDR-players	1.06.1998	CDR
CDR930/00S	2016CDR-players	1.10.1999	CDR
CDR930/17S	2016CDR-players	1.11.1999	CDR
CDR950/00	2016CDR-players	1.06.2000	CDR
CDR950/01C	2016CDR-players		CDR
CDR950/06	2016CDR-players		CDR
CDR950/13	2016CDR-players		CDR
CDR950/14	2016CDR-players		CDR
CDR950/17	2016CDR-players	1.08.2001	CDR
CDR951/00C	2016CDR-players	1.06.2000	CDR

CDR952/00C	2016CDR-players		CDR
CI231A/10G	2012Institutional analogue		SATELLITE
CI3222/00R	2012Institutional analogue		SATELLITE
CLARINW/07	1004		TELEPHONES CORDED
CMR4380L/76	700114i (13v) stereo	1.03.1992	TELEVISION
CRICK1876/00R	700120i (19v) mono	1.10.1996	TELEVISION
CT14MV1L	1022Leader		TVCR
CT2501/00R	700120i (19v) mono	1.10.1996	TELEVISION
CT2551/00R	700120i (19v) mono	1.10.1996	TELEVISION
CT2651/00R	700120i (19v) mono	1.10.1996	TELEVISION
CT2755/00R	700120i (19v) mono	1.10.1996	TELEVISION
CTU1103/19G	2012PAL/SECAM terminal		SATELLITE
CTU900/00	2012PAL/SECAM terminal	1.05.1995	SATELLITE
CTU902/00M	2012Accessories / spares	1.07.1993	SATELLITE
CTU902/02M	2012Accessories / spares	1.03.1992	SATELLITE
CTU902/10M	2012Accessories / spares	1.03.1992	SATELLITE
D1102/01R	1041Portable radio	1.03.1992	RADIO PORTABLE
D1868/00	1041Portable radio	1.03.1992	RADIO PORTABLE
D1868/03	1041Portable radio	1.03.1992	RADIO PORTABLE
D1875/00X	1041Portable radio	1.03.1992	RADIO PORTABLE
D1875/15X	1041Portable radio	1.03.1992	RADIO PORTABLE
D1875/17X	1041Portable radio	1.03.1992	RADIO PORTABLE
D2345/00X	1041Portable radio	1.03.1992	RADIO PORTABLE
D2345/05X	1041Portable radio	1.03.1992	RADIO PORTABLE
D2345/08X	1041Portable radio	1.03.1992	RADIO PORTABLE
D2345/10X	1041Portable radio	1.03.1992	RADIO PORTABLE
D6280/00	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
D6280/05	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
D6290/17X	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
D6350/60	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
D6350/65	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
D6550/30R	1041Cassette only	1.09.1993	PERSONAL STEREO
D6550/30Z	1041Cassette only	1.03.1992	PERSONAL STEREO
D6560/00	1041Cassette only	1.07.1998	PERSONAL STEREO
D6650/30	1041Radio + Cassette	1.03.1992	PERSONAL STEREO
D6650/30R	1041Cassette only	1.09.1993	PERSONAL STEREO
D7180/70R	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
D7181/61R	1041Radio cassette recorders - mono	1.03.1992	RADIO MONO + STEREO
D9033/08	1004		TELEPHONES CORDED
D9039B/21	1004		TELEPHONES CORDED
DBS25910/19G	2012Accessories / spares		SATELLITE
DBS25911/19G	2012Accessories / spares		SATELLITE

DBS26210/19G	2012Accessories / spares		SATELLITE
DBS26211/19G	2012Accessories / spares		SATELLITE
DBU15991/19G	2012Analogue antennas	1.09.1996	SATELLITE
DBU25901/19G	2012Accessories / spares		SATELLITE
DBU26101/19G	2012Accessories / spares	1.09.1996	SATELLITE
DBU26201/19B	2012Analogue antennas	1.09.1997	SATELLITE
DBU27151/19G	2012Accessories / spares	1.07.1996	SATELLITE
DCC170/00	1041Miscellaneous	1.09.1994	PORTABLE OTHER
DCC170/01	1041Miscellaneous	1.03.1994	PORTABLE OTHER
DCC170/03	1041Miscellaneous	1.03.1995	PORTABLE OTHER
DCC170/05	1041Miscellaneous	1.12.1994	PORTABLE OTHER
DCC170/06	1041Miscellaneous	1.12.1994	PORTABLE OTHER
DCC170/17	1041Miscellaneous	1.02.1995	PORTABLE OTHER
DCC175/00	1041Miscellaneous	1.10.1995	PORTABLE OTHER
DCC730/00B	1049	1.03.1995	DCC
DCC951/00S	1049	1.09.1994	DCC
DCCSTAT/00	1049	1.05.1996	DCC
DCCSTAT/01	1049		DCC
DH255/00I	1058		SPEAKER BOXES
DH310CL/15	1049		MIDISYSTEMS
DH448/00I	1058		SPEAKER BOXES
DH458/00I	1058		SPEAKER BOXES
DL019/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL129/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL148/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL149/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL166/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL167/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL224/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL225/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL258/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL259/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL263/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL334/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL371/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DL851/00I	1041Portable radio	1.11.1996	RADIO PORTABLE
DR121/00I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO
DR122/00I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO
DR142/00I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO
DR253/00I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO
DR435/00I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO
DR442/10I	1041Radio cassette recorders - mono	1.11.1996	RADIO MONO + STEREO

DR445/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR447/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR454/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR455/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR521/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR529/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR561/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR568/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR603/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR748/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR828/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR920/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DR950/00I	1041Radio cassette recorders - mono		1.11.1996	RADIO MONO + STEREO
DS720/00I	1041Radio + Cassette		1.11.1996	PERSONAL STEREO
DS739/00I	1041Radio + Cassette		1.11.1996	PERSONAL STEREO
DSII75B/08R	2012Institutional digital terminals			SATELLITE
DSII75B/16R	2012Institutional digital terminals			SATELLITE
DSII85A/19R	2012Institutional digital terminals		1.04.1996	SATELLITE
DSII85A/G2	2012Institutional digital terminals		1.03.1996	SATELLITE
DSII85B/19R	2012Institutional digital terminals			SATELLITE
DSS330/17	1058			SPEAKER BOXES
DSS350/17	1058		1.01.1999	SPEAKER BOXES
DSS370/17	1058		1.01.1999	SPEAKER BOXES
DSS940/00B	1058		1.08.1994	SPEAKER BOXES
DV10/16	1021Leader	PAULIN_ECN	1.07.1996Economy	VCR
DV10/39	1021Leader	PAULIN_ECN	1.06.1996Economy	VCR
DV105/05	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
DV15/05	1021Leader	PAULIN_ECN	1.08.1996Economy	VCR
DV25/39	1021Leader	PAULIN_ECN	1.07.1996Economy	VCR
DV35/39	1021Leader	PAULIN_ECN	1.08.1996Economy	VCR
DV40/08	1021Leader show view	PAULIN_ECN	1.07.1996Economy	VCR
DV40/39	1021Leader show view	PAULIN_ECN	1.07.1996Economy	VCR
DV50/01	1021Leader show view	PAULIN_ECN	1.09.1996Economy	VCR
DV55/39	1021Leader show view	PAULIN_STN	1.07.1996Standard	VCR
DV60/39	1021Leader	PAULIN_STU	1.09.1996Step-up	VCR
DV605/05	1021Leader	QUEEN_VL	1.06.1997Volume Line	VCR
DV615/05	1021Leader			VCR
DV65/05	1021Leader	PAULIN_ECN	1.10.1996Economy	VCR
DVD002/002	2015DVD Video			DVD
DVD002/003	2015DVD Video			DVD
DVD002/004	2015DVD Video			DVD
DVD002/005	2015DVD Video			DVD

DVD004/001	2015DVD Video		DVD
DVD004/002	2015DVD Video		DVD
DVD004/003	2015DVD Video		DVD
DVD005/001	2015DVD Video		DVD
DVD005/002	2015DVD Video		DVD
DVD005/003	2015DVD Video		DVD
DVD011/001	2015DVD Video		DVD
DVD1000/001	2015DVD Video		DVD
DVD1000/171	2015DVD Video		DVD
DVD1000/691	2015DVD Video		DVD
DVD1000/931	2015DVD Video		DVD
DVD1010/001	2015DVD Video	1.01.2001	DVD
DVD1010/002	DVD Video		DVD
DVD1010/691	2015DVD Video	1.03.2001	DVD
DVD400/171	2015DVD Video	1.12.1997	DVD
DVD405/171	2015DVD Video	1.01.1999	DVD
DVD420/171	2015DVD Video	1.12.1997	DVD
DVD501/171	2015DVD Video		DVD
DVD502/171	2015DVD Video		DVD
DVD570M/691	2015DVD Video	1.10.1999	DVD
DVD570M/692	2015DVD Video	1.05.2000	DVD
DVD570M/931	2015DVD Video	1.12.1999	DVD
DVD570M/932	2015DVD Video		DVD
DVD580M/691	2015DVD Video		DVD
DVD580M/751	2015DVD Video		DVD
DVD612/001	2015DVD Video	1.03.2001	DVD
DVD612/002	2015DVD Video	1.08.2001	DVD
DVD612/021	2015DVD Video	1.03.2001	DVD
DVD612/022	2015DVD Video	1.08.2001	DVD
DVD612/031	2015DVD Video		DVD
DVD612/051	2015DVD Video	1.04.2001	DVD
DVD612/052	2015DVD Video	1.08.2001	DVD
DVD612/691	2015DVD Video		DVD
DVD612/751	2015DVD Video		DVD
DVD612S/001	2015DVD Video	1.03.2001	DVD
DVD612S/002	2015DVD Video	1.08.2001	DVD
DVD612S/022	2015DVD Video	1.09.2001	DVD
DVD612S/052	2015DVD Video	1.09.2001	DVD
DVD612S/F01	2015DVD Video	1.09.2001	DVD
DVD616K/031	DVD Video		DVD
DVD616K/691	DVD Video		DVD
DVD616K/751	DVD Video		DVD

DVD620/021	DVD Video		DVD
DVD621K/931	2015DVD Video		DVD
DVD622/001	2015DVD Video	1.06.2001	DVD
DVD622/021	2015DVD Video	1.06.2001	DVD
DVD622/051	2015DVD Video	1.06.2001	DVD
DVD622/F01	2015DVD Video	1.09.2001	DVD
DVD622/G51	2015DVD Video	1.08.2001	DVD
DVD623/021	DVD Video		DVD
DVD633/021	DVD Video		DVD
DVD700/002	2015DVD Video	1.11.1999	DVD
DVD700/003	2015DVD Video	1.09.1999	DVD
DVD700/004	2015DVD Video	1.02.2000	DVD
DVD700/P02	2015DVD Video	1.09.1999	DVD
DVD701/002	2015DVD Video	1.09.2000	DVD
DVD701/171	2015DVD Video		DVD
DVD701/172	2015DVD Video		DVD
DVD701/932	2015DVD Video		DVD
DVD702/171	2015DVD Video		DVD
DVD702/172	2015DVD Video		DVD
DVD703/031	2015DVD Video	1.08.2001	DVD
DVD703/691	2015DVD Video	1.03.2001	DVD
DVD703/692	2015DVD Video	1.08.2001	DVD
DVD703/751	2015DVD Video	1.04.2001	DVD
DVD705/002	2015DVD Video	1.11.1998	DVD
DVD707/751	2015DVD Video	1.11.2001	DVD
DVD710/001	2015DVD Video	1.03.1999	DVD
DVD710/002	2015DVD Video	1.09.1999	DVD
DVD710/003	2015DVD Video	1.10.1999	DVD
DVD710/P01	2015DVD Video	1.09.1999	DVD
DVD710/P02	2015DVD Video	1.09.1999	DVD
DVD710/P03	2015DVD Video	1.10.1999	DVD
DVD711/001	2015DVD Video	1.04.2000	DVD
DVD711/002	2015DVD Video	1.06.2000	DVD
DVD711/052	2015DVD Video	1.07.2000	DVD
DVD711/102	2015DVD Video	1.02.2001	DVD
DVD711/171	2015DVD Video		DVD
DVD711/172	2015DVD Video		DVD
DVD711/681	2015DVD Video		DVD
DVD711/682	2015DVD Video		DVD
DVD711/691	2015DVD Video	1.06.2000	DVD
DVD711/692	2015DVD Video	1.08.2000	DVD
DVD711/751	2015DVD Video	1.06.2000	DVD

DVD711/752	2015DVD Video	1.09.2000	DVD
DVD711/931	2015DVD Video		DVD
DVD711/932	2015DVD Video		DVD
DVD711/G52	2015DVD Video	1.09.2000	DVD
DVD712/001	2015DVD Video	1.06.2001	DVD
DVD712/021	2015DVD Video	1.06.2001	DVD
DVD712/051	2015DVD Video	1.06.2001	DVD
DVD712/171	2015DVD Video		DVD
DVD712/172	2015DVD Video		DVD
DVD718/682	2015DVD Video		DVD
DVD718/692	2015DVD Video	1.09.1999	DVD
DVD718/752	2015DVD Video	1.01.2000	DVD
DVD718/932	2015DVD Video	1.12.1999	DVD
DVD720/781	2015DVD Video		DVD
DVD722/001	2015DVD Video	1.06.2001	DVD
DVD722/021	2015DVD Video	1.06.2001	DVD
DVD722/051	2015DVD Video	1.06.2001	DVD
DVD722/F01	2015DVD Video	1.09.2001	DVD
DVD723/021	DVD Video		DVD
DVD725/682	2015DVD Video		DVD
DVD725/691	2015DVD Video	1.04.1999	DVD
DVD725/692	2015DVD Video	1.10.1999	DVD
DVD725/931	2015DVD Video	1.07.1999	DVD
DVD725/932	2015DVD Video	1.12.1999	DVD
DVD729K/031	2015DVD Video	1.10.2001	DVD
DVD729K/691	2015DVD Video	1.07.2001	DVD
DVD729K/751	2015DVD Video	1.08.2001	DVD
DVD730/001	2015DVD Video	1.05.1998	DVD
DVD730/002	2015DVD Video	1.03.1998	DVD
DVD730/003	2015DVD Video	1.04.1998	DVD
DVD730/004	2015DVD Video	1.03.1999	DVD
DVD730/005	2015DVD Video	1.02.1999	DVD
DVD730K/691	2015DVD Video	1.10.2001	DVD
DVD732K/681	2015DVD Video		DVD
DVD732K/682	2015DVD Video		DVD
DVD732K/691	2015DVD Video	1.06.2000	DVD
DVD732K/692	2015DVD Video	1.09.2000	DVD
DVD732K/932	2015DVD Video		DVD
DVD733K/691	2015DVD Video		DVD
DVD741/171	2015DVD Video		DVD
DVD741/172	2015DVD Video		DVD
DVD743/021	DVD Video		DVD

DVD750/001	2015DVD Video	1.09.1999	DVD
DVD750/002	2015DVD Video	1.08.1999	DVD
DVD750/003	2015DVD Video	1.09.1999	DVD
DVD750/004	2015DVD Video	1.10.1999	DVD
DVD750/005	2015DVD Video	1.09.1999	DVD
DVD750/P01	2015DVD Video	1.09.1999	DVD
DVD750/P02	2015DVD Video	1.09.1999	DVD
DVD751/001	2015DVD Video	1.05.2000	DVD
DVD751/002	2015DVD Video	1.06.2000	DVD
DVD751/052	2015DVD Video	1.07.2000	DVD
DVD751/171	2015DVD Video		DVD
DVD751/172	2015DVD Video		DVD
DVD751/D02	2015DVD Video	1.09.2000	DVD
DVD751/F02	2015DVD Video	1.09.2000	DVD
DVD751/G52	2015DVD Video	1.09.2000	DVD
DVD751/I02	2015DVD Video	1.09.2000	DVD
DVD751/N02	2015DVD Video	1.09.2000	DVD
DVD751/S02	2015DVD Video	1.10.2000	DVD
DVD751/Y02	2015DVD Video	1.09.2000	DVD
DVD751/Z02	2015DVD Video	1.09.2000	DVD
DVD752/001	2015DVD Video	1.06.2001	DVD
DVD752/021	2015DVD Video	1.06.2001	DVD
DVD752/051	DVD Video		DVD
DVD752/B01	2015DVD Video	1.09.2001	DVD
DVD752/N01	2015DVD Video	1.09.2001	DVD
DVD755/002	2015DVD Video	1.12.1999	DVD
DVD755/003	2015DVD Video		DVD
DVD755/P02	2015DVD Video	1.12.1999	DVD
DVD756/002	2015DVD Video	1.09.2000	DVD
DVD756/D02	2015DVD Video	1.09.2000	DVD
DVD756/F02	2015DVD Video	1.09.2000	DVD
DVD756/G52	2015DVD Video	1.09.2000	DVD
DVD756/I02	2015DVD Video	1.09.2000	DVD
DVD756/N02	2015DVD Video	1.09.2000	DVD
DVD756/S02	2015DVD Video	1.09.2000	DVD
DVD756/Y02	2015DVD Video		DVD
DVD756/Z02	2015DVD Video	1.09.2000	DVD
DVD761/002	2015DVD Video	1.09.2000	DVD
DVD761/D01	2015DVD Video	1.09.2000	DVD
DVD761/D02	2015DVD Video	1.10.2000	DVD
DVD761/F02	2015DVD Video	1.10.2000	DVD
DVD761/G52	2015DVD Video	1.12.2000	DVD

DVD761/I02	2015DVD Video	1.09.2000	DVD
DVD761/N02	2015DVD Video	1.09.2000	DVD
DVD761/S02	2015DVD Video	1.09.2000	DVD
DVD761/Y02	2015DVD Video	1.12.2000	DVD
DVD761/Z02	2015DVD Video	1.10.2000	DVD
DVD761FJ/P00	2015DVD Video	1.03.2001	DVD
DVD761K/691	2015DVD Video	1.03.2001	DVD
DVD761K/751	2015DVD Video	1.04.2001	DVD
DVD761RS/P00	DVD Video		DVD
DVD762/001	2015DVD Video	1.06.2001	DVD
DVD762/021	2015DVD Video	1.06.2001	DVD
DVD762/051	2015DVD Video	1.06.2001	DVD
DVD762/B01	2015DVD Video	1.09.2001	DVD
DVD762/D01	2015DVD Video	1.09.2001	DVD
DVD762/E21	2015DVD Video	1.09.2001	DVD
DVD762/F21	2015DVD Video	1.09.2001	DVD
DVD762/G51	2015DVD Video	1.08.2001	DVD
DVD762/I21	2015DVD Video	1.09.2001	DVD
DVD762/N01	2015DVD Video	1.09.2001	DVD
DVD762/U21	2015DVD Video	1.10.2001	DVD
DVD762HC/001	2015DVD Video	1.10.2001	DVD
DVD762HC/021	2015DVD Video	1.10.2001	DVD
DVD762HC/051	2015DVD Video	1.10.2001	DVD
DVD762K/031	2015DVD Video		DVD
DVD762K/691	2015DVD Video	1.08.2001	DVD
DVD762K/751	2015DVD Video	1.09.2001	DVD
DVD763SA/021	SACD		SUPER AUDIO CD
DVD763SA/691	SACD		SUPER AUDIO CD
DVD763SA/751	SACD		SUPER AUDIO CD
DVD765K/691	DVD Video		DVD
DVD765K/751	DVD Video		DVD
DVD771C/931	2015DVD Video		DVD
DVD781C/171	2015DVD Video		DVD
DVD800/001	DVD Video		DVD
DVD815/171	2015DVD Video	1.01.1999	DVD
DVD820/691	2015DVD Video	1.07.1998	DVD
DVD820/692	2015DVD Video	1.10.1998	DVD
DVD820/931	2015DVD Video	1.09.1998	DVD
DVD820/932	2015DVD Video	1.10.1998	DVD
DVD825/171	2015DVD Video	1.03.1999	DVD
DVD825/172	2015DVD Video	1.09.1999	DVD
DVD825/173	2015DVD Video	1.09.1999	DVD

DVD835/171	2015DVD Video		DVD
DVD840/171	2015DVD Video	1.01.1999	DVD
DVD840/691	2015DVD Video	1.09.1997	DVD
DVD840/931	2015DVD Video	1.09.1998	DVD
DVD850/171	2015DVD Video	1.01.1999	DVD
DVD855/171	2015DVD Video	1.01.1999	DVD
DVD860/691	2015DVD Video	1.11.1998	DVD
DVD860/931	2015DVD Video	1.01.1999	DVD
DVD865/171	2015DVD Video	1.12.1999	DVD
DVD865/172	2015DVD Video		DVD
DVD870/001	2015DVD Video	1.07.2001	DVD
DVD870/021	2015DVD Video	1.08.2001	DVD
DVD870/051	2015DVD Video	1.09.2001	DVD
DVD870L/001	2015DVD Video	1.07.2001	DVD
DVD870L/021	2015DVD Video	1.08.2001	DVD
DVD870L/051	2015DVD Video	1.09.2001	DVD
DVD870P/001	2015DVD Video	1.08.2001	DVD
DVD870P/021	2015DVD Video	1.09.2001	DVD
DVD870P/051	2015DVD Video	1.09.2001	DVD
DVD930/001	2015DVD Video	1.12.1997	DVD
DVD930/002	2015DVD Video	1.03.1998	DVD
DVD930/004	2015DVD Video	1.01.1999	DVD
DVD931/691	2015DVD Video	1.11.1999	DVD
DVD931/931	2015DVD Video	1.12.1999	DVD
DVD935/002	2015DVD Video	1.09.1998	DVD
DVD935/004	2015DVD Video	1.12.1998	DVD
DVD940/171	2015DVD Video	1.09.1999	DVD
DVD941/171	2015DVD Video		DVD
DVD942/031	2015DVD Video		DVD
DVD942/691	2015DVD Video		DVD
DVD942/751	2015DVD Video		DVD
DVD950/002	2015DVD Video	1.11.1999	DVD
DVD950/171	2015DVD Video		DVD
DVD950/P02	2015DVD Video	1.11.1999	DVD
DVD951/001	2015DVD Video	1.11.2000	DVD
DVD951/171	2015DVD Video		DVD
DVD951/691	2015DVD Video	1.11.2000	DVD
DVD951/751	2015DVD Video	1.11.2000	DVD
DVD951/931	2015DVD Video		DVD
DVD951/D01	2015DVD Video	1.10.2000	DVD
DVD951/F01	2015DVD Video	1.10.2000	DVD
DVD951/G51	2015DVD Video	1.11.2000	DVD

DVD951/I01	2015DVD Video	1.10.2000	DVD
DVD951/N01	2015DVD Video	1.10.2000	DVD
DVD951/S01	2015DVD Video	1.10.2000	DVD
DVD951/Y01	2015DVD Video	1.10.2000	DVD
DVD951/Z01	2015DVD Video	1.10.2000	DVD
DVD951FJ/P00	2015DVD Video	1.03.2001	DVD
DVD952/001	2015DVD Video	1.07.2001	DVD
DVD952/021	2015DVD Video	1.09.2001	DVD
DVD952/051	DVD Video		DVD
DVD952/691	2015DVD Video		DVD
DVD952/751	2015DVD Video		DVD
DVD952/B01	DVD Video		DVD
DVD952/B02	DVD Video		DVD
DVD952/D01	2015DVD Video	1.09.2001	DVD
DVD952/D02	DVD Video		DVD
DVD952/E21	2015DVD Video	1.09.2001	DVD
DVD952/E22	DVD Video		DVD
DVD952/F21	2015DVD Video	1.09.2001	DVD
DVD952/F22	DVD Video		DVD
DVD952/I21	DVD Video		DVD
DVD952/I22	DVD Video		DVD
DVD952/N01	DVD Video		DVD
DVD952/N02	DVD Video		DVD
DVD952/U21	DVD Video	1.12.2001	DVD
DVD952/U22	DVD Video		DVD
DVD952K/031	2015DVD Video		DVD
DVD952K/691	2015DVD Video		DVD
DVD952K/751	2015DVD Video		DVD
DVD955/002	2015DVD Video	1.12.1999	DVD
DVD955/003	2015DVD Video		DVD
DVD955/691	2015DVD Video	1.11.1999	DVD
DVD955/692	2015DVD Video	1.06.2000	DVD
DVD955/781	2015DVD Video	1.01.2000	DVD
DVD955/931	2015DVD Video	1.12.1999	DVD
DVD955/P02	2015DVD Video	1.12.1999	DVD
DVD956/002	2015DVD Video	1.12.1999	DVD
DVD956/P02	2015DVD Video	1.12.1999	DVD
DVD956K/691	2015DVD Video	1.11.2000	DVD
DVD957/001	2015DVD Video	1.10.2000	DVD
DVD957/171	2015DVD Video		DVD
DVD957/D01	2015DVD Video	1.10.2000	DVD
DVD957/F01	2015DVD Video	1.10.2000	DVD

DVD957/G51	2015DVD Video	1.10.2000	DVD
DVD957/I01	2015DVD Video	1.11.2000	DVD
DVD957/N01	2015DVD Video	1.11.2000	DVD
DVD957/S01	2015DVD Video	1.11.2000	DVD
DVD957/Y01	2015DVD Video	1.12.2000	DVD
DVD957/Z01	2015DVD Video	1.11.2000	DVD
DVD957FJ/P00	2015DVD Video	1.03.2001	DVD
DVD958/001	2015DVD Video	1.11.2000	DVD
DVD958/D01	2015DVD Video	1.10.2000	DVD
DVD958/F01	2015DVD Video	1.11.2000	DVD
DVD958/G51	2015DVD Video	1.11.2000	DVD
DVD958/I01	2015DVD Video	1.11.2000	DVD
DVD958/N01	2015DVD Video	1.10.2000	DVD
DVD958/S01	2015DVD Video	1.10.2000	DVD
DVD958/Y01	2015DVD Video		DVD
DVD958/Z01	2015DVD Video		DVD
DVD958FJ/P00	2015DVD Video	1.03.2001	DVD
DVD960/001	2015DVD Video	1.10.1999	DVD
DVD960/P02	2015DVD Video	1.11.1999	DVD
DVD961/171	2015DVD Video		DVD
DVD962SA/021	SACD		SUPER AUDIO CD
DVD962SA/691	SACD		SUPER AUDIO CD
DVD963SA/021	SACD		SUPER AUDIO CD
DVD963SA/691	SACD		SUPER AUDIO CD
DVD963SA/751	SACD		SUPER AUDIO CD
DVD970/171	2015DVD Video		DVD
DVD978K/691	DVD Video		DVD
DVD978K/751	DVD Video		DVD
DVDQ30/691	DVD Video		DVD
DVDQ30/751	DVD Video		DVD
DVDQ40/001	2015DVD Video	1.07.2001	DVD
DVDQ40/021	2015DVD Video	1.09.2001	DVD
DVDQ40/051	2015DVD Video	1.08.2001	DVD
DVDQ40/691	DVD Video		DVD
DVDQ40/751	DVD Video		DVD
DVDQ50/001	2015DVD Video	1.07.2001	DVD
DVDQ50/021	2015DVD Video	1.08.2001	DVD
DVDQ50/051	2015DVD Video	1.09.2001	DVD
DVDQ50/691	2015DVD Video	1.08.2001	DVD
DVDQ50/751	2015DVD Video	1.08.2001	DVD
DVDR1000/001	2019DVD+RW	1.08.2001	DVD+RW
DVDR1000/021	2019DVD+RW	1.09.2001	DVD+RW

DVDR1000/051	2019DVD+RW	1.09.2001	DVD+RW
DVDR1000/171	2019DVD+RW	1.11.2001	DVD+RW
DVDR1000/691	2019DVD+RW	1.10.2001	DVD+RW
EM2200/60	1049Tuners	1.03.1992	TUNERS
EM2200/80	1049Tuners	1.08.1992	TUNERS
EXP101/00	1042CD personal	1.08.2000	PERSONAL CD
EXP101/11	1042CD personal	1.08.2000	PERSONAL CD
EXP101/11H	1042CD personal		PERSONAL CD
EXP101/13	1042CD personal	1.08.2001	PERSONAL CD
EXP101/17	1042CD personal		PERSONAL CD
EXP103/00	1042CD personal		PERSONAL CD
EXP103/01	1042CD personal	1.09.2000	PERSONAL CD
EXP103/05	1042CD personal	1.09.2000	PERSONAL CD
EXP103/10	1042CD personal		PERSONAL CD
EXP103/17	1042CD personal	1.08.2001	PERSONAL CD
EXP200/00	1042CD personal	1.09.2001	PERSONAL CD
EXP201/00	1042CD personal		PERSONAL CD
EXP201/17	1042CD personal		PERSONAL CD
EXP201/17P	1042CD personal	1.08.2001	PERSONAL CD
EXP203/00	1042CD personal	1.09.2001	PERSONAL CD
EXP203/05	1042CD personal		PERSONAL CD
EXP203/17P	1042CD personal	1.08.2001	PERSONAL CD
EXP210/00	1042CD personal		PERSONAL CD
EXP211/00C	1042CD personal		PERSONAL CD
EXP211/01	1042CD personal		PERSONAL CD
EXP211/17	1042CD personal		PERSONAL CD
EXP212/17	1042CD personal		PERSONAL CD
EXP213/10	1042CD personal		PERSONAL CD
EXP301/00	1042CD personal	1.09.2001	PERSONAL CD
EXP301/11	1042CD personal	1.10.2001	PERSONAL CD
EXP301/13	1042CD personal		PERSONAL CD
EXP301/17	1042CD personal	1.09.2001	PERSONAL CD
EXP303/01	1042CD personal	1.10.2001	PERSONAL CD
EXP303/05	1042CD personal	1.10.2001	PERSONAL CD
EXP303/10	1042CD personal		PERSONAL CD
EXP303/17	1042CD personal	1.09.2001	PERSONAL CD
EXP303/19	1042CD personal		PERSONAL CD
EXP311/00	1042CD personal		PERSONAL CD
EXP311/17	1042CD personal		PERSONAL CD
EXP313/17	1042CD personal		PERSONAL CD
EXP401/00	1042CD personal	1.11.2001	PERSONAL CD
EXP401/01	1042CD personal	1.10.2001	PERSONAL CD

EXP401/17	1042CD personal	1.10.2001	PERSONAL CD
EXP411/00	1042CD personal		PERSONAL CD
EXP411/01	1042CD personal		PERSONAL CD
EXP411/17	1042CD personal		PERSONAL CD
EXP431/00C	1042CD personal		PERSONAL CD
EXP431/01	1042CD personal		PERSONAL CD
EXP431/17	1042CD personal		PERSONAL CD
EXP501/00	1042CD personal	1.11.2001	PERSONAL CD
EXP501/11	1042CD personal		PERSONAL CD
EXP501/17	1042CD personal		PERSONAL CD
EXP503/17	1042CD personal	1.09.2001	PERSONAL CD
EXP511/00C	1042CD personal		PERSONAL CD
EXP511/01	1042CD personal		PERSONAL CD
EXP511/17	1042CD personal		PERSONAL CD
EXP513/17	1042CD personal		PERSONAL CD
EXP601/00	1042VCD personal		PERSONAL CD
EXP601/01	1042VCD personal		PERSONAL CD
EXP601/17	1042VCD personal		PERSONAL CD
FA741/00	1049Amplifiers	1.10.1996	AMPLIFIERS
FA761/00	1049Amplifiers	1.10.1996	AMPLIFIERS
FA911/00S	1049Amplifiers	1.08.1994	AMPLIFIERS
FA911/01S	1049Amplifiers	1.08.1994	AMPLIFIERS
FA931/00S	1049Amplifiers	1.06.1994	AMPLIFIERS
FA931/01S	1049Amplifiers	1.07.1994	AMPLIFIERS
FA951/00S	1049Amplifiers	1.08.1993	AMPLIFIERS
FA951/01S	1049Amplifiers	1.07.1994	AMPLIFIERS
FAXTOTUM/08	1006Philips thermal fax		FAXES
FB210/00	1058	1.10.1996	SPEAKER BOXES
FB301/01	1058	1.03.1999	SPEAKER BOXES
FB305/00	1058	1.04.1997	SPEAKER BOXES
FB305/00G	1058	1.05.1993	SPEAKER BOXES
FB310/00G	1058	1.05.1993	MIDISYSTEMS
FB320/00G	1058	1.05.1993	MIDISYSTEMS
FB330/00G	1058	1.05.1993	MIDISYSTEMS
FB350/00	1058	1.04.1997	SPEAKER BOXES
FB355C/21	1058		SPEAKER BOXES
FB505/00	1058	1.05.1996	SPEAKER BOXES
FB550/00B	1058	1.06.1996	SPEAKER BOXES
FB550/01B	1058	1.06.1996	SPEAKER BOXES
FB550/17B	1058	1.01.1997	SPEAKER BOXES
FB560/00B	1058	1.10.1995	SPEAKER BOXES
FB560/01B	1058	1.02.1996	SPEAKER BOXES

FB602/00	1058	1.03.1995	SPEAKER BOXES
FB603/00	1058	1.03.1995	SPEAKER BOXES
FB605/00	1058	1.12.1994	SPEAKER BOXES
FB605/20	1058	1.12.1995	SPEAKER BOXES
FB642/00B	1058	1.11.1995	SPEAKER BOXES
FB650/00L	1058	1.05.1993	SPEAKER BOXES
FB650/17L	1058	1.05.1993	SPEAKER BOXES
FB651/00B	1058	1.07.1994	SPEAKER BOXES
FB651/17B	1058	1.11.1994	SPEAKER BOXES
FB652G/00B	1058	1.06.1998	SPEAKER BOXES
FB670/00L	1058	1.05.1993	SPEAKER BOXES
FB670/17L	1058	1.05.1993	SPEAKER BOXES
FB671/00B	1058	1.06.1994	SPEAKER BOXES
FB671/01	1058	1.06.1995	SPEAKER BOXES
FB671/17B	1058	1.11.1994	SPEAKER BOXES
FB690/00L	1058	1.05.1993	SPEAKER BOXES
FB690/17L	1058	1.05.1993	SPEAKER BOXES
FB691/00B	1058	1.06.1994	SPEAKER BOXES
FB691/01	1058	1.05.1995	SPEAKER BOXES
FB691/17B	1058	1.11.1994	SPEAKER BOXES
FB692/00B	1058	1.06.1997	SPEAKER BOXES
FB695/00L	1058	1.05.1993	SPEAKER BOXES
FB695/17L	1058	1.05.1993	SPEAKER BOXES
FB696/00B	1058	1.07.1994	SPEAKER BOXES
FB696/01	1058	1.06.1995	SPEAKER BOXES
FB698/00B	1058	1.09.1996	SPEAKER BOXES
FB700/00	1058	1.02.1997	SPEAKER BOXES
FB715/00	1058	1.02.1995	SPEAKER BOXES
FB720/00B	1058	1.05.1993	SPEAKER BOXES
FB720/04B	1058	1.05.1993	SPEAKER BOXES
FB720/06B	1058	1.08.1993	SPEAKER BOXES
FB732/01	1058	1.11.1996	SPEAKER BOXES
FB735/01	1058		SPEAKER BOXES
FB755/00	1058		SPEAKER BOXES
FB755/01	1058	1.09.1999	SPEAKER BOXES
FB755V/00	1058	1.08.1999	SPEAKER BOXES
FB815/00	1058	1.05.1993	SPEAKER BOXES
FB815/00B	1058	1.05.1993	SPEAKER BOXES
FB815/04	1058	1.05.1993	SPEAKER BOXES
FB815/17	1058	1.05.1993	SPEAKER BOXES
FB815/30B	1058	1.05.1993	SPEAKER BOXES
FB815/34B	1058	1.05.1993	SPEAKER BOXES

FB820/00	1058	1.05.1993	SPEAKER BOXES
FB820/04	1058	1.05.1993	SPEAKER BOXES
FB820/17	1058	1.10.1993	SPEAKER BOXES
FB820/30B	1058	1.05.1993	SPEAKER BOXES
FB820/34B	1058	1.05.1993	SPEAKER BOXES
FB821/00	1058	1.05.1993	SPEAKER BOXES
FB821/17	1058	1.05.1993	SPEAKER BOXES
FB821/30B	1058	1.05.1993	SPEAKER BOXES
FB821/34B	1058	1.05.1993	SPEAKER BOXES
FB825/00	1058	1.05.1993	SPEAKER BOXES
FB825/04R	1058	1.05.1993	SPEAKER BOXES
FB825/17	1058	1.05.1993	SPEAKER BOXES
FB825/30B	1058	1.05.1993	SPEAKER BOXES
FB900/00G	1058	1.05.1993	MIDISYSTEMS
FB975/01	1058	1.09.1999	SPEAKER BOXES
FBPSS1/00	1058	1.01.1994	SPEAKER BOXES
FBPSS2/00	1058	1.01.1994	SPEAKER BOXES
FC731/00	1049	1.03.1996	CASSETTEDECKS
FC731/01	1049	1.11.1996	CASSETTEDECKS
FC911/00S	1049	1.05.1994	CASSETTEDECKS
FC911/17S	1049	1.06.1994	CASSETTEDECKS
FC931/00S	1049	1.05.1994	CASSETTEDECKS
FC931/01S	1049	1.07.1994	CASSETTEDECKS
FC931/17S	1049	1.06.1994	CASSETTEDECKS
FM762X6	1021Leader		VCR
FM764X6	1021Leader show view		VCR
FR731/00	1049Receivers	1.12.1995	RECEIVERS
FR732/00	1049Receivers	1.11.1996	RECEIVERS
FR732/01	1049Receivers	1.11.1996	RECEIVERS
FR732/01X	1049Receivers	1.01.1999	RECEIVERS
FR732BP/00	1049Receivers		RECEIVERS
FR732BP/01	1049Receivers		RECEIVERS
FR735/00	1049Receivers	1.06.1999	RECEIVERS
FR735/01	1049Receivers	1.07.1999	RECEIVERS
FR735/14	1049Receivers		RECEIVERS
FR740/00	1049Receivers	1.05.2000	RECEIVERS
FR740/01	1049Receivers		RECEIVERS
FR751/00	1049Receivers	1.12.1995	RECEIVERS
FR752/00	1049Receivers	1.11.1996	RECEIVERS
FR752/01	1049Receivers	1.10.1996	RECEIVERS
FR755/00	1049Receivers	1.06.1999	RECEIVERS
FR755/01	1049Receivers	1.07.1999	RECEIVERS

FR760/00	1049Receivers		1.06.2000	RECEIVERS
FR760/01	1049Receivers			RECEIVERS
FR911/00S	1049Receivers		1.09.1994	RECEIVERS
FR911/17S	1049Receivers		1.06.1994	RECEIVERS
FR931/00S	1049Receivers		1.09.1994	RECEIVERS
FR931/01S	1049Receivers		1.10.1994	RECEIVERS
FR931/17S	1049Receivers		1.08.1994	RECEIVERS
FR951/00S	1049Receivers		1.10.1994	RECEIVERS
FR951/17S	1049Receivers		1.09.1994	RECEIVERS
FR960/00	1049Receivers		1.07.1999	RECEIVERS
FR960/14	1049Receivers			RECEIVERS
FR960/17	1049Receivers		1.09.1999	RECEIVERS
FR960/20	1049Receivers		1.02.2000	RECEIVERS
FR965/00	1049Receivers		1.06.2000	RECEIVERS
FR966/00S	1049Receivers		1.11.2000	RECEIVERS
FR970/00	1049Receivers		1.07.1999	RECEIVERS
FR970/01C	1049Receivers		1.08.1999	RECEIVERS
FR970/14	1049Receivers			RECEIVERS
FR970/17	1049Receivers			RECEIVERS
FR975/00	1049Receivers		1.06.2000	RECEIVERS
FR975/01	1049Receivers			RECEIVERS
FR975/01C	1049Receivers		1.07.2000	RECEIVERS
FR975/17	1049Receivers		1.08.2001	RECEIVERS
FR976/00C	1049Receivers		1.08.2000	RECEIVERS
FR985/00	1049Receivers		1.08.2001	RECEIVERS
FR986/00S	1049Receivers		1.08.2001	RECEIVERS
FR995/00	1049Receivers		1.09.2001	RECEIVERS
FR996/00S	1049Receivers		1.08.2001	RECEIVERS
FR996/01S	1049Receivers		1.08.2001	RECEIVERS
FR996/17S	1049Receivers		1.10.2001	RECEIVERS
FS400/02	1049		1.08.1995	MIDISYSTEMS
FS410/02	1049		1.09.1994	MIDISYSTEMS
FT741/00	1049Tuners		1.11.1996	TUNERS
FTR9950/12	Flat TV			FLAT TV
FTR9950/19	Flat TV			FLAT TV
FTR9952/12	2001Flat TV	FTV1.9	1.04.2000Flat TV	FLAT TV
FTR9952/12S	2001Flat TV		1.07.2001	FLAT TV
FTR9952/17	2001Flat TV	FTV1.9	1.07.2000Flat TV	FLAT TV
FTR9952/19S	Flat TV			FLAT TV
FTR9952/58S	2001Flat TV	FTV1.9	1.09.2000Flat TV	FLAT TV
FTR9952/69C	2001Flat TV	FTV1.9	1.10.2000Flat TV	FLAT TV
FTR9964/12S	2001Flat TV	F21RE	1.11.2001Flat TV	FLAT TV

FTR9964/17S	Flat TV			FLAT TV
FTR9964/69S	2001Flat TV	F21RE	1.11.2001	FLAT TV
FV106/00S	1058		1.09.1993	SPEAKER BOXES
FV130/00B	1058		1.09.1993	SPEAKER BOXES
FV150/00B	1058		1.09.1993	SPEAKER BOXES
FV160X6	1022Leader			TVCR
FV605/00	1058		1.11.1999	SPEAKER BOXES
FW-C1/19	Mini systems			MINISYSTEMS
FW-C1/37	1049Mini systems		1.01.2000	MINISYSTEMS
FW-C10/18	1049Mini systems		1.01.2001	MINISYSTEMS
FW-C10/19	1049Mini systems		1.02.2001	MINISYSTEMS
FW-C10/19E	Mini systems			MINISYSTEMS
FW-C10/21	1049Mini systems		1.05.2000	MINISYSTEMS
FW-C10/22	1049Mini systems		1.03.2000	MINISYSTEMS
FW-C10/34	1049Mini systems		1.02.2000	MINISYSTEMS
FW-C10/37	1049Mini systems		1.01.2000	MINISYSTEMS
FW-C100/18	1049Mini systems		1.03.2001	MINISYSTEMS
FW-C100/19	1049Mini systems		1.02.2001	MINISYSTEMS
FW-C100/19E	1049Mini systems		1.07.2001	MINISYSTEMS
FW-C100/21	1049Mini systems		1.01.2001	MINISYSTEMS
FW-C100/21M	1049Mini systems			MINISYSTEMS
FW-C100/22	1049Mini systems		1.01.2001	MINISYSTEMS
FW-C100/25	1049Mini systems		1.03.2001	MINISYSTEMS
FW-C100/30	1049Mini systems		1.02.2001	MINISYSTEMS
FW-C100/33	1049Mini systems		1.08.2001	MINISYSTEMS
FW-C100/34	1049Mini systems		1.03.2001	MINISYSTEMS
FW-C100/37	1049Mini systems		1.08.2001	MINISYSTEMS
FW-C115/22	Mini systems			MINISYSTEMS
FW-C150/37	1049Mini systems		1.08.2001	MINISYSTEMS
FW-C155/19	Mini systems			MINISYSTEMS
FW-C155/21	Mini systems			MINISYSTEMS
FW-C155/34	Mini systems			MINISYSTEMS
FW-C155/37	Mini systems			MINISYSTEMS
FW-C200/21	1049Mini systems		1.02.2001	MINISYSTEMS
FW-C200/21M	1049Mini systems		1.04.2001	MINISYSTEMS
FW-C200/30	1049Mini systems		1.11.2000	MINISYSTEMS
FW-C200/33	1049Mini systems		1.08.2001	MINISYSTEMS
FW-C220/22	1049Mini systems		1.02.2001	MINISYSTEMS
FW-C220/25	1049Mini systems		1.11.2001	MINISYSTEMS
FW-C220/34	1049Mini systems		1.03.2001	MINISYSTEMS
FW-C250/18	1049Mini systems		1.04.2001	MINISYSTEMS
FW-C250/19	1049Mini systems		1.03.2001	MINISYSTEMS

FW-C250/19E	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C250/21	1049Mini systems	1.12.2000	MINISYSTEMS
FW-C250/37	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C252/19	Mini systems		MINISYSTEMS
FW-C255/21	Mini systems		MINISYSTEMS
FW-C255/30	Mini systems		MINISYSTEMS
FW-C255/33	Mini systems		MINISYSTEMS
FW-C255/37	Mini systems		MINISYSTEMS
FW-C28/22	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C28/33	1049Mini systems		MINISYSTEMS
FW-C28/34	1049Mini systems	1.06.2000	MINISYSTEMS
FW-C280/22	1049Mini systems	1.02.2001	MINISYSTEMS
FW-C280/25	1049Mini systems	1.11.2001	MINISYSTEMS
FW-C280/34	1049Mini systems	1.03.2001	MINISYSTEMS
FW-C290/18	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C290/19	1049Mini systems	1.03.2001	MINISYSTEMS
FW-C290/19E	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C290/21	1049Mini systems	1.01.2001	MINISYSTEMS
FW-C3/37	1049Mini systems	1.02.2000	MINISYSTEMS
FW-C30/18	1049Mini systems	1.01.2001	MINISYSTEMS
FW-C30/19	1049Mini systems	1.02.2001	MINISYSTEMS
FW-C30/19E	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C30/21	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C30/21M	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C30/30	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C30/37	1049Mini systems		MINISYSTEMS
FW-C35/37	1049Mini systems	1.01.2000	MINISYSTEMS
FW-C355/21	Mini systems		MINISYSTEMS
FW-C355/22	Mini systems		MINISYSTEMS
FW-C355/33	Mini systems		MINISYSTEMS
FW-C355/34	Mini systems		MINISYSTEMS
FW-C38/18	1049Mini systems	1.01.2001	MINISYSTEMS
FW-C38/19	1049Mini systems	1.02.2001	MINISYSTEMS
FW-C38/19E	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C38/21	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C38/21M	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C38/22	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C38/34	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C38/37	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C380/18	1049Mini systems	1.09.2001	MINISYSTEMS
FW-C380/19	1049Mini systems	1.09.2001	MINISYSTEMS
FW-C380/21	1049Mini systems	1.05.2001	MINISYSTEMS

FW-C380/22	1049Mini systems	1.01.2001	MINISYSTEMS
FW-C380/25	Mini systems	1.12.2001	MINISYSTEMS
FW-C380/30	1049Mini systems	1.03.2001	MINISYSTEMS
FW-C380/33	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C380/34	1049Mini systems	1.03.2001	MINISYSTEMS
FW-C380/37	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C380/42	1049Mini systems	1.10.2001	MINISYSTEMS
FW-C380/54	1049Mini systems	1.11.2001	MINISYSTEMS
FW-C39/21	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C39/21M	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C39/30	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C39/33	1049Mini systems		MINISYSTEMS
FW-C399/21	Mini systems		MINISYSTEMS
FW-C399/21M	Mini systems		MINISYSTEMS
FW-C399/22	Mini systems		MINISYSTEMS
FW-C399/30	Mini systems		MINISYSTEMS
FW-C399/33	Mini systems		MINISYSTEMS
FW-C399/34	Mini systems		MINISYSTEMS
FW-C399/37	Mini systems		MINISYSTEMS
FW-C40/22	1049Mini systems	1.08.2000	MINISYSTEMS
FW-C50/37	1049Mini systems	1.02.2000	MINISYSTEMS
FW-C500/37	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C505/19	Mini systems		MINISYSTEMS
FW-C505/21	Mini systems		MINISYSTEMS
FW-C505/22	Mini systems		MINISYSTEMS
FW-C55/22	1049Mini systems	1.03.2000	MINISYSTEMS
FW-C55/34	1049Mini systems	1.03.2000	MINISYSTEMS
FW-C550/37	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C555/19	Mini systems		MINISYSTEMS
FW-C555/21	Mini systems		MINISYSTEMS
FW-C555/37	Mini systems		MINISYSTEMS
FW-C58/18	1049Mini systems	1.01.2001	MINISYSTEMS
FW-C58/19	1049Mini systems	1.02.2001	MINISYSTEMS
FW-C58/21	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C58/21M	1049Mini systems	1.06.2000	MINISYSTEMS
FW-C58/30	1049Mini systems		MINISYSTEMS
FW-C58/33	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C58/34	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C70/37	1049Mini systems	1.01.2000	MINISYSTEMS
FW-C700/19	Mini systems		MINISYSTEMS
FW-C700/21	Mini systems	1.12.2001	MINISYSTEMS
FW-C700/22	1049Mini systems	1.05.2001	MINISYSTEMS

FW-C700/34	1049Mini systems	1.06.2001	MINISYSTEMS
FW-C700/37	1049Mini systems		MINISYSTEMS
FW-C71/37	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C72/37	1049Mini systems		MINISYSTEMS
FW-C720/18	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C720/19	1049Mini systems	1.07.2001	MINISYSTEMS
FW-C720/19E	Mini systems		MINISYSTEMS
FW-C720/21	1049Mini systems	1.05.2001	MINISYSTEMS
FW-C780/18	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C780/19	1049Mini systems	1.07.2001	MINISYSTEMS
FW-C780/21	1049Mini systems	1.05.2001	MINISYSTEMS
FW-C780/22	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C780/30	1049Mini systems	1.06.2001	MINISYSTEMS
FW-C780/33	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C780/34	1049Mini systems	1.05.2001	MINISYSTEMS
FW-C780/37	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C785/22	Mini systems		MINISYSTEMS
FW-C785/34	Mini systems		MINISYSTEMS
FW-C788/18	Mini systems		MINISYSTEMS
FW-C788/19	Mini systems		MINISYSTEMS
FW-C788/21	Mini systems		MINISYSTEMS
FW-C788/21M	Mini systems		MINISYSTEMS
FW-C788/30	Mini systems		MINISYSTEMS
FW-C788/33	Mini systems		MINISYSTEMS
FW-C788/37	Mini systems		MINISYSTEMS
FW-C798/18	Mini systems		MINISYSTEMS
FW-C798/19	Mini systems		MINISYSTEMS
FW-C798/21	Mini systems		MINISYSTEMS
FW-C798/37	Mini systems		MINISYSTEMS
FW-C80/22	1049Mini systems	1.05.2000	MINISYSTEMS
FW-C80/34	1049Mini systems	1.07.2000	MINISYSTEMS
FW-C80/37	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C83/22	1049Mini systems	1.06.2000	MINISYSTEMS
FW-C83/37	1049Mini systems		MINISYSTEMS
FW-C85/02	1049Mini systems	1.06.2000	MINISYSTEMS
FW-C85/18	1049Mini systems	1.01.2001	MINISYSTEMS
FW-C85/19	1049Mini systems	1.02.2001	MINISYSTEMS
FW-C85/19E	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C85/21	1049Mini systems	1.07.2000	MINISYSTEMS
FW-C85/21M	1049Mini systems	1.07.2000	MINISYSTEMS
FW-C85/22	1049Mini systems		MINISYSTEMS
FW-C85/30	1049Mini systems	1.09.2000	MINISYSTEMS

FW-C85/34	1049Mini systems	1.07.2000	MINISYSTEMS
FW-C85/37	1049Mini systems	1.04.2000	MINISYSTEMS
FW-C870/18	1049Mini systems	1.06.2001	MINISYSTEMS
FW-C870/19	1049Mini systems	1.04.2001	MINISYSTEMS
FW-C870/19E	1049Mini systems	1.06.2001	MINISYSTEMS
FW-C870/21	1049Mini systems	1.01.2001	MINISYSTEMS
FW-C870/37	1049Mini systems	1.08.2001	MINISYSTEMS
FW-C90/02	1049Mini systems	1.06.2000	MINISYSTEMS
FW-C90/22	1049Mini systems		MINISYSTEMS
FW-C99/37	1049Mini systems	1.10.2001	MINISYSTEMS
FW-D1/21	1049Mini (DVD)		RECEIVERS
FW-D1/21M	1049Mini (DVD)	1.10.2000	RECEIVERS
FW-D5/21	1049Mini (DVD)	1.09.2000	RECEIVERS
FW-D5/21M	1049Mini (DVD)	1.08.2000	RECEIVERS
FW-D5/22	1049Mini (DVD)	1.09.2000	RECEIVERS
FW-D5/30	1049Mini (DVD)	1.10.2000	RECEIVERS
FW-D5/33	1049Mini systems A/V	1.08.2001	MINISYSTEMS
FW-D5/37	1049Mini (DVD)	1.08.2001	RECEIVERS
FW-I1000/37	1049Mini systems	1.09.2001	MINISYSTEMS
FW-M355/22	Mini systems		MINISYSTEMS
FW-M355/34	Mini systems		MINISYSTEMS
FW-M355/37	Mini systems		MINISYSTEMS
FW-M55/22	1049Mini systems	1.09.2000	MINISYSTEMS
FW-M55/37	1049Mini systems	1.09.2001	MINISYSTEMS
FW-P73/37	1049Mini systems	1.04.2000	MINISYSTEMS
FW-P75/22	1049Mini systems	1.04.2000	MINISYSTEMS
FW-P75/34	1049Mini systems	1.05.2000	MINISYSTEMS
FW-P750/22	1049Mini systems	1.05.2001	MINISYSTEMS
FW-P750/34	1049Mini systems	1.06.2001	MINISYSTEMS
FW-P750/37	1049Mini systems	1.08.2001	MINISYSTEMS
FW-P78/21	1049Mini systems	1.05.2000	MINISYSTEMS
FW-P78/21M	1049Mini systems	1.06.2000	MINISYSTEMS
FW-P78/30	1049Mini systems	1.05.2000	MINISYSTEMS
FW-P78/33	1049Mini systems	1.08.2001	MINISYSTEMS
FW-P78/34	1049Mini systems	1.05.2000	MINISYSTEMS
FW-P78/37	1049Mini systems	1.01.2000	MINISYSTEMS
FW-P88/02	1049Mini systems	1.06.2000	MINISYSTEMS
FW-P88/22	1049Mini systems		MINISYSTEMS
FW-P88/37	1049Mini systems	1.04.2000	MINISYSTEMS
FW-P880/37	1049Mini systems	1.08.2001	MINISYSTEMS
FW-P900/37	1049Mini systems	1.08.2001	MINISYSTEMS
FW-R33/37	1049Mini (CDR)	1.10.2001	CDR

FW-R55/19	Mini (CDR)		CDR
FW-R55/19E	Mini (CDR)		CDR
FW-R55/21	1049Mini (CDR)	1.12.2001	CDR
FW-R55/21M	1049Mini (CDR)		CDR
FW-R55/22	1049Mini (CDR)	1.10.2001	CDR
FW-R55/33	1049Mini (CDR)		CDR
FW-R55/37	1049Mini (CDR)	1.10.2001	CDR
FW-R7/21	1049Mini (CDR)	1.08.2000	CDR
FW-R7/21M	1049Mini (CDR)		CDR
FW-R7/22	1049Mini (CDR)	1.06.2000	CDR
FW-R7/33	1049Mini (CDR)	1.08.2001	CDR
FW-R7/37	1049Mini (CDR)	1.05.2000	CDR
FW-R8/21	1049Mini (CDR)	1.08.2000	CDR
FW-R8/21M	1049CDR-players		CDR
FW-R8/22	1049Mini (CDR)	1.06.2000	CDR
FW-R8/37	1049Mini (CDR)	1.10.2001	CDR
FW-R88/21	1049Mini (CDR)	1.04.2001	CDR
FW-R88/22	1049Mini (CDR)	1.03.2001	CDR
FW-R88/37	1049Mini (CDR)	1.08.2001	CDR
FW-V220/21M	1049Mini systems A/V	1.05.2001	MINISYSTEMS
FW-V220/28	1049Mini systems A/V		MINISYSTEMS
FW-V28/21M	1049Mini systems	1.06.2000	MINISYSTEMS
FW-V320/21M	1049Mini systems A/V	1.05.2001	MINISYSTEMS
FW-V320/28	1049Mini systems A/V		MINISYSTEMS
FW-V355/12	Mini systems		MINISYSTEMS
FW-V355/21M	Mini systems		MINISYSTEMS
FW-V39/21M	1049Mini systems	1.06.2000	MINISYSTEMS
FW-V39/28	1049Mini systems A/V	1.12.2000	MINISYSTEMS
FW-V520/21M	1049Mini systems A/V	1.11.2001	MINISYSTEMS
FW-V55/21	1049Mini systems		MINISYSTEMS
FW-V55/21M	1049Mini systems	1.07.2000	MINISYSTEMS
FW-V720/21M	1049Mini systems A/V	1.06.2001	MINISYSTEMS
FW-V720/28	1049Mini systems A/V		MINISYSTEMS
FW-V780/21M	Mini systems A/V	1.12.2001	MINISYSTEMS
FW-V785/21M	Mini systems A/V		MINISYSTEMS
FW-V795/21M	Mini systems A/V		MINISYSTEMS
FW10/21	1049Mini systems	1.05.1993	MINISYSTEMS
FW11/20	1049Micro systems	1.09.1994	MICROSYSTEMS
FW11/21	1049Micro systems	1.11.1994	MICROSYSTEMS
FW11/25	1049Micro systems	1.10.1994	MICROSYSTEMS
FW11/30	1049Micro systems	1.12.1994	MICROSYSTEMS
FW11/31	1049Micro systems	1.11.1994	MICROSYSTEMS

FW12/20	1049Micro systems	1.08.1995	MICROSYSTEMS
FW12/21	1049Micro systems	1.05.1995	MICROSYSTEMS
FW12/21M	1049Micro systems	1.05.1995	MICROSYSTEMS
FW12/22	1049Micro systems	1.08.1995	MICROSYSTEMS
FW12/25	1049Micro systems	1.09.1995	MICROSYSTEMS
FW12/26	1049Micro systems	1.08.1995	MICROSYSTEMS
FW14/37	1049Micro systems	1.09.1994	MICROSYSTEMS
FW15/20	1049Micro systems	1.12.1994	MICROSYSTEMS
FW15/21	1049Micro systems	1.02.1995	MICROSYSTEMS
FW15/21M	1049Micro systems	1.10.1994	MICROSYSTEMS
FW15/22	1049Micro systems	1.02.1995	MICROSYSTEMS
FW15/26	1049Micro systems	1.12.1994	MICROSYSTEMS
FW15/37	1049Micro systems	1.09.1994	MICROSYSTEMS
FW16/20	1049Micro systems	1.07.1994	MICROSYSTEMS
FW16/21	1049Micro systems	1.11.1993	MICROSYSTEMS
FW16/41	1049Micro systems	1.01.1995	MICROSYSTEMS
FW16/41M	1049Micro systems	1.04.1994	MICROSYSTEMS
FW17/21	1049Micro systems	1.03.1995	MICROSYSTEMS
FW17/21I	1049Micro systems	1.11.1996	MICROSYSTEMS
FW17/21M	1049Micro systems	1.10.1994	MICROSYSTEMS
FW17/22	1049Micro systems	1.01.1995	MICROSYSTEMS
FW17/26	1049Micro systems	1.12.1994	MICROSYSTEMS
FW18/21	1049Micro systems	1.10.1995	MICROSYSTEMS
FW18/21M	1049Micro systems	1.11.1995	MICROSYSTEMS
FW18/22	1049Micro systems	1.12.1995	MICROSYSTEMS
FW19/37	1049Mini systems	1.09.1993	MINISYSTEMS
FW20/20	1049Mini systems	1.08.1992	MINISYSTEMS
FW20/21	1049Mini systems	1.07.1992	MINISYSTEMS
FW20/22	1049Mini systems	1.09.1992	MINISYSTEMS
FW20/30	1049Mini systems	1.07.1992	MINISYSTEMS
FW20/37	1049Mini systems	1.07.1992	MINISYSTEMS
FW2010/20	1049Mini systems	1.03.1992	MINISYSTEMS
FW2010/21	1049Mini systems	1.03.1992	MINISYSTEMS
FW2010/22	1049Mini systems	1.03.1992	MINISYSTEMS
FW2010/30	1049Mini systems	1.04.1992	MINISYSTEMS
FW2010/37	1049Mini systems	1.04.1992	MINISYSTEMS
FW2012/20	1049	1.03.1992	MIDISYSTEMS
FW2012/21	1049	1.03.1992	MIDISYSTEMS
FW2012/22	1049	1.03.1992	MIDISYSTEMS
FW2012/28	1049	1.03.1992	MIDISYSTEMS
FW2012/30	1049	1.03.1992	MIDISYSTEMS
FW2012/37	1049	1.03.1992	MIDISYSTEMS

FW2012/39	1049	1.08.1992	MIDISYSTEMS
FW2014/20	1049Mini systems	1.03.1992	MINISYSTEMS
FW2014/21	1049Mini systems	1.03.1992	MINISYSTEMS
FW2014/22	1049Mini systems	1.03.1992	MINISYSTEMS
FW2014/30	1049Mini systems	1.05.1992	MINISYSTEMS
FW2014/37	1049Mini systems	1.03.1992	MINISYSTEMS
FW2015/20	1049Mini systems	1.03.1992	MINISYSTEMS
FW2015/21	1049Mini systems	1.03.1992	MINISYSTEMS
FW2015/22	1049Mini systems	1.03.1992	MINISYSTEMS
FW2015/30	1049Mini systems	1.03.1992	MINISYSTEMS
FW2015/37	1049Mini systems	1.03.1992	MINISYSTEMS
FW2015/39	1049Mini systems	1.06.1992	MINISYSTEMS
FW2017/20	1049	1.03.1992	MIDISYSTEMS
FW2017/21	1049	1.03.1992	MIDISYSTEMS
FW2017/22	1049	1.03.1992	MIDISYSTEMS
FW2017/30	1049	1.05.1992	MIDISYSTEMS
FW2019/20	1049Mini systems	1.03.1992	MINISYSTEMS
FW2019/21	1049Mini systems	1.03.1992	MINISYSTEMS
FW21/20	1049Mini systems	1.04.1993	MINISYSTEMS
FW21/21	1049Mini systems	1.05.1993	MINISYSTEMS
FW21/22	1049Mini systems	1.06.1993	MINISYSTEMS
FW21/25	1049Mini systems	1.08.1993	MINISYSTEMS
FW210/37	1049Mini systems	1.09.1996	MINISYSTEMS
FW24/37	1049Mini systems	1.05.1994	MINISYSTEMS
FW25/20	1049Mini systems	1.05.1993	MINISYSTEMS
FW25/21	1049Mini systems	1.10.1993	MINISYSTEMS
FW25/22	1049Mini systems	1.12.1993	MINISYSTEMS
FW25/30	1049Mini systems	1.08.1993	MINISYSTEMS
FW25/37	1049Mini systems	1.09.1992	MINISYSTEMS
FW26/20	1049Mini systems	1.03.1994	MINISYSTEMS
FW26/21	1049Mini systems	1.04.1994	MINISYSTEMS
FW26/21M	1049Mini systems	1.11.1994	MINISYSTEMS
FW26/22	1049Mini systems	1.04.1994	MINISYSTEMS
FW26/25	1049Mini systems	1.06.1994	MINISYSTEMS
FW26/26	1049Mini systems	1.03.1994	MINISYSTEMS
FW26/30	1049Mini systems	1.07.1994	MINISYSTEMS
FW26/34	1049Mini systems	1.06.1994	MINISYSTEMS
FW26/37	1049Mini systems	1.07.1994	MINISYSTEMS
FW26CL/21	1049Mini systems		MINISYSTEMS
FW27/37	1049Mini systems	1.09.1993	MINISYSTEMS
FW28/37	1049Mini systems	1.05.1995	MINISYSTEMS
FW29/37	1049Mini systems	1.09.1995	MINISYSTEMS

FW30/20	1049Mini systems	1.06.1992	MINISYSTEMS
FW30/20S	1049Mini systems	1.02.1993	MINISYSTEMS
FW30/21	1049Mini systems	1.07.1992	MINISYSTEMS
FW30/22	1049Mini systems	1.09.1992	MINISYSTEMS
FW30/30	1049Mini systems	1.08.1992	MINISYSTEMS
FW30/34	1049Mini systems	1.10.1992	MINISYSTEMS
FW30/37	1049Mini systems	1.07.1992	MINISYSTEMS
FW306/21	1049Mini systems	1.07.1998	MINISYSTEMS
FW306/21M	1049Mini systems	1.06.1998	MINISYSTEMS
FW306/22	1049Mini systems	1.07.1998	MINISYSTEMS
FW306/34	1049Mini systems	1.09.1998	MINISYSTEMS
FW31/20	1049Mini systems	1.05.1993	MINISYSTEMS
FW31/21	1049Mini systems	1.06.1993	MINISYSTEMS
FW31/22	1049Mini systems	1.06.1993	MINISYSTEMS
FW31/34	1049Mini systems	1.11.1993	MINISYSTEMS
FW315C/22	1049Mini systems	1.08.1997	MINISYSTEMS
FW315C/37	1049Mini systems	1.04.1997	MINISYSTEMS
FW316C/19	1049Mini systems	1.06.1998	MINISYSTEMS
FW316C/21M	1049Mini systems	1.04.1999	MINISYSTEMS
FW316C/22	1049Mini systems	1.05.1998	MINISYSTEMS
FW316C/37	1049Mini systems	1.03.1998	MINISYSTEMS
FW318C/37	1049Mini systems	1.07.1998	MINISYSTEMS
FW32/37	1049Mini systems	1.08.1994	MINISYSTEMS
FW320C/21	1049Mini systems	1.04.1999	MINISYSTEMS
FW320C/22	1049Mini systems	1.04.1999	MINISYSTEMS
FW320C/37	1049Mini systems	1.01.1999	MINISYSTEMS
FW322C/37	1049Mini systems	1.05.1996	MINISYSTEMS
FW322C/37P	1049Mini systems	1.10.1996	MINISYSTEMS
FW322C/37S	1049Mini systems	1.02.1997	MINISYSTEMS
FW325/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW326/12	1049Mini systems	1.07.1998	MINISYSTEMS
FW326/21	1049Mini systems	1.06.1998	MINISYSTEMS
FW326/21M	1049Mini systems	1.06.1998	MINISYSTEMS
FW326/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW326/34	1049Mini systems	1.08.1998	MINISYSTEMS
FW33/20	1049Mini systems	1.02.1995	MINISYSTEMS
FW33/37	1049Mini systems	1.11.1994	MINISYSTEMS
FW330/20	1049Mini systems	1.05.1995	MINISYSTEMS
FW330/21	1049Mini systems	1.04.1995	MINISYSTEMS
FW330/21I	1049Mini systems	1.11.1996	MINISYSTEMS
FW330/21M	1049Mini systems	1.04.1995	MINISYSTEMS
FW330/22	1049Mini systems	1.05.1995	MINISYSTEMS

FW330/25	1049Mini systems	1.07.1995	MINISYSTEMS
FW330/30	1049Mini systems	1.06.1995	MINISYSTEMS
FW330/34	1049Mini systems	1.07.1995	MINISYSTEMS
FW330CL/15	1049Mini systems		MINISYSTEMS
FW330V2/15	1049Mini systems		MINISYSTEMS
FW331G-CL/15	1049Mini systems		MINISYSTEMS
FW331G/26	1049Mini systems	1.03.1995	MINISYSTEMS
FW332/21	1049Mini systems	1.09.1996	MINISYSTEMS
FW332/21M	1049Mini systems	1.10.1996	MINISYSTEMS
FW332/22	1049Mini systems	1.08.1996	MINISYSTEMS
FW332/25	1049Mini systems	1.09.1996	MINISYSTEMS
FW332/34	1049Mini systems	1.09.1996	MINISYSTEMS
FW332/34H	1049Mini systems	1.05.1997	MINISYSTEMS
FW335/12	1049Mini systems	1.12.1997	MINISYSTEMS
FW335/21	1049Mini systems	1.05.1997	MINISYSTEMS
FW335/21G	1049Mini systems	1.06.1997	MINISYSTEMS
FW335/21M	1049Mini systems	1.05.1997	MINISYSTEMS
FW335/21Z	1049Mini systems	1.07.1997	MINISYSTEMS
FW335/22	1049Mini systems	1.07.1997	MINISYSTEMS
FW335/25	1049Mini systems	1.07.1997	MINISYSTEMS
FW335/34	1049Mini systems	1.05.1997	MINISYSTEMS
FW335/34G	1049Mini systems	1.08.1997	MINISYSTEMS
FW335/34H	1049Mini systems	1.07.1997	MINISYSTEMS
FW338C/37	1049Mini systems	1.05.1998	MINISYSTEMS
FW339C/19	1049Mini systems	1.06.1998	MINISYSTEMS
FW339C/21	1049Mini systems	1.06.1998	MINISYSTEMS
FW339C/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW339C/30	1049Mini systems	1.07.1998	MINISYSTEMS
FW34/20	1049Mini systems	1.06.1995	MINISYSTEMS
FW34/37	1049Mini systems	1.04.1995	MINISYSTEMS
FW340C/30G	1049Mini systems	1.09.1997	MINISYSTEMS
FW340C/37	1049Mini systems	1.05.1997	MINISYSTEMS
FW342C/37	1049Mini systems	1.09.1996	MINISYSTEMS
FW346C/22	1049Mini systems	1.09.1998	MINISYSTEMS
FW35/37	1049Mini systems	1.09.1993	MINISYSTEMS
FW350C/22	1049Mini systems	1.05.1999	MINISYSTEMS
FW350C/34	1049Mini systems	1.06.1999	MINISYSTEMS
FW351C/37	1049Mini systems	1.08.1995	MINISYSTEMS
FW352C/21	1049Mini systems	1.09.1996	MINISYSTEMS
FW352C/22	1049Mini systems	1.09.1996	MINISYSTEMS
FW352C/25	1049Mini systems	1.09.1996	MINISYSTEMS
FW352C/30	1049Mini systems	1.09.1996	MINISYSTEMS

FW352C/37	1049Mini systems	1.08.1996	MINISYSTEMS
FW355C/12	1049Mini systems	1.02.1998	MINISYSTEMS
FW355C/21	1049Mini systems	1.05.1997	MINISYSTEMS
FW355C/21G	1049Mini systems	1.08.1997	MINISYSTEMS
FW355C/21Z	1049Mini systems	1.08.1997	MINISYSTEMS
FW355C/22G	1049Mini systems	1.09.1997	MINISYSTEMS
FW355C/22K	1049Mini systems	1.09.1997	MINISYSTEMS
FW355C/22S	1049Mini systems	1.07.1997	MINISYSTEMS
FW355C/25	1049Mini systems	1.07.1997	MINISYSTEMS
FW355C/25G	1049Mini systems	1.10.1997	MINISYSTEMS
FW355C/30	1049Mini systems	1.09.1997	MINISYSTEMS
FW355C/37	1049Mini systems	1.05.1997	MINISYSTEMS
FW355C/37G	1049Mini systems	1.07.1997	MINISYSTEMS
FW355P/P01	1049Mini systems		MINISYSTEMS
FW356C/19	1049Mini systems	1.07.1998	MINISYSTEMS
FW356C/21	1049Mini systems	1.06.1998	MINISYSTEMS
FW356C/21M	1049Mini systems	1.06.1998	MINISYSTEMS
FW356C/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW356C/33	1049Mini systems		MINISYSTEMS
FW356C/34	1049Mini systems	1.09.1998	MINISYSTEMS
FW358C/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW358C/30	1049Mini systems	1.08.1998	MINISYSTEMS
FW358C/37	1049Mini systems	1.06.1998	MINISYSTEMS
FW359C/22	1049Mini systems	1.09.1998	MINISYSTEMS
FW36/20	1049Mini systems	1.09.1994	MINISYSTEMS
FW36/21	1049Mini systems	1.07.1994	MINISYSTEMS
FW36/22	1049Mini systems	1.09.1994	MINISYSTEMS
FW36/25	1049Mini systems	1.09.1994	MINISYSTEMS
FW36/30	1049Mini systems	1.08.1994	MINISYSTEMS
FW36/37	1049Mini systems	1.06.1994	MINISYSTEMS
FW360C/20	1049Mini systems	1.08.1995	MINISYSTEMS
FW360C/21	1049Mini systems	1.06.1995	MINISYSTEMS
FW360C/21M	1049Mini systems	1.06.1995	MINISYSTEMS
FW360C/22	1049Mini systems	1.08.1995	MINISYSTEMS
FW360C/25	1049Mini systems	1.09.1995	MINISYSTEMS
FW360C/30	1049Mini systems	1.09.1995	MINISYSTEMS
FW360C/37	1049Mini systems	1.05.1995	MINISYSTEMS
FW361C/37	1049Mini systems	1.07.1997	MINISYSTEMS
FW361C/37G	1049Mini systems	1.08.1997	MINISYSTEMS
FW362/21	1049Mini systems	1.10.1996	MINISYSTEMS
FW362/21M	1049Mini systems	1.10.1996	MINISYSTEMS
FW362/22	1049Mini systems	1.09.1996	MINISYSTEMS

FW362/34	1049Mini systems	1.10.1996	MINISYSTEMS
FW362/41	1049Mini systems	1.11.1996	MINISYSTEMS
FW363/21M	1049Mini systems	1.09.1997	MINISYSTEMS
FW363/22	1049Mini systems	1.07.1997	MINISYSTEMS
FW363/22G	1049Mini systems	1.01.1998	MINISYSTEMS
FW363/34	1049Mini systems	1.09.1997	MINISYSTEMS
FW363/34G	1049Mini systems	1.02.1998	MINISYSTEMS
FW365C/21	1049Mini systems	1.06.1997	MINISYSTEMS
FW365C/22	1049Mini systems	1.09.1997	MINISYSTEMS
FW365C/22G	1049Mini systems	1.01.1998	MINISYSTEMS
FW365C/37	1049Mini systems	1.04.1997	MINISYSTEMS
FW365C/37G	1049Mini systems	1.02.1998	MINISYSTEMS
FW372C/21	1049Mini systems	1.08.1996	MINISYSTEMS
FW372C/21P	1049Mini systems	1.04.1997	MINISYSTEMS
FW372C/22	1049Mini systems	1.08.1996	MINISYSTEMS
FW372C/22B	1049Mini systems	1.05.1997	MINISYSTEMS
FW372C/22P	1049Mini systems	1.03.1997	MINISYSTEMS
FW372C/25	1049Mini systems	1.09.1996	MINISYSTEMS
FW372C/25P	1049Mini systems	1.06.1997	MINISYSTEMS
FW372C/30	1049Mini systems	1.09.1996	MINISYSTEMS
FW372C/34	1049Mini systems	1.09.1996	MINISYSTEMS
FW372C/34P	1049Mini systems	1.05.1997	MINISYSTEMS
FW372C/37	1049Mini systems	1.08.1996	MINISYSTEMS
FW372C/41	1049Mini systems	1.09.1996	MINISYSTEMS
FW373C/21	1049Mini systems	1.06.1997	MINISYSTEMS
FW373C/22B	1049Mini systems	1.09.1997	MINISYSTEMS
FW373C/34	1049Mini systems	1.10.1997	MINISYSTEMS
FW375P/21	1049Mini systems	1.06.1997	MINISYSTEMS
FW375P/22	1049Mini systems	1.07.1997	MINISYSTEMS
FW375P/22G	1049Mini systems	1.02.1998	MINISYSTEMS
FW375P/30	1049Mini systems	1.04.1997	MINISYSTEMS
FW375P/37	1049Mini systems	1.04.1997	MINISYSTEMS
FW375P/37G	1049Mini systems	1.02.1998	MINISYSTEMS
FW380C/18	Mini systems		MINISYSTEMS
FW380C/19	1049Mini systems	1.05.1999	MINISYSTEMS
FW380C/21	1049Mini systems	1.04.1999	MINISYSTEMS
FW380C/21M	1049Mini systems	1.04.1999	MINISYSTEMS
FW380C/30	1049Mini systems	1.06.1999	MINISYSTEMS
FW380C/37	1049Mini systems	1.06.1999	MINISYSTEMS
FW380I/00	1054CDI	1.07.1995	CDI
FW380I/00S	1054CDI	1.10.1995	CDI
FW380I/05	1054CDI	1.09.1995	CDI

FW380I/20	1054CDI	1.10.1995	CDI
FW380I/20N	1054CDI	1.02.1996	CDI
FW380V/41	1049Mini systems A/V	1.06.1997	MINISYSTEMS
FW380VCL/15	1049Mini systems		MINISYSTEMS
FW382V/21	1049Mini systems	1.12.1996	MINISYSTEMS
FW383V/21S	1049Mini systems	1.08.1997	MINISYSTEMS
FW385P/37	1049Mini systems	1.06.1997	MINISYSTEMS
FW386C/37	1049Mini systems	1.02.1999	MINISYSTEMS
FW388V/12	1049Mini systems	1.11.1998	MINISYSTEMS
FW388V/21	1049Mini systems	1.10.1998	MINISYSTEMS
FW390C/18	1049Mini systems	1.08.1999	MINISYSTEMS
FW390C/19	1049Mini systems	1.06.1999	MINISYSTEMS
FW390C/21	1049Mini systems	1.03.1999	MINISYSTEMS
FW390C/22	1049Mini systems	1.04.1999	MINISYSTEMS
FW390C/34	1049Mini systems	1.05.1999	MINISYSTEMS
FW390C/37	1049Mini systems	1.05.1999	MINISYSTEMS
FW391C/22	1049Mini systems	1.09.1999	MINISYSTEMS
FW391C/37	1049Mini systems	1.08.1996	MINISYSTEMS
FW392C/21	1049Mini systems	1.09.1996	MINISYSTEMS
FW392C/30	1049Mini systems	1.11.1996	MINISYSTEMS
FW392C/37	1049Mini systems	1.08.1996	MINISYSTEMS
FW395C/21	1049Mini systems	1.09.1996	MINISYSTEMS
FW395C/22	1049Mini systems	1.11.1996	MINISYSTEMS
FW395C/41	1049Mini systems	1.10.1996	MINISYSTEMS
FW396C/22	1049Mini systems	1.08.1999	MINISYSTEMS
FW396C/30	1049Mini systems	1.11.1999	MINISYSTEMS
FW398C/21	1049Mini systems	1.04.1999	MINISYSTEMS
FW398C/21M	1049Mini systems	1.04.1999	MINISYSTEMS
FW398C/30	1049Mini systems	1.06.1999	MINISYSTEMS
FW398C/33	1049Mini systems		MINISYSTEMS
FW398C/34	1049Mini systems	1.07.1999	MINISYSTEMS
FW399V/21	1049Mini systems		MINISYSTEMS
FW399V/21M	1049Mini systems	1.07.1999	MINISYSTEMS
FW40/20	1049Mini systems	1.07.1992	MINISYSTEMS
FW40/21	1049Mini systems	1.08.1992	MINISYSTEMS
FW40/22	1049Mini systems	1.09.1992	MINISYSTEMS
FW40/25	1049Mini systems	1.09.1992	MINISYSTEMS
FW40/30	1049Mini systems	1.09.1992	MINISYSTEMS
FW40/34	1049Mini systems	1.10.1992	MINISYSTEMS
FW40/37	1049Mini systems	1.01.1993	MINISYSTEMS
FW41/20	1049Mini systems	1.05.1993	MINISYSTEMS
FW41/21	1049Mini systems	1.05.1993	MINISYSTEMS

FW41/22	1049Mini systems	1.06.1993	MINISYSTEMS
FW41/25	1049Mini systems	1.06.1993	MINISYSTEMS
FW41/30	1049Mini systems	1.06.1993	MINISYSTEMS
FW41/34	1049Mini systems	1.09.1993	MINISYSTEMS
FW41CL/35	1049Mini systems		MINISYSTEMS
FW45C/37	1049Mini systems	1.02.1999	MINISYSTEMS
FW46/20	1049Mini systems	1.06.1994	MINISYSTEMS
FW46/21	1049Mini systems	1.04.1994	MINISYSTEMS
FW46/21M	1049Mini systems	1.09.1994	MINISYSTEMS
FW46/22	1049Mini systems	1.06.1994	MINISYSTEMS
FW46/25	1049Mini systems	1.07.1994	MINISYSTEMS
FW46/26	1049Mini systems	1.12.1994	MINISYSTEMS
FW46/34	1049Mini systems	1.06.1994	MINISYSTEMS
FW46/41M	1049Mini systems	1.11.1994	MINISYSTEMS
FW48/37	1049Mini systems	1.05.1997	MINISYSTEMS
FW48VCD/21	1049Mini systems	1.03.1995	MINISYSTEMS
FW48VCD/41	1049Mini systems	1.01.1995	MINISYSTEMS
FW510C/37	1049Mini systems	1.08.1998	MINISYSTEMS
FW520C/12	1049Mini systems	1.09.1998	MINISYSTEMS
FW520C/37	1049Mini systems	1.09.1998	MINISYSTEMS
FW52C/37	1049Mini systems	1.04.1998	MINISYSTEMS
FW530C/22	1049Mini systems	1.05.1998	MINISYSTEMS
FW530C/34	1049Mini systems	1.09.1998	MINISYSTEMS
FW530C/37	1049Mini systems	1.04.1998	MINISYSTEMS
FW535C/21	1049Mini systems	1.06.1998	MINISYSTEMS
FW535C/21M	1049Mini systems	1.06.1998	MINISYSTEMS
FW535C/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW535C/30	1049Mini systems	1.08.1998	MINISYSTEMS
FW535C/34	1049Mini systems	1.09.1998	MINISYSTEMS
FW538/22	1049Mini systems	1.09.1998	MINISYSTEMS
FW538SR/P22	1049Mini (CDR)	1.08.2001	CDR
FW54/37	1049Mini systems	1.03.1995	MINISYSTEMS
FW540C/37	1049Mini systems	1.04.1999	MINISYSTEMS
FW545C/21	1049Mini systems	1.04.1999	MINISYSTEMS
FW545C/22	1049Mini systems	1.04.1999	MINISYSTEMS
FW545C/34	1049Mini systems	1.06.1999	MINISYSTEMS
FW545C/37	1049Mini systems	1.03.1999	MINISYSTEMS
FW548C/18	1049Mini systems	1.09.1999	MINISYSTEMS
FW548C/19	1049Mini systems	1.07.1999	MINISYSTEMS
FW548C/21	1049Mini systems	1.06.1999	MINISYSTEMS
FW548C/21M	1049Mini systems		MINISYSTEMS
FW548C/34	1049Mini systems	1.05.1999	MINISYSTEMS

FW548V/21M	1049Mini systems	1.01.2000	MINISYSTEMS
FW550C/22	1049Mini systems	1.07.1998	MINISYSTEMS
FW555C/22	1049Mini systems	1.06.1999	MINISYSTEMS
FW555C/37	1049Mini systems	1.06.1999	MINISYSTEMS
FW56/20	1049Mini systems	1.09.1994	MINISYSTEMS
FW56/21	1049Mini systems	1.07.1994	MINISYSTEMS
FW56/22	1049Mini systems	1.09.1994	MINISYSTEMS
FW56/25	1049Mini systems	1.10.1994	MINISYSTEMS
FW56/30	1049Mini systems	1.09.1994	MINISYSTEMS
FW56/37	1049Mini systems	1.08.1994	MINISYSTEMS
FW560C/37	1049Mini systems	1.06.1998	MINISYSTEMS
FW570C/21	1049Mini systems	1.07.1998	MINISYSTEMS
FW570C/21M	1049Mini systems	1.07.1998	MINISYSTEMS
FW570C/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW570C/37	1049Mini systems	1.05.1998	MINISYSTEMS
FW575C/21	1049Mini systems	1.08.1998	MINISYSTEMS
FW575C/21M	1049Mini systems	1.09.1998	MINISYSTEMS
FW575C/33	1049Mini systems		MINISYSTEMS
FW58/37	1049Mini systems	1.09.1997	MINISYSTEMS
FW58/37G	1049Mini systems	1.02.1998	MINISYSTEMS
FW585C/37	1049Mini systems	1.06.1999	MINISYSTEMS
FW590C/34	1049Mini systems	1.06.1999	MINISYSTEMS
FW595C/21M	1049Mini systems	1.06.1999	MINISYSTEMS
FW595C/30	1049Mini systems	1.07.1999	MINISYSTEMS
FW595C/33	1049Mini systems		MINISYSTEMS
FW60/20	1049Mini systems	1.01.1993	MINISYSTEMS
FW60/21X	1049Mini systems	1.02.1993	MINISYSTEMS
FW60/22	1049Mini systems	1.08.1992	MINISYSTEMS
FW61/22	1049Mini systems	1.03.1994	MINISYSTEMS
FW610/22	1049Mini systems	1.11.1995	MINISYSTEMS
FW620C/22	1049Mini systems	1.01.1996	MINISYSTEMS
FW620C/37	1049Mini systems	1.11.1995	MINISYSTEMS
FW62C/37	1049Mini systems	1.05.1998	MINISYSTEMS
FW630/21M	1049Mini systems	1.10.1995	MINISYSTEMS
FW630/22	1049Mini systems	1.11.1995	MINISYSTEMS
FW630/34	1049Mini systems	1.12.1995	MINISYSTEMS
FW630/41	1049Mini systems	1.10.1995	MINISYSTEMS
FW650C/21M	1049Mini systems	1.09.1995	MINISYSTEMS
FW650C/22	1049Mini systems	1.11.1995	MINISYSTEMS
FW650C/33	1049Mini systems		MINISYSTEMS
FW650C/37	1049Mini systems	1.05.1996	MINISYSTEMS
FW650C/41	1049Mini systems	1.09.1995	MINISYSTEMS

FW65C/37	1049Mini systems	1.03.1999	MINISYSTEMS
FW66/21B	1049Mini systems	1.08.1994	MINISYSTEMS
FW66/22B	1049Mini systems	1.09.1994	MINISYSTEMS
FW66/25B	1049Mini systems	1.09.1994	MINISYSTEMS
FW670P/21	1049Mini systems	1.07.1996	MINISYSTEMS
FW670P/22	1049Mini systems	1.07.1996	MINISYSTEMS
FW680V/21	1049Mini systems	1.07.1996	MINISYSTEMS
FW690/22	1049Mini systems	1.08.1998	MINISYSTEMS
FW70/20	1049Mini systems	1.02.1993	MINISYSTEMS
FW70/21	1049Mini systems	1.09.1992	MINISYSTEMS
FW70/21X	1049Mini systems	1.04.1993	MINISYSTEMS
FW70/22	1049Mini systems	1.07.1992	MINISYSTEMS
FW70/25	1049Mini systems	1.10.1992	MINISYSTEMS
FW70/37	1049Mini systems	1.08.1992	MINISYSTEMS
FW710C/21S	1049Mini systems	1.10.1997	MINISYSTEMS
FW710C/30S	1049Mini systems	1.09.1997	MINISYSTEMS
FW710C/41S	1049Mini systems	1.01.1998	MINISYSTEMS
FW725C/22	1049Mini systems	1.06.1997	MINISYSTEMS
FW72C/37	1049Mini systems	1.09.1998	MINISYSTEMS
FW730C/21	1049Mini systems	1.05.1997	MINISYSTEMS
FW730C/21M	1049Mini systems	1.05.1997	MINISYSTEMS
FW730C/21S	1049Mini systems	1.09.1997	MINISYSTEMS
FW730C/22	1049Mini systems	1.04.1997	MINISYSTEMS
FW730C/22S	1049Mini systems	1.05.1997	MINISYSTEMS
FW730C/25	1049Mini systems	1.06.1997	MINISYSTEMS
FW730C/34	1049Mini systems	1.06.1997	MINISYSTEMS
FW730C/41	1049Mini systems	1.01.1998	MINISYSTEMS
FW730C/41S	1049Mini systems	1.12.1997	MINISYSTEMS
FW730C/42	1049Mini systems	1.02.1998	MINISYSTEMS
FW730C/42S	1049Mini systems	1.02.1998	MINISYSTEMS
FW730C/53	1049Mini systems		MINISYSTEMS
FW730C/54	1049Mini systems	1.03.1998	MINISYSTEMS
FW730V/35	1049Mini systems	1.12.1997	MINISYSTEMS
FW730V/41M	1049Mini systems	1.12.1997	MINISYSTEMS
FW745C/22	1049Mini systems	1.06.1997	MINISYSTEMS
FW748P/22	1049Mini systems	1.06.1999	MINISYSTEMS
FW748P/37	1049Mini systems	1.05.1999	MINISYSTEMS
FW750C/21	1049Mini systems	1.12.1996	MINISYSTEMS
FW750C/21S	1049Mini systems	1.05.1997	MINISYSTEMS
FW750C/21X	1049Mini systems	1.07.1997	MINISYSTEMS
FW750C/22	1049Mini systems	1.06.1997	MINISYSTEMS
FW750C/22S	1049Mini systems	1.06.1997	MINISYSTEMS

FW750C/25	1049Mini systems	1.06.1997	MINISYSTEMS
FW750C/30S	1049Mini systems	1.08.1997	MINISYSTEMS
FW750C/34S	1049Mini systems	1.07.1997	MINISYSTEMS
FW750C/34X	1049Mini systems	1.09.1997	MINISYSTEMS
FW750C/37	1049Mini systems	1.06.1997	MINISYSTEMS
FW750C/41S	1049Mini systems	1.05.1997	MINISYSTEMS
FW750C/41X	1049Mini systems	1.09.1997	MINISYSTEMS
FW750C/42	1049Mini systems	1.02.1998	MINISYSTEMS
FW750C/42S	1049Mini systems	1.02.1998	MINISYSTEMS
FW750C/50S	1049Mini systems	1.02.1998	MINISYSTEMS
FW750C/53S	1049Mini systems		MINISYSTEMS
FW754P/37	1049Mini systems	1.06.1998	MINISYSTEMS
FW76/21B	1049Mini systems	1.12.1994	MINISYSTEMS
FW76/22B	1049Mini systems	1.09.1994	MINISYSTEMS
FW765P/21	1049Mini systems	1.07.1998	MINISYSTEMS
FW765P/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW765P/33	1049Mini systems		MINISYSTEMS
FW765P/34	1049Mini systems	1.09.1998	MINISYSTEMS
FW768P/18	1049Mini systems	1.03.2000	MINISYSTEMS
FW768P/19	1049Mini systems	1.09.1999	MINISYSTEMS
FW768P/21	1049Mini systems	1.06.1999	MINISYSTEMS
FW768P/21M	1049Mini systems	1.06.1999	MINISYSTEMS
FW768P/22	1049Mini systems	1.06.1999	MINISYSTEMS
FW768P/33	1049Mini systems		MINISYSTEMS
FW768P/34	1049Mini systems	1.07.1999	MINISYSTEMS
FW768P/37	1049Mini systems	1.05.1999	MINISYSTEMS
FW770P/21	1049Mini systems	1.02.1997	MINISYSTEMS
FW775P/22	1049Mini systems	1.06.1998	MINISYSTEMS
FW775P/30	1049Mini systems	1.08.1998	MINISYSTEMS
FW775P/37	1049Mini systems	1.05.1998	MINISYSTEMS
FW780P/21	1049Mini systems	1.12.1996	MINISYSTEMS
FW780P/21S	1049Mini systems	1.05.1997	MINISYSTEMS
FW780P/22	1049Mini systems	1.05.1997	MINISYSTEMS
FW780P/30S	1049Mini systems	1.07.1997	MINISYSTEMS
FW780P/34S	1049Mini systems	1.07.1997	MINISYSTEMS
FW780V/35	1049Mini systems	1.12.1997	MINISYSTEMS
FW780V/41M	1049Mini systems	1.01.1998	MINISYSTEMS
FW790P/21S	1049Mini systems	1.06.1997	MINISYSTEMS
FW790P/22	1049Mini systems	1.05.1997	MINISYSTEMS
FW795W/22	1049Mini systems	1.08.1998	MINISYSTEMS
FW795W/37	1049Mini systems	1.12.1998	MINISYSTEMS
FW798W/22	1049Mini systems	1.09.1999	MINISYSTEMS

FW798W/37	1049Mini systems	1.06.1999	MINISYSTEMS
FW8/21M	1049Micro systems	1.08.1996	MICROSYSTEMS
FW8/25M	1049Micro systems	1.05.1996	MICROSYSTEMS
FW8/30	1049Micro systems	1.07.1996	MICROSYSTEMS
FW80/02	1049Mini systems	1.05.1993	MINISYSTEMS
FW80/21	1049Mini systems	1.09.1992	MINISYSTEMS
FW80/21X	1049Mini systems	1.03.1993	MINISYSTEMS
FW80/22	1049Mini systems	1.07.1992	MINISYSTEMS
FW80/25	1049Mini systems	1.11.1992	MINISYSTEMS
FW830C/21	1049Mini systems	1.09.1999	MINISYSTEMS
FW830C/22	1049Mini systems	1.08.1999	MINISYSTEMS
FW830C/34	1049Mini systems	1.09.1999	MINISYSTEMS
FW830C/37	1049Mini systems	1.06.1999	MINISYSTEMS
FW840C/22	1049Mini systems	1.09.1999	MINISYSTEMS
FW850C/18	1049Mini systems	1.11.1998	MINISYSTEMS
FW850C/21	1049Mini systems	1.04.1998	MINISYSTEMS
FW850C/22	1049Mini systems	1.04.1998	MINISYSTEMS
FW850C/22B	1049Mini systems	1.12.1998	MINISYSTEMS
FW850C/34	1049Mini systems	1.05.1998	MINISYSTEMS
FW855C/21	1049Mini systems	1.05.1998	MINISYSTEMS
FW855C/21M	1049Mini systems	1.06.1998	MINISYSTEMS
FW855C/34	1049Mini systems	1.07.1998	MINISYSTEMS
FW860P/21	1049Mini systems	1.06.1998	MINISYSTEMS
FW870C/18	1049Mini systems		MINISYSTEMS
FW870C/19	1049Mini systems	1.09.1999	MINISYSTEMS
FW870C/21	1049Mini systems	1.07.1999	MINISYSTEMS
FW870C/22	1049Mini systems	1.06.1999	MINISYSTEMS
FW878C/34	1049Mini systems	1.09.1999	MINISYSTEMS
FW880/02	1049Mini systems	1.06.1998	MINISYSTEMS
FW880P/21	1049Mini systems	1.04.1998	MINISYSTEMS
FW880P/21M	1049Mini systems	1.05.1998	MINISYSTEMS
FW880P/33	1049Mini systems		MINISYSTEMS
FW880P/34	1049Mini systems	1.06.1998	MINISYSTEMS
FW880W/21	1049Mini systems	1.06.1998	MINISYSTEMS
FW880W/34	1049Mini systems	1.08.1998	MINISYSTEMS
FW890P/18	1049Mini systems		MINISYSTEMS
FW890P/21	1049Mini systems	1.07.1999	MINISYSTEMS
FW890P/22	1049Mini systems	1.07.1999	MINISYSTEMS
FW890P/30	1049Mini systems		MINISYSTEMS
FW890P/37	1049Mini systems	1.06.1999	MINISYSTEMS
FW898W/21	1049Mini systems	1.07.1999	MINISYSTEMS
FW898W/34	1049Mini systems	1.09.1999	MINISYSTEMS

FW910R/22	1049Mini systems	1.10.1999	MINISYSTEMS
FW910SR/P22	1049Mini (CDR)	1.11.1999	CDR
FW930/22	1049Mini systems	1.10.1999	MINISYSTEMS
FW930/37	1049Mini systems	1.11.1999	MINISYSTEMS
FW930SR/P22	1049Mini (CDR)	1.11.1999	CDR
GDV100D/002	DVD Video		DVD
GDV110D/001	DVD Video		DVD
GDV110D/002	DVD Video		DVD
GDV110D/003	DVD Video		DVD
GDV200D/002	DVD Video		DVD
GDV200D/003	DVD Video		DVD
GOLF10X/91	1003		TELEPHONES CORDLESS
GOLFPPLUS/91	1003		TELEPHONES CORDLESS
GPE0111/FBY	1004		TELEPHONES CORDED
GPE0151/HBY	1004		TELEPHONES CORDED
GPE0251/IBY	1004		TELEPHONES CORDED
GV 720TL	4010VCR Timelapse		VCR
GV26	1021Leader		VCR
GV26EURO	1021Leader		VCR
GV26VPS	1021Leader		VCR
GV27	1021Leader		VCR
GV27EURO	1021Leader		VCR
GV27VPS/5	1021Leader		VCR
GV45SV/5	1021Leader show view		VCR
GV46	1021Leader show view		VCR
GV46VPS	1021Leader show view		VCR
GV47	1021Leader show view		VCR
GV47VPS/5	1021Leader show view		VCR
GV5000SV	1021Leader		VCR
GV5000VPS/5	1021Leader		VCR
GV5050	1021Leader	G-OLIVIA	VCR
GV5300VPS/5	1021Leader show view		VCR
GV6000EUR/O	1021Leader		VCR
GV6000SV	1021Leader		VCR
GV6000SV/1	1021Leader		VCR
GV6001V+	1021Leader		VCR
GV600SV	1021Leader		VCR
GV600SV/1	1021Leader		VCR
GV605EURO	1021Leader		VCR
GV6066	1021Leader		VCR
GV6096SV/1	1021Leader		VCR
GV609M/99	1021Leader		VCR

GV6300EUR/O	1021Leader show view			VCR
GV6300SV	1021Leader show view			VCR
GV6300SV/1	1021Leader show view			VCR
GV630SV	1021Leader show view			VCR
GV630SV/1	1021Leader show view			VCR
GV635EURO	1021Leader show view			VCR
GV6396SV	1021Leader show view			VCR
GV6400HIF/5	1021Leader			VCR
GV6400NIC	1021Leader			VCR
GV6400NIC/2	1021Leader			VCR
GV6401NIC	1021Leader			VCR
GV640HIFI	1021Leader			VCR
GV640NIC	1021Leader			VCR
GV645EURO	1021Leader			VCR
GV650HIFI	1021Step-up			VCR
GV6596HIF/I	1021Leader			VCR
GV6596NIC	1021Step-up			VCR
GV660HIFI	1021Step-up			VCR
GV660NIC	1021Step-up			VCR
GV665EURO	1021Step-up			VCR
GV670SHIF/I	1021Leader			VCR
GV670SNIC	1021Leader			VCR
GV690SHIF/I	1021Leader			VCR
GV690SNIC	1021Leader			VCR
GV7000EUR/O	1021Leader			VCR
GV7000GB	1021Leader			VCR
GV7000SV	1021Leader			VCR
GV7000SV-/C	1021Leader			VCR
GV7003	1021Leader			VCR
GV709M/99	1021Leader	PJVM	1.09.1996	VCR
GV729M/99	1021Leader	PJVM	1.09.1996	VCR
GV7300EUR/O	1021Leader show view			VCR
GV7300SV	1021Leader show view			VCR
GV7300SV/5	1021Leader show view			VCR
GV7400EUR/O	1021Leader			VCR
GV7400GB	1021Leader			VCR
GV7400HIF/5	1021Leader			VCR
GV7400HIF/I	1021Leader			VCR
GV7400NIC	1021Leader			VCR
GV7400NIC/2	1021Leader			VCR
GV740HIFI	1021Leader			VCR
GV740NIC	1021Leader			VCR

GV745EURO	1021Leader		VCR
GV809M/99	1021Leader		VCR
GV819M/99	1021Leader		VCR
GV849M/99	1021Leader show view		VCR
GVP600ICN/EUR	1021Leader		VCR
HFC10/02	1006Philips thermal fax	NOVA	FAXES
HFC10/02C	1006Philips thermal fax	NOVA	FAXES
HFC10/03	1006Philips thermal fax	NOVA	FAXES
HFC10/03C	1006Philips thermal fax	NOVA	FAXES
HFC10/04C	1006Philips thermal fax	NOVA	FAXES
HFC10/05	1006Philips thermal fax	NOVA	FAXES
HFC10/05C	1006Philips thermal fax	NOVA	FAXES
HFC10/06	1006Philips thermal fax	NOVA	FAXES
HFC10/06C	1006Philips thermal fax	NOVA	FAXES
HFC10/07	1006Philips thermal fax	NOVA	FAXES
HFC10/07C	1006Philips thermal fax	NOVA	FAXES
HFC10/08	1006Philips thermal fax	NOVA	FAXES
HFC10/08C	1006Philips thermal fax	NOVA	FAXES
HFC10/09	1006Philips thermal fax	NOVA	FAXES
HFC10/09C	1006Philips thermal fax	NOVA	FAXES
HFC10/10	1006Philips thermal fax	NOVA	FAXES
HFC10/10C	1006Philips thermal fax	NOVA	FAXES
HFC10/13	1006Philips thermal fax	NOVA	FAXES
HFC10/13C	1006Philips thermal fax	NOVA	FAXES
HFC10/14C	1006Philips thermal fax	NOVA	FAXES
HFC10/16	1006Philips thermal fax	NOVA	FAXES
HFC10/16C	1006Philips thermal fax	NOVA	FAXES
HFC10/17C	1006Philips thermal fax	NOVA	FAXES
HFC10/19	1006Philips thermal fax	NOVA	FAXES
HFC10/19C	1006Philips thermal fax	NOVA	FAXES
HFC10/37C	1006Philips thermal fax	NOVA	FAXES
HFC10/38C	1006Philips thermal fax		FAXES
HFC10A1/02	1006Philips thermal fax	NOVA	FAXES
HFC10A1/03	1006Philips thermal fax	NOVA	FAXES
HFC10A1/09	1006Philips thermal fax	NOVA	FAXES
HFC10S/02	1006Philips thermal fax	NOVA	FAXES
HFC111/02	1006Philips thermal fax		FAXES
HFC111/03	1006Philips thermal fax		FAXES
HFC111/05	1006Philips thermal fax		FAXES
HFC111/08	1006Philips thermal fax		FAXES
HFC111/19	1006Philips thermal fax		FAXES
HFC12/02	1006Philips thermal fax	MAGIC	FAXES

HFC12/03	1006Philips thermal fax	MAGIC	FAXES
HFC12/04	1006Philips thermal fax		FAXES
HFC12/06	1006Philips thermal fax	MAGIC	FAXES
HFC12/08	1006Philips thermal fax	MAGIC	FAXES
HFC12/09	1006Philips thermal fax	MAGIC	FAXES
HFC12/10	1006Philips thermal fax	MAGIC	FAXES
HFC12/13	1006Philips thermal fax		FAXES
HFC12/14	1006Philips thermal fax		FAXES
HFC12/15	1006Philips thermal fax		FAXES
HFC12/16	1006Philips thermal fax	MAGIC	FAXES
HFC12/17	1006Philips thermal fax		FAXES
HFC12/19	1006Philips thermal fax	MAGIC	FAXES
HFC12/20	1006Philips thermal fax		FAXES
HFC141/00	1006Philips thermal fax		FAXES
HFC141/02	1006Philips thermal fax		FAXES
HFC141/03	1006Philips thermal fax		FAXES
HFC141/04	1006Philips thermal fax		FAXES
HFC141/05	1006Philips thermal fax		FAXES
HFC141/06	1006Philips thermal fax		FAXES
HFC141/07	1006Philips thermal fax		FAXES
HFC141/08	1006Philips thermal fax		FAXES
HFC141/09	1006Philips thermal fax		FAXES
HFC141/10	1006Philips thermal fax		FAXES
HFC141/13	1006Philips thermal fax		FAXES
HFC141/14	1006Philips thermal fax		FAXES
HFC141/15	1006Philips thermal fax		FAXES
HFC141/16	1006Philips thermal fax		FAXES
HFC141/17	1006Philips thermal fax		FAXES
HFC141/19	1006Philips thermal fax		FAXES
HFC141/20	1006Philips thermal fax		FAXES
HFC171/00	1006Philips thermal fax		FAXES
HFC171/02	1006Philips thermal fax		FAXES
HFC171/03	1006Philips thermal fax		FAXES
HFC171/04	1006Philips thermal fax		FAXES
HFC171/05	1006Philips thermal fax		FAXES
HFC171/06	1006Philips thermal fax		FAXES
HFC171/07	1006Philips thermal fax		FAXES
HFC171/08	1006Philips thermal fax		FAXES
HFC171/09	1006Philips thermal fax		FAXES
HFC171/10	1006Philips thermal fax		FAXES
HFC171/13	1006Philips thermal fax		FAXES
HFC171/14	1006Philips thermal fax		FAXES

HFC171/15	1006Philips thermal fax		FAXES
HFC171/16	1006Philips thermal fax		FAXES
HFC171/17	1006Philips thermal fax		FAXES
HFC171/19	1006Philips thermal fax		FAXES
HFC171/20	1006Philips thermal fax		FAXES
HFC20/02	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/00	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/02	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/03	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/04	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/05	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/06	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/07	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/08	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/08A	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/09	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/10	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/13	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/14	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/15	1006Philips thermal fax		FAXES
HFC21/16	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/17	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/19	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21/20	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21I/02	1006Philips thermal fax	SUPERNOVA	FAXES
HFC21I/03	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/00	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/02	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/03	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/04	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/05	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/06	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/07	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/08	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/08A	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/09	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/10	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/13	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/14	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/15	1006Philips thermal fax		FAXES
HFC22/16	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/17	1006Philips thermal fax	SUPERNOVA	FAXES

HFC22/19	1006Philips thermal fax	SUPERNOVA	FAXES
HFC22/20	1006Philips thermal fax	SUPERNOVA	FAXES
HFC31/02	1006Philips thermal fax	SUPERNOVA	FAXES
HFC31/08	1006Philips thermal fax	SUPERNOVA	FAXES
HFC31/08A	1006Philips thermal fax	SUPERNOVA	FAXES
HFC31/19	1006Philips thermal fax	SUPERNOVA	FAXES
HFC4/02	1006Philips thermal fax	MAGIC	FAXES
HFC4/03	1006Philips thermal fax	MAGIC	FAXES
HFC4/04	1006Philips thermal fax	MAGIC	FAXES
HFC4/05	1006Philips thermal fax	MAGIC	FAXES
HFC4/06	1006Philips thermal fax	MAGIC	FAXES
HFC4/08	1006Philips thermal fax	MAGIC	FAXES
HFC4/09	1006Philips thermal fax	MAGIC	FAXES
HFC4/10	1006Philips thermal fax	MAGIC	FAXES
HFC4/13	1006Philips thermal fax	MAGIC	FAXES
HFC4/14	1006Philips thermal fax	MAGIC	FAXES
HFC4/15	1006Philips thermal fax	MAGIC	FAXES
HFC4/16	1006Philips thermal fax	MAGIC	FAXES
HFC4/17	1006Philips thermal fax	MAGIC	FAXES
HFC4/19	1006Philips thermal fax	MAGIC	FAXES
HFC4/20	1006Philips thermal fax	MAGIC	FAXES
HFC4/35	1006Philips thermal fax	MAGIC	FAXES
HFC4/36	1006Philips thermal fax	MAGIC	FAXES
HFC4/37	1006Philips thermal fax	MAGIC	FAXES
HFC4/79	1006Philips thermal fax	MAGIC	FAXES
HFC41/02	1006Philips thermal fax	TAURUS	FAXES
HFC41/09	1006Philips thermal fax		FAXES
HFC41B/02	1006Philips thermal fax		FAXES
HFC42/02	1006Philips thermal fax	TAURUS	FAXES
HFC42/03	1006Philips thermal fax	TAURUS	FAXES
HFC42/09	1006Philips thermal fax	TAURUS	FAXES
HFC42/10	1006Philips thermal fax	TAURUS	FAXES
HFC42B/02	1006Philips thermal fax		FAXES
HFC42B/09	1006Philips thermal fax		FAXES
HFC50/02	1006Philips thermal fax	SUPERNOVA	FAXES
HFC6/02	1006Philips thermal fax	NOVA	FAXES
HFC6/02C	1006Philips thermal fax		FAXES
HFC6/03	1006Philips thermal fax	NOVA	FAXES
HFC6/03C	1006Philips thermal fax		FAXES
HFC6/04C	1006Philips thermal fax	NOVA	FAXES
HFC6/05C	1006Philips thermal fax	NOVA	FAXES
HFC6/06	1006Philips thermal fax	NOVA	FAXES

HFC6/06C	1006Philips thermal fax	NOVA	FAXES
HFC6/07C	1006Philips thermal fax	NOVA	FAXES
HFC6/08	1006Philips thermal fax	NOVA	FAXES
HFC6/08C	1006Philips thermal fax	NOVA	FAXES
HFC6/09	1006Philips thermal fax	NOVA	FAXES
HFC6/09C	1006Philips thermal fax	NOVA	FAXES
HFC6/10	1006Philips thermal fax	NOVA	FAXES
HFC6/10C	1006Philips thermal fax	NOVA	FAXES
HFC6/13	1006Philips thermal fax	NOVA	FAXES
HFC6/13C	1006Philips thermal fax	NOVA	FAXES
HFC6/14C	1006Philips thermal fax	NOVA	FAXES
HFC6/15	1006Philips thermal fax	NOVA	FAXES
HFC6/16	1006Philips thermal fax	NOVA	FAXES
HFC6/16C	1006Philips thermal fax	NOVA	FAXES
HFC6/17C	1006Philips thermal fax	NOVA	FAXES
HFC6/19	1006Philips thermal fax	NOVA	FAXES
HFC6/19C	1006Philips thermal fax	NOVA	FAXES
HFC8/02	1006Philips thermal fax	MAGIC	FAXES
HFC8/03	1006Philips thermal fax	MAGIC	FAXES
HFC8/03W	1006Philips thermal fax	MAGIC	FAXES
HFC8/04	1006Philips thermal fax	MAGIC	FAXES
HFC8/05	1006Philips thermal fax	MAGIC	FAXES
HFC8/06	1006Philips thermal fax	MAGIC	FAXES
HFC8/06W	1006Philips thermal fax	MAGIC	FAXES
HFC8/08	1006Philips thermal fax	MAGIC	FAXES
HFC8/09	1006Philips thermal fax	MAGIC	FAXES
HFC8/10	1006Philips thermal fax	MAGIC	FAXES
HFC8/13	1006Philips thermal fax	MAGIC	FAXES
HFC8/14	1006Philips thermal fax	MAGIC	FAXES
HFC8/15	1006Philips thermal fax	MAGIC	FAXES
HFC8/16	1006Philips thermal fax	MAGIC	FAXES
HFC8/17	1006Philips thermal fax	MAGIC	FAXES
HFC8/19	1006Philips thermal fax	MAGIC	FAXES
HFC8/20	1006Philips thermal fax	MAGIC	FAXES
HFC8/35	1006Philips thermal fax	MAGIC	FAXES
HFC8/36	1006Philips thermal fax	MAGIC	FAXES
HFC8/37	1006Philips thermal fax	MAGIC	FAXES
HFC8/38	1006Philips thermal fax	MAGIC	FAXES
HFC8/40	1006Philips thermal fax	MAGIC	FAXES
HFC8/79	1006Philips thermal fax	MAGIC	FAXES
HFC9/02	1006Philips thermal fax	MAGIC	FAXES
HFC9/06	1006Philips thermal fax	MAGIC	FAXES

HS39/A	1004			TELEPHONES CORDED
HS39/BR	1004			TELEPHONES CORDED
HS39/BRH	1004			TELEPHONES CORDED
HS39/CR	1004			TELEPHONES CORDED
HS39/G	1004			TELEPHONES CORDED
HS39/LG	1004			TELEPHONES CORDED
HS39/MB	1004			TELEPHONES CORDED
HS39/MDG	1004			TELEPHONES CORDED
HS39/MFW	1004			TELEPHONES CORDED
HS39/MG	1004			TELEPHONES CORDED
HS39/MLG	1004			TELEPHONES CORDED
HS39/MM	1004			TELEPHONES CORDED
HS39/MW	1004			TELEPHONES CORDED
HS39/SBH	1004			TELEPHONES CORDED
HSTD9048E/05	1004			TELEPHONES CORDED
HSTD9048E/19	1004			TELEPHONES CORDED
K-SC12/.	1041	Clock radio		CLOCKRADIO
K-SC12/W	1041	Clock radio		CLOCKRADIO
K-SC12L/AB	1041	Clock radio		CLOCKRADIO
K-SC40/.	1041	Clock radio		CLOCKRADIO
KV5001VPS/5	1021	Leader		VCR
KV5301VPS/5	1021	Leader show view		VCR
KV7001VPS/5	1021	Leader		VCR
KV7301VPS/5	1021	Leader show view		VCR
LARGE/TW	7001	25i mono	1.03.1992	TELEVISION
LDV501L/001		DVD Video		DVD
LDV501L/002		DVD Video		DVD
LDV501L/003		DVD Video		DVD
LDV501U/001		DVD Video		DVD
LDV501U/002		DVD Video		DVD
LDV501U/003		DVD Video		DVD
LDV502L/001		DVD Video		DVD
LDV502L/002		DVD Video		DVD
LDV502L/003		DVD Video		DVD
LDV502U/001		DVD Video		DVD
LDV502U/002		DVD Video		DVD
LDV502U/003		DVD Video		DVD
LIBRAW/07	1003			TELEPHONES CORDLESS
M14/76	7001	14i (13v) stereo	1.05.1993	TELEVISION
M1426/00	7001	14i (13v) stereo		TELEVISION
M1432/00	7001	14i (13v) mono	L6.1	1.06.1996Basic TV
M1432/01	7001	14i (13v) stereo	L6.1	1.05.1996Basic TV

M1432/05	700114i (13v) mono	L6.1	1.04.1996Basic TV	TELEVISION
M1432/07	700114i (13v) stereo	L6.1	1.10.1996Basic TV	TELEVISION
M1432/25	700114i (13v) mono	L6.1	1.09.1998Basic TV	TELEVISION
M1452/05	700114i (13v) mono	L6.1	1.09.1996Basic TV	TELEVISION
M1452/25	700114i (13v) mono	L6.1	1.10.1998Basic TV	TELEVISION
M14L/76	700114i (13v) stereo		1.03.1992	TELEVISION
M18C/22	1049Mini systems			MINISYSTEMS
M20/76	700120i (19v) mono		1.05.1993	TELEVISION
M2032/00	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
M2032/01	700120i (19v) mono	L6.1	1.06.1996Basic TV	TELEVISION
M2032/05	700120i (19v) mono	L6.1	1.07.1996Basic TV	TELEVISION
M2032/05X	700120i (19v) mono	L6.1	1.06.1997Basic TV	TELEVISION
M2041/00	700120i (19v) mono			TELEVISION
M2052/00	700120i (19v) mono	L6.1	1.04.1997Basic TV	TELEVISION
M2052/01	700120i (19v) mono	L6.1	1.07.1997Basic TV	TELEVISION
M2052/05	700120i (19v) mono	L6.1	1.09.1996Basic TV	TELEVISION
M2052/05X	700120i (19v) mono	L6.1	1.06.1997Basic TV	TELEVISION
M2085/00	700120i (19v) mono			TELEVISION
M20L/76	700120i (19v) mono		1.03.1992	TELEVISION
M2125/00	700121i (20v) mono	ANUBIS_A	1.03.1995Basic TV	TELEVISION
M2126/00	700120i (19v) mono	AA5	1.05.1996Basic TV	TELEVISION
M2132/00	700120i (19v) mono	L6.1	1.06.1996Basic TV	TELEVISION
M2132/01	700120i (19v) mono	L6.1	1.12.1996Basic TV	TELEVISION
M2132/07	700120i (19v) mono	L6.1	1.10.1996Basic TV	TELEVISION
M2132/11	700121i (20v) mono			TELEVISION
M2152/00	700121i (20v) mono	L6.1	1.05.1997Basic TV	TELEVISION
M2152/15	700120i (19v) mono	L6.1	1.07.1997Basic TV	TELEVISION
M2182/00	700121i (20v) stereo medium	L6.1	1.02.1997Basic TV	TELEVISION
M2185/00	700120i (19v) mono			TELEVISION
M2192/01	700121i (20v) stereo medium			TELEVISION
M2192/05	700120i (19i) stereo medium	L6.1	1.12.1996Basic TV	TELEVISION
M2192/05X	700121i (20v) stereo medium	L6.1	1.07.1997Basic TV	TELEVISION
M28C/22	1049Mini systems			MINISYSTEMS
M38C/22	1049Mini systems			MINISYSTEMS
M48DC/22	1049Mini systems			MINISYSTEMS
M620/21		M		CAMCORDERS
M622/21		M		CAMCORDERS
M623/21		M		CAMCORDERS
M660/21		M		CAMCORDERS
M661/21		M		CAMCORDERS
M7229/11	710125i stereo large 50Hz	GR2.2	1.08.1995Basic TV	TELEVISION
M820/21		H		CAMCORDERS

M870/21		H		CAMCORDERS
MAS-100/37	Mini systems			MINISYSTEMS
MAS-150/37	Mini systems			MINISYSTEMS
MC-10/19	1049Micro systems		1.04.2001	MICROSYSTEMS
MC-10/19E	Micro systems			MICROSYSTEMS
MC-10/21	1049Micro systems		1.11.2000	MICROSYSTEMS
MC-10/22	1049Micro systems		1.09.2000	MICROSYSTEMS
MC-10/25	1049Micro systems		1.02.2001	MICROSYSTEMS
MC-10/29	1049Micro systems		1.01.2001	MICROSYSTEMS
MC-10/33	1049Micro systems		1.08.2001	MICROSYSTEMS
MC-10/37	1049Micro systems		1.05.2001	MICROSYSTEMS
MC-100/21M	Micro systems		1.12.2001	MICROSYSTEMS
MC-100/22	Micro systems			MICROSYSTEMS
MC-100/30	Micro systems			MICROSYSTEMS
MC-100/33	Micro systems			MICROSYSTEMS
MC-100/37	Micro systems		1.12.2001	MICROSYSTEMS
MC-105/19	Micro systems			MICROSYSTEMS
MC-105/21	Micro systems		1.12.2001	MICROSYSTEMS
MC-105/21M	Micro systems		1.11.2001	MICROSYSTEMS
MC-105/22	Micro systems			MICROSYSTEMS
MC-105/29	Micro systems			MICROSYSTEMS
MC-105/33	1049Micro systems			MICROSYSTEMS
MC-105/37	Micro systems		1.12.2001	MICROSYSTEMS
MC-110/21	Micro systems			MICROSYSTEMS
MC-110/21M	Micro systems			MICROSYSTEMS
MC-110/22	Micro systems			MICROSYSTEMS
MC-110/29	Micro systems			MICROSYSTEMS
MC-110/33	Micro systems			MICROSYSTEMS
MC-110/37	Micro systems			MICROSYSTEMS
MC-20/21	1049Micro systems		1.10.2000	MICROSYSTEMS
MC-20/21M	1049Micro systems		1.10.2000	MICROSYSTEMS
MC-20/22	1049Micro systems		1.09.2000	MICROSYSTEMS
MC-20/30	1049Micro systems		1.11.2000	MICROSYSTEMS
MC-20/33	1049Micro systems		1.08.2001	MICROSYSTEMS
MC-200/19	Micro systems			MICROSYSTEMS
MC-200/21	Micro systems		1.12.2001	MICROSYSTEMS
MC-200/21M	Micro systems		1.12.2001	MICROSYSTEMS
MC-200/22	Micro systems			MICROSYSTEMS
MC-200/29	Micro systems			MICROSYSTEMS
MC-200/30	Micro systems		1.12.2001	MICROSYSTEMS
MC-200/33	1049Micro systems		1.11.2001	MICROSYSTEMS
MC-30/22	1049Micro systems		1.01.2001	MICROSYSTEMS

MC-30/37	1049Micro systems	1.05.2001	MICROSYSTEMS
MC-45/37	1049Micro systems	1.08.2001	MICROSYSTEMS
MC-50/22	1049Micro systems	1.04.2001	MICROSYSTEMS
MC-50/33	1049Micro systems	1.08.2001	MICROSYSTEMS
MC-50/37	1049Micro systems	1.08.2001	MICROSYSTEMS
MC-55/21M	1049Micro systems	1.01.2001	MICROSYSTEMS
MC-70/21	1049Micro systems	1.07.2001	MICROSYSTEMS
MC-70/21M	1049Micro systems	1.06.2001	MICROSYSTEMS
MC-70/22	1049Micro systems	1.05.2001	MICROSYSTEMS
MC-70/33	1049Micro systems	1.08.2001	MICROSYSTEMS
MC-70/37	1049Micro systems	1.08.2001	MICROSYSTEMS
MC-77/21	Micro systems		MICROSYSTEMS
MC-77/21M	Micro systems		MICROSYSTEMS
MC-77/22	Micro systems		MICROSYSTEMS
MC-77/33	Micro systems		MICROSYSTEMS
MC-77/37	Micro systems		MICROSYSTEMS
MC-90/21M	Micro systems		MICROSYSTEMS
MC-90/22	Micro systems		MICROSYSTEMS
MC-90/37	Micro systems		MICROSYSTEMS
MC-I200/21M	Micro systems		MICROSYSTEMS
MC-I200/22	Micro systems		MICROSYSTEMS
MC-I200/33	Micro systems		MICROSYSTEMS
MC-I200/37	Micro systems		MICROSYSTEMS
MC-M250/21	Micro systems		MICROSYSTEMS
MC-M250/21M	Micro systems		MICROSYSTEMS
MC-M250/22	Micro systems		MICROSYSTEMS
MC-M250/30	Micro systems		MICROSYSTEMS
MC-M250/33	Micro systems		MICROSYSTEMS
MC-M250/37	Micro systems		MICROSYSTEMS
MC115/01	1049Micro systems	1.10.1998	MICROSYSTEMS
MC115/02	1049Micro systems	1.07.1998	MICROSYSTEMS
MC115/11	1049Micro systems	1.09.1998	MICROSYSTEMS
MC115/13	1049Micro systems		MICROSYSTEMS
MC115/14	1049Micro systems	1.09.1998	MICROSYSTEMS
MC118/21	1049Micro systems	1.04.2000	MICROSYSTEMS
MC118/21M	1049Micro systems	1.03.2000	MICROSYSTEMS
MC118/22	1049Micro systems	1.01.2000	MICROSYSTEMS
MC118/29	Micro systems		MICROSYSTEMS
MC118/33	1049Micro systems		MICROSYSTEMS
MC118/37	1049Micro systems	1.01.2000	MICROSYSTEMS
MC130/21	1049Micro systems	1.09.1996	MICROSYSTEMS
MC130/22	1049Micro systems	1.10.1996	MICROSYSTEMS

MC130/30	1049Micro systems	1.01.1997	MICROSYSTEMS
MC130/33	1049Micro systems		MICROSYSTEMS
MC135/21	1049Micro systems	1.12.1996	MICROSYSTEMS
MC135/21M	1049Micro systems	1.01.1998	MICROSYSTEMS
MC135/22	1049Micro systems	1.10.1997	MICROSYSTEMS
MC136/21	1049Micro systems	1.07.1998	MICROSYSTEMS
MC136/21M	1049Micro systems	1.06.1998	MICROSYSTEMS
MC136/22	1049Micro systems	1.07.1998	MICROSYSTEMS
MC136/29	1049Micro systems	1.11.1998	MICROSYSTEMS
MC136/33	1049Micro systems		MICROSYSTEMS
MC145/01	1049Micro systems	1.06.1999	MICROSYSTEMS
MC145/02	1049Micro systems	1.03.1999	MICROSYSTEMS
MC145/05	1049Micro systems	1.04.1999	MICROSYSTEMS
MC145/11	1049Micro systems	1.05.1999	MICROSYSTEMS
MC145/13	1049Micro systems		MICROSYSTEMS
MC145/14	1049Micro systems	1.05.1999	MICROSYSTEMS
MC145C/37	1049Micro systems	1.05.1999	MICROSYSTEMS
MC148/21M	1049Micro systems	1.03.2000	MICROSYSTEMS
MC148/22	1049Micro systems	1.01.2000	MICROSYSTEMS
MC148/30	1049Micro systems	1.03.2001	MICROSYSTEMS
MC148/33	1049Micro systems		MICROSYSTEMS
MC148/37	1049Micro systems	1.03.2000	MICROSYSTEMS
MC150/21	1049Micro systems	1.08.1996	MICROSYSTEMS
MC150/21H	1049Micro systems	1.08.1996	MICROSYSTEMS
MC150/21M	1049Micro systems	1.08.1996	MICROSYSTEMS
MC150/22	1049Micro systems	1.08.1996	MICROSYSTEMS
MC150/25	1049Micro systems	1.09.1996	MICROSYSTEMS
MC150/26	1049Micro systems	1.08.1996	MICROSYSTEMS
MC150/33	1049Micro systems		MICROSYSTEMS
MC150/34	1049Micro systems	1.09.1996	MICROSYSTEMS
MC155/21	1049Micro systems	1.03.1998	MICROSYSTEMS
MC155/21M	1049Micro systems	1.02.1998	MICROSYSTEMS
MC155/22	1049Micro systems	1.09.1997	MICROSYSTEMS
MC155/25	1049Micro systems	1.11.1997	MICROSYSTEMS
MC156/21	1049Micro systems	1.11.1998	MICROSYSTEMS
MC156/21M	1049Micro systems	1.05.1998	MICROSYSTEMS
MC156/22	1049Micro systems	1.07.1998	MICROSYSTEMS
MC156/25	1049Micro systems	1.06.1998	MICROSYSTEMS
MC156/33	1049Micro systems		MICROSYSTEMS
MC156/34	1049Micro systems	1.07.1998	MICROSYSTEMS
MC165/02	1049Micro systems	1.04.1999	MICROSYSTEMS
MC165/10	1049Micro systems	1.09.1999	MICROSYSTEMS

MC165/11	1049Micro systems	1.07.1999	MICROSYSTEMS
MC165C/37	1049Micro systems	1.05.1999	MICROSYSTEMS
MC170/21	1049Micro systems	1.07.1996	MICROSYSTEMS
MC170/21M	1049Micro systems	1.05.1996	MICROSYSTEMS
MC170/22	1049Micro systems	1.08.1996	MICROSYSTEMS
MC170/33	1049Micro systems		MICROSYSTEMS
MC170/34	1049Micro systems	1.01.1997	MICROSYSTEMS
MC172/21	1049Micro systems	1.08.1997	MICROSYSTEMS
MC172/21M	1049Micro systems	1.10.1997	MICROSYSTEMS
MC172/22	1049Micro systems	1.10.1997	MICROSYSTEMS
MC172/30	1049Micro systems	1.11.1997	MICROSYSTEMS
MC172/41	1049Micro systems	1.01.1998	MICROSYSTEMS
MC172/41M	1049Micro systems	1.03.1998	MICROSYSTEMS
MC172/42	1049Micro systems	1.02.1998	MICROSYSTEMS
MC172/50	1049Micro systems	1.05.1998	MICROSYSTEMS
MC172/54	1049Micro systems	1.07.1998	MICROSYSTEMS
MC175/01	1049Micro systems	1.04.1999	MICROSYSTEMS
MC175/02	1049Micro systems	1.01.1999	MICROSYSTEMS
MC175/10	1049Micro systems	1.07.1999	MICROSYSTEMS
MC175/11	1049Micro systems	1.01.1999	MICROSYSTEMS
MC175/13	1049Micro systems		MICROSYSTEMS
MC175/14	1049Micro systems	1.05.1999	MICROSYSTEMS
MC175C/37	1049Micro systems	1.03.1999	MICROSYSTEMS
MCR220BK/17	Clock radio		CLOCKRADIO
MCS200SL/17	Single deck		RADIORECORDERS + CD
MD1420/76	700114i (13v) stereo	1.05.1993	TELEVISION
MD1420L/76	700114i (13v) stereo	1.07.1992	TELEVISION
MD1422/76	700114i (13v) stereo	1.10.1993	TELEVISION
MD2020/76	700120i (19v) mono	1.05.1993	TELEVISION
MD2020L/76	700120i (19v) mono	1.07.1992	TELEVISION
MD2022/76	700120i (19v) mono	1.10.1993	TELEVISION
MD2602L/76	700125i mono	1.07.1992	TELEVISION
MD2603/76	700120i (19v) mono	1.01.1994	TELEVISION
MEDIUM/TW	700120i (19v) mono	1.03.1992	TELEVISION
MG-C100/17	1041Clock radio	1.08.2001	CLOCKRADIO
MG-C105/17	1041Clock radio	1.08.2001	CLOCKRADIO
MG-C200/17	1041Clock radio	1.08.2001	CLOCKRADIO
MG-C205/17	1041Clock radio	1.09.2001	CLOCKRADIO
MG9218/17	1042CD personal		PERSONAL CD
MIDILFL/00	1049	1.03.1992	MIDISYSTEMS
MIDILFL/01	1049	1.03.1992	MIDISYSTEMS
MIDILFL/02	1049	1.10.1992	MIDISYSTEMS

MIDILFL/04	1049	1.03.1992	MIDISYSTEMS
MK4010L/76N	700114i (13v) stereo	1.03.1992	TELEVISION
MK4025L/76N	700114i (13v) stereo	1.03.1992	TELEVISION
MK4030L/76	700114i (13v) stereo	1.03.1992	TELEVISION
MK4035L/76	700114i (13v) stereo	1.03.1992	TELEVISION
MK4055L/76	700114i (13v) stereo	1.03.1992	TELEVISION
MK4260L/76	700120i (19v) mono	1.03.1992	TELEVISION
MK4270L/76	700120i (19v) mono	1.03.1992	TELEVISION
MK4353L/76	700125i stereo large 50Hz	1.04.1992	TELEVISION
MK4482L/76	700125i mono	1.03.1992	TELEVISION
MK4485L/84	700125i stereo large 50Hz	1.03.1992	TELEVISION
MK5541L/84	700125i stereo large 50Hz	1.10.1992	TELEVISION
ML2120/76	700120i (19v) mono	1.05.1993	TELEVISION
ML2121/76	700120i (19v) mono	1.05.1993	TELEVISION
ML2126/76	700120i (19v) mono	1.07.1993	TELEVISION
MM8560L/76	200648i rear-PTV 4:3	1.03.1992	PROJECTION TV
MM8560L/84	200648i rear-PTV 4:3	1.04.1992	PROJECTION TV
MM8560L/86	200648i rear-PTV 4:3	1.04.1992	PROJECTION TV
MM8560L/87	200648i rear-PTV 4:3	1.07.1992	PROJECTION TV
MM8560L/99	200648i rear-PTV 4:3	1.04.1992	PROJECTION TV
MMS130/17	1058	1.01.1999	SPEAKER BOXES
MMS230/17	1058	1.01.1999	SPEAKER BOXES
MMS250/17	1058		SPEAKER BOXES
MMS310/17	1058		SPEAKER BOXES
MMS320/17	1058		SPEAKER BOXES
MN5251/76	200648i rear-PTV 4:3	1.05.1993	PROJECTION TV
MN5251/84	200648i rear-PTV 4:3	1.05.1993	PROJECTION TV
MN5251/86	200648i rear-PTV 4:3	1.06.1993	PROJECTION TV
MN5251/87	200648i rear-PTV 4:3	1.05.1993	PROJECTION TV
MN5251/99	200648i rear-PTV 4:3	1.09.1993	PROJECTION TV
MN5251L/76	200648i rear-PTV 4:3	1.12.1992	PROJECTION TV
MN5251L/84	200648i rear-PTV 4:3	1.03.1993	PROJECTION TV
MN5251L/86	200648i rear-PTV 4:3	1.04.1993	PROJECTION TV
MN5251L/87	200648i rear-PTV 4:3	1.07.1993	PROJECTION TV
MOK151L/76	700125i stereo large 50Hz	1.04.1992	TELEVISION
MOK151L/84	700125i stereo large 50Hz	1.05.1992	TELEVISION
MOK291L/84	700125i stereo large 50Hz	1.04.1992	TELEVISION
MOK371L/84	700125i stereo large 50Hz	1.05.1992	TELEVISION
MONT100W/92	1003		TELEPHONES CORDLESS
MONT110A/92	1003		TELEPHONES CORDLESS
MONT110W/92	1003		TELEPHONES CORDLESS
MOS272L/76	700125i stereo large 50Hz	1.03.1992	TELEVISION

MP2980/76	700125i stereo large 50Hz	1.08.1993	TELEVISION
MP2980L/76	700125i stereo large 50Hz	1.03.1992	TELEVISION
MP2980L/99	700125i stereo large 50Hz	1.04.1992	TELEVISION
MP2982/76	700125i stereo large 50Hz	1.05.1993	TELEVISION
MP2982/84	700125i stereo large 50Hz	1.05.1993	TELEVISION
MP2982/87	700125i stereo large 50Hz	1.05.1993	TELEVISION
MP2982/99	700125i stereo large 50Hz	1.05.1993	TELEVISION
MP2982L/76	700125i stereo large 50Hz	1.10.1992	TELEVISION
MP2982L/84	700125i stereo large 50Hz	1.01.1993	TELEVISION
MP2982L/87	700125i stereo large 50Hz	1.02.1993	TELEVISION
MP2982L/99	700125i stereo large 50Hz	1.08.1992	TELEVISION
MP2985/76	700125i stereo large 50Hz	1.01.1994	TELEVISION
MP2985/84	700125i stereo large 50Hz	1.12.1993	TELEVISION
MP2985/99	700125i stereo large 50Hz	1.10.1993	TELEVISION
MP2986/87	700125i stereo large 50Hz	1.04.1994	TELEVISION
MR1423/76	700114i (13v) stereo	1.11.1993	TELEVISION
MR1430/76	700114i (13v) stereo	1.05.1993	TELEVISION
MR1430/84	700114i (13v) stereo	1.05.1993	TELEVISION
MR1430/99	700114i (13v) stereo	1.05.1993	TELEVISION
MR1430L/76	700114i (13v) stereo	1.03.1992	TELEVISION
MR1430L/84	700114i (13v) stereo	1.03.1992	TELEVISION
MR1430L/99	700114i (13v) stereo	1.03.1992	TELEVISION
MR1431/76	700114i (13v) stereo	1.08.1993	TELEVISION
MR1431/84	700114i (13v) stereo	1.09.1993	TELEVISION
MR1431/99	700114i (13v) stereo	1.07.1993	TELEVISION
MR1445/76	700114i (13v) stereo	1.05.1993	TELEVISION
MR1445/84	700114i (13v) stereo	1.05.1993	TELEVISION
MR1445L/76	700114i (13v) stereo	1.03.1992	TELEVISION
MR1445L/84	700114i (13v) stereo	1.04.1993	TELEVISION
MR1445L/99	700114i (13v) stereo	1.05.1992	TELEVISION
MR1446/76	700114i (13v) stereo	1.11.1993	TELEVISION
MR2003/76	700120i (19v) mono	1.05.1993	TELEVISION
MR2003/84	700120i (19v) mono	1.05.1993	TELEVISION
MR2003/99	700120i (19v) mono	1.05.1993	TELEVISION
MR2003L/76	700120i (19v) mono	1.03.1992	TELEVISION
MR2003L/84	700120i (19v) mono	1.03.1992	TELEVISION
MR2003L/99	700120i (19v) mono	1.03.1992	TELEVISION
MR2004/76	700120i (19v) mono	1.09.1993	TELEVISION
MR2004/99	700120i (19v) mono	1.08.1993	TELEVISION
MR2023/76	700120i (19v) mono	1.10.1993	TELEVISION
MR2045/76	700120i (19v) mono	1.05.1993	TELEVISION
MR2045/84	700120i (19v) mono	1.05.1993	TELEVISION

MR2045L/76	700120i (19v) mono	1.06.1992	TELEVISION
MR2045L/84	700120i (19v) mono	1.04.1993	TELEVISION
MR2045L/99	700120i (19v) mono	1.06.1992	TELEVISION
MR2047/76	700120i (19v) mono	1.10.1993	TELEVISION
MR2047/84	700120i (19v) mono	1.01.1994	TELEVISION
MR2047/87	700120i (19v) mono	1.12.1993	TELEVISION
MR2047/99	700120i (19v) mono	1.10.1993	TELEVISION
MR2121/99	700120i (19v) mono	1.10.1993	TELEVISION
MR2125/76	700120i (19v) mono	1.06.1993	TELEVISION
MR2125/84	700120i (19v) mono	1.05.1993	TELEVISION
MR2125/99	700120i (19v) mono	1.06.1993	TELEVISION
MR2125L/76	700120i (19v) mono	1.07.1993	TELEVISION
MR2125L/84	700120i (19v) mono	1.04.1993	TELEVISION
MR2125L/99	700120i (19v) mono	1.04.1992	TELEVISION
MR2641/76	700125i stereo large 50Hz	1.10.1993	TELEVISION
MR2641/84	700125i stereo large 50Hz	1.10.1993	TELEVISION
MR2641/99	700125i stereo large 50Hz	1.09.1993	TELEVISION
MS1460/76	700114i (13v) stereo	1.05.1993	TELEVISION
MS1460/84	700114i (13v) stereo	1.05.1993	TELEVISION
MS1460/86	700114i (13v) stereo	1.08.1993	TELEVISION
MS1460/87	700114i (13v) stereo	1.10.1993	TELEVISION
MS1460L/76	700114i (13v) stereo	1.03.1992	TELEVISION
MS1460L/84	700114i (13v) stereo	1.04.1992	TELEVISION
MS1460L/86	700114i (13v) stereo	1.03.1992	TELEVISION
MS1460L/87	700114i (13v) stereo	1.03.1992	TELEVISION
MS1460L/99	700114i (13v) stereo	1.03.1992	TELEVISION
MS1461/86	700114i (13v) stereo	1.05.1993	TELEVISION
MS1461/87	700114i (13v) stereo	1.05.1993	TELEVISION
MS1461L/86	700114i (13v) stereo	1.12.1992	TELEVISION
MS1461L/87	700114i (13v) stereo	1.10.1992	TELEVISION
MS1462/76	700114i (13v) stereo	1.09.1993	TELEVISION
MS1462/86	700114i (13v) stereo	1.11.1993	TELEVISION
MS1462/99	700114i (13v) stereo	1.01.1994	TELEVISION
MS2007/76	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2007/84	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2007/87	700125i stereo large 50Hz	1.09.1993	TELEVISION
MS2007L/76	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2007L/84	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2007L/86	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2007L/87	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2007L/99	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2008/86	700125i stereo large 50Hz	1.05.1993	TELEVISION

MS2008/87	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2008L/86	700125i stereo large 50Hz	1.12.1992	TELEVISION
MS2008L/87	700125i stereo large 50Hz	1.09.1992	TELEVISION
MS2010/76	700125i stereo large 50Hz	1.11.1993	TELEVISION
MS2010/84	700125i stereo large 50Hz	1.12.1993	TELEVISION
MS2010/86	700125i stereo large 50Hz	1.10.1993	TELEVISION
MS2010/99	700125i stereo large 50Hz	1.01.1994	TELEVISION
MS2126/76	700125i stereo large 50Hz	1.03.1994	TELEVISION
MS2670/76	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2670/99	700125i stereo large 50Hz	1.08.1993	TELEVISION
MS2670L/76	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2670L/84	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2670L/87	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2670L/99	700125i stereo large 50Hz	1.03.1992	TELEVISION
MS2671/76	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2671L/76	700125i stereo large 50Hz	1.10.1992	TELEVISION
MS2672/84	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2672/87	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2672/99	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2672L/84	700125i stereo large 50Hz	1.10.1992	TELEVISION
MS2672L/87	700125i stereo large 50Hz	1.10.1992	TELEVISION
MS2672L/99	700125i stereo large 50Hz	1.08.1992	TELEVISION
MS2673/86	700125i stereo large 50Hz	1.06.1993	TELEVISION
MS2675/76	700125i stereo large 50Hz	1.11.1993	TELEVISION
MS2675/99	700125i stereo large 50Hz	1.04.1994	TELEVISION
MS2676/84	700125i stereo large 50Hz	1.10.1993	TELEVISION
MS2676/86	700125i stereo large 50Hz	1.10.1993	TELEVISION
MS2946/76	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2946/84	700125i stereo large 50Hz	1.12.1993	TELEVISION
MS2946L/76	700125i stereo large 50Hz	1.10.1992	TELEVISION
MS2946L/84	700125i stereo large 50Hz	1.12.1992	TELEVISION
MS2947/84	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2947/86	700125i stereo large 50Hz	1.06.1993	TELEVISION
MS2947/87	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2947/99	700125i stereo large 50Hz	1.05.1993	TELEVISION
MS2947L/84	700125i stereo large 50Hz	1.11.1992	TELEVISION
MS2947L/86	700125i stereo large 50Hz	1.07.1993	TELEVISION
MS2947L/87	700125i stereo large 50Hz	1.09.1992	TELEVISION
MS2947L/99	700125i stereo large 50Hz	1.08.1992	TELEVISION
MS2951/76	700125i stereo large 50Hz	1.12.1993	TELEVISION
MS2951/84	700125i stereo large 50Hz	1.12.1993	TELEVISION
MS2951/99	700125i stereo large 50Hz	1.10.1993	TELEVISION

MS2952/86	700125i stereo large 50Hz		1.11.1993	TELEVISION
MS2952/87	700125i stereo large 50Hz		1.04.1994	TELEVISION
MS2965/76	700125i stereo large 50Hz		1.08.1993	TELEVISION
MS2965/84	700125i stereo large 50Hz		1.06.1993	TELEVISION
MS2965L/76	700125i stereo large 50Hz		1.03.1992	TELEVISION
MS2965L/84	700125i stereo large 50Hz		1.03.1992	TELEVISION
MS2966/76	700125i stereo large 50Hz		1.08.1993	TELEVISION
MS2966/84	700125i stereo large 50Hz		1.12.1993	TELEVISION
MS2966/86	700125i stereo large 50Hz		1.09.1993	TELEVISION
MS2966L/76	700125i stereo large 50Hz		1.03.1992	TELEVISION
MS2966L/84	700125i stereo large 50Hz		1.06.1992	TELEVISION
MS2966L/86	700125i stereo large 50Hz		1.04.1992	TELEVISION
MS2966L/99	700125i stereo large 50Hz		1.03.1992	TELEVISION
MT2801/76	700125i stereo large 50Hz		1.05.1993	TELEVISION
MT2801L/76	700125i stereo large 50Hz		1.03.1992	TELEVISION
MUSICTIME/00	1041Radio + Cassette		1.06.1997	PERSONAL STEREO
MUSICTIME/01	1041Radio + Cassette		1.06.1997	PERSONAL STEREO
MUSICTIME/14	1041Radio + Cassette		1.04.1997	PERSONAL STEREO
MV1953	1021Leader	OLIVIA_ECN	1.11.1996Economy	VCR
MV1971	1021Leader show view	QUEEN_VL	1.08.1997Volume Line	VCR
MV232	1021Leader		1.12.1996	VCR
MV2951	1021Leader	VCR_INKOOOP	1.12.1995	VCR
MV404SV	1021Leader show view		1.12.1996	VCR
MV4951	1021Leader show view	OLIVIA_ECN	1.12.1995Economy	VCR
MV4971	1021Leader show view		1.08.1998	VCR
MV510U/99	1021Leader			VCR
MV530/99	1021Leader			VCR
MV6001SV	1021Leader			VCR
MV830/99	1021Leader			VCR
MV880/99	1021Leader			VCR
MX1015D/37	1049Receivers		1.08.2001	RECEIVERS
MX1050D/22	1049Receivers		1.09.2001	RECEIVERS
MX1055D/37S	1049Receivers		1.09.2001	RECEIVERS
MX1060D/21M	1049Receivers			RECEIVERS
MX1060D/22S	1049Receivers		1.09.2001	RECEIVERS
MX1300L/84	700114i (13v) stereo		1.03.1992	TELEVISION
MX1500D/22	Receivers			RECEIVERS
MX1700D/19S	Receivers			RECEIVERS
MX1700D/21R	Receivers			RECEIVERS
MX1700D/22S	Receivers			RECEIVERS
MX3600D/37	Receivers			RECEIVERS
MX3800D/22S	Receivers			RECEIVERS

MX5000D/21R	Receivers		RECEIVERS
MX5000D/22S	Receivers		RECEIVERS
MX5000D/37S	Receivers		RECEIVERS
MX731/22	1049Receivers	1.07.1996	RECEIVERS
MX731/30	1049Receivers	1.08.1996	RECEIVERS
MX732/21	1049Receivers	1.02.1997	RECEIVERS
MX732/22	1049Receivers	1.01.1997	RECEIVERS
MX732/30	1049Receivers	1.11.1997	RECEIVERS
MX735/21	1049Receivers	1.09.1999	RECEIVERS
MX735/22	1049Receivers	1.06.1999	RECEIVERS
MX735/37	1049Receivers		RECEIVERS
MX740/22	1049Receivers	1.05.2000	RECEIVERS
MX751PRO/17	1049Receivers	1.09.1996	RECEIVERS
MX765/37	1049Receivers		RECEIVERS
MX775W/37	1049Receivers		RECEIVERS
MX8000D/21R	Receivers		RECEIVERS
MX8000D/22S	Receivers		RECEIVERS
MX8000D/33S	Receivers		RECEIVERS
MX8000D/37S	Receivers		RECEIVERS
MX890AHT/37	1049Receivers	1.08.1996	RECEIVERS
MX891/37	1049Receivers	1.02.1996	RECEIVERS
MX893AHT/37	1049Receivers	1.03.1996	RECEIVERS
MX900/21	1049Receivers	1.07.1997	RECEIVERS
MX900/22	1049Receivers	1.04.1997	RECEIVERS
MX900/30	1049Receivers	1.07.1997	RECEIVERS
MX900/37	1049Receivers	1.12.1997	RECEIVERS
MX9000SA/22S	Receivers		RECEIVERS
MX9000SA/37S	Receivers		RECEIVERS
MX920AHT/37	1049Receivers	1.06.1997	RECEIVERS
MX931/PRO	1049Receivers	1.11.1994	RECEIVERS
MX931SSS/17	1049Receivers	1.11.1994	RECEIVERS
MX940AHT/37	1049Receivers	1.06.1997	RECEIVERS
MX951/37	1049Receivers	1.10.1995	RECEIVERS
MX951SSS/17	1049Receivers	1.11.1995	RECEIVERS
MX951TVL/17	1049Receivers	1.11.1995	RECEIVERS
MX955/37	1049Receivers	1.08.2001	RECEIVERS
MX956/22S	1049Receivers	1.06.2001	RECEIVERS
MX960D/37	1049Receivers	1.04.2000	RECEIVERS
MX960PRO/17	1049Receivers	1.02.1997	RECEIVERS
MX963AHT/37	1049Receivers	1.09.1996	RECEIVERS
MX964AHT/37	1049Receivers	1.11.1996	RECEIVERS
MX965/37	1049Receivers	1.08.2001	RECEIVERS

MX966/37S	1049Receivers	1.08.2001	RECEIVERS
MX970/37	Receivers		RECEIVERS
MX975D/21	1049Receivers	1.09.1999	RECEIVERS
MX975D/37	1049Receivers	1.07.1999	RECEIVERS
MX976/22S	1049Receivers	1.07.2001	RECEIVERS
MX980/22S	Receivers		RECEIVERS
MX980D/37	1049Receivers		RECEIVERS
MX985D/37	Receivers		RECEIVERS
MX990D/37	1049Receivers	1.08.2001	RECEIVERS
MX995D/37	1049Receivers	1.09.2001	RECEIVERS
MX999/22S	Receivers		RECEIVERS
MX999/37	Receivers		RECEIVERS
MZ-3/21	1049Micro systems	1.05.2000	MICROSYSTEMS
MZ-3/21M	1049Micro systems	1.04.2000	MICROSYSTEMS
MZ-3/22	1049Micro systems	1.05.2000	MICROSYSTEMS
MZ-3/30	1049Micro systems	1.06.2000	MICROSYSTEMS
MZ-3/33	1049Micro systems		MICROSYSTEMS
MZ-3/37	1049Micro systems	1.04.2000	MICROSYSTEMS
MZ-33/21M	1049Micro systems	1.06.2000	MICROSYSTEMS
MZ-33/22	1049Micro systems	1.08.2000	MICROSYSTEMS
MZ-33/30	1049Micro systems	1.08.2000	MICROSYSTEMS
MZ-33/33	Micro systems		MICROSYSTEMS
MZ-33/37	1049Micro systems	1.08.2001	MICROSYSTEMS
MZ-5/21	Micro systems		MICROSYSTEMS
MZ-5/22	Micro systems		MICROSYSTEMS
MZ-5/30	Micro systems		MICROSYSTEMS
MZ-5/33	Micro systems		MICROSYSTEMS
MZ-5/37	Micro systems		MICROSYSTEMS
MZ-9/22	Mini systems		MINISYSTEMS
MZ7/21	1049Mini systems	1.02.2000	MINISYSTEMS
MZ7/22	1049Mini systems	1.09.1999	MINISYSTEMS
MZ7/34	1049Mini systems	1.09.1999	MINISYSTEMS
MZ7/37	1049Mini systems	1.08.1999	MINISYSTEMS
NM8560/76	200648i rear-PTV 4:3	1.08.1993	PROJECTION TV
NM8560/84	200648i rear-PTV 4:3	1.06.1993	PROJECTION TV
NM8560/86	200648i rear-PTV 4:3	1.09.1993	PROJECTION TV
OSLO13B/92	1004		TELEPHONES CORDED
OSLO13W/92	1004		TELEPHONES CORDED
OSLOW/92	1004		TELEPHONES CORDED
PALMAB/91	1004		TELEPHONES CORDED
PALMAI/91	1004		TELEPHONES CORDED
PALMAMB/91	1004		TELEPHONES CORDED

PALMAMI/91	1004		TELEPHONES CORDED
PASS/1.6	2012	Institutional analogue	SATELLITE
PD1700	1021	Leader	1.11.1994 VCR
PD1750	1021	Leader	1.07.1995 VCR
PD1760	1021	Leader	1.06.1996 VCR
PEGASO/08	1006	Magic Philips	FAXES
PFAPTT/IT	1006	Magic Philips	FAXES
PFC25/02	1006	Philips thermal fax	BARBARA FAXES
PFC25/03	1006	Philips thermal fax	BARBARA FAXES
PFC25/10	1006	Philips thermal fax	BARBARA FAXES
PFC25/17	1006	Philips thermal fax	BARBARA FAXES
PFC25/19	1006	Philips thermal fax	BARBARA FAXES
PFC35/03	1006	Philips thermal fax	BARBARA FAXES
PFC35/09	1006	Philips thermal fax	BARBARA FAXES
PFC35/10	1006	Philips thermal fax	BARBARA FAXES
PFC35/13	1006	Philips thermal fax	BARBARA FAXES
PFC35/14	1006	Philips thermal fax	BARBARA FAXES
PFC35/17	1006	Philips thermal fax	BARBARA FAXES
PFC35/19	1006	Philips thermal fax	BARBARA FAXES
PFC35/20	1006	Philips thermal fax	BARBARA FAXES
PFC45/02	1006	Philips thermal fax	BARBARA FAXES
PFC45/03	1006	Philips thermal fax	BARBARA FAXES
PFC45/04	1006	Philips thermal fax	BARBARA FAXES
PFC45/06	1006	Philips thermal fax	BARBARA FAXES
PFC45/09	1006	Philips thermal fax	BARBARA FAXES
PFC45/10	1006	Philips thermal fax	BARBARA FAXES
PFC45/14	1006	Philips thermal fax	BARBARA FAXES
PFC45/17	1006	Philips thermal fax	BARBARA FAXES
PFC45/19	1006	Philips thermal fax	BARBARA FAXES
PFC50/03	1006	Philips thermal fax	C1 FAXES
PFC50/03C	1006	Philips thermal fax	C1 FAXES
PFC50/06	1006	Philips thermal fax	C1 FAXES
PFC50/06C	1006	Philips thermal fax	FAXES
PFC50/08	1006	Philips thermal fax	FAXES
PFC50/08C	1006	Philips thermal fax	C1 FAXES
PFC50/09	1006	Philips thermal fax	C1 FAXES
PFC50/09C	1006	Philips thermal fax	FAXES
PFC50/10	1006	Philips thermal fax	C1 FAXES
PFC50/10C	1006	Philips thermal fax	C1 FAXES
PFC50/17C	1006	OEM thermal fax	C1 FAXES
PFC50/19C	1006	Philips thermal fax	C1 FAXES
PFC50/36C	1006	Philips thermal fax	C1 FAXES

PFC50/37C	1006Philips thermal fax	C1		FAXES
PFC50/79C	1006Philips thermal fax	C1		FAXES
PFC55/02	1006Philips thermal fax	C1		FAXES
PFC55/02C	1006Philips thermal fax	C1		FAXES
PFC55/03	1006Philips thermal fax	C1		FAXES
PFC55/03C	1006Philips thermal fax	C1		FAXES
PFC55/06	1006Philips thermal fax	C1		FAXES
PFC55/06C	1006Philips thermal fax	C1		FAXES
PFC55/08	1006Philips thermal fax	C1		FAXES
PFC55/08C	1006Philips thermal fax	C1		FAXES
PFC55/09	1006Philips thermal fax	C1		FAXES
PFC55/09C	1006Philips thermal fax			FAXES
PFC55/10	1006Philips thermal fax	C1		FAXES
PFC55/10C	1006Philips thermal fax	C1		FAXES
PFC55/13	1006Philips thermal fax	C1		FAXES
PFC55/13C	1006Philips thermal fax	C1		FAXES
PFC55/17C	1006Philips thermal fax	C1		FAXES
PFC55/19C	1006Philips thermal fax			FAXES
PFC55/36C	1006Philips thermal fax	C1		FAXES
PFC55/37C	1006Philips thermal fax	C1		FAXES
PFC55/79C	1006Philips thermal fax	C1		FAXES
PH931SSS/00	1049Tuners		1.09.1995	TUNERS
PH951SSS/17	1049Tuners		1.06.1995	TUNERS
PL3125/76	700120i (19v) mono		1.03.1994	TELEVISION
PMK172/76	700120i (19v) mono		1.04.1992	TELEVISION
PML192/76	700120i (19v) mono		1.04.1992	TELEVISION
PMX162/76	700120i (19v) mono		1.05.1992	TELEVISION
PPF211/02B	1006Magic Philips			FAXES
PPF211/05B	1006Magic Philips			FAXES
PPF211/08B	1006Philips thermal fax			FAXES
PPF211/09B	1006Magic Philips			FAXES
PPF211/16B	1006Magic Philips			FAXES
PPF211/19B	1006Magic Philips			FAXES
PPF241/00	1006Philips thermal fax			FAXES
PPF241/00B	1006Magic Philips	GALLILEO		FAXES
PPF241/02B	1006Magic Philips	GALLILEO		FAXES
PPF241/03B	1006Magic Philips	GALLILEO		FAXES
PPF241/04B	1006Magic Philips	GALLILEO		FAXES
PPF241/05B	1006Magic Philips	GALLILEO		FAXES
PPF241/06B	1006Magic Philips	GALLILEO		FAXES
PPF241/07B	1006Magic Philips	GALLILEO		FAXES
PPF241/08B	1006Magic Philips	GALLILEO		FAXES

PPF241/09B	1006Magic Philips	GALLILEO	FAXES
PPF241/10B	1006Magic Philips	GALLILEO	FAXES
PPF241/13B	1006Magic Philips	GALLILEO	FAXES
PPF241/14B	1006Magic Philips	GALLILEO	FAXES
PPF241/15B	1006Magic Philips	GALLILEO	FAXES
PPF241/16B	1006Magic Philips	GALLILEO	FAXES
PPF241/17B	1006Magic Philips	GALLILEO	FAXES
PPF241/19B	1006Magic Philips	GALLILEO	FAXES
PPF241/20B	1006Magic Philips	GALLILEO	FAXES
PPF242/02B	1006Magic Philips		FAXES
PPF251/02B	1006Magic Philips		FAXES
PPF251/05B	1006Magic Philips		FAXES
PPF251/08B	1006Magic Philips		FAXES
PPF251/09B	1006Magic Philips		FAXES
PPF251/16B	1006Magic Philips		FAXES
PPF251/19B	1006Magic Philips		FAXES
PPF271/00	1006Magic Philips		FAXES
PPF271/00B	1006Philips thermal fax	GALLILEO	FAXES
PPF271/02B	1006Magic Philips	GALLILEO	FAXES
PPF271/03B	1006Magic Philips	GALLILEO	FAXES
PPF271/04B	1006Magic Philips	GALLILEO	FAXES
PPF271/05B	1006Magic Philips	GALLILEO	FAXES
PPF271/06B	1006Magic Philips	GALLILEO	FAXES
PPF271/07B	1006Magic Philips	GALLILEO	FAXES
PPF271/08B	1006Magic Philips	GALLILEO	FAXES
PPF271/09B	1006Magic Philips	GALLILEO	FAXES
PPF271/10B	1006Magic Philips	GALLILEO	FAXES
PPF271/13B	1006Magic Philips	GALLILEO	FAXES
PPF271/14B	1006Magic Philips	GALLILEO	FAXES
PPF271/15B	1006Magic Philips	GALLILEO	FAXES
PPF271/16B	1006Magic Philips	GALLILEO	FAXES
PPF271/17B	1006Magic Philips	GALLILEO	FAXES
PPF271/19B	1006Magic Philips	GALLILEO	FAXES
PPF271/20B	1006Magic Philips	GALLILEO	FAXES
PPF272/02B	1006Magic Philips		FAXES
PPF276/02B	1006Magic Philips		FAXES
PPF281/02B	1006Magic Philips		FAXES
PPF281/08B	1006Magic Philips		FAXES
PPF281/19B	1006Magic Philips		FAXES
PPF30/05	1006Magic Philips		FAXES
PPF30/08	1006Magic Philips		FAXES
PPF30/09	1006Magic Philips		FAXES

PPF30/13	1006Magic Philips	FAXES
PPF311/02	1006Magic Philips	FAXES
PPF311/03	1006Magic Philips	FAXES
PPF311/04	1006Magic Philips	FAXES
PPF311/05	1006Magic Philips	FAXES
PPF311/06	1006Magic Philips	FAXES
PPF311/08	1006Magic Philips	FAXES
PPF311/09	1006Magic Philips	FAXES
PPF311/10	1006Magic Philips	FAXES
PPF311/13	1006Magic Philips	FAXES
PPF311/14	1006Magic Philips	FAXES
PPF311/16	1006Magic Philips	FAXES
PPF311/17	1006Magic Philips	FAXES
PPF311/19	1006Magic Philips	FAXES
PPF311/20	1006Magic Philips	FAXES
PPF312/02	1006Magic Philips	FAXES
PPF312/03	1006Magic Philips	FAXES
PPF312/04	1006Magic Philips	FAXES
PPF312/05	1006Magic Philips	FAXES
PPF312/06	1006Magic Philips	FAXES
PPF312/08	1006Magic Philips	FAXES
PPF312/09	1006Magic Philips	FAXES
PPF312/10	1006Magic Philips	FAXES
PPF312/13	1006Magic Philips	FAXES
PPF312/14	1006Magic Philips	FAXES
PPF312/16	1006Magic Philips	FAXES
PPF312/17	1006Magic Philips	FAXES
PPF312/19	1006Magic Philips	FAXES
PPF312/20	1006Magic Philips	FAXES
PPF35/05	1006Magic OEM	FAXES
PPF35/08	1006Magic Philips	FAXES
PPF35/09	1006Magic Philips	FAXES
PPF35/13	1006Magic Philips	FAXES
PPF441/02B	1006Magic Philips	FAXES
PPF441/03B	Magic Philips	FAXES
PPF441/05B	Magic Philips	FAXES
PPF441/06B	Magic Philips	FAXES
PPF441/08B	Magic Philips	FAXES
PPF441/09B	Magic Philips	FAXES
PPF441/10B	Magic Philips	FAXES
PPF441/13B	Magic Philips	FAXES
PPF441/16B	Magic Philips	FAXES

PPF441/19B	Magic Philips		FAXES
PPF456/02B	1006Magic Philips		FAXES
PPF456/03B	1006Magic Philips		FAXES
PPF456/05B	1006Magic Philips		FAXES
PPF456/06B	1006Magic Philips		FAXES
PPF456/08B	1006Magic Philips		FAXES
PPF456/09B	1006Magic Philips		FAXES
PPF456/10B	1006Magic Philips		FAXES
PPF456/13B	1006Magic Philips		FAXES
PPF456/15B	Magic Philips		FAXES
PPF456/16B	1006Magic Philips		FAXES
PPF456/17B	Magic Philips		FAXES
PPF456/19B	1006Magic Philips		FAXES
PPF476/02B	1006Magic Philips		FAXES
PPF476/03B	1006Magic Philips		FAXES
PPF476/05B	1006Magic Philips		FAXES
PPF476/06B	1006Magic Philips		FAXES
PPF476/08B	1006Magic Philips		FAXES
PPF476/09B	1006Magic Philips		FAXES
PPF476/10B	1006Magic Philips		FAXES
PPF476/13B	1006Magic Philips		FAXES
PPF476/15B	Magic Philips		FAXES
PPF476/16B	1006Magic Philips		FAXES
PPF476/17B	Magic Philips		FAXES
PPF476/19B	1006Magic Philips		FAXES
PPF486/02B	1006Magic Philips		FAXES
PPF486/05B	Magic Philips		FAXES
PPF486/08B	Magic Philips		FAXES
PPF486/19B	Magic Philips		FAXES
PTT-BLACK/08	1006Philips thermal fax		FAXES
PTT-BLACK/08A	1006Philips thermal fax		FAXES
PTT-TAM/08	1006Philips thermal fax		FAXES
PTT-TAM/08A	1006Philips thermal fax		FAXES
PTT-WHITE/08	1006Philips thermal fax		FAXES
PTT-WHITE/08A	1006Philips thermal fax		FAXES
PVR200/54	1021Leader	1.03.1992	VCR
PVR200/54Z	1021Leader	1.02.1994	VCR
PVR570/54	1021Leader	1.03.1992	VCR
PVR570/54Z	1021Leader	1.01.1994	VCR
PVR830/76			CAMCORDERS
PVR830/77			CAMCORDERS
PVR850/76			CAMCORDERS

PVT6050/99	2012PAL/SECAM terminal	1.02.1993	SATELLITE
RC8510/DLD	Remote Controls Non-Chargeable		REMOTE CONTROLS NON-CHARGEABLE
RC8530/00	Remote Controls Non-Chargeable		REMOTE CONTROLS NON-CHARGEABLE
RT24A5T/.,	2010		OBSERVATION SYSTEMS
RTV250EC	1021Leader	1.11.1994	VCR
RTV256EG	1021Leader	1.11.1994	VCR
RTV256EGC	1021Leader	1.12.1994	VCR
RTV256EP	1021Leader	1.11.1994	VCR
RTV256EPC	1021Leader	1.02.1995	VCR
RTV265EI	1021Leader	1.09.1995	VCR
RTV265EPC/11	1021Leader	1.07.1995	VCR
RTV365EPC	1021Leader	1.07.1995	VCR
RTV365EPC/11	1021Leader	1.11.1995	VCR
RTV450OIR/T	1021Leader show view	1.02.1995	VCR
RTV465EPC	1021Leader show view	1.07.1995	VCR
RTV465EPC/11	1021Leader show view	1.11.1995	VCR
RTV675EPC	1021Leader show view	1.07.1995	VCR
RTV716EGC	1021Leader	1.12.1994	VCR
RTV716EN	1021Leader	1.01.1995	VCR
RTV725EN	1021Leader	1.11.1995	VCR
RTV725EPC	1021Leader	1.09.1995	VCR
RTV725PSW	1021Leader	1.01.1996	VCR
RTV785HIF/IEN	1021Leader	1.10.1995	VCR
RTV785HIF/IEP	1021Leader	1.10.1995	VCR
SA100/11	1046Solid State	1.06.2000	SOLID STATE (Rush)
SA101/00	1046Solid State		SOLID STATE (Rush)
SA101/01	1046Solid State	1.07.2000	SOLID STATE (Rush)
SA101/11	1046Solid State		SOLID STATE (Rush)
SA101/17	1046Solid State	1.08.2001	SOLID STATE (Rush)
SA103/17	1046Solid State		SOLID STATE (Rush)
SA105/00	1046Solid State		SOLID STATE (Rush)
SA105/11	1046Solid State		SOLID STATE (Rush)
SA107/17	1046Solid State	1.08.2001	SOLID STATE (Rush)
SA125/00	1046Solid State	1.09.2000	SOLID STATE (Rush)
SA125/01	1046Solid State		SOLID STATE (Rush)
SA125/19	1046Solid State		SOLID STATE (Rush)
SA126/05	1046Solid State	1.09.2000	SOLID STATE (Rush)
SA126/05S	1046Solid State		SOLID STATE (Rush)
SA126/11	1046Solid State	1.10.2000	SOLID STATE (Rush)
SA205/00	Solid State		SOLID STATE (Rush)
SA205/01	Solid State		SOLID STATE (Rush)
SA205/11	Solid State		SOLID STATE (Rush)

SA205/17	Solid State			SOLID STATE (Rush)
SA209/00	Solid State			SOLID STATE (Rush)
SACD1000/001	2015SACD		1.02.2001	SUPER AUDIO CD
SACD1000/171	SACD			SUPER AUDIO CD
SACD1000/691	2015SACD		1.03.2001	SUPER AUDIO CD
SACD1000/931	SACD			SUPER AUDIO CD
SACD962/001	SACD			SUPER AUDIO CD
SACD962/691	SACD			SUPER AUDIO CD
SB10/03	1021Leader	PAULIN_ECN	1.09.1996Economy	VCR
SB10/08	1021Leader	PAULIN_ECN	1.10.1996Economy	VCR
SB10/11	1021Leader	PAULIN_ECN	1.09.1996Economy	VCR
SB10/16	1021Leader	PAULIN_ECN	1.06.1996Economy	VCR
SB10/38	1021Leader	PAULIN_ECN	1.06.1996Economy	VCR
SB100/03	1021Leader	QUEEN_VL	1.06.1997Volume Line	VCR
SB100/08	1021Leader	QUEEN_VL	1.09.1997Volume Line	VCR
SB100/11	1021Leader	QUEEN_VL	1.05.1997Volume Line	VCR
SB100/16	1021Leader	QUEEN_VL	1.07.1997Volume Line	VCR
SB100/38	1021Leader	QUEEN_VL	1.06.1997Volume Line	VCR
SB105/03	1021Leader show view	QUEEN_VL	1.07.1997Volume Line	VCR
SB105/07	1021Leader show view	QUEEN_VL	1.10.1997Volume Line	VCR
SB105/11	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
SB105/38	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
SB1080/19G	2012PAL/SECAM terminal		1.01.1997	SATELLITE
SB1090/19G	2012PAL/SECAM terminal		1.06.1998	SATELLITE
SB110/03	1021Leader	APOLLO10	1.06.1998	VCR
SB115/03	1021Leader show view	APOLLO10	1.06.1998	VCR
SB1191/05G	2012PAL/SECAM terminal		1.08.1996	SATELLITE
SB120/03	1021Leader	APOLLO11	1.06.1999	VCR
SB120/16	1021Leader			VCR
SB120/38	1021Leader	APOLLO11	1.08.1999	VCR
SB125/03	1021Leader show view	APOLLO11	1.06.1999	VCR
SB125/11	1021Leader show view	APOLLO11	1.06.1999	VCR
SB125/16	1021Leader show view	APOLLO11	1.06.1999	VCR
SB125/38	1021Leader show view	APOLLO11	1.08.1999	VCR
SB1290/19G	2012PAL/SECAM terminal		1.07.1996	SATELLITE
SB130/03	1021Leader	APOLLO12	1.04.2000	VCR
SB130/38	1021Leader	APOLLO12	1.05.2000	VCR
SB135/03	1021Leader show view	APOLLO12	1.04.2000	VCR
SB135/07	1021Leader show view	APOLLO12	1.08.2000	VCR
SB135/11	1021Leader show view	APOLLO12	1.05.2000	VCR
SB135/16	1021Leader show view	APOLLO12	1.06.2000	VCR
SB135/38	1021Leader show view	APOLLO12	1.06.2000	VCR

SB140/03	1021Subleader	APOLLO13	1.06.2001	VCR
SB140/38	Subleader	APOLLO13		VCR
SB145/03	1021Leader show view	APOLLO13	1.05.2001	VCR
SB145/11	1021Leader show view	APOLLO13	1.06.2001	VCR
SB15/03	1021Leader	PAULIN_ECN	1.07.1996Economy	VCR
SB15/11	1021Leader	PAULIN_ECN	1.09.1996Economy	VCR
SB20/16	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
SB205/02	1021Leader show view	QUEEN_VL	1.08.1997Volume Line	VCR
SB205/02N	1021Step-up show view	QUEEN_VL	1.02.1998Volume Line	VCR
SB215/02	1021Leader show view	APOLLO10	1.07.1998	VCR
SB215/02B	1021Leader show view	APOLLO10	1.11.1998	VCR
SB215/02D	1021Leader	APOLLO10	1.08.1998	VCR
SB215/02G	1021Leader show view	APOLLO10	1.10.1998	VCR
SB215/02S	1021Leader show view	APOLLO10	1.10.1998	VCR
SB230/02	1021Leader show view	APOLLO11	1.09.1999	VCR
SB230DE	1021Leader show view	APOLLO11	1.06.1999	VCR
SB230ES	1021Leader show view		1.06.1999	VCR
SB230GR	1021Leader show view		1.09.1999	VCR
SB230XE	1021Leader show view		1.08.1999	VCR
SB25/02	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
SB25/03	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
SB25/11	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
SB25/38	1021Leader	PAULIN_STN	1.06.1996Standard	VCR
SB30/08	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
SB30/16	1021Leader show view	PAULIN_STN	1.09.1996Standard	VCR
SB35/11	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
SB35/38	1021Leader	PAULIN_STN	1.06.1996Standard	VCR
SB40/08	1021Leader show view	PAULIN_ECN	1.10.1996Economy	VCR
SB40/16	1021Leader show view	PAULIN_ECN	1.08.1996Economy	VCR
SB40/38	1021Leader show view	PAULIN_ECN	1.06.1996Economy	VCR
SB405/08	1021Leader show view	QUEEN_VL	1.09.1997Volume Line	VCR
SB405/11	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
SB405/16	1021Leader show view	QUEEN_VL	1.07.1997Volume Line	VCR
SB405/38	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
SB425/11	1021Leader show view	APOLLO11	1.06.1999	VCR
SB425/16	1021Leader show view			VCR
SB425/38	1021Leader show view	APOLLO11	1.07.1999	VCR
SB435/11	1021Leader show view	APOLLO12	1.06.2000	VCR
SB435/38	1021Leader show view	APOLLO12	1.06.2000	VCR
SB445/11	1021Leader show view	APOLLO13	1.06.2001	VCR
SB445/38	Leader show view	APOLLO13		VCR
SB50/16	1021Leader show view	PAULIN_STN	1.07.1996Standard	VCR

SB505/38	1021Step-up show view	QUEEN_VL	1.06.1997Volume Line	VCR
SB525/38	1021Step-up show view	APOLLO11	1.09.1999	VCR
SB535/38	1021Step-up show view	APOLLO12	1.07.2000	VCR
SB55/11	1021Leader show view	PAULIN_STN	1.09.1996Standard	VCR
SB55/38	1021Leader show view	PAULIN_STN	1.07.1996Standard	VCR
SB605/02	1021Leader	QUEEN_VLH	1.09.1997Volume Line Hifi	VCR
SB605/03	1021Leader	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
SB605/07	1021Leader	QUEEN_VLH	1.10.1997Volume Line Hifi	VCR
SB605/11	1021Leader	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
SB605/16	1021Leader	QUEEN_VLH	1.09.1997Volume Line Hifi	VCR
SB605/38	1021Leader	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
SB615/02	1021Leader	APOLLO10	1.08.1998	VCR
SB615/02B	1021Leader	APOLLO10	1.11.1998	VCR
SB615/02D	1021Leader	APOLLO10	1.08.1998	VCR
SB615/03	1021Leader	APOLLO10	1.06.1998	VCR
SB615/11	1021Leader	APOLLO10	1.06.1998	VCR
SB615/13	1021Leader	APOLLO10	1.11.1998	VCR
SB615/13B	1021Leader	APOLLO10	1.12.1998	VCR
SB615/13G	1021Leader	APOLLO10	1.10.1998	VCR
SB625/03	1021Leader	APOLLO11	1.07.1999	VCR
SB625/11	1021Leader	APOLLO11	1.08.1999	VCR
SB625/16	1021Leader	APOLLO11	1.06.1999	VCR
SB625/38	1021Leader	APOLLO11	1.08.1999	VCR
SB630/02	1021Leader			VCR
SB630/13	1021Leader	APOLLO11	1.08.1999	VCR
SB630/16	1021Leader	APOLLO11	1.06.1999	VCR
SB630DE	1021Leader	APOLLO11	1.06.1999	VCR
SB630GR	1021Leader		1.09.1999	VCR
SB635/03	1021Leader	APOLLO12	1.05.2000	VCR
SB635/07	1021Leader	APOLLO12		VCR
SB635/11	1021Leader	APOLLO12	1.06.2000	VCR
SB635/16	1021Leader	APOLLO12	1.06.2000	VCR
SB635/38	1021Leader	APOLLO12	1.06.2000	VCR
SB645/03	1021Leader	APOLLO13	1.06.2001	VCR
SB645/11	1021Leader	APOLLO13	1.07.2001	VCR
SB645/38	1021Leader	APOLLO13	1.08.2001	VCR
SB65/02	1021Leader	PAULIN_ECN	1.10.1996Economy	VCR
SB65/03	1021Leader	PAULIN_ECN	1.09.1996Economy	VCR
SB65/16	1021Leader	PAULIN_ECN	1.10.1996Economy	VCR
SB65/38	1021Leader	PAULIN_ECN	1.10.1996Economy	VCR
SB705/38	1021Step-up	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
SB715/03	1021Leader	APOLLO10	1.10.1998	VCR

SB725/03	1021Leader	APOLLO11	1.06.1999	VCR
SB725/11	1021Leader	APOLLO11	1.06.1999	VCR
SB725/38	1021Leader	APOLLO11	1.07.1999	VCR
SB735/03	1021Leader	APOLLO12	1.06.2000	VCR
SB735/11	1021Leader	APOLLO12	1.08.2000	VCR
SB735/38	1021Leader	APOLLO12	1.06.2000	VCR
SB745/03	1021Leader	APOLLO13	1.06.2001	VCR
SB745/11	1021Leader	APOLLO13	1.07.2001	VCR
SB745/38	Leader	APOLLO13		VCR
SB75/11	1021Leader	PAULIN_STU	1.09.1996Step-up	VCR
SB75/38	1021Leader	PAULIN_STU	1.10.1996Step-up	VCR
SC817/00	2012Accessories / spares			SATELLITE
SC817DSFL/00	2012Accessories / spares			SATELLITE
SC817FL/00	2012Accessories / spares			SATELLITE
SC823/00	2012Accessories / spares			SATELLITE
SC823FL/00	2012Accessories / spares			SATELLITE
SCC1280/00R	2012Accessories / spares		1.09.1996	SATELLITE
SCC1282/00R	2012Accessories / spares		1.09.1998	SATELLITE
SCC1891/00M	2012Accessories / spares			SATELLITE
SCC200/01	2012Accessories / spares		1.03.1992	SATELLITE
SCC202/01	2012Accessories / spares		1.03.1992	SATELLITE
SCC204/01	2012Accessories / spares		1.03.1992	SATELLITE
SCC209/01	2012Accessories / spares		1.09.1992	SATELLITE
SCC209/05	2012Accessories / spares		1.08.1992	SATELLITE
SCC209/13	2012Accessories / spares		1.10.1992	SATELLITE
SCC222/31	2012Accessories / spares		1.12.1992	SATELLITE
SCC224/01	2012Accessories / spares		1.08.1993	SATELLITE
SCC240A/50G	2012Accessories / spares			SATELLITE
SCC250/01	2012Accessories / spares		1.12.1994	SATELLITE
SCC260/01	2012Accessories / spares		1.09.1994	SATELLITE
SCC3810/00R	2012Accessories / spares		1.12.1996	SATELLITE
SCC409/01	2012Accessories / spares		1.05.1992	SATELLITE
SCC900/01	2012PAL/SECAM terminal		1.03.1992	SATELLITE
SCC900/30	2012PAL/SECAM terminal		1.03.1992	SATELLITE
SCC904/01	2012PAL/SECAM terminal		1.03.1992	SATELLITE
SCC907/11	2012Accessories / spares		1.03.1995	SATELLITE
SD100/00M	1049CD Video		1.09.1999	CDC / CDV
SD100/01M	1049CD Video		1.12.1999	CDC / CDV
SD110/21M	1049CD Video		1.03.2001	CDC / CDV
SD1800	1021Leader		1.07.1997	VCR
SD1800PDC	1021Leader		1.06.1997	VCR
SD1810U1/08G	2012Accessories / spares		1.05.1996	SATELLITE

SD1810U1/G	2012Accessories / spares	1.04.1996	SATELLITE
SD2400U1/00G	2012Accessories / spares		SATELLITE
SD2410U1/00G	2012Accessories / spares	1.01.1997	SATELLITE
SD241S3A/00G	2012Accessories / spares	1.11.1994	SATELLITE
SD260S2A/05R	2012Accessories / spares	1.01.1996	SATELLITE
SD260S3A/00R	2012Accessories / spares	1.10.1995	SATELLITE
SD2610S1/00G	2012Accessories / spares	1.04.1996	SATELLITE
SD2610T1/00G	2012Accessories / spares	1.07.1996	SATELLITE
SD2610U1/00B	2012Accessories / spares	1.03.1997	SATELLITE
SD2610U1/00G	2012Analogue antennas	1.09.1996	SATELLITE
SD2610U1/06G	2012Accessories / spares	1.11.1996	SATELLITE
SD2610U2/05R	2012Accessories / spares	1.08.1997	SATELLITE
SD2611U1/19G	2012Analogue antennas	1.09.1997	SATELLITE
SD2620U1/00B	2012Analogue antennas	1.09.1997	SATELLITE
SD2620U1/00G	2012Analogue antennas	1.09.1997	SATELLITE
SD264S3A/13R	2012Analogue antennas	1.12.1994	SATELLITE
SD265S3A/00R	2012Analogue antennas	1.11.1994	SATELLITE
SD270S3A/00G	2012Accessories / spares	1.03.1995	SATELLITE
SD270T3A/00G	2012Accessories / spares	1.06.1995	SATELLITE
SD2710T1/00G	2012Accessories / spares	1.02.1997	SATELLITE
SD2710T1/00M	2012Accessories / spares	1.07.1996	SATELLITE
SD2710U1/00B	2012Accessories / spares	1.01.1997	SATELLITE
SD2710U1/00G	2012Accessories / spares	1.01.1997	SATELLITE
SD2710U1/00M	2012Accessories / spares	1.07.1996	SATELLITE
SD2720T1/00G	2012Analogue antennas	1.09.1997	SATELLITE
SD2720U1/00B	2012Analogue antennas	1.10.1997	SATELLITE
SD2720U1/00G	2012Accessories / spares	1.09.1997	SATELLITE
SD2805S3/13M	2012Accessories / spares	1.09.1996	SATELLITE
SD2805U3/00R	2012Accessories / spares		SATELLITE
SD280S1A/00R	2012Accessories / spares	1.09.1994	SATELLITE
SD280S1B/19R	2012Accessories / spares		SATELLITE
SD280S2A/05R	2012Accessories / spares	1.01.1996	SATELLITE
SD280S3A/00R	2012Analogue antennas	1.10.1994	SATELLITE
SD280S3A/13R	2012Accessories / spares	1.09.1995	SATELLITE
SD280T3A/00R	2012Analogue antennas	1.11.1994	SATELLITE
SD280U3A/00R	2012Accessories / spares	1.03.1996	SATELLITE
SD2810T1/00G	2012Analogue antennas	1.02.1997	SATELLITE
SD2810T1/00M	2012Accessories / spares	1.07.1996	SATELLITE
SD2810U1/00B	2012Accessories / spares	1.02.1997	SATELLITE
SD2810U1/00G	2012Analogue antennas	1.01.1997	SATELLITE
SD2810U1/00M	2012Analogue antennas	1.07.1996	SATELLITE
SD2810U1/06G	2012Accessories / spares	1.11.1996	SATELLITE

SD2810U2/05R	2012Accessories / spares	1.09.1997	SATELLITE
SD2810U3/13M	2012Analogue antennas	1.09.1997	SATELLITE
SD2810U3/13P	2012Accessories / spares	1.12.1996	SATELLITE
SD2815U1/00B	2012Accessories / spares	1.02.1997	SATELLITE
SD2815U1/00G	2012Analogue antennas	1.01.1997	SATELLITE
SD2815U1/00M	2012Analogue antennas	1.07.1996	SATELLITE
SD2815U3/13M	2012Analogue antennas	1.03.1997	SATELLITE
SD2815U3/13P	2012Accessories / spares	1.03.1997	SATELLITE
SD2820I1/00G	2012Analogue antennas	1.06.1998	SATELLITE
SD2820U1/00B	2012Analogue antennas	1.05.1998	SATELLITE
SD2820U1/00G	2012Analogue antennas	1.07.1998	SATELLITE
SD2825U1/00B	2012Analogue antennas		SATELLITE
SD2825U1/00G	2012Analogue antennas	1.07.1998	SATELLITE
SD283M1A/00R	2012Accessories / spares		SATELLITE
SD283M1B/19R	2012Accessories / spares		SATELLITE
SD283S1A/00G	2012Accessories / spares		SATELLITE
SD283S1A/00R	2012Accessories / spares	1.03.1996	SATELLITE
SD283S1B/19R	2012Accessories / spares		SATELLITE
SD284S3A/13R	2012Accessories / spares	1.11.1994	SATELLITE
SD285S3A/00R	2012Accessories / spares	1.12.1995	SATELLITE
SD300/01M	1049CD Video	1.06.2000	CDC / CDV
SD330/21M	1049CD Video	1.03.2001	CDC / CDV
SD360S3A/00R	2012Accessories / spares	1.03.1995	SATELLITE
SD360T3A/00R	2012Accessories / spares	1.06.1995	SATELLITE
SD360U1A/00R	2012Accessories / spares	1.01.1996	SATELLITE
SD3610T1/00M	2012Accessories / spares	1.09.1996	SATELLITE
SD4610T1/00P	2012Accessories / spares	1.07.1997	SATELLITE
SD560S1A/00G	2012Accessories / spares	1.02.1995	SATELLITE
SD560S1A/00R	2012Accessories / spares	1.12.1994	SATELLITE
SD560T1A/00G	2012Accessories / spares	1.12.1994	SATELLITE
SD560T1A/00R	2012Accessories / spares	1.12.1994	SATELLITE
SD5610T1/00M	2012Accessories / spares	1.08.1996	SATELLITE
SD5610U1/00M	2012Accessories / spares		SATELLITE
SD5705U1/19G	2012Accessories / spares		SATELLITE
SD570S1A/00G	2012Accessories / spares	1.12.1994	SATELLITE
SD570S1A/19G	2012Accessories / spares		SATELLITE
SD570T1A/00G	2012Accessories / spares	1.01.1995	SATELLITE
SD570T1A/00R	2012Accessories / spares	1.01.1995	SATELLITE
SD570U1A/19G	2012Accessories / spares	1.03.1996	SATELLITE
SD573M1A/19G	2012Accessories / spares		SATELLITE
SD573S1A/19G	2012Accessories / spares	1.05.1995	SATELLITE
SD5810T1/00M	2012Accessories / spares	1.08.1996	SATELLITE

SD5810U1/00M	2012Accessories / spares	1.08.1996	SATELLITE
SD5815T1/00M	2012Accessories / spares	1.08.1996	SATELLITE
SD5815U1/00M	2012Accessories / spares	1.08.1996	SATELLITE
SD5820T1/00M	2012Analogue antennas	1.10.1997	SATELLITE
SD5820U1/00M	2012Analogue antennas	1.10.1997	SATELLITE
SD5905U1/19G	2012Accessories / spares		SATELLITE
SD590S1A/00G	2012Accessories / spares	1.03.1995	SATELLITE
SD590S1A/19G	2012Accessories / spares	1.10.1995	SATELLITE
SD590T1A/00G	2012Accessories / spares	1.12.1994	SATELLITE
SD6620T1/00M	2012Analogue antennas	1.11.1997	SATELLITE
SD6620T1/00P	2012Analogue antennas	1.10.1997	SATELLITE
SD6620U1/00M	2012Analogue antennas	1.11.1997	SATELLITE
SD814S4A/00R	2012Analogue antennas	1.12.1994	SATELLITE
SD860T1A/00R	2012Accessories / spares	1.10.1995	SATELLITE
SD8610Q1/00M	2012Analogue antennas	1.12.1996	SATELLITE
SD8610T1/00M	2012Analogue antennas	1.12.1996	SATELLITE
SD8610U1/00M	2012Analogue antennas	1.11.1996	SATELLITE
SD890D1A/00R	2012Accessories / spares	1.06.1995	SATELLITE
SD8910Q1/00M	2012Analogue antennas	1.01.1997	SATELLITE
SD8910U1/00M	2012Accessories / spares	1.11.1996	SATELLITE
SD8914S4/00R	2012Analogue antennas	1.03.1996	SATELLITE
SD8915T1/00M	2012Analogue antennas	1.11.1996	SATELLITE
SD8915U1/00M	2012Analogue antennas	1.11.1996	SATELLITE
SD8920Q1/00M	2012Analogue antennas	1.11.1997	SATELLITE
SD894S4A/00R	2012Accessories / spares	1.11.1994	SATELLITE
SD895H1A/13R	2012Accessories / spares	1.02.1995	SATELLITE
SD895S1A/00R	2012Analogue antennas	1.07.1995	SATELLITE
SD895T1A/00R	2012Accessories / spares	1.07.1995	SATELLITE
SDC1800/00R	2012Accessories / spares	1.06.1996	SATELLITE
SDC31/12R	2012Accessories / spares	1.03.1995	SATELLITE
SDC51/43R	2012Accessories / spares	1.06.1995	SATELLITE
SDC51/53R	2012Accessories / spares		SATELLITE
SDC51/63R	2012Accessories / spares		SATELLITE
SDC52/13R	2012Accessories / spares	1.03.1995	SATELLITE
SDC53/23R	2012Accessories / spares		SATELLITE
SDC53/43G	2012Accessories / spares		SATELLITE
SDC53/43R	2012Accessories / spares		SATELLITE
SDC61/63R	2012Accessories / spares		SATELLITE
SDP06/03R	2012Accessories / spares	1.01.1993	SATELLITE
SDP06/13R	2012Accessories / spares	1.07.1993	SATELLITE
SDP06/33R	2012Accessories / spares	1.09.1993	SATELLITE
SDP09/01R	2012Accessories / spares	1.03.1992	SATELLITE

SDP09/02R	2012Accessories / spares	1.03.1992	SATELLITE
SDP09/03R	2012Accessories / spares	1.03.1992	SATELLITE
SDP09/05R	2012Accessories / spares	1.06.1992	SATELLITE
SDP09/06R	2012Accessories / spares	1.04.1993	SATELLITE
SDP09/13R	2012Accessories / spares	1.11.1993	SATELLITE
SDP09/16R	2012Accessories / spares	1.09.1993	SATELLITE
SDP09/23R	2012Accessories / spares	1.01.1993	SATELLITE
SDP09/33R	2012Accessories / spares	1.09.1993	SATELLITE
SDP12/01R	2012Accessories / spares	1.10.1992	SATELLITE
SDP12/02R	2012Accessories / spares		SATELLITE
SDP12/05R	2012Accessories / spares	1.11.1992	SATELLITE
SDP12/06R	2012Accessories / spares	1.03.1993	SATELLITE
SDP12/11R	2012Accessories / spares	1.05.1994	SATELLITE
SDP12/16R	2012Accessories / spares	1.03.1994	SATELLITE
SDP23/02R	2012Accessories / spares	1.03.1992	SATELLITE
SDP23/05R	2012Accessories / spares	1.03.1992	SATELLITE
SDP26/02R	2012Accessories / spares	1.03.1992	SATELLITE
SDP26/03R	2012Accessories / spares	1.03.1993	SATELLITE
SDP26/05R	2012Accessories / spares	1.10.1992	SATELLITE
SDP26/15R	2012Accessories / spares	1.11.1993	SATELLITE
SDP26/32R	2012Accessories / spares	1.11.1992	SATELLITE
SDP26/42R	2012Accessories / spares	1.10.1993	SATELLITE
SDP26/62R	2012Accessories / spares	1.02.1994	SATELLITE
SDP26/69R	2012Accessories / spares		SATELLITE
SDP29/02R	2012Accessories / spares	1.03.1992	SATELLITE
SDP29/05R	2012Accessories / spares	1.10.1992	SATELLITE
SDP29/15R	2012Accessories / spares	1.11.1993	SATELLITE
SDP29/32R	2012Accessories / spares	1.04.1993	SATELLITE
SDP29/42R	2012Accessories / spares	1.10.1993	SATELLITE
SDP29/44R	2012Accessories / spares	1.06.1994	SATELLITE
SDP29/52R	2012Accessories / spares	1.04.1993	SATELLITE
SDP29/62R	2012Accessories / spares	1.11.1993	SATELLITE
SDP29/72R	2012Accessories / spares	1.03.1993	SATELLITE
SDP29/92R	2012Accessories / spares	1.02.1994	SATELLITE
SDP35/01G	2012Accessories / spares	1.09.1993	SATELLITE
SDP56/01R	2012Accessories / spares	1.03.1992	SATELLITE
SDP59/01R	2012Accessories / spares	1.03.1992	SATELLITE
SDP66/01G	2012Accessories / spares	1.03.1993	SATELLITE
SDP66/01R	2012Accessories / spares	1.01.1993	SATELLITE
SDP66/11G	2012Accessories / spares	1.07.1993	SATELLITE
SDP66/11R	2012Accessories / spares	1.07.1993	SATELLITE
SDP66/21R	2012Accessories / spares	1.01.1993	SATELLITE

SDP66/31G	2012Accessories / spares	1.02.1994	SATELLITE
SDP66/31R	2012Accessories / spares	1.10.1993	SATELLITE
SDP67/11G	2012Accessories / spares	1.11.1993	SATELLITE
SDP67/31G	2012Accessories / spares	1.02.1994	SATELLITE
SDP67/31R	2012Accessories / spares	1.02.1994	SATELLITE
SDP67/41R	2012Accessories / spares	1.06.1994	SATELLITE
SDP69/01G	2012Accessories / spares	1.05.1993	SATELLITE
SDP69/11G	2012Accessories / spares	1.10.1993	SATELLITE
SDP69/29G	2012Accessories / spares		SATELLITE
SDP69/31G	2012Accessories / spares	1.02.1994	SATELLITE
SDP70/01R	2012Accessories / spares	1.10.1993	SATELLITE
SDS04/03R	2012Accessories / spares		SATELLITE
SDS60/02G	2012Accessories / spares	1.02.1998	SATELLITE
SE6104SV	1021Leader show view		VCR
SE6106HIF/I	1021Leader		VCR
SE7100SV/PAL	1021Leader		VCR
SE7104SV/FLO	1021Leader show view		VCR
SE7105/SEV	1021Leader		VCR
SE7106HIF/I	1021Leader		VCR
SE7497NIC	1021Leader		VCR
SET196/00	1004		TELEPHONES CORDED
SET196/02	1004		TELEPHONES CORDED
SET196/10	1004		TELEPHONES CORDED
SIDECAR/00	2012Institutional analogue		SATELLITE
SPEAKERB/923	1004		TELEPHONES CORDED
SPEAKERW/923	1004		TELEPHONES CORDED
SR289N1A/00R	2012Accessories / spares		SATELLITE
SR899N1A/00R	2012Accessories / spares		SATELLITE
STR707/00	2012PAL/SECAM terminal	1.12.1992	SATELLITE
STU1100/00G	2012PAL/SECAM terminal	1.04.1996	SATELLITE
STU1110/00G	2012PAL/SECAM terminal	1.12.1996	SATELLITE
STU1120/00G	2012PAL/SECAM terminal	1.04.1997	SATELLITE
STU1130/00G	2012PAL/SECAM terminal	1.04.1998	SATELLITE
STU130A/00G	2012PAL/SECAM terminal	1.02.1995	SATELLITE
STU1310/00G	2012PAL/SECAM terminal	1.06.1996	SATELLITE
STU1320/00G	2012PAL/SECAM terminal	1.07.1997	SATELLITE
STU1330/00G	2012PAL/SECAM terminal	1.04.1998	SATELLITE
STU1400/00G	2012PAL/SECAM terminal	1.07.1996	SATELLITE
STU1400/13G	2012PAL/SECAM terminal	1.03.1997	SATELLITE
STU1401/05G	2012PAL/SECAM terminal	1.11.1996	SATELLITE
STU1420/00G	2012PAL/SECAM terminal	1.09.1997	SATELLITE
STU3300/22G	2012PAL/SECAM terminal	1.01.1997	SATELLITE

STU3301/05G	2012PAL/SECAM terminal	1.07.1996	SATELLITE
STU330A/00G	2012PAL/SECAM terminal	1.10.1994	SATELLITE
STU330A/01G	2012PAL/SECAM terminal	1.12.1994	SATELLITE
STU330A/22G	2012PAL/SECAM terminal	1.05.1995	SATELLITE
STU3310/00G	2012PAL/SECAM terminal	1.06.1996	SATELLITE
STU3310/01G	2012PAL/SECAM terminal	1.08.1996	SATELLITE
STU3310/22G	2012PAL/SECAM terminal	1.08.1996	SATELLITE
STU3330/00G	2012PAL/SECAM terminal	1.11.1998	SATELLITE
STU340A/50G	2012PAL/SECAM terminal		SATELLITE
STU3501/05G	2012PAL/SECAM terminal	1.07.1996	SATELLITE
STU350A/00G	2012PAL/SECAM terminal	1.10.1994	SATELLITE
STU3510/00G	2012PAL/SECAM terminal	1.08.1996	SATELLITE
STU3530/00G	2012PAL/SECAM terminal	1.11.1998	SATELLITE
STU3601/05G	2012PAL/SECAM terminal	1.07.1996	SATELLITE
STU430A/00G	2012PAL/SECAM terminal	1.03.1995	SATELLITE
STU430A/22G	2012PAL/SECAM terminal	1.11.1995	SATELLITE
STU4310/00G	2012PAL/SECAM terminal	1.11.1996	SATELLITE
STU560A/00G	2012PAL/SECAM terminal	1.09.1994	SATELLITE
STU660A/00G	2012PAL/SECAM terminal	1.06.1995	SATELLITE
STU800/01R	2012PAL/SECAM terminal	1.03.1992	SATELLITE
STU801/01R	2012PAL/SECAM terminal	1.03.1992	SATELLITE
STU801/02R	2012PAL/SECAM terminal	1.03.1992	SATELLITE
STU801/05R	2012PAL/SECAM terminal	1.03.1992	SATELLITE
STU801/19R	2012PAL/SECAM terminal	1.03.1992	SATELLITE
STU801/21R	2012PAL/SECAM terminal	1.10.1992	SATELLITE
STU801/22R	2012PAL/SECAM terminal	1.06.1992	SATELLITE
STU801/25R	2012PAL/SECAM terminal	1.08.1992	SATELLITE
STU802/05M	2012PAL/SECAM terminal	1.01.1993	SATELLITE
STU802/05R	2012PAL/SECAM terminal	1.10.1992	SATELLITE
STU803/02R	2012PAL/SECAM terminal	1.01.1993	SATELLITE
STU803/22R	2012PAL/SECAM terminal	1.10.1993	SATELLITE
STU804/01G	2012PAL/SECAM terminal	1.06.1993	SATELLITE
STU804/02G	2012PAL/SECAM terminal	1.01.1993	SATELLITE
STU804/19G	2012PAL/SECAM terminal	1.11.1993	SATELLITE
STU804/22G	2012PAL/SECAM terminal	1.07.1993	SATELLITE
STU811/02G	2012PAL/SECAM terminal	1.09.1993	SATELLITE
STU812/05M	2012PAL/SECAM terminal	1.06.1994	SATELLITE
STU824/05G	2012PAL/SECAM terminal	1.10.1993	SATELLITE
STU901/00R	2012PAL/SECAM terminal	1.03.1992	SATELLITE
STU901/01R	2012PAL/SECAM terminal	1.03.1992	SATELLITE
STU901/05R	2012PAL/SECAM terminal	1.04.1992	SATELLITE
STU901/13R	2012PAL/SECAM terminal	1.03.1992	SATELLITE

STU901/19R	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU901/25R	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU901/43R	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU901/63R	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU902/05R	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU904/30R	2012PAL/SECAM terminal		1.05.1992	SATELLITE
STU904/31R	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU904/43R	2012PAL/SECAM terminal		1.10.1992	SATELLITE
STU904/53R	2012PAL/SECAM terminal		1.02.1993	SATELLITE
STU904/58R	2012PAL/SECAM terminal		1.02.1993	SATELLITE
STU904/63R	2012PAL/SECAM terminal		1.09.1993	SATELLITE
STU904/63Y	2012PAL/SECAM terminal		1.08.1994	SATELLITE
STU904/83G	2012PAL/SECAM terminal		1.08.1995	SATELLITE
STU906/02R	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU909/02M	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU909/32M	2012PAL/SECAM terminal		1.10.1992	SATELLITE
STU909/49M	2012PAL/SECAM terminal		1.03.1992	SATELLITE
STU909/52M	2012PAL/SECAM terminal		1.07.1992	SATELLITE
STU909/55M	2012PAL/SECAM terminal		1.07.1992	SATELLITE
STU909/63M	2012PAL/SECAM terminal		1.08.1992	SATELLITE
STU909/69M	2012PAL/SECAM terminal		1.07.1992	SATELLITE
STU909/89M	2012PAL/SECAM terminal		1.12.1993	SATELLITE
SV622	1021Leader		1.12.1996	VCR
SV642	1021Leader show view		1.12.1996	VCR
SV661S	1021Leader		1.02.1997	VCR
SVD100/171	DVD Video			DVD
SVD101/171	DVD Video			DVD
SW931PRO/17	1049Tuners		1.11.1995	TUNERS
TC22805T/,,	2010	VM8		OBSERVATION SYSTEMS
TC22885T/,,	2010			OBSERVATION SYSTEMS
TC2901/00	2010	ACC		OBSERVATION SYSTEMS
TC2902/00	2010	ACC		OBSERVATION SYSTEMS
TC2903/05	2010	ACC		OBSERVATION SYSTEMS
TC2905/00	2010	ACC		OBSERVATION SYSTEMS
TC2906/00	2010	VCM		OBSERVATION SYSTEMS
TC32805T/,,	2010	VM8		OBSERVATION SYSTEMS
TC44805T/,,	2010	VM8		OBSERVATION SYSTEMS
TC82505T/,,	2010	VM5		OBSERVATION SYSTEMS
TC89755T/,,	2010	X9-B/W		OBSERVATION SYSTEMS
TC89765T/,,	2010	X9-B/W		OBSERVATION SYSTEMS
TC91755T/,,	2010	X1S-COLOUR		OBSERVATION SYSTEMS
TC94515T/,,	2010	VM5		OBSERVATION SYSTEMS

TD5100AA/021	1003		TELEPHONES CORDLESS
TD5100AA/028	1003		TELEPHONES CORDLESS
TD5100AA/029	1003		TELEPHONES CORDLESS
TD5100AA/061	1003		TELEPHONES CORDLESS
TD5100AA/081	1003	1.12.1999	TELEPHONES CORDLESS
TD5100AA/088	1003	1.12.1999	TELEPHONES CORDLESS
TD5100AA/089	1003	1.12.1999	TELEPHONES CORDLESS
TD5100AA/091	1003		TELEPHONES CORDLESS
TD5100AA/101	1003		TELEPHONES CORDLESS
TD5100AA/108	1003		TELEPHONES CORDLESS
TD5100AA/109	1003		TELEPHONES CORDLESS
TD5100AA/131	1003		TELEPHONES CORDLESS
TD5100AA/138	1003		TELEPHONES CORDLESS
TD5100AA/139	1003		TELEPHONES CORDLESS
TD5100AA/141	1003		TELEPHONES CORDLESS
TD5100AA/158	1003		TELEPHONES CORDLESS
TD5100AA/201	1003		TELEPHONES CORDLESS
TD5100AA/351	1003		TELEPHONES CORDLESS
TD5100AA/621	1003	1.12.1999	TELEPHONES CORDLESS
TD5100AH/933	1003		TELEPHONES CORDLESS
TD5100AH/938	1003		TELEPHONES CORDLESS
TD5100AH/939	1003		TELEPHONES CORDLESS
TD5100AM/933	1003		TELEPHONES CORDLESS
TD5100AM/938	1003		TELEPHONES CORDLESS
TD5100AM/939	1003		TELEPHONES CORDLESS
TD5100BB/088	1003	1.12.1999	TELEPHONES CORDLESS
TD5100BB/913	1003		TELEPHONES CORDLESS
TD5100BB/919	1003		TELEPHONES CORDLESS
TD5100HG/913	1003		TELEPHONES CORDLESS
TD5100HG/919	1003		TELEPHONES CORDLESS
TD5200AA/163	1003		TELEPHONES CORDLESS
TD5200AH/051	1003		TELEPHONES CORDLESS
TD5200AH/171	1003		TELEPHONES CORDLESS
TD5200AR/191	1003		TELEPHONES CORDLESS
TD5200BG/193	1003		TELEPHONES CORDLESS
TD5200WG/163	1003		TELEPHONES CORDLESS
TD5200WG/173	1003		TELEPHONES CORDLESS
TD5200WW/163	1003		TELEPHONES CORDLESS
TD520AH/03	1003		TELEPHONES CORDLESS
TD520AH/16	1003		TELEPHONES CORDLESS
TD520AH/19	1003		TELEPHONES CORDLESS
TD520AH/194	1003		TELEPHONES CORDLESS

TD520AK/03	1003		TELEPHONES CORDLESS
TD5220BG/193	1003		TELEPHONES CORDLESS
TD5220HG/163	1003		TELEPHONES CORDLESS
TD522AH/03	1003		TELEPHONES CORDLESS
TD522AH/16	1003		TELEPHONES CORDLESS
TD522AH/19	1003		TELEPHONES CORDLESS
TD522AH/194	1003		TELEPHONES CORDLESS
TD522AK/03	1003		TELEPHONES CORDLESS
TD5250BB/038	1003		TELEPHONES CORDLESS
TD5250BB/058	1003		TELEPHONES CORDLESS
TD5250BB/059			TELEPHONES CORDLESS
TD5250BB/168	1003	1.12.1999	TELEPHONES CORDLESS
TD5250BB/178	1003	1.12.1999	TELEPHONES CORDLESS
TD5250BB/179			TELEPHONES CORDLESS
TD5250BB/191	1003		TELEPHONES CORDLESS
TD5250BB/194	1003		TELEPHONES CORDLESS
TD5250BB/196			TELEPHONES CORDLESS
TD5250BB/197	1003	1.12.1999	TELEPHONES CORDLESS
TD5250BB/198	1003	1.12.1999	TELEPHONES CORDLESS
TD5250BB/199			TELEPHONES CORDLESS
TD5250GH/168	1003	1.12.1999	TELEPHONES CORDLESS
TD5250GO/038	1003		TELEPHONES CORDLESS
TD5250GO/168	1003	1.12.1999	TELEPHONES CORDLESS
TD5250GO/191	1003		TELEPHONES CORDLESS
TD5250GO/194	1003		TELEPHONES CORDLESS
TD5250GO/197	1003		TELEPHONES CORDLESS
TD5250GO/198	1003	1.12.1999	TELEPHONES CORDLESS
TD5250GS/038	1003		TELEPHONES CORDLESS
TD5250GS/058	1003		TELEPHONES CORDLESS
TD5250GS/168	1003	1.12.1999	TELEPHONES CORDLESS
TD5260BB/191	1003		TELEPHONES CORDLESS
TD5260BB/194	1003		TELEPHONES CORDLESS
TD5260BB/196			TELEPHONES CORDLESS
TD5260BB/197	1003	1.12.1999	TELEPHONES CORDLESS
TD5260BB/198	1003	1.12.1999	TELEPHONES CORDLESS
TD5260BB/199			TELEPHONES CORDLESS
TD5350BB/038	1003		TELEPHONES CORDLESS
TD5350BB/039			TELEPHONES CORDLESS
TD5350BB/058	1003		TELEPHONES CORDLESS
TD5350BB/059			TELEPHONES CORDLESS
TD5350BB/168	1003	1.12.1999	TELEPHONES CORDLESS
TD5350BB/191	1003		TELEPHONES CORDLESS

TD5350BB/194	1003		TELEPHONES CORDLESS
TD5350BB/197	1003		TELEPHONES CORDLESS
TD5350BB/198	1003	1.12.1999	TELEPHONES CORDLESS
TD5350GS/038	1003		TELEPHONES CORDLESS
TD5350GS/168	1003	1.12.1999	TELEPHONES CORDLESS
TD5350GS/191	1003		TELEPHONES CORDLESS
TD5350GS/197	1003		TELEPHONES CORDLESS
TD5350GS/198	1003	1.12.1999	TELEPHONES CORDLESS
TD5400AH/191	1003	1.12.1999	TELEPHONES CORDLESS
TD5500AH/161	1003		TELEPHONES CORDLESS
TD5500AH/191	1003		TELEPHONES CORDLESS
TD5550BB/051	1003		TELEPHONES CORDLESS
TD5550BB/058	1003		TELEPHONES CORDLESS
TD5550BB/191	1003	1.12.1999	TELEPHONES CORDLESS
TD5550BB/198	1003		TELEPHONES CORDLESS
TD5550GG/953	1003		TELEPHONES CORDLESS
TD5550GG/958	1003		TELEPHONES CORDLESS
TD5550GH/191	1003	1.12.1999	TELEPHONES CORDLESS
TD5550GH/198	1003		TELEPHONES CORDLESS
TD5550RR/953	1003		TELEPHONES CORDLESS
TD5550RR/958	1003		TELEPHONES CORDLESS
TD5600AH/031	1003		TELEPHONES CORDLESS
TD5600AH/051	1003		TELEPHONES CORDLESS
TD5600AH/161	1003		TELEPHONES CORDLESS
TD5600AH/191	1003	1.12.1999	TELEPHONES CORDLESS
TD5600AH/199	1003		TELEPHONES CORDLESS
TD5600AH/231	1003		TELEPHONES CORDLESS
TD5800AH/031	1003		TELEPHONES CORDLESS
TD5800AH/051	1003		TELEPHONES CORDLESS
TD5800AH/161	1003		TELEPHONES CORDLESS
TD5800AH/191	1003		TELEPHONES CORDLESS
TD5800AH/231	1003		TELEPHONES CORDLESS
TD6100AG/021	1003		TELEPHONES CORDLESS
TD6100AG/031	1003		TELEPHONES CORDLESS
TD6100AG/041	1003		TELEPHONES CORDLESS
TD6100AG/051	1003		TELEPHONES CORDLESS
TD6100AG/061	1003		TELEPHONES CORDLESS
TD6100AG/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6100AG/091	1003		TELEPHONES CORDLESS
TD6100AG/101	1003		TELEPHONES CORDLESS
TD6100AG/131	1003		TELEPHONES CORDLESS
TD6100AG/141	1003		TELEPHONES CORDLESS

TD6100AG/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6100AG/201	1003		TELEPHONES CORDLESS
TD6120BB/021	1003		TELEPHONES CORDLESS
TD6120BB/041	1003		TELEPHONES CORDLESS
TD6120BB/061	1003		TELEPHONES CORDLESS
TD6120BB/081	1003	1.12.1999	TELEPHONES CORDLESS
TD6120BB/091	1003		TELEPHONES CORDLESS
TD6120BB/131	1003		TELEPHONES CORDLESS
TD6120BB/141	1003		TELEPHONES CORDLESS
TD6120BB/161	1003		TELEPHONES CORDLESS
TD6120BB/171	1003	1.12.1999	TELEPHONES CORDLESS
TD6120BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6120BB/201	1003		TELEPHONES CORDLESS
TD6120GH/021	1003		TELEPHONES CORDLESS
TD6120GH/031	1003		TELEPHONES CORDLESS
TD6120GH/041	1003		TELEPHONES CORDLESS
TD6120GH/051	1003		TELEPHONES CORDLESS
TD6120GH/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6120GH/101	1003		TELEPHONES CORDLESS
TD6120GH/131	1003		TELEPHONES CORDLESS
TD6120GH/141	1003		TELEPHONES CORDLESS
TD6120GH/151	1003		TELEPHONES CORDLESS
TD6120GH/201	1003		TELEPHONES CORDLESS
TD6120GM/021	1003		TELEPHONES CORDLESS
TD6120GM/029			TELEPHONES CORDLESS
TD6120GM/031	1003		TELEPHONES CORDLESS
TD6120GM/059			TELEPHONES CORDLESS
TD6120GM/089			TELEPHONES CORDLESS
TD6120GM/101	1003		TELEPHONES CORDLESS
TD6120GM/199			TELEPHONES CORDLESS
TD6120SS/051	1003		TELEPHONES CORDLESS
TD6120SY/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6120SY/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6121BB/933			TELEPHONES CORDLESS
TD6121BB/943			TELEPHONES CORDLESS
TD6123BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6123GH/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6123SY/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6200AG/021	1003		TELEPHONES CORDLESS
TD6200AG/031	1003		TELEPHONES CORDLESS
TD6200AG/041	1003		TELEPHONES CORDLESS
TD6200AG/051	1003		TELEPHONES CORDLESS

TD6200AG/061	1003		TELEPHONES CORDLESS
TD6200AG/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6200AG/091	1003		TELEPHONES CORDLESS
TD6200AG/101	1003		TELEPHONES CORDLESS
TD6200AG/131	1003		TELEPHONES CORDLESS
TD6200AG/141	1003		TELEPHONES CORDLESS
TD6200AG/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6200AG/201	1003		TELEPHONES CORDLESS
TD6200AG/261	1003		TELEPHONES CORDLESS
TD6200AG/263	1003		TELEPHONES CORDLESS
TD6200AH/021	1003		TELEPHONES CORDLESS
TD6200AH/031	1003		TELEPHONES CORDLESS
TD6200AH/051	1003		TELEPHONES CORDLESS
TD6200AH/061	1003		TELEPHONES CORDLESS
TD6200AH/091	1003		TELEPHONES CORDLESS
TD6200AH/131	1003		TELEPHONES CORDLESS
TD6200AH/261	1003		TELEPHONES CORDLESS
TD6200AH/263	1003		TELEPHONES CORDLESS
TD6200AK/021	1003		TELEPHONES CORDLESS
TD6200AK/031	1003		TELEPHONES CORDLESS
TD6200AK/101	1003		TELEPHONES CORDLESS
TD6200AK/131	1003		TELEPHONES CORDLESS
TD6200AK/141	1003		TELEPHONES CORDLESS
TD6200AK/201	1003		TELEPHONES CORDLESS
TD6200AV/021	1003		TELEPHONES CORDLESS
TD6200AV/031	1003		TELEPHONES CORDLESS
TD6200AV/101	1003		TELEPHONES CORDLESS
TD6200AV/571	1003		TELEPHONES CORDLESS
TD6210BB/001	1003		TELEPHONES CORDLESS
TD6210BB/021	1003		TELEPHONES CORDLESS
TD6210BB/031	1003		TELEPHONES CORDLESS
TD6210BB/051	1003		TELEPHONES CORDLESS
TD6210BB/061	1003		TELEPHONES CORDLESS
TD6210BB/081	1003	1.12.1999	TELEPHONES CORDLESS
TD6210BB/091	1003		TELEPHONES CORDLESS
TD6210BB/101	1003		TELEPHONES CORDLESS
TD6210BB/151	1003	1.11.1999	TELEPHONES CORDLESS
TD6210BB/171	1003	1.11.1999	TELEPHONES CORDLESS
TD6210BG/021	1003		TELEPHONES CORDLESS
TD6210BG/031	1003		TELEPHONES CORDLESS
TD6210BG/041	1003		TELEPHONES CORDLESS
TD6210BG/051	1003		TELEPHONES CORDLESS

TD6210BG/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6210BG/101	1003		TELEPHONES CORDLESS
TD6210BG/131	1003		TELEPHONES CORDLESS
TD6210BG/141	1003		TELEPHONES CORDLESS
TD6210BG/201	1003		TELEPHONES CORDLESS
TD6210BH/021	1003		TELEPHONES CORDLESS
TD6210BH/061	1003		TELEPHONES CORDLESS
TD6210BH/091	1003		TELEPHONES CORDLESS
TD6211BB/161	1003	1.11.1999	TELEPHONES CORDLESS
TD6211BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6211BH/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6211BH/931	1003		TELEPHONES CORDLESS
TD6211BX/921	1003		TELEPHONES CORDLESS
TD6310BB/061	1003		TELEPHONES CORDLESS
TD6310BB/099	1003		TELEPHONES CORDLESS
TD6310BB/149	1003		TELEPHONES CORDLESS
TD6311BB/029	1003		TELEPHONES CORDLESS
TD6311BB/049	1003		TELEPHONES CORDLESS
TD6311BB/059	1003		TELEPHONES CORDLESS
TD6311BB/139	1003		TELEPHONES CORDLESS
TD6311BB/169	1003	1.12.1999	TELEPHONES CORDLESS
TD6311BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6311BB/199	1003	1.11.1999	TELEPHONES CORDLESS
TD6311BB/209	1003		TELEPHONES CORDLESS
TD6311BB/921	1003		TELEPHONES CORDLESS
TD6311BH/921	1003		TELEPHONES CORDLESS
TD6311HH/029	1003		TELEPHONES CORDLESS
TD6311HH/039	1003		TELEPHONES CORDLESS
TD6311HH/059	1003		TELEPHONES CORDLESS
TD6311HH/089	1003	1.11.1999	TELEPHONES CORDLESS
TD6311HH/109	1003		TELEPHONES CORDLESS
TD6311MM/029	1003		TELEPHONES CORDLESS
TD6326BB/021	1003		TELEPHONES CORDLESS
TD6326BB/051	1003		TELEPHONES CORDLESS
TD6326BB/081			TELEPHONES CORDLESS
TD6326BB/131			TELEPHONES CORDLESS
TD6326BB/191	1003		TELEPHONES CORDLESS
TD6326BG/021	1003		TELEPHONES CORDLESS
TD6326BH/021	1003		TELEPHONES CORDLESS
TD6400AB/913	1003		TELEPHONES CORDLESS
TD6400AG/021	1003		TELEPHONES CORDLESS
TD6400AG/131	1003		TELEPHONES CORDLESS

TD6400AG/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6400AG/301	1003		TELEPHONES CORDLESS
TD6400AG/361	1003		TELEPHONES CORDLESS
TD6400AG/601	1003		TELEPHONES CORDLESS
TD6400AH/021	1003		TELEPHONES CORDLESS
TD6400AH/089	1003		TELEPHONES CORDLESS
TD6400AM/913	1003		TELEPHONES CORDLESS
TD6410BB/061	1003		TELEPHONES CORDLESS
TD6410BB/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6410BB/091	1003		TELEPHONES CORDLESS
TD6410BG/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6411BB/021	1003		TELEPHONES CORDLESS
TD6411BB/031	1003		TELEPHONES CORDLESS
TD6411BB/041	1003		TELEPHONES CORDLESS
TD6411BB/051	1003		TELEPHONES CORDLESS
TD6411BB/101	1003		TELEPHONES CORDLESS
TD6411BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6411BG/021	1003		TELEPHONES CORDLESS
TD6411BG/031	1003		TELEPHONES CORDLESS
TD6411BG/051	1003		TELEPHONES CORDLESS
TD6411BG/101	1003		TELEPHONES CORDLESS
TD6411BG/131	1003		TELEPHONES CORDLESS
TD6411BG/191	1003		TELEPHONES CORDLESS
TD6411BH/021	1003		TELEPHONES CORDLESS
TD6510BB/099	1003		TELEPHONES CORDLESS
TD6511BB/029	1003		TELEPHONES CORDLESS
TD6511BB/059	1003		TELEPHONES CORDLESS
TD6511BB/139	1003		TELEPHONES CORDLESS
TD6511BB/199	1003	1.11.1999	TELEPHONES CORDLESS
TD6511BM/931	1003		TELEPHONES CORDLESS
TD6511HH/029	1003		TELEPHONES CORDLESS
TD6511HH/059	1003		TELEPHONES CORDLESS
TD6511HH/109	1003		TELEPHONES CORDLESS
TD6511MM/029	1003		TELEPHONES CORDLESS
TD6511MM/089	1003	1.11.1999	TELEPHONES CORDLESS
TD6523BB/021	1003		TELEPHONES CORDLESS
TD6523BB/051	1003		TELEPHONES CORDLESS
TD6523BB/061	1003		TELEPHONES CORDLESS
TD6523BB/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6523BB/151	1003		TELEPHONES CORDLESS
TD6523BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6523GH/021	1003		TELEPHONES CORDLESS

TD6523GH/051	1003		TELEPHONES CORDLESS
TD6523GH/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6523GH/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6523GM/021	1003		TELEPHONES CORDLESS
TD6523SM/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6523SY/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6600AG/021	1003		TELEPHONES CORDLESS
TD6600AG/051	1003		TELEPHONES CORDLESS
TD6600AG/061	1003		TELEPHONES CORDLESS
TD6600AG/091	1003		TELEPHONES CORDLESS
TD6600AG/131	1003		TELEPHONES CORDLESS
TD6600AG/191	1003		TELEPHONES CORDLESS
TD6600AG/199	1003	1.11.1999	TELEPHONES CORDLESS
TD6600AH/021	1003		TELEPHONES CORDLESS
TD6600AH/061	1003		TELEPHONES CORDLESS
TD6600AH/091	1003		TELEPHONES CORDLESS
TD6600AH/131	1003		TELEPHONES CORDLESS
TD6600AH/191	1003		TELEPHONES CORDLESS
TD6600AH/953	1003		TELEPHONES CORDLESS
TD6600AK/031	1003		TELEPHONES CORDLESS
TD6600AK/101	1003		TELEPHONES CORDLESS
TD6600AV/081	1003	1.11.1999	TELEPHONES CORDLESS
TD6611BB/021	1003		TELEPHONES CORDLESS
TD6611BB/031	1003		TELEPHONES CORDLESS
TD6611BB/051	1003		TELEPHONES CORDLESS
TD6611BB/081	1003	1.12.1999	TELEPHONES CORDLESS
TD6611BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6611BH/021	1003		TELEPHONES CORDLESS
TD6611BK/081	1003	1.12.1999	TELEPHONES CORDLESS
TD6611BS/191	1003		TELEPHONES CORDLESS
TD6626BB/021	1003		TELEPHONES CORDLESS
TD6626BB/031			TELEPHONES CORDLESS
TD6626BB/051	1003		TELEPHONES CORDLESS
TD6626BB/081			TELEPHONES CORDLESS
TD6626BB/131			TELEPHONES CORDLESS
TD6626BB/191	1003		TELEPHONES CORDLESS
TD6626BG/021	1003		TELEPHONES CORDLESS
TD6626HH/021	1003		TELEPHONES CORDLESS
TD6711BB/031	1003		TELEPHONES CORDLESS
TD6711BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6720GH/051			TELEPHONES CORDLESS
TD6721BB/051			TELEPHONES CORDLESS

TD6800AG/021	1003		TELEPHONES CORDLESS
TD6800AG/031	1003		TELEPHONES CORDLESS
TD6800AG/051	1003		TELEPHONES CORDLESS
TD6800AG/061	1003		TELEPHONES CORDLESS
TD6800AG/091	1003		TELEPHONES CORDLESS
TD6800AG/131	1003		TELEPHONES CORDLESS
TD6800AG/141	1003		TELEPHONES CORDLESS
TD6800AG/201	1003		TELEPHONES CORDLESS
TD6800AG/263	1003		TELEPHONES CORDLESS
TD6800AH/021	1003		TELEPHONES CORDLESS
TD6800AH/031	1003		TELEPHONES CORDLESS
TD6800AH/051	1003		TELEPHONES CORDLESS
TD6800AH/061	1003		TELEPHONES CORDLESS
TD6800AH/091	1003		TELEPHONES CORDLESS
TD6800AH/263	1003		TELEPHONES CORDLESS
TD6800AK/021	1003		TELEPHONES CORDLESS
TD6800AK/031	1003		TELEPHONES CORDLESS
TD6800AK/101	1003		TELEPHONES CORDLESS
TD6800AV/021	1003		TELEPHONES CORDLESS
TD6800AV/031	1003		TELEPHONES CORDLESS
TD6800AV/101	1003		TELEPHONES CORDLESS
TD6800AX/002	1003		TELEPHONES CORDLESS
TD6800AX/022	1003		TELEPHONES CORDLESS
TD6800AX/052	1003		TELEPHONES CORDLESS
TD6810BB/021	1003		TELEPHONES CORDLESS
TD6810BB/031	1003		TELEPHONES CORDLESS
TD6810BB/051	1003		TELEPHONES CORDLESS
TD6810BB/061	1003		TELEPHONES CORDLESS
TD6810BB/081	1003	1.12.1999	TELEPHONES CORDLESS
TD6810BB/091	1003		TELEPHONES CORDLESS
TD6810BB/101	1003		TELEPHONES CORDLESS
TD6810BB/151	1003	1.11.1999	TELEPHONES CORDLESS
TD6810BB/161	1003	1.11.1999	TELEPHONES CORDLESS
TD6810BB/171	1003	1.11.1999	TELEPHONES CORDLESS
TD6810BB/191	1003	1.11.1999	TELEPHONES CORDLESS
TD6810BG/041	1003		TELEPHONES CORDLESS
TD6810BG/131	1003		TELEPHONES CORDLESS
TD6810BG/141	1003		TELEPHONES CORDLESS
TD6810BG/201	1003		TELEPHONES CORDLESS
TD6810BH/931	1003		TELEPHONES CORDLESS
TD6810BX/921	1003		TELEPHONES CORDLESS
TD6812BB/001	1003		TELEPHONES CORDLESS

TD6812BB/651	1003	1.11.1999	TELEPHONES CORDLESS
TD6816BB/001	1003	1.11.1999	TELEPHONES CORDLESS
TD6816BB/009	1003		TELEPHONES CORDLESS
TD6816BB/051	1003		TELEPHONES CORDLESS
TD6816BB/921	1003		TELEPHONES CORDLESS
TD6816BH/001	1003	1.11.1999	TELEPHONES CORDLESS
TD6816BH/009	1003		TELEPHONES CORDLESS
TD6816BH/051	1003		TELEPHONES CORDLESS
TD6816BK/001	1003		TELEPHONES CORDLESS
TD6816BM/931	1003		TELEPHONES CORDLESS
TD6816BO/001	1003	1.11.1999	TELEPHONES CORDLESS
TD6820AG/021	1003		TELEPHONES CORDLESS
TD6820AG/041	1003		TELEPHONES CORDLESS
TD6820AG/051	1003		TELEPHONES CORDLESS
TD6820AG/061	1003		TELEPHONES CORDLESS
TD6820AG/081	1003	1.12.1999	TELEPHONES CORDLESS
TD6820AG/091	1003		TELEPHONES CORDLESS
TD6820AG/131	1003		TELEPHONES CORDLESS
TD6820AG/141	1003		TELEPHONES CORDLESS
TD6820AG/191	1003		TELEPHONES CORDLESS
TD6820AG/201	1003		TELEPHONES CORDLESS
TD6820AG/261	1003		TELEPHONES CORDLESS
TD6820AG/263	1003		TELEPHONES CORDLESS
TD6820AG/301	1003		TELEPHONES CORDLESS
TD6820AG/361	1003		TELEPHONES CORDLESS
TD6820AG/601	1003		TELEPHONES CORDLESS
TD6820AH/021	1003		TELEPHONES CORDLESS
TD6820AH/051	1003		TELEPHONES CORDLESS
TD6820AH/061	1003		TELEPHONES CORDLESS
TD6820AH/089	1003		TELEPHONES CORDLESS
TD6820AH/091	1003		TELEPHONES CORDLESS
TD6820AH/263	1003		TELEPHONES CORDLESS
TD6820AK/021	1003		TELEPHONES CORDLESS
TD6820AK/031	1003		TELEPHONES CORDLESS
TD6820AK/101	1003		TELEPHONES CORDLESS
TD6820AK/131	1003		TELEPHONES CORDLESS
TD6820AK/141	1003		TELEPHONES CORDLESS
TD6820AK/201	1003		TELEPHONES CORDLESS
TD6820AM/913	1003		TELEPHONES CORDLESS
TD6820AV/021	1003		TELEPHONES CORDLESS
TD6820AV/031	1003		TELEPHONES CORDLESS
TD6820AV/101	1003		TELEPHONES CORDLESS

TD6820AX/002	1003		TELEPHONES CORDLESS
TD6820AX/022	1003		TELEPHONES CORDLESS
TD6820AX/032	1003		TELEPHONES CORDLESS
TD6820AX/042	1003		TELEPHONES CORDLESS
TD6820AX/052	1003		TELEPHONES CORDLESS
TD6821BB/933			TELEPHONES CORDLESS
TD6821BB/943			TELEPHONES CORDLESS
TD6822BB/001	1003	1.11.1999	TELEPHONES CORDLESS
TD6822BB/009	1003		TELEPHONES CORDLESS
TD6822BB/051	1003		TELEPHONES CORDLESS
TD6822GH/001	1003	1.11.1999	TELEPHONES CORDLESS
TD6822GH/051	1003		TELEPHONES CORDLESS
TD6825BB/001	1003		TELEPHONES CORDLESS
TD6825BB/009			TELEPHONES CORDLESS
TD6825BB/051	1003		TELEPHONES CORDLESS
TD6825BG/001	1003		TELEPHONES CORDLESS
TD6825BH/001	1003		TELEPHONES CORDLESS
TD6850AG/021	1003		TELEPHONES CORDLESS
TD6850AG/051	1003		TELEPHONES CORDLESS
TD6850AG/061	1003		TELEPHONES CORDLESS
TD6850AG/091	1003		TELEPHONES CORDLESS
TD6850AG/131	1003		TELEPHONES CORDLESS
TD6850AG/191	1003		TELEPHONES CORDLESS
TD6850AG/199	1003		TELEPHONES CORDLESS
TD6850AH/021	1003		TELEPHONES CORDLESS
TD6850AH/061	1003		TELEPHONES CORDLESS
TD6850AH/091	1003		TELEPHONES CORDLESS
TD6850AH/161	1003		TELEPHONES CORDLESS
TD6850AH/191	1003		TELEPHONES CORDLESS
TD6850AH/953	1003		TELEPHONES CORDLESS
TD6850AK/031	1003		TELEPHONES CORDLESS
TD6850AK/101	1003		TELEPHONES CORDLESS
TD6850AV/081	1003	1.12.1999	TELEPHONES CORDLESS
TD9048B/00	1004		TELEPHONES CORDED
TD9048B/02	1004		TELEPHONES CORDED
TD9048B/03	1004		TELEPHONES CORDED
TD9048B/05	1004		TELEPHONES CORDED
TD9048B/08	1004		TELEPHONES CORDED
TD9048B/084	1004		TELEPHONES CORDED
TD9048B/09	1004		TELEPHONES CORDED
TD9048B/10	1004		TELEPHONES CORDED
TD9048B/16	1004		TELEPHONES CORDED

TD9048B/194	1004		TELEPHONES CORDED
TD9048B/20	1004		TELEPHONES CORDED
TD9048CB/00	1004		TELEPHONES CORDED
TD9048CB/084	1004		TELEPHONES CORDED
TD9048CI/00	1004		TELEPHONES CORDED
TD9048CI/084	1004		TELEPHONES CORDED
TD9048CM/084	1004		TELEPHONES CORDED
TD9048H/194	1004		TELEPHONES CORDED
TD9048I/00	1004		TELEPHONES CORDED
TD9048I/02	1004		TELEPHONES CORDED
TD9048I/03	1004		TELEPHONES CORDED
TD9048I/084	1004		TELEPHONES CORDED
TD9048I/10	1004		TELEPHONES CORDED
TD9048I/19	1004		TELEPHONES CORDED
TD9048I/194	1004		TELEPHONES CORDED
TD9048M/084	1004		TELEPHONES CORDED
TD9049T/03	1004		TELEPHONES CORDED
TD9049T/88	1004		TELEPHONES CORDED
TD9049Z/194	1004		TELEPHONES CORDED
TD9049Z/88	1004		TELEPHONES CORDED
TD9051B/00	1004		TELEPHONES CORDED
TD9051B/02	1004		TELEPHONES CORDED
TD9051B/03	1004		TELEPHONES CORDED
TD9051B/06	1004		TELEPHONES CORDED
TD9051B/08	1004	1.12.1999	TELEPHONES CORDED
TD9051B/10	1004		TELEPHONES CORDED
TD9051B/18	1004		TELEPHONES CORDED
TD9051B/71	1004		TELEPHONES CORDED
TD9051H/02	1004		TELEPHONES CORDED
TD9051I/00	1004		TELEPHONES CORDED
TD9051I/02	1004		TELEPHONES CORDED
TD9051I/03	1004		TELEPHONES CORDED
TD9051I/08	1004	1.12.1999	TELEPHONES CORDED
TD9051I/19	1004		TELEPHONES CORDED
TD9051I/194	1004		TELEPHONES CORDED
TD9051I/71	1004		TELEPHONES CORDED
TD9053B/054	1004		TELEPHONES CORDED
TD9053W/021	1004		TELEPHONES CORDED
TD9053W/031	1004		TELEPHONES CORDED
TD9053W/051	1004		TELEPHONES CORDED
TD9053W/061	1004		TELEPHONES CORDED
TD9053W/091	1004		TELEPHONES CORDED

TD9053W/101	1004		TELEPHONES CORDED
TD9060G/05	1004		TELEPHONES CORDED
TD9061B/00	1004		TELEPHONES CORDED
TD9061B/009	1004		TELEPHONES CORDED
TD9061B/03	1004		TELEPHONES CORDED
TD9061I/00	1004		TELEPHONES CORDED
TD9061I/009	1004		TELEPHONES CORDED
TD9061I/03	1004		TELEPHONES CORDED
TD9061I/10	1004		TELEPHONES CORDED
TD9061I/16	1004		TELEPHONES CORDED
TD9061I/194	1004		TELEPHONES CORDED
TD9063T/78	1004		TELEPHONES CORDED
TD9063Z/00	1004		TELEPHONES CORDED
TD9063Z/32	1004		TELEPHONES CORDED
TD9064B/00	1004		TELEPHONES CORDED
TD9064B/10	1004		TELEPHONES CORDED
TD9064B/13	1004		TELEPHONES CORDED
TD9064B/16	1004		TELEPHONES CORDED
TD9064I/00	1004		TELEPHONES CORDED
TD9064I/03	1004		TELEPHONES CORDED
TD9064I/08	1004	1.12.1999	TELEPHONES CORDED
TD9064I/10	1004		TELEPHONES CORDED
TD9064I/16	1004		TELEPHONES CORDED
TD9065T/02	1004		TELEPHONES CORDED
TD9065T/08	1004	1.12.1999	TELEPHONES CORDED
TD9136B/03	1004		TELEPHONES CORDED
TD9136B/06	1004		TELEPHONES CORDED
TD9136B/18	1004		TELEPHONES CORDED
TD9136B/19	1004		TELEPHONES CORDED
TD9136B/194	1004		TELEPHONES CORDED
TD9136B/20	1004		TELEPHONES CORDED
TD9136I/00	1004		TELEPHONES CORDED
TD9136I/03	1004		TELEPHONES CORDED
TD9136I/10	1004		TELEPHONES CORDED
TD9136I/16	1004		TELEPHONES CORDED
TD9136I/18	1004		TELEPHONES CORDED
TD9136I/19	1004		TELEPHONES CORDED
TD9136I/194	1004		TELEPHONES CORDED
TD9136I/37	1004		TELEPHONES CORDED
TD9137T/78	1004		TELEPHONES CORDED
TD9137Z/78	1004		TELEPHONES CORDED
TD9141B/16	1004		TELEPHONES CORDED

TD9141G/10	1004		TELEPHONES CORDED
TD9142B/03	1004		TELEPHONES CORDED
TD9142B/10	1004		TELEPHONES CORDED
TD9142G/00	1004		TELEPHONES CORDED
TD9142G/03	1004		TELEPHONES CORDED
TD9142G/09	1004		TELEPHONES CORDED
TD9142G/10	1004		TELEPHONES CORDED
TD9150G/05	1004		TELEPHONES CORDED
TD9202A/02	1003		TELEPHONES CORDLESS
TD9202A/09	1003		TELEPHONES CORDLESS
TD9202A/109	1003		TELEPHONES CORDLESS
TD9203A/08	1003		TELEPHONES CORDLESS
TD9204A/06	1003		TELEPHONES CORDLESS
TD9204A/10	1003		TELEPHONES CORDLESS
TD9204A/20	1003		TELEPHONES CORDLESS
TD9206W/05	1003		TELEPHONES CORDLESS
TD9210T/00	1003		TELEPHONES CORDLESS
TD9210T/78	1003		TELEPHONES CORDLESS
TD9210T/86	1003		TELEPHONES CORDLESS
TD9213W/16	1003		TELEPHONES CORDLESS
TD9215T/00	1003		TELEPHONES CORDLESS
TD9215T/78	1003		TELEPHONES CORDLESS
TD9215T/86	1003		TELEPHONES CORDLESS
TD9220BK/031	1003		TELEPHONES CORDLESS
TD9220BK/161	1003	1.12.1999	TELEPHONES CORDLESS
TD9220BK/191	1003	1.12.1999	TELEPHONES CORDLESS
TD9220BK/194	1003	1.12.1999	TELEPHONES CORDLESS
TD9228T/78	1003		TELEPHONES CORDLESS
TD9228Z/16	1003		TELEPHONES CORDLESS
TD9238T/86	1003		TELEPHONES CORDLESS
TD9249B/03	1003		TELEPHONES CORDLESS
TD9249B/163	1003		TELEPHONES CORDLESS
TD9249B/19	1003		TELEPHONES CORDLESS
TD9249W/163	1003		TELEPHONES CORDLESS
TD9249W/19	1003		TELEPHONES CORDLESS
TD9280G/02	1004		TELEPHONES CORDED
TD9292A/19	1003		TELEPHONES CORDLESS
TD9294A/03	1003		TELEPHONES CORDLESS
TD9294A/16	1003		TELEPHONES CORDLESS
TD9335/05	1004	1.05.1993	TELEPHONES ANSWERING
TD9335/18	1004	1.06.1993	TELEPHONES ANSWERING
TD9335B/18	1004	1.07.1993	TELEPHONES ANSWERING

TD9335G/05	1004	1.05.1992	TELEPHONES ANSWERING
TD9336/02	1004	1.05.1993	TELEPHONES ANSWERING
TD9336/09	1004	1.09.1993	TELEPHONES ANSWERING
TD9336/18	1004	1.05.1993	TELEPHONES ANSWERING
TD9336B/02	1004	1.10.1992	TELEPHONES ANSWERING
TD9336G/02	1004	1.04.1992	TELEPHONES ANSWERING
TD9336G/18	1004	1.11.1992	TELEPHONES ANSWERING
TD9340/18R	1004	1.03.1992	TELEPHONES ANSWERING
TD9357/02	1004	1.09.1997	TELEPHONES ANSWERING
TD9357/08	1004	1.10.1997	TELEPHONES ANSWERING
TD9357/19	1004	1.10.1997	TELEPHONES ANSWERING
TD9357/194	1004	1.10.1997	TELEPHONES ANSWERING
TD9357Z/06	1004		TELEPHONES ANSWERING
TD9358/02	1004	1.06.1996	TELEPHONES ANSWERING
TD9358/03	1004	1.08.1996	TELEPHONES ANSWERING
TD9358/05	1004	1.06.1996	TELEPHONES ANSWERING
TD9358/08	1004	1.09.1996	TELEPHONES ANSWERING
TD9358/09	1004	1.03.1997	TELEPHONES ANSWERING
TD9358/10	1004	1.03.1997	TELEPHONES ANSWERING
TD9358/16	1004	1.11.1997	TELEPHONES ANSWERING
TD9358/19	1004	1.07.1996	TELEPHONES ANSWERING
TD9358/194	1004	1.07.1996	TELEPHONES ANSWERING
TD9358T/02	1004		TELEPHONES ANSWERING
TD9358T/08	1004		TELEPHONES ANSWERING
TD9358T/19	1004		TELEPHONES ANSWERING
TD9358T/194	1004		TELEPHONES ANSWERING
TD9358Z/05	1004		TELEPHONES ANSWERING
TD9359/00	1004	1.11.1994	TELEPHONES ANSWERING
TD9359/02	1004	1.01.1995	TELEPHONES ANSWERING
TD9359/08	1004	1.11.1995	TELEPHONES ANSWERING
TD9359/09	1004	1.07.1995	TELEPHONES ANSWERING
TD9359/10	1004	1.06.1995	TELEPHONES ANSWERING
TD9359/13	1004	1.08.1996	TELEPHONES ANSWERING
TD9359/16	1004	1.01.1996	TELEPHONES ANSWERING
TD9359/18	1004	1.12.1994	TELEPHONES ANSWERING
TD9359/19	1004	1.04.1996	TELEPHONES ANSWERING
TD9359/194	1004	1.04.1996	TELEPHONES ANSWERING
TD9359/20	1004	1.08.1996	TELEPHONES ANSWERING
TD9359A/00	1004		TELEPHONES ANSWERING
TD9359A/08	1004		TELEPHONES ANSWERING
TD9359A/09	1004		TELEPHONES ANSWERING
TD9359A/10	1004		TELEPHONES ANSWERING

TD9359A/13	1004		TELEPHONES ANSWERING
TD9359A/16	1004		TELEPHONES ANSWERING
TD9359A/19	1004		TELEPHONES ANSWERING
TD9359A/20	1004		TELEPHONES ANSWERING
TD9361/00	1004	1.03.1996	TELEPHONES ANSWERING
TD9361/02	1004	1.02.1995	TELEPHONES ANSWERING
TD9361/03	1004	1.11.1994	TELEPHONES ANSWERING
TD9361/16	1004	1.03.1995	TELEPHONES ANSWERING
TD9361/18	1004	1.09.1994	TELEPHONES ANSWERING
TD9361/19	1004	1.04.1996	TELEPHONES ANSWERING
TD9361/194	1004	1.04.1996	TELEPHONES ANSWERING
TD9361A/00	1004		TELEPHONES ANSWERING
TD9361A/03	1004		TELEPHONES ANSWERING
TD9361I/03	1004		TELEPHONES ANSWERING
TD9361I/194	1004		TELEPHONES ANSWERING
TD9362/02	1004	1.04.1992	TELEPHONES ANSWERING
TD9362/08	1004	1.09.1996	TELEPHONES ANSWERING
TD9362/09	1004	1.03.1992	TELEPHONES ANSWERING
TD9362/16	1004	1.05.1993	TELEPHONES ANSWERING
TD9362/18R	1004	1.05.1992	TELEPHONES ANSWERING
TD9362/19	1004	1.04.1996	TELEPHONES ANSWERING
TD9362/194	1004	1.04.1996	TELEPHONES ANSWERING
TD9362B/16	1004	1.03.1992	TELEPHONES ANSWERING
TD9362T/08	1004		TELEPHONES ANSWERING
TD9362Z/194	1004		TELEPHONES ANSWERING
TD9363/081	1004	1.04.1998	TELEPHONES ANSWERING
TD9363/09	1004	1.05.1993	TELEPHONES ANSWERING
TD9363/16	1004	1.05.1993	TELEPHONES ANSWERING
TD9363/191	1004	1.04.1998	TELEPHONES ANSWERING
TD9363/194	1004	1.04.1998	TELEPHONES ANSWERING
TD9363A/09	1004	1.06.1992	TELEPHONES ANSWERING
TD9363A/16	1004	1.07.1992	TELEPHONES ANSWERING
TD9363BSH/021	1004		TELEPHONES ANSWERING
TD9363BSH/031	1004		TELEPHONES ANSWERING
TD9363BSH/051	1004		TELEPHONES ANSWERING
TD9363BSH/061	1004		TELEPHONES ANSWERING
TD9363BSH/081	1004	1.11.1999	TELEPHONES ANSWERING
TD9363BSH/091	1004		TELEPHONES ANSWERING
TD9363BSH/101	1004		TELEPHONES ANSWERING
TD9363BSH/131	1004		TELEPHONES ANSWERING
TD9363BSH/161	1004		TELEPHONES ANSWERING
TD9363BSH/191	1004	1.11.1999	TELEPHONES ANSWERING

TD9363BSH/194	1004	1.11.1999	TELEPHONES ANSWERING
TD9363BSH/201	1004		TELEPHONES ANSWERING
TD9363BSH/781	1004		TELEPHONES ANSWERING
TD9363NIW/021	1004		TELEPHONES ANSWERING
TD9363NIW/051	1004		TELEPHONES ANSWERING
TD9363NIW/061	1004		TELEPHONES ANSWERING
TD9363NIW/081	1004		TELEPHONES ANSWERING
TD9363NIW/091	1004		TELEPHONES ANSWERING
TD9363NIW/101	1004		TELEPHONES ANSWERING
TD9363NIW/131	1004		TELEPHONES ANSWERING
TD9363NIW/161	1004		TELEPHONES ANSWERING
TD9363NIW/191	1004		TELEPHONES ANSWERING
TD9363NIW/194	1004		TELEPHONES ANSWERING
TD9368BSH/021	1004		TELEPHONES ANSWERING
TD9368BSH/051	1004		TELEPHONES ANSWERING
TD9368BSH/081	1004	1.12.1999	TELEPHONES ANSWERING
TD9368BSH/191	1004	1.11.1999	TELEPHONES ANSWERING
TD9368BSH/194	1004	1.12.1999	TELEPHONES ANSWERING
TD9368NIW/021	1004		TELEPHONES ANSWERING
TD9368NIW/051	1004		TELEPHONES ANSWERING
TD9368NIW/081	1004		TELEPHONES ANSWERING
TD9368NIW/191	1004		TELEPHONES ANSWERING
TD9368NIW/194	1004		TELEPHONES ANSWERING
TD9450A/56	1004	1.03.1992	TELEPHONES ANSWERING
TD9450G/56	1004	1.03.1992	TELEPHONES ANSWERING
TD9451A/18	1004	1.03.1992	TELEPHONES ANSWERING
TD9460/16	1004	1.05.1993	TELEPHONES ANSWERING
TD9460/19A	1004	1.03.1992	TELEPHONES ANSWERING
TD9460A/16	1004	1.10.1992	TELEPHONES ANSWERING
TD9461/08	1004	1.12.1997	TELEPHONES ANSWERING
TD9461/19	1004	1.01.1998	TELEPHONES ANSWERING
TD9461/194	1004	1.01.1998	TELEPHONES ANSWERING
TD9462/02	1004	1.09.1996	TELEPHONES ANSWERING
TD9462/08	1004	1.10.1996	TELEPHONES ANSWERING
TD9462/19	1004	1.10.1996	TELEPHONES ANSWERING
TD9462/194	1004	1.12.1996	TELEPHONES ANSWERING
TD9462T/02	1004		TELEPHONES ANSWERING
TD9462T/08	1004	1.11.1999	TELEPHONES ANSWERING
TD9462T/19	1004	1.12.1999	TELEPHONES ANSWERING
TD9462T/194	1004		TELEPHONES ANSWERING
TD9465/18	1004	1.05.1993	TELEPHONES ANSWERING
TD9465/19	1004	1.08.1996	TELEPHONES ANSWERING

TD9465B/18	1004	1.12.1992	TELEPHONES ANSWERING
TD9466/18	1004	1.05.1993	TELEPHONES ANSWERING
TD9466B/18	1004	1.12.1992	TELEPHONES ANSWERING
TD9470/00	1004	1.03.1996	TELEPHONES ANSWERING
TD9470/02	1004	1.06.1995	TELEPHONES ANSWERING
TD9470/03	1004	1.08.1995	TELEPHONES ANSWERING
TD9470/08	1004	1.05.1996	TELEPHONES ANSWERING
TD9470/09	1004	1.08.1996	TELEPHONES ANSWERING
TD9470/10	1004	1.09.1995	TELEPHONES ANSWERING
TD9470/16	1004	1.07.1995	TELEPHONES ANSWERING
TD9470/18	1004	1.02.1995	TELEPHONES ANSWERING
TD9470/19	1004	1.04.1996	TELEPHONES ANSWERING
TD9470/194	1004	1.04.1996	TELEPHONES ANSWERING
TD9470A/02	1004		TELEPHONES ANSWERING
TD9470A/08	1004		TELEPHONES ANSWERING
TD9470A/09	1004		TELEPHONES ANSWERING
TD9470A/10	1004		TELEPHONES ANSWERING
TD9470A/19	1004		TELEPHONES ANSWERING
TD9470C/19	1004		TELEPHONES ANSWERING
TD9470I/00	1004		TELEPHONES ANSWERING
TD9470I/03	1004		TELEPHONES ANSWERING
TD9470I/16	1004		TELEPHONES ANSWERING
TD9470I/19	1004		TELEPHONES ANSWERING
TD9470I/194	1004		TELEPHONES ANSWERING
TD9471/02	1004	1.05.1997	TELEPHONES ANSWERING
TD9471/08	1004	1.11.1997	TELEPHONES ANSWERING
TD9471/19	1004	1.06.1997	TELEPHONES ANSWERING
TD9471/194	1004	1.06.1997	TELEPHONES ANSWERING
TD9471X/19	1004		TELEPHONES ANSWERING
TD9473/081	1004	1.05.1998	TELEPHONES ANSWERING
TD9473/191	1004	1.05.1998	TELEPHONES ANSWERING
TD9473/194	1004	1.06.1998	TELEPHONES ANSWERING
TD9473W/021	1004		TELEPHONES ANSWERING
TD9473W/051	1004		TELEPHONES ANSWERING
TD9473W/081	1004		TELEPHONES ANSWERING
TD9473W/091	1004		TELEPHONES ANSWERING
TD9473W/101	1004		TELEPHONES ANSWERING
TD9473W/161	1004		TELEPHONES ANSWERING
TD9473W/194	1004		TELEPHONES ANSWERING
TD9481/02	1004	1.05.1993	TELEPHONES ANSWERING
TD9481/18	1004	1.09.1993	TELEPHONES ANSWERING
TD9481G/02	1004	1.06.1992	TELEPHONES ANSWERING

TD9571A/02	1003		TELEPHONES CORDLESS
TD9571A/03	1003		TELEPHONES CORDLESS
TD9571A/04	1003		TELEPHONES CORDLESS
TD9571A/05	1003		TELEPHONES CORDLESS
TD9571A/06	1003		TELEPHONES CORDLESS
TD9571A/08	1003		TELEPHONES CORDLESS
TD9571A/09	1003		TELEPHONES CORDLESS
TD9571A/10	1003		TELEPHONES CORDLESS
TD9571A/13	1003		TELEPHONES CORDLESS
TD9571A/14	1003		TELEPHONES CORDLESS
TD9571A/19	1003		TELEPHONES CORDLESS
TD9571A/20	1003		TELEPHONES CORDLESS
TD9603A/16	1003		TELEPHONES CORDLESS
TD9603B/19	1003		TELEPHONES CORDLESS
TD9603W/16	1003		TELEPHONES CORDLESS
TD9603W/19	1003		TELEPHONES CORDLESS
TD9606W/05	1003		TELEPHONES CORDLESS
TD9694A/03	1003		TELEPHONES CORDLESS
TD9694A/08	1003		TELEPHONES CORDLESS
TD9694A/19	1003		TELEPHONES CORDLESS
TD9841A/953	1003		TELEPHONES CORDLESS
TD9841P/953	1003		TELEPHONES CORDLESS
TD9871A/02	1003		TELEPHONES CORDLESS
TD9871A/03	1003		TELEPHONES CORDLESS
TD9871A/04	1003		TELEPHONES CORDLESS
TD9871A/05	1003		TELEPHONES CORDLESS
TD9871A/06	1003		TELEPHONES CORDLESS
TD9871A/08	1003	1.11.1999	TELEPHONES CORDLESS
TD9871A/09	1003		TELEPHONES CORDLESS
TD9871A/10	1003		TELEPHONES CORDLESS
TD9871A/13	1003		TELEPHONES CORDLESS
TD9871A/14	1003		TELEPHONES CORDLESS
TD9871A/19	1003		TELEPHONES CORDLESS
TD9871A/20	1003		TELEPHONES CORDLESS
TD9893A/03	1003		TELEPHONES CORDLESS
TD9893A/19	1003		TELEPHONES CORDLESS
TD9894A/08	1003		TELEPHONES CORDLESS
TH189/37	1049	1.08.1992	MIDISYSTEMS
TH892/17	1049	1.10.1992	MIDISYSTEMS
TK503/18	1049	1.09.1993	MIDISYSTEMS
TL24A5T/,,	2010		OBSERVATION SYSTEMS
TL24R/00	2010	TL-VCR	OBSERVATION SYSTEMS

TL960A5T/,,	2010		OBSERVATION SYSTEMS
TR16S/00	1041Radio + Cassette	1.12.1999	PERSONAL STEREO
TR16S/00B	1041Radio + Cassette	1.12.1999	PERSONAL STEREO
TR22AX/00	1041Radio + Cassette	1.12.1999	PERSONAL STEREO
TR22AX/00W	1041Cassette only		PERSONAL STEREO
TR5500/00	1041Radio + Cassette		PERSONAL STEREO
TR9559/00	1041Radio cassette recorders - mono		RADIO MONO + STEREO
TR9559/00W	1041Radio cassette recorders - mono		RADIO MONO + STEREO
TT9053H/921	1004		TELEPHONES CORDED
TT9136B/93	1004		TELEPHONES CORDED
TT9202A/08	1003		TELEPHONES CORDLESS
TT9470/93	1004	1.04.1997	TELEPHONES ANSWERING
TUDINICAM/00	2012Institutional analogue		SATELLITE
TVB441/022	1022Leader	1.11.1995	TVCR
TVR-445	1022Leader		TVCR
TVR3700FR	1022Leader		TVCR
TVR3701SV/1	1022Leader		TVCR
TVR3701SV/2	1022Leader		TVCR
TVR3701SV/3	1022Leader		TVCR
TVR3701SV/FR	1022Leader		TVCR
TVR3705/1	1022Leader		TVCR
TVR3705/2	1022Leader		TVCR
TVR3705/3	1022Leader		TVCR
TVR3705FR	1022Leader		TVCR
TVR3710/1	1022Leader		TVCR
TVR3710FR	1022Leader		TVCR
TVR3710GB	1022Leader		TVCR
TVR3720/1	1022Leader		TVCR
TVR3720GB	1022Leader		TVCR
TVR5100/1	1022Leader		TVCR
TVR5100/2	1022Leader		TVCR
TVR5100/3	1022Leader		TVCR
TVR5100FR	1022Leader		TVCR
TVR5100GB	1022Leader		TVCR
TVR5120FR	1022Leader		TVCR
TVR5500/1	1022High-end		TVCR
TVR5500FR	1022High-end		TVCR
TVR5530ST/ERE	1022High-end		TVCR
VC11000R/,,	2010	VCM	OBSERVATION SYSTEMS
VC11625R/,,	2010		OBSERVATION SYSTEMS
VC13525T/,,	2010		OBSERVATION SYSTEMS
VC311050/,,	2010	X1-B/W	OBSERVATION SYSTEMS

VC315150/,,	2010			OBSERVATION SYSTEMS
VC391050/,,	2010			OBSERVATION SYSTEMS
VC425050/,,	2010	X2-COLOUR		OBSERVATION SYSTEMS
VC445050/,,	2010	X4-COLOUR		OBSERVATION SYSTEMS
VC61105T/,,	2010	X1-B/W		OBSERVATION SYSTEMS
VC61505T/,,	2010	X1-B/W		OBSERVATION SYSTEMS
VC71375T/,,	2010	X1-COLOUR		OBSERVATION SYSTEMS
VC71385T/,,	2010	X1-COLOUR		OBSERVATION SYSTEMS
VC71775T/,,	2010	X1-COLOUR		OBSERVATION SYSTEMS
VC71785T/,,	2010	X1-COLOUR		OBSERVATION SYSTEMS
VC72505T/,,	2010	X2-COLOUR		OBSERVATION SYSTEMS
VC81605R/,,	2010	X1-B/W		OBSERVATION SYSTEMS
VC81615R/,,	2010	X1-B/W		OBSERVATION SYSTEMS
VC86305R/,,	2010			OBSERVATION SYSTEMS
VC86375T/,,	2010			OBSERVATION SYSTEMS
VC86775T/,,	2010			OBSERVATION SYSTEMS
VC867775T/,,	2010			OBSERVATION SYSTEMS
VC86785T/,,	2010			OBSERVATION SYSTEMS
VC89355T/,,	2010	X9-B/W		OBSERVATION SYSTEMS
VC89705T/,,	2010	X9-B/W		OBSERVATION SYSTEMS
VC89715R/,,	2010	X9-B/W		OBSERVATION SYSTEMS
VC89715T/,,	2010	X9-B/W		OBSERVATION SYSTEMS
VC89755T/,,	2010	X9-B/W		OBSERVATION SYSTEMS
VC89765T/,,	2010	X9-B/W		OBSERVATION SYSTEMS
VC89775T/,,	2010			OBSERVATION SYSTEMS
VC89785T/,,	2010			OBSERVATION SYSTEMS
VC91755T/,,	2010	X1S-COLOUR		OBSERVATION SYSTEMS
VC91765T/,,	2010	X1S-COLOUR		OBSERVATION SYSTEMS
VCD923/00	1049CD		1.01.1995	CD PLAYERS
VCD923/02	1049CD		1.02.1995	CD PLAYERS
VCD923/17	1049CD		1.01.1995	CD PLAYERS
VCD928/00	1049CD		1.07.1995	CD PLAYERS
VCD928/02	1049CD		1.09.1995	CD PLAYERS
VCD928/17	1049CD		1.07.1995	CD PLAYERS
VCM1100/00T	6010	VCM		OBSERVATION SYSTEMS
VCM1150/00T	6010	VCM		OBSERVATION SYSTEMS
VCM1151/00T	6010	VCM		OBSERVATION SYSTEMS
VCM1152/00T	6010	VCM		OBSERVATION SYSTEMS
VCM1161/00R		VCM		OBSERVATION SYSTEMS
VCM1161/01R		VCM		OBSERVATION SYSTEMS
VCM1162/00R	6010	VCM		OBSERVATION SYSTEMS
VCM1162/01R	6010	VCM		OBSERVATION SYSTEMS

VCM1352/00T	6010	ACC	OBSERVATION SYSTEMS
VCM2104/00R	2010	VCM	OBSERVATION SYSTEMS
VCM2106/00R	2010	VCM	OBSERVATION SYSTEMS
VCM2108/00	6010		OBSERVATION SYSTEMS
VCM2108/00R	6010	VCM	OBSERVATION SYSTEMS
VCM2112/00R	2010	VCM	OBSERVATION SYSTEMS
VCM2124/00R	2010	VCM	OBSERVATION SYSTEMS
VCM2128/00R	2010	VCM	OBSERVATION SYSTEMS
VCM3110/00	2010	X1-B/W	OBSERVATION SYSTEMS
VCM3150/00	2010	X1-B/W	OBSERVATION SYSTEMS
VCM4250/00	2010	X2-COLOUR	OBSERVATION SYSTEMS
VCM6110/00T	2010	X1-B/W	OBSERVATION SYSTEMS
VCM6150/00T	2010	X1-B/W	OBSERVATION SYSTEMS
VCM6159/00T	2010	X1-B/W	OBSERVATION SYSTEMS
VCM6159/05T	2010	X1-B/W	OBSERVATION SYSTEMS
VCM6259/00T	2010	X2-B/W	OBSERVATION SYSTEMS
VCM6259/05T	2010	X2-B/W	OBSERVATION SYSTEMS
VCM7137/00T	6010	X1-COLOUR	OBSERVATION SYSTEMS
VCM7138/00T	6010	X1-COLOUR	OBSERVATION SYSTEMS
VCM7158/00T	2010	X1-COLOUR	OBSERVATION SYSTEMS
VCM7159/00T	2010	X1-COLOUR	OBSERVATION SYSTEMS
VCM7159/05T	2010	X1-COLOUR	OBSERVATION SYSTEMS
VCM7177/00T	6010	X1-COLOUR	OBSERVATION SYSTEMS
VCM7177/54T	6010	X1-COLOUR	OBSERVATION SYSTEMS
VCM7178/00T	6010	X1-COLOUR	OBSERVATION SYSTEMS
VCM7250/00T	2010	X2-COLOUR	OBSERVATION SYSTEMS
VCM7259/00T	2010	X2-COLOUR	OBSERVATION SYSTEMS
VCM7A37/00T	6010		OBSERVATION SYSTEMS
VCM7A38/00T	6010		OBSERVATION SYSTEMS
VCM7A77/00T	6010	VM7	OBSERVATION SYSTEMS
VCM7A79/00T	6010	X-FILES	OBSERVATION SYSTEMS
VCM8120/00T	6010	X1-B/W	OBSERVATION SYSTEMS
VCM8120/01T	6010	X1-B/W	OBSERVATION SYSTEMS
VCM8160/00T	6010	X1-B/W	OBSERVATION SYSTEMS
VCM8160/01T	6010	X1-B/W	OBSERVATION SYSTEMS
VCM8161/00T	6010	X1-B/W	OBSERVATION SYSTEMS
VCM8161/01T	6010	X1-B/W	OBSERVATION SYSTEMS
VCM8175/00T	6010	X1S-B/W	OBSERVATION SYSTEMS
VCM8175/19T	6010	X1S-B/W	OBSERVATION SYSTEMS
VCM8176/00T	6010	X1S-B/W	OBSERVATION SYSTEMS
VCM8630/00R	6010		OBSERVATION SYSTEMS
VCM8637/00T	6010	X6-B/W	OBSERVATION SYSTEMS

VCM8638/00T	6010	X6-B/W		OBSERVATION SYSTEMS
VCM8932/00T	6010			OBSERVATION SYSTEMS
VCM8935/00T	6010	X9-B/W		OBSERVATION SYSTEMS
VCM8936/00T	6010	X9-B/W		OBSERVATION SYSTEMS
VCM9175/00T	6010	X1S-COLOUR		OBSERVATION SYSTEMS
VCM9175/19T	6010	X1S-COLOUR		OBSERVATION SYSTEMS
VCM9176/00T	6010	X1S-COLOUR		OBSERVATION SYSTEMS
VCP1000/99	1021Leader		1.10.1992	VCR
VCP2100/99	1021Leader		1.03.1992	VCR
VCP2200/99	1021Leader		1.03.1992	VCR
VCP2800/99	1021Leader		1.04.1992	VCR
VCP3100/99	1021Leader		1.05.1994	VCR
VCP3200/99	1021Leader		1.04.1992	VCR
VCP3300/99	1021Leader		1.10.1993	VCR
VCP3800/99	1021Leader		1.08.1992	VCR
VCP3900/99	1021Leader		1.10.1993	VCR
VCR8100/99	1021Leader		1.03.1992	VCR
VCS21N/EA	2010			OBSERVATION SYSTEMS
VCS21NEA/,,	2010			OBSERVATION SYSTEMS
VCS21NFA/,,	2010			OBSERVATION SYSTEMS
VCS21NSA/,,	2010			OBSERVATION SYSTEMS
VCT425/99	1021Leader			VCR
VCT445/99	1021Leader show view			VCR
VCT565/99	1021Leader			VCR
VCU442/99	1021Leader show view		1.10.1996	VCR
VCU464/99	1021Leader		1.10.1996	VCR
VCX442/99	1021Leader show view			VCR
VCX462/99	1021Leader			VCR
VEGA-PTT/08	1006Philips thermal fax			FAXES
VISIOPASS/1.7	2012Institutional analogue			SATELLITE
VK26/93	1021Step-up show view			VCR
VK556/55	1021Step-up show view		1.10.1996	VCR
VK8300/99	1021Leader		1.03.1992	VCR
VK8800/99	1021Leader		1.03.1992	VCR
VK8900/99	1021Leader		1.10.1993	VCR
VK956/55	1021High-end		1.11.1996	VCR
VKR6841/00		J		CAMCORDERS
VKR6843/20		M		CAMCORDERS
VKR6847/20		M	1.11.1999	CAMCORDERS
VKR6853/21		M		CAMCORDERS
VKR6855/20		M		CAMCORDERS
VKR6860/20		P		CAMCORDERS

VKR6860/21		P		CAMCORDERS
VKR6870/20		J		CAMCORDERS
VKR6880/21		J		CAMCORDERS
VKR6890/21		M		CAMCORDERS
VKR9015/21		M		CAMCORDERS
VN7000	1021Leader		1.09.1996	VCR
VN8000	1021Leader		1.07.1997	VCR
VN8000PDC	1021Leader		1.06.1997	VCR
VOLKER/09	1006Philips thermal fax			FAXES
VP16/55	1021Step-up show view			VCR
VP2100B/99	1021Leader		1.12.1994	VCR
VP2200A/99	1021Leader		1.12.1993	VCR
VP2200B/99	1021Leader		1.07.1995	VCR
VP225/58	1021Leader		1.10.1995	VCR
VP2300	1021Leader		1.11.1994	VCR
VP2350	1021Leader		1.07.1995	VCR
VP2360	1021Leader		1.06.1996	VCR
VP2400	1021Leader show view		1.07.1997	VCR
VP2400PDC	1021Leader		1.06.1997	VCR
VP26/53	1021Step-up show view	U12		VCR
VP26/57	1021Step-up show view			VCR
VP28/55	1021Step-up show view	VCR_INKOOOP	1.04.1998	VCR
VP3230/95	1021Leader		1.03.1992	VCR
VP37/55	1021Step-up show view			VCR
VP3900A/99	1021Leader		1.11.1994	VCR
VP58/55	1021Step-up show view	VCR_INKOOOP	1.03.1998	VCR
VP9004/76	1021Leader		1.03.1992	VCR
VP9204/76	1021Leader		1.06.1992	VCR
VR-BG2/99	1021Leader		1.10.1996	VCR
VR-BG3/99	1021Leader			VCR
VR-G1/99	1021Leader		1.09.1996	VCR
VR-G2/99	1021Leader		1.02.1997	VCR
VR-G3/99	1021Leader		1.10.1997	VCR
VR-G8/99	1021Leader			VCR
VR-G88/99	1021Leader			VCR
VR-H2/99	1021Leader		1.09.1996	VCR
VR-H3/99	1021Leader		1.10.1996	VCR
VR-H4/99	1021Leader			VCR
VR-S88/99	1021Leader			VCR
VR10/58	1021Leader			VCR
VR1000/02	1021Step-up	PJVM	1.08.1999	VCR
VR1000/02X	1021Step-up	PJVM	1.09.1999	VCR

VR1000/07	1021Step-up	PJVM	1.09.1999	VCR
VR1000/39	1021Step-up	PJVM	1.10.1999	VCR
VR101/00P	Subleader	APOLLO12		VCR
VR101/02	1021Subleader	APOLLO12	1.03.2000	VCR
VR101/39	1021Subleader	APOLLO12	1.04.2000	VCR
VR101/58	1021Subleader	APOLLO12	1.03.2000	VCR
VR101DE	1021Leader show view	APOLLO12	1.04.2000	VCR
VR101ES	1021Leader show view	APOLLO12	1.04.2000	VCR
VR101XE	1021Leader show view	APOLLO12	1.04.2000	VCR
VR110/02	1021Leader	APOLLO12	1.05.2000	VCR
VR110/07	1021Leader	APOLLO12	1.05.2000	VCR
VR110/16	Subleader	APOLLO12		VCR
VR110/58	1021Leader	APOLLO12	1.04.2000	VCR
VR110/ES	1021Subleader	APOLLO12	1.10.2000	VCR
VR1100/02	1021Step-up	PJVM	1.07.2000	VCR
VR1100/02X	1021Step-up	PJVM	1.07.2000	VCR
VR1100/07	1021Step-up	PJVM	1.03.2001	VCR
VR1100/39	1021Step-up	PJVM	1.09.2000	VCR
VR1100/58X	1021Step-up	PJVM		VCR
VR110DE	1021Leader	APOLLO12	1.04.2000	VCR
VR110ES	1021Leader	APOLLO12	1.07.2000	VCR
VR110GR	1021Leader	APOLLO12	1.05.2000	VCR
VR110XE	1021Leader	APOLLO12	1.05.2000	VCR
VR120/02	Subleader			VCR
VR120/55	Subleader			VCR
VR120/58	Subleader			VCR
VR120/GR	1021Subleader	APOLLO13	1.05.2001	VCR
VR120/XE	Subleader			VCR
VR1200/02	1021Step-up	PJVM	1.09.2001	VCR
VR1200/02X	1021Step-up	PJVM	1.10.2001	VCR
VR1200/39	1021Step-up	PJVM	1.10.2001	VCR
VR1200/58	1021Step-up	PJVM	1.09.2001	VCR
VR122/02	1021Subleader	FUNAI	1.09.2001	VCR
VR122/58	1021Subleader	FUNAI	1.10.2001	VCR
VR1500/02	1021High-end	PJVM	1.09.1999	VCR
VR1500/58	1021High-end	PJVM	1.08.1999	VCR
VR1500/58X	1021High-end	PJVM	1.09.1999	VCR
VR151/01	1021Leader	OLIVIA_ECN	1.04.1995Economy	VCR
VR151/02	1021Leader	OLIVIA_ECN	1.04.1995Economy	VCR
VR151/03	1021Leader	OLIVIA_ECN	1.04.1995Economy	VCR
VR151/05	1021Leader	OLIVIA_ECN	1.04.1995Economy	VCR
VR151/06	1021Leader	OLIVIA_ECN	1.10.1995Economy	VCR

VR151/07	1021Leader	OLIVIA_ECN	1.06.1995Economy	VCR
VR151/10	1021Leader	OLIVIA_ECN	1.07.1995Economy	VCR
VR151/13	1021Leader	OLIVIA_ECN	1.06.1995Economy	VCR
VR151/59	1021Leader	OLIVIA_ECN	1.06.1995Economy	VCR
VR151/59R	1021Leader	OLIVIA_ECN	1.12.1995Economy	VCR
VR1541/05	1021Leader	VCR_INKOOOP	1.11.1994	VCR
VR155/55	1021Step-up show view	PJVM	1.09.1996	VCR
VR155/75	1021Leader	PJVM	1.09.1996	VCR
VR157/05	1021Leader	OLIVIA_ECN	1.07.1995Economy	VCR
VR157/07	1021Leader	OLIVIA_ECN	1.06.1995Economy	VCR
VR1600/58	1021High-end	PJVM	1.12.2000	VCR
VR1600/58X	1021High-end	PJVM	1.12.2000	VCR
VR161/01	1021Leader	PAULIN_ECN	1.06.1996Economy	VCR
VR161/02	1021Leader	PAULIN_ECN	1.06.1996Economy	VCR
VR161/07	1021Leader	PAULIN_ECN	1.08.1996Economy	VCR
VR161/08	1021Leader	PAULIN_ECN	1.09.1996Economy	VCR
VR161/13	1021Leader	PAULIN_ECN	1.08.1996Economy	VCR
VR161/60	1021Leader	PAULIN_ECN	1.11.1996Economy	VCR
VR165/02	1021Leader show view	PAULIN_ECN	1.06.1996Economy	VCR
VR165/03	1021Leader show view	PAULIN_ECN	1.07.1996Economy	VCR
VR165/05	1021Leader	PAULIN_ECN	1.05.1996Economy	VCR
VR165/07	1021Leader show view	PAULIN_ECN	1.09.1996Economy	VCR
VR165/13	1021Leader	PAULIN_ECN	1.09.1996Economy	VCR
VR170/02	1021Leader show view	APOLLO13	1.04.2001	VCR
VR170/07	1021Leader show view	APOLLO13	1.06.2001	VCR
VR170/39	1021Leader show view	APOLLO13	1.07.2001	VCR
VR170/58	1021Leader show view	APOLLO13	1.04.2001	VCR
VR170/ES	1021Leader show view	APOLLO13	1.05.2001	VCR
VR170/XE	1021Leader show view	APOLLO13	1.05.2001	VCR
VR171/02	1021Leader	QUEEN_VL	1.05.1997Volume Line	VCR
VR171/02D	1021Leader	QUEEN_VL	1.10.1998Volume Line	VCR
VR171/07	1021Leader	QUEEN_VL	1.09.1997Volume Line	VCR
VR171/13	1021Leader	QUEEN_VL	1.09.1997Volume Line	VCR
VR171/16	1021Leader	QUEEN_VL	1.05.1997Volume Line	VCR
VR171/58	1021Leader	QUEEN_VL	1.07.1997Volume Line	VCR
VR175/02	1021Leader show view	QUEEN_VL	1.05.1997Volume Line	VCR
VR175/02A	1021Leader show view	QUEEN_VL	1.04.1998Volume Line	VCR
VR175/02D	1021Leader	QUEEN_VL	1.08.1998Volume Line	VCR
VR175/05	1021Leader show view	QUEEN_VL	1.05.1997Volume Line	VCR
VR175/07	1021Leader show view	QUEEN_VL	1.09.1997Volume Line	VCR
VR175/13	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR175/16	1021Leader show view	QUEEN_VL	1.05.1997Volume Line	VCR

VR175/39	1021Leader show view	QUEEN_VL	1.05.1997Volume Line	VCR
VR1835/76	1021Leader	VCR_INKOOOP	1.07.1992	VCR
VR200/02	1021Leader show view	APOLLO11	1.04.1999	VCR
VR200/05	1021Leader show view	APOLLO11	1.04.1999	VCR
VR200/07	1021Leader show view	APOLLO11	1.04.1999	VCR
VR200/39	1021Leader show view	APOLLO11	1.04.1999	VCR
VR200/58	1021Leader show view	APOLLO11	1.03.1999	VCR
VR200A/02	1021Leader show view	APOLLO11	1.10.2000	VCR
VR200A/07	1021Leader show view	APOLLO11		VCR
VR200A/39	1021Leader show view	APOLLO11	1.10.2000	VCR
VR200A/58	1021Leader show view	APOLLO11	1.07.2000	VCR
VR200AD	1021Leader show view	APOLLO11		VCR
VR200AE	1021Leader show view	APOLLO11		VCR
VR200AG	1021Leader show view	APOLLO11		VCR
VR200AX	1021Leader show view	APOLLO11		VCR
VR200DE	1021Leader show view	APOLLO11	1.04.1999	VCR
VR200ES	1021Leader show view	APOLLO11	1.04.1999	VCR
VR200GR	1021Leader show view	APOLLO11	1.07.1999	VCR
VR200XE	1021Leader show view	APOLLO11	1.05.1999	VCR
VR201/01	1021Leader	JASMIN_STN	1.03.1994Standard	VCR
VR202/01	1021Leader	JASMIN_STN	1.09.1994Standard	VCR
VR203/02	1021Leader	JASMIN_STN	1.05.1994Standard	VCR
VR203/05	1021Leader	JASMIN_STN	1.09.1994Standard	VCR
VR203/16	1021Leader	JASMIN_STN	1.03.1994Standard	VCR
VR205/02	1021Leader show view	APOLLO11	1.05.1999	VCR
VR205/05	1021Leader show view	APOLLO11	1.07.1999	VCR
VR205DE	1021Leader show view	APOLLO11	1.05.1999	VCR
VR205ES	1021Leader show view		1.06.1999	VCR
VR205XE	1021Leader show view	APOLLO11	1.06.1999	VCR
VR20D/07	1021DVHS	DIGITAL_VCR	1.04.2000	DIGITAL VCR
VR20D/39	1021DVHS	DIGITAL_VCR	1.04.2000	DIGITAL VCR
VR20D/58	1021DVHS	DIGITAL_VCR	1.12.1999	DIGITAL VCR
VR210/02	1021Leader show view	APOLLO12	1.05.2000	VCR
VR210/07	1021Leader	APOLLO12	1.05.2000	VCR
VR210/39	1021Leader	APOLLO12	1.09.2000	VCR
VR210/58	1021Leader	APOLLO12	1.04.2000	VCR
VR210/60	1021Leader	APOLLO12	1.07.2000	VCR
VR210DE	1021Leader show view	APOLLO12	1.05.2000	VCR
VR210ES	1021Leader show view	APOLLO12	1.06.2000	VCR
VR210GR	1021Leader show view	APOLLO12	1.07.2000	VCR
VR210XE	1021Leader show view	APOLLO12	1.05.2000	VCR
VR211/01	1021Leader	KATE _STN	1.03.1994Standard	VCR

VR211/06M	1021Leader	KATE _STN	1.05.1994Standard	VCR
VR2115/59	1021Leader	JASMIN_STN	1.01.1993Standard	VCR
VR215/02	1021Leader show view	APOLLO12	1.06.2000	VCR
VR215/07	1021Leader show view	APOLLO12	1.07.2000	VCR
VR215DE	1021Leader show view	APOLLO12	1.07.2000	VCR
VR215ES	1021Leader show view	APOLLO12	1.07.2000	VCR
VR215XE	1021Leader show view	APOLLO12	1.07.2000	VCR
VR217/02	1021Leader show view	APOLLO12	1.06.2000	VCR
VR217/07	1021Leader show view	APOLLO12		VCR
VR217DE	1021Leader show view	APOLLO12	1.06.2000	VCR
VR217ES	1021Leader show view	APOLLO12	1.07.2000	VCR
VR217GR	1021Leader show view	APOLLO12		VCR
VR217XE	1021Leader show view	APOLLO12	1.07.2000	VCR
VR220/02	1021Leader show view	APOLLO13	1.04.2001	VCR
VR220/07	1021Leader show view	APOLLO13	1.05.2001	VCR
VR220/39	1021Leader show view	APOLLO13	1.06.2001	VCR
VR220/58	1021Leader show view	APOLLO13	1.04.2001	VCR
VR220/CH	1021Leader show view	APOLLO13	1.06.2001	VCR
VR220/GR	1021Leader show view	APOLLO13	1.05.2001	VCR
VR220/XE	1021Leader show view	APOLLO13	1.05.2001	VCR
VR231/01	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR231/02	1021Leader	MICHEL_STN	1.03.1994Standard	VCR
VR231/02W	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR231/05	1021Leader	MICHEL_STN	1.12.1994Standard	VCR
VR231/06	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR231/07	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR231/08	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR231/13	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR231/58	1021Leader	MICHEL_STN	1.03.1993Standard	VCR
VR231/59	1021Leader	MICHEL_STN	1.01.1993Standard	VCR
VR232/01	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR232/02	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR232/06	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR232/13	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR232/16	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR237/01	1021Leader	MICHEL_STN	1.03.1994Standard	VCR
VR237/02	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR237/08	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR237/13	1021Leader	MICHEL_STN	1.05.1995Standard	VCR
VR237/16	1021Leader	MICHEL_STN	1.04.1994Standard	VCR
VR241/02	1021Leader	NORA _STN	1.05.1994Standard	VCR
VR241/06	1021Leader	NORA _STN	1.08.1994Standard	VCR

VR241/08	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR241/10	1021Leader	NORA _STN	1.04.1994Standard	VCR
VR241/13	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR241/15	1021Leader	NORA _STN	1.09.1994Standard	VCR
VR241/58	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR241/59	1021Leader	NORA _STN	1.07.1995Standard	VCR
VR241/60	1021Leader	NORA _STN	1.02.1995Standard	VCR
VR2410/19	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR2419/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR242/02	1021Leader	NORA _STN	1.06.1994Standard	VCR
VR242/03	1021Leader	NORA _STN	1.09.1994Standard	VCR
VR242/13	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR242/16	1021Leader	NORA _STN	1.09.1994Standard	VCR
VR243/01	1021Leader	NORA _STN	1.04.1994Standard	VCR
VR243/13	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR245/02	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR2469/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR247/01	1021Leader	NORA _STN	1.08.1995Standard	VCR
VR247/02	1021Leader	NORA _STN	1.05.1994Standard	VCR
VR247/03	1021Leader	NORA _STN	1.09.1994Standard	VCR
VR247/06	1021Leader	NORA _STN	1.05.1994Standard	VCR
VR247/07	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR247/08	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR247/13	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR247/13X	1021Leader	NORA _STN	1.01.1995Standard	VCR
VR2479/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR250/02	1021Step-up show view	APOLLO11	1.05.1999	VCR
VR250/07	1021Step-up show view	APOLLO11		VCR
VR250/39	1021Step-up show view	APOLLO11	1.05.1999	VCR
VR250/58	1021Step-up show view	APOLLO11	1.06.1999	VCR
VR250DE	1021Step-up show view	APOLLO11	1.05.1999	VCR
VR250ES	1021Step-up show view	APOLLO11	1.05.1999	VCR
VR250XE	1021Step-up show view	APOLLO11	1.05.1999	VCR
VR251/01	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR251/13	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
VR251/39	1021Leader	OLIVIA_STN	1.12.1995Standard	VCR
VR252/01	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR252/02	1021Leader	OLIVIA_STN	1.06.1995Standard	VCR
VR252/02L	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
VR252/03	1021Leader	OLIVIA_STN	1.08.1995Standard	VCR
VR252/03L	1021Leader	OLIVIA_STN	1.12.1995Standard	VCR
VR252/13	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR

VR253/50	1021Step-up show view	VCR_INKOOOP	1.10.1993	VCR
VR253/55	1021Step-up show view	VCR_INKOOOP	1.10.1993	VCR
VR253/55S	1021Leader	VCR_INKOOOP	1.01.1994	VCR
VR253/57	1021Leader	VCR_INKOOOP	1.10.1993	VCR
VR253/75	1021Leader	VCR_INKOOOP	1.10.1993	VCR
VR253/77	1021Leader	VCR_INKOOOP	1.10.1993	VCR
VR254/50	1021Step-up show view	VCR_INKOOOP	1.07.1994	VCR
VR254/55	1021Step-up show view	VCR_INKOOOP	1.06.1994	VCR
VR254/75	1021Leader	VCR_INKOOOP	1.08.1994	VCR
VR254/93	1021Leader	VCR_INKOOOP	1.10.1994	VCR
VR2547/05	1021Leader	VCR_INKOOOP	1.11.1994	VCR
VR255/50	1021Step-up show view	VCR_INKOOOP	1.10.1995	VCR
VR255/55	1021Step-up show view	VCR_INKOOOP	1.03.1996	VCR
VR255/57	1021Step-up show view	VCR_INKOOOP	1.07.1997	VCR
VR255/75	1021Leader	VCR_INKOOOP	1.09.1996	VCR
VR255/93	1021Leader	VCR_INKOOOP	1.09.1996	VCR
VR255/97	1021Step-up show view	VCR_INKOOOP	1.09.1996	VCR
VR256/02	1021Step-up show view	OLIVIA_STN	1.10.1995Standard	VCR
VR256/02W	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR256/39	1021Leader	OLIVIA_STN	1.05.1995Standard	VCR
VR256/39L	1021Leader	OLIVIA_STN	1.11.1995Standard	VCR
VR256/58	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR256/75	1021Step-up show view	OLIVIA_STN	1.09.1996Standard	VCR
VR256/93	1021Step-up show view	OLIVIA_STN	1.09.1996Standard	VCR
VR256/97	1021Step-up show view	OLIVIA_STN	1.05.1997Standard	VCR
VR257/01	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR257/02	1021Leader	OLIVIA_STN	1.06.1995Standard	VCR
VR257/02L	1021Leader	OLIVIA_STN	1.08.1995Standard	VCR
VR257/03	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR257/13	1021Leader	OLIVIA_STN	1.08.1995Standard	VCR
VR257/50	1021Step-up show view	OLIVIA_STN	1.08.1997Standard	VCR
VR257/75	1021Step-up show view	OLIVIA_STN	1.09.1997Standard	VCR
VR258/02	1021Leader	OLIVIA_STN	1.07.1995Standard	VCR
VR258/02L	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR258/03	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR258/05	1021Leader	OLIVIA_STN	1.07.1995Standard	VCR
VR258/05L	1021Leader	OLIVIA_STN	1.02.1996Standard	VCR
VR258/06	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR258/39	1021Leader	OLIVIA_STN	1.08.1995Standard	VCR
VR260/02	1021Step-up show view	APOLLO12	1.05.2000	VCR
VR260/07	1021Step-up show view	APOLLO12	1.05.2000	VCR
VR260/39	1021Step-up show view	APOLLO12	1.06.2000	VCR

VR260/58	1021Step-up show view	APOLLO12	1.04.2000	VCR
VR260DE	1021Step-up show view	APOLLO12	1.05.2000	VCR
VR260ES	1021Step-up show view	APOLLO12	1.06.2000	VCR
VR260XE	1021Step-up show view	APOLLO12		VCR
VR262/01	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
VR262/13	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR262/39	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR266/01	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR266/02	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR266/13	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR266/39	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
VR268/01	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
VR268/02	1021Step-up show view	PAULIN_STN	1.09.1996Standard	VCR
VR268/05	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
VR268/06	1021Leader	PAULIN_STN	1.11.1996Standard	VCR
VR268/13	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
VR270B/02	1021Step-up show view	APOLLO13	1.04.2001	VCR
VR270B/07	1021Step-up show view	APOLLO13	1.06.2001	VCR
VR270B/39	1021Step-up show view	APOLLO13	1.06.2001	VCR
VR270B/58	1021Step-up show view	APOLLO13	1.05.2001	VCR
VR270B/ES	Step-up show view			VCR
VR270B/GR	1021Step-up show view	APOLLO13	1.05.2001	VCR
VR270W/02	1021Step-up show view	APOLLO13	1.04.2001	VCR
VR270W/07	1021Step-up show view	APOLLO13	1.07.2001	VCR
VR270W/39	1021Step-up show view	APOLLO13	1.06.2001	VCR
VR270W/58	1021Step-up show view	APOLLO13	1.05.2001	VCR
VR274/55	1021Leader	VCR_INKOOOP	1.01.1995	VCR
VR274/57	1021Leader	VCR_INKOOOP	1.05.1995	VCR
VR276/02	1021Step-up show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR276/02G	1021Step-up show view	QUEEN_VL	1.06.1998Volume Line	VCR
VR276/13	1021Step-up show view	QUEEN_VL	1.08.1997Volume Line	VCR
VR276/39	1021Step-up show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR277/02	1021Step-up show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR277/05	1021Step-up show view	QUEEN_VL	1.07.1997Volume Line	VCR
VR285/02	1021Leader show view	APOLLO10	1.04.1998	VCR
VR285/02D	1021Leader show view	APOLLO10	1.07.1998	VCR
VR285/02G	1021Leader show view	APOLLO10	1.11.1998	VCR
VR285/05	1021Leader show view	APOLLO10	1.04.1998	VCR
VR285/07	1021Leader show view	APOLLO10	1.10.1998	VCR
VR285/13	1021Leader show view	APOLLO10	1.08.1998	VCR
VR285/39	1021Leader show view	APOLLO10	1.07.1998	VCR
VR285/58	1021Leader show view	APOLLO10	1.05.1998	VCR

VR285/60	1021Leader show view	APOLLO10	1.10.1998	VCR
VR286/02	1021Leader show view	APOLLO10	1.05.1998	VCR
VR286/02D	1021Leader	APOLLO10	1.10.1998	VCR
VR287/02	1021Step-up show view	APOLLO10	1.04.1998	VCR
VR287/02D	1021Leader	APOLLO10	1.10.1998	VCR
VR287/07	1021Step-up show view	APOLLO10	1.05.1998	VCR
VR287/13	1021Step-up show view	APOLLO10	1.08.1998	VCR
VR287/39	1021Step-up show view	APOLLO10	1.07.1998	VCR
VR288/55	1021Step-up show view	PJVM	1.07.1998	VCR
VR288/75	1021Step-up show view	PJVM	1.08.1998	VCR
VR296/55	1021Step-up show view	PJVM	1.08.1996	VCR
VR297/55	1021Step-up show view	PJVM	1.07.1997	VCR
VR302/01	1021Leader	JASMIN_STN	1.07.1994Standard	VCR
VR305/01	1021Leader	JASMIN_STN	1.07.1994Standard	VCR
VR312/01	1021Leader	KATE _STN	1.07.1994Standard	VCR
VR312/02	1021Leader	KATE _STN	1.12.1993Standard	VCR
VR312/05	1021Leader	KATE _STN	1.04.1994Standard	VCR
VR313/02	1021Leader	KATE _STN	1.01.1994Standard	VCR
VR322/01	1021Leader	LUCY _STN	1.07.1994Standard	VCR
VR322/02R	1021Leader	LUCY _STN	1.04.1994Standard	VCR
VR322/05	1021Leader	LUCY _STN	1.04.1994Standard	VCR
VR322/07	1021Leader	LUCY _STN	1.01.1994Standard	VCR
VR322/59	1021Leader	LUCY _STN	1.01.1993Standard	VCR
VR323/02	1021Leader	LUCY _STN	1.01.1994Standard	VCR
VR323/02R	1021Leader	LUCY _STN	1.01.1994Standard	VCR
VR323/05	1021Leader	LUCY _STN	1.01.1994Standard	VCR
VR323/16	1021Leader	LUCY _STN	1.01.1994Standard	VCR
VR3241/53	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3241/57	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3241/67	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3241/75	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3241/95	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3242/57	1021Leader	VCR_INKOOOP	1.11.1992	VCR
VR3242/75	1021Leader	VCR_INKOOOP	1.12.1992	VCR
VR3242/95	1021Leader	VCR_INKOOOP	1.10.1992	VCR
VR3260/57	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3260/67	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3260/73	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3260/95	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3261/52	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3261/55	1021Leader	VCR_INKOOOP	1.05.1992	VCR
VR3261/57	1021Leader	VCR_INKOOOP	1.03.1992	VCR

VR3261/67	1021Leader	VCR_INKOOOP	1.06.1992	VCR
VR3261/73	1021Leader	VCR_INKOOOP	1.04.1992	VCR
VR3261/75	1021Leader	VCR_INKOOOP	1.06.1992	VCR
VR3261/79	1021Leader	VCR_INKOOOP	1.06.1992	VCR
VR3261/95	1021Leader	VCR_INKOOOP	1.04.1992	VCR
VR330/58	Leader show view			VCR
VR332/01	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR332/02	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR332/06	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR332/07	1021Leader	MICHEL_STN	1.12.1994Standard	VCR
VR332/08	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR332/13	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR332/59	1021Leader	MICHEL_STN	1.01.1993Standard	VCR
VR3320/87	1021Leader	MICHEL_STN	1.03.1992Standard	VCR
VR333/01	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR333/02	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR333/16	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR3349/76	1021Leader	VCR_INKOOOP	1.04.1992	VCR
VR3360/60	1021Leader	VCR_INKOOOP	1.04.1992	VCR
VR3360/73	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3360/75	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3360/95	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR337/01	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR337/02	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR337/08	1021Leader	MICHEL_STN	1.01.1994Standard	VCR
VR337/13	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR337/16	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR3379/39	1021Leader	MICHEL_STN	1.11.1994Standard	VCR
VR3410/76	1021Leader		1.07.1992	VCR
VR3419/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR342/01	1021Leader	NORA _STN	1.09.1994Standard	VCR
VR342/03	1021Leader	NORA _STN	1.09.1994Standard	VCR
VR342/08	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR342/59	1021Leader	NORA _STN	1.09.1994Standard	VCR
VR3420/76	1021Leader		1.03.1992	VCR
VR3420/77	1021Leader		1.03.1992	VCR
VR3420/87	1021Leader		1.03.1992	VCR
VR3420L/77	1021Leader		1.04.1992	VCR
VR3421/77	1021Leader		1.12.1992	VCR
VR3422/50	1021Leader	VCR_INKOOOP	1.06.1992	VCR
VR3422/50E	1021Leader	VCR_INKOOOP	1.03.1993	VCR
VR343/01	1021Leader	NORA _STN	1.07.1994Standard	VCR

VR343/13	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR3442/57	1021Leader show view	VCR_INKOOOP	1.07.1992	VCR
VR3442/75	1021Leader show view	VCR_INKOOOP	1.08.1992	VCR
VR3442/93	1021Leader show view	VCR_INKOOOP	1.11.1992	VCR
VR3442/95	1021Leader show view	VCR_INKOOOP	1.10.1992	VCR
VR3449/77	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR3469/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR347/02	1021Leader	NORA _STN	1.05.1994Standard	VCR
VR347/03	1021Leader	NORA _STN	1.09.1994Standard	VCR
VR347/06	1021Leader	NORA _STN	1.06.1994Standard	VCR
VR347/07	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR347/08	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR347/10	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR347/13	1021Leader	NORA _STN	1.02.1995Standard	VCR
VR3479/39	1021Leader	NORA _STN	1.11.1994Standard	VCR
VR351/39	1021Leader	OLIVIA_STN	1.05.1995Standard	VCR
VR351/39L	1021Leader	OLIVIA_STN	1.11.1995Standard	VCR
VR3510/76	1021Leader		1.10.1993	VCR
VR352/01	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR352/03	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR3520/78	1021Leader		1.03.1992	VCR
VR3521/50	1021Leader show view		1.03.1992	VCR
VR3522/50	1021Leader show view	VCR_INKOOOP	1.08.1992	VCR
VR3522/50E	1021Leader show view	VCR_INKOOOP	1.10.1993	VCR
VR3522/78	1021Leader show view	VCR_INKOOOP	1.08.1992	VCR
VR3522L/78	1021Leader show view		1.03.1993	VCR
VR354/77	1021Step-up show view		1.11.1994	VCR
VR354/78	1021Leader show view		1.11.1994	VCR
VR354L/78	1021Leader show view		1.04.1995	VCR
VR355/50	1021Step-up show view	PJVM	1.08.1995	VCR
VR355/55	1021Step-up show view	PJVM	1.02.1996	VCR
VR355/77	1021Step-up show view	PJVM	1.07.1996	VCR
VR355/77A	1021Step-up show view			VCR
VR355/77B	1021Leader show view	PJVM	1.09.1996	VCR
VR355/78	1021Step-up show view	PJVM	1.10.1995	VCR
VR355/78B	1021Leader show view	PJVM	1.06.1996	VCR
VR355/93	1021Step-up show view	PJVM	1.09.1996	VCR
VR355L/78	1021Leader show view		1.01.1996	VCR
VR356/01	1021Leader	OLIVIA_STN	1.10.1995Standard	VCR
VR356/75	1021Leader	OLIVIA_STN	1.09.1996Standard	VCR
VR3561/54	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR357/01	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR

VR357/02	1021Leader	OLIVIA_STN	1.06.1995Standard	VCR
VR357/02L	1021Leader	OLIVIA_STN	1.08.1995Standard	VCR
VR357/75	1021Step-up show view	OLIVIA_STN	1.09.1997Standard	VCR
VR358/03	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR358/39	1021Leader	OLIVIA_STN	1.09.1995Standard	VCR
VR362/01	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
VR362/39	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR3621/77	1021Leader show view		1.12.1992	VCR
VR3622/50	1021Leader	VCR_INKOOOP	1.09.1992	VCR
VR3622/50E	1021Leader	VCR_INKOOOP	1.10.1993	VCR
VR366/01	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR366/02	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR368/39	1021Leader	PAULIN_STN	1.10.1996Standard	VCR
VR3730/6	1021Leader		1.06.1995	VCR
VR3861/56S	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR388/55	1021Step-up show view	PJVM	1.09.1998	VCR
VR388/75	1021Step-up show view	PJVM	1.09.1998	VCR
VR397/55	1021Step-up show view	PJVM	1.09.1997	VCR
VR400/02	1021Leader show view	APOLLO11	1.04.1999	VCR
VR400/39	1021Leader show view	APOLLO11	1.07.1999	VCR
VR400/58	1021Leader show view	APOLLO11	1.03.1999	VCR
VR400A/58	1021Leader show view	APOLLO11	1.06.2000	VCR
VR400DE	1021Leader show view	APOLLO11	1.05.1999	VCR
VR400ES	1021Leader show view	APOLLO11	1.04.1999	VCR
VR400GR	1021Leader show view	APOLLO11	1.07.1999	VCR
VR401/58	1021Leader show view		1.03.2000	VCR
VR402/58	1021Leader non-show view	APOLLO13	1.05.2001	VCR
VR410/02	1021Leader show view	APOLLO12	1.06.2000	VCR
VR410/39	1021Leader show view	APOLLO12	1.06.2000	VCR
VR410/58	1021Leader show view	APOLLO12	1.03.2000	VCR
VR410DE	1021Leader show view	APOLLO12	1.05.2000	VCR
VR410ES	1021Leader show view	APOLLO12	1.06.2000	VCR
VR410GR	1021Leader show view	APOLLO12	1.09.2000	VCR
VR410XE	1021Leader show view	APOLLO12		VCR
VR412/00	1021Leader	KATE _STN	1.02.1994Standard	VCR
VR42/78	1021Leader		1.03.1992	VCR
VR420/02	1021Leader show view	APOLLO13	1.04.2001	VCR
VR420/39	1021Leader show view	APOLLO13	1.07.2001	VCR
VR420/58	1021Leader show view	APOLLO13	1.05.2001	VCR
VR420/ES	1021Leader show view	APOLLO13	1.05.2001	VCR
VR420/GR	1021Leader show view	APOLLO13	1.06.2001	VCR
VR422/01	1021Leader show view	LUCY _STU	1.01.1994Step-up	VCR

VR422/02	1021Leader show view	LUCY _STU	1.07.1994Step-up	VCR
VR422/05	1021Leader show view	LUCY _STU	1.01.1994Step-up	VCR
VR43/78	1021Leader		1.03.1992	VCR
VR432/01	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
VR432/02	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
VR432/08	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
VR432/16	1021Leader show view	MICHEL_STN	1.11.1994Standard	VCR
VR432/59	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
VR437/01	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
VR437/02	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
VR437/05	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
VR437/07	1021Leader show view	MICHEL_STN	1.11.1994Standard	VCR
VR437/08	1021Leader show view	MICHEL_STN	1.11.1994Standard	VCR
VR437/13	1021Leader show view	MICHEL_STN	1.12.1994Standard	VCR
VR437/16	1021Leader show view	MICHEL_STN	1.01.1994Standard	VCR
VR441/60	1021Leader show view	NORA _STN	1.02.1995Standard	VCR
VR442/08	1021Leader show view	NORA _STN	1.10.1994Standard	VCR
VR442/58	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
VR445/02	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
VR4469/39	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
VR447/01	1021Leader show view	NORA _STN	1.10.1994Standard	VCR
VR447/02	1021Leader show view	NORA _STN	1.09.1994Standard	VCR
VR447/03	1021Leader show view	NORA _STN	1.09.1994Standard	VCR
VR447/05	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
VR447/08	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
VR447/13	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
VR4479/39	1021Leader show view	NORA _STN	1.11.1994Standard	VCR
VR450/02	1021Step-up show view	APOLLO11	1.05.1999	VCR
VR450/39	1021Step-up show view	APOLLO11	1.07.1999	VCR
VR450/58	1021Step-up show view	APOLLO11	1.06.1999	VCR
VR451/02	1021Leader show view	OLIVIA_ECN	1.05.1996Economy	VCR
VR451/39	1021Leader show view	OLIVIA_ECN	1.07.1995Economy	VCR
VR451/59	1021Leader show view	OLIVIA_ECN	1.06.1995Economy	VCR
VR451/59R	1021Leader show view	OLIVIA_ECN	1.12.1995Economy	VCR
VR452/01	1021Leader show view	OLIVIA_STN	1.09.1995Standard	VCR
VR453/50	1021Leader show view	VCR_INKOOOP	1.10.1993	VCR
VR453/55	1021Step-up show view	VCR_INKOOOP	1.10.1993	VCR
VR453/55S	1021Step-up show view	VCR_INKOOOP	1.02.1994	VCR
VR453/75	1021Leader show view	VCR_INKOOOP	1.10.1993	VCR
VR453/77	1021Leader show view	VCR_INKOOOP	1.10.1993	VCR
VR453/78	1021Leader show view	VCR_INKOOOP	1.12.1993	VCR
VR453/93	1021Leader show view	VCR_INKOOOP	1.10.1993	VCR

VR453L/78	1021Leader show view		1.04.1994	VCR
VR454/50	1021Leader show view	VCR_INKOOOP	1.06.1994	VCR
VR454/55	1021Step-up show view	VCR_INKOOOP	1.06.1994	VCR
VR454/75	1021Step-up show view	VCR_INKOOOP	1.08.1994	VCR
VR454/77	1021Step-up show view	VCR_INKOOOP	1.11.1994	VCR
VR454/77B	1021Leader show view	VCR_INKOOOP	1.04.1996	VCR
VR454/78	1021Step-up show view	VCR_INKOOOP	1.02.1995	VCR
VR454/93	1021Leader show view	VCR_INKOOOP	1.11.1994	VCR
VR4547/05	1021Leader show view	V07	1.05.1996	VCR
VR454705	1021Leader show view		1.11.1994	VCR
VR454L/78	1021Leader show view		1.04.1995	VCR
VR455/50	1021Step-up show view	VCR_INKOOOP	1.10.1995	VCR
VR455/57	1021Step-up show view	VCR_INKOOOP	1.05.1997	VCR
VR455/61	1021Leader show view	VCR_INKOOOP		VCR
VR455/75	1021Step-up show view	VCR_INKOOOP	1.09.1996	VCR
VR455/77	1021Step-up show view	VCR_INKOOOP	1.09.1996	VCR
VR455/77A	1021Step-up show view			VCR
VR455/77B	1021Leader show view	VCR_INKOOOP	1.09.1996	VCR
VR455/78	1021Step-up show view	VCR_INKOOOP	1.10.1995	VCR
VR455/78B	1021Leader show view	VCR_INKOOOP	1.06.1996	VCR
VR455/93	1021Leader show view	VCR_INKOOOP	1.09.1996	VCR
VR455/97	1021Step-up show view	VCR_INKOOOP	1.09.1996	VCR
VR4557/05	1021Leader show view	VCR_INKOOOP	1.02.1996	VCR
VR455L/78	1021Leader show view		1.01.1996	VCR
VR456/50	1021Leader show view	OLIVIA_ECN	1.09.1996Economy	VCR
VR456/57	1021Leader show view	OLIVIA_ECN	Economy	VCR
VR456/58	1021Leader show view	OLIVIA_ECN	1.02.1996Economy	VCR
VR456/61	1021Leader show view	OLIVIA_ECN	Economy	VCR
VR456/75	1021Leader show view	OLIVIA_ECN	1.09.1996Economy	VCR
VR456/78	1021Leader show view	OLIVIA_ECN	1.09.1996Economy	VCR
VR456/78B	1021Leader show view	OLIVIA_ECN	1.09.1996Economy	VCR
VR456/78F	1021Leader show view	OLIVIA_ECN	1.11.1996Economy	VCR
VR456/93	1021Leader show view	OLIVIA_ECN	1.09.1996Economy	VCR
VR457/02	1021Leader show view	OLIVIA_STN	1.08.1995Standard	VCR
VR457/03	1021Leader show view	OLIVIA_STN	1.09.1995Standard	VCR
VR457/07	1021Leader show view	OLIVIA_STN	1.06.1995Standard	VCR
VR457/13	1021Leader show view	OLIVIA_STN	1.10.1995Standard	VCR
VR457/39	1021Leader show view	OLIVIA_STN	1.07.1995Standard	VCR
VR457/39L	1021Leader show view	OLIVIA_STN	1.10.1995Standard	VCR
VR457/50	1021Step-up show view	OLIVIA_STN	1.08.1997Standard	VCR
VR457/58	1021Leader show view	OLIVIA_STN	1.09.1995Standard	VCR
VR457/61	1021Step-up show view	OLIVIA_STN	Standard	VCR

VR457/75	1021Step-up show view	OLIVIA_STN	1.09.1997Standard	VCR
VR457/77	1021Step-up show view			VCR
VR457/77A	1021Step-up show view			VCR
VR457/78	1021Step-up show view	OLIVIA_STN	Standard	VCR
VR458/01	1021Leader show view	OLIVIA_STN	1.09.1995Standard	VCR
VR458/02	1021Leader show view	OLIVIA_STN	1.07.1995Standard	VCR
VR458/02L	1021Leader show view	OLIVIA_STN	1.08.1995Standard	VCR
VR459/03	1021Leader show view	OLIVIA_STN	1.09.1995Standard	VCR
VR459/39	1021Leader show view	OLIVIA_STN	1.09.1995Standard	VCR
VR460/02	1021Step-up show view	APOLLO12	1.06.2000	VCR
VR460/39	1021Step-up show view	APOLLO12	1.05.2000	VCR
VR460/58	1021Step-up show view	APOLLO12	1.04.2000	VCR
VR461/01	1021Leader show view	PAULIN_ECN	1.09.1996Economy	VCR
VR461/60	1021Leader show view	PAULIN_ECN	1.11.1996Economy	VCR
VR462/01	1021Leader show view	PAULIN_STN	1.10.1996Standard	VCR
VR462/39	1021Leader show view	PAULIN_STN	1.09.1996Standard	VCR
VR465/02	1021Leader show view	PAULIN_STN	1.08.1996Standard	VCR
VR465/07	1021Leader show view	PAULIN_STN	1.08.1996Standard	VCR
VR465/58	1021Step-up show view			VCR
VR466/02	1021Leader show view	PAULIN_STN	1.09.1996Standard	VCR
VR466/13	1021Leader show view	PAULIN_STN	1.11.1996Standard	VCR
VR466/39	1021Leader show view	PAULIN_STN	1.09.1996Standard	VCR
VR468/01	1021Leader show view	PAULIN_STN	1.10.1996Standard	VCR
VR468/02	1021Step-up show view	PAULIN_STN	1.10.1996Standard	VCR
VR468/05	1021Leader show view	PAULIN_STN	1.12.1996Standard	VCR
VR468/39	1021Leader show view	PAULIN_STN	1.10.1996Standard	VCR
VR468/58	1021Step-up show view	PAULIN_STN	1.11.1996Standard	VCR
VR471/58	1021Leader show view	QUEEN_VL	1.08.1997Volume Line	VCR
VR474/55	1021Step-up show view	VCR_INKOOOP	1.02.1995	VCR
VR474/57	1021Step-up show view	VCR_INKOOOP	1.05.1995	VCR
VR475/02	1021Leader show view	QUEEN_VL	1.05.1997Volume Line	VCR
VR475/16	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR475/39	1021Leader show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR475/58	1021Leader show view	QUEEN_VL	1.08.1997Volume Line	VCR
VR476/39	1021Step-up show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR476/58	1021Step-up show view			VCR
VR477/02	1021Step-up show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR477/39	1021Step-up show view	QUEEN_VL	1.06.1997Volume Line	VCR
VR477/58	1021Step-up show view	QUEEN_VL	1.08.1997Volume Line	VCR
VR485/01	1021Leader show view			VCR
VR485/02	1021Leader show view	APOLLO10	1.05.1998	VCR
VR485/02D	1021Leader show view	APOLLO10	1.10.1998	VCR

VR485/39	1021Leader show view	APOLLO10	1.07.1998	VCR
VR485/58	1021Leader show view	APOLLO10	1.06.1998	VCR
VR487/02	1021Step-up show view	APOLLO10	1.05.1998	VCR
VR487/39	1021Step-up show view	APOLLO10	1.07.1998	VCR
VR487/58	1021Step-up show view	APOLLO10	1.06.1998	VCR
VR488/50	1021Step-up show view			VCR
VR488/55	1021Step-up show view	PJVM	1.08.1998	VCR
VR488/61	1021Step-up show view	PJVM		VCR
VR488/77A	1021Step-up show view			VCR
VR496/55	1021Step-up show view	PJVM	1.09.1996	VCR
VR497/55	1021Step-up show view	PJVM	1.07.1997	VCR
VR500/02	1021Leader	APOLLO11	1.08.1999	VCR
VR500/13	1021Leader	APOLLO11	1.01.2000	VCR
VR500/39	1021Leader	APOLLO11	1.03.2000	VCR
VR501/00P	Leader	APOLLO12		VCR
VR501/02	1021Leader	APOLLO12	1.04.2000	VCR
VR501/16	1021Leader	APOLLO12	1.04.2000	VCR
VR501/39	1021Leader	APOLLO12		VCR
VR501/58	1021Leader	APOLLO12	1.03.2000	VCR
VR501DE	1021Leader	APOLLO12	1.04.2000	VCR
VR501XE	1021Leader	APOLLO12	1.04.2000	VCR
VR502/01	1021Leader	JASMIN_STU	1.01.1994Step-up	VCR
VR502/05	1021Leader	JASMIN_STU	1.01.1994Step-up	VCR
VR502/13	1021Leader	JASMIN_STU	1.03.1992Step-up	VCR
VR502/16	1021Leader	JASMIN_STU	1.01.1994Step-up	VCR
VR505	1021Leader	CHARLY	1.11.1994	VCR
VR510/02	1021Leader	APOLLO12	1.06.2000	VCR
VR510/07	1021Leader	APOLLO12	1.05.2000	VCR
VR510/16	1021Leader	APOLLO12	1.07.2000	VCR
VR510/39	1021Leader	APOLLO12	1.07.2000	VCR
VR510/58	1021Leader	APOLLO12	1.03.2000	VCR
VR510DE	1021Leader	APOLLO12	1.06.2000	VCR
VR510GR	1021Leader	APOLLO12	1.09.2000	VCR
VR510XE	1021Leader	APOLLO12	1.05.2000	VCR
VR512/02	1021Leader show view	KATE _STU	1.01.1994Step-up	VCR
VR520/02	1021Subleader	APOLLO13	1.06.2001	VCR
VR520/07	1021Subleader	APOLLO13	1.06.2001	VCR
VR520/16	1021Subleader	APOLLO13	1.07.2001	VCR
VR520/58	1021Subleader	APOLLO13	1.05.2001	VCR
VR520/GR	1021Subleader	APOLLO13	1.06.2001	VCR
VR520/XE	1021Subleader	APOLLO13	1.06.2001	VCR
VR522/01	1021Leader show view	LUCY _STU	1.01.1994Step-up	VCR

VR522/02	1021Leader show view	LUCY _STU	1.03.1994Step-up	VCR
VR522/05	1021Leader show view	LUCY _STU	1.01.1994Step-up	VCR
VR522/08	1021Leader show view	LUCY _STU	1.03.1994Step-up	VCR
VR522/13	1021Leader show view	LUCY _STU	1.01.1994Step-up	VCR
VR5229/39	1021Leader show view	LUCY _STU	1.01.1994Step-up	VCR
VR530/58	Subleader			VCR
VR542/51	1021Leader		1.12.1993	VCR
VR553/78	1021Leader show view	VCR_INKOOOP	1.05.1994	VCR
VR553L/78	1021Leader show view		1.03.1994	VCR
VR555/61	1021Leader show view	PJVM		VCR
VR555/75	1021Leader show view	PJVM	1.09.1996	VCR
VR556/50	1021Leader show view		1.09.1996	VCR
VR556/61	1021Leader show view			VCR
VR556/78	1021Leader show view		1.09.1996	VCR
VR556/78B	1021Leader show view		1.09.1996	VCR
VR556/78F	1021Leader show view		1.12.1996	VCR
VR557/50	1021Step-up show view	PJVM	1.12.1996	VCR
VR557/61	1021Step-up show view	PJVM		VCR
VR557/77	1021Step-up show view			VCR
VR557/77A	1021Step-up show view			VCR
VR557/78	1021Step-up show view	PJVM		VCR
VR557/78A	1021Step-up show view			VCR
VR570/02	1021Leader	APOLLO13	1.07.2001	VCR
VR570/07	1021Leader	APOLLO13	1.06.2001	VCR
VR570/16	1021Leader	APOLLO13	1.07.2001	VCR
VR570/39	1021Leader	APOLLO13	1.07.2001	VCR
VR570/58	1021Leader	APOLLO13	1.06.2001	VCR
VR570/XE	1021Leader	APOLLO13	1.07.2001	VCR
VR572/02	1021Leader	APOLLO13	1.08.2001	VCR
VR572/07	1021Leader	APOLLO13	1.08.2001	VCR
VR572/16	1021Leader	APOLLO13	1.09.2001	VCR
VR572/XE	1021Leader	APOLLO13	1.07.2001	VCR
VR588/50	1021Step-up show view	PJVM	1.07.1998	VCR
VR588/55	1021Step-up show view	PJVM	1.09.1998	VCR
VR588/61	1021Step-up show view	PJVM		VCR
VR588/75	1021Step-up show view	PJVM	1.08.1998	VCR
VR588/77	1021Step-up show view			VCR
VR588/77A	1021Step-up show view			VCR
VR597/55	1021Step-up show view	PJVM	1.09.1997	VCR
VR60/58	1021Leader			VCR
VR600/02	1021Leader	APOLLO11	1.05.1999	VCR
VR600/07	1021Leader	APOLLO11	1.05.1999	VCR

VR600/13	1021Leader	APOLLO11	1.06.1999	VCR
VR600/16	1021Leader	APOLLO11	1.06.1999	VCR
VR600/39	1021Leader	APOLLO11	1.05.1999	VCR
VR600/58	1021Leader	APOLLO11	1.11.1999	VCR
VR600A/02	1021Leader	APOLLO12	1.09.2000	VCR
VR600A/07	1021Leader	APOLLO12		VCR
VR600A/16	1021Leader	APOLLO12		VCR
VR600A/39	1021Leader	APOLLO12		VCR
VR600A/58	1021Leader	APOLLO12	1.06.2000	VCR
VR600AD	1021Leader	APOLLO11		VCR
VR600AG	1021Leader	APOLLO11		VCR
VR600AX	1021Leader	APOLLO11	1.10.2000	VCR
VR600DE	1021Leader	APOLLO11	1.05.1999	VCR
VR600GR	1021Leader	APOLLO11	1.09.1999	VCR
VR601/02	1021Leader			VCR
VR601/16	1021Leader			VCR
VR601/39	1021Leader			VCR
VR601/58	1021Leader			VCR
VR605/02	1021Leader	APOLLO11	1.05.1999	VCR
VR605/07	1021Leader	APOLLO11	1.05.1999	VCR
VR605/13	1021Leader	APOLLO11	1.07.1999	VCR
VR605/16	1021Leader	APOLLO11	1.06.1999	VCR
VR605/39	1021Leader	APOLLO11	1.07.1999	VCR
VR605/58	1021Leader	APOLLO11	1.04.1999	VCR
VR605A/58	1021Leader		1.06.2000	VCR
VR605DE	1021Leader			VCR
VR6065L/76	1021Leader		1.04.1992	VCR
VR6065L/84	1021Leader		1.02.1993	VCR
VR607/02	1021Leader	APOLLO11	1.09.1999	VCR
VR607/07	1021Leader	APOLLO11	1.09.1999	VCR
VR607/13	1021Leader	APOLLO11	1.10.1999	VCR
VR607/16	1021Leader	APOLLO11	1.09.1999	VCR
VR607/39	1021Leader	APOLLO11	1.09.1999	VCR
VR607A/02	1021Leader	APOLLO11		VCR
VR607A/07	1021Leader	APOLLO11		VCR
VR607A/16	1021Leader	APOLLO11		VCR
VR607A/39	1021Leader	APOLLO11		VCR
VR607AD	1021Leader	APOLLO11		VCR
VR607AX	1021Leader	APOLLO11		VCR
VR607DE	1021Leader	APOLLO11	1.09.1999	VCR
VR608/02	1021Leader	APOLLO12	1.09.2000	VCR
VR608/07	1021Leader	APOLLO12	1.09.2000	VCR

VR608/16	1021Leader	APOLLO12	1.09.2000	VCR
VR608/39	1021Leader	APOLLO12	1.09.2000	VCR
VR608/XE	1021Leader	APOLLO12	1.10.2000	VCR
VR608XE	Leader	APOLLO12		VCR
VR610/02	1021Leader	APOLLO12	1.06.2000	VCR
VR610/07	1021Leader	APOLLO12	1.08.2000	VCR
VR610/16	1021Leader	APOLLO12	1.06.2000	VCR
VR610/39	1021Leader	APOLLO12	1.06.2000	VCR
VR610/60	1021Leader	APOLLO12	1.09.2000	VCR
VR610DE	1021Leader	APOLLO12	1.07.2000	VCR
VR610GR	1021Leader	APOLLO12	1.09.2000	VCR
VR610XE	1021Leader	APOLLO12	1.06.2000	VCR
VR617/02	1021Leader	APOLLO12	1.06.2000	VCR
VR617/07	1021Leader	APOLLO12	1.06.2000	VCR
VR617/16	1021Leader	APOLLO12	1.05.2000	VCR
VR617/58	1021Leader	APOLLO12	1.04.2000	VCR
VR617/GB	1021Leader	APOLLO12	1.10.2000	VCR
VR617DE	1021Leader	APOLLO12	1.06.2000	VCR
VR617GB	1021Leader	APOLLO12	1.08.2000	VCR
VR617XE	1021Leader	APOLLO12	1.07.2000	VCR
VR620/02	1021Leader	APOLLO13	1.06.2001	VCR
VR620/07	1021Leader	APOLLO13	1.06.2001	VCR
VR620/16	1021Leader	APOLLO13	1.06.2001	VCR
VR620/39	1021Leader	APOLLO13	1.06.2001	VCR
VR620/58	1021Leader	APOLLO13	1.06.2001	VCR
VR620/CH	1021Leader	APOLLO13	1.07.2001	VCR
VR620/GR	1021Leader	APOLLO13	1.06.2001	VCR
VR620/XE	1021Leader	APOLLO13	1.06.2001	VCR
VR622/02	Leader		1.12.2001	VCR
VR622/16	Leader	APOLLO13	1.12.2001	VCR
VR627/02	1021Leader	APOLLO13	1.07.2001	VCR
VR627/16	1021Leader	APOLLO13	1.10.2001	VCR
VR627/58	Leader	APOLLO13		VCR
VR627/XE	1021Leader	APOLLO13	1.07.2001	VCR
VR6290/01	1021Leader	INGRID	1.01.1994	VCR
VR630/58	Leader			VCR
VR632/01	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR632/02	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR632/13	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR632/16	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR632/16W	1021Leader	MICHEL_STU	1.02.1995Step-up	VCR
VR6349/57S	1021Leader	VCR_INKOOP	1.07.1992	VCR

VR6349/67S	1021Leader	VCR_INKOOOP	1.06.1992	VCR
VR6349/73F	1021Leader	VCR_INKOOOP	1.07.1992	VCR
VR6349/95S	1021Leader	VCR_INKOOOP	1.04.1992	VCR
VR637/01	1021Leader	MICHEL_STU	1.03.1994Step-up	VCR
VR637/02	1021Leader	MICHEL_STU	1.03.1994Step-up	VCR
VR637/13	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR637/16	1021Leader	MICHEL_STU	1.03.1994Step-up	VCR
VR6379/39	1021Leader	MICHEL_STU	1.05.1994Step-up	VCR
VR6379/39N	1021Leader	MICHEL_STU	1.10.1994Step-up	VCR
VR6395/97	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR6396/97	1021Leader		1.03.1992	VCR
VR6415/76	1021Leader		1.03.1993	VCR
VR642/01	1021Leader	NORA _STU	1.09.1994Step-up	VCR
VR642/08	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR642/56	1021Leader	NORA _STU	1.01.1993Step-up	VCR
VR6448/67S	1021Leader	VCR_INKOOOP	1.12.1992	VCR
VR6448/73S	1021Leader	VCR_INKOOOP	1.11.1992	VCR
VR6448/95S	1021Leader	VCR_INKOOOP	1.04.1993	VCR
VR6449/75L	1021Leader	VCR_INKOOOP	1.05.1992	VCR
VR647/01	1021Leader	NORA _STU	1.06.1994Step-up	VCR
VR647/02	1021Leader	NORA _STU	1.09.1994Step-up	VCR
VR647/07	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR647/08	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR647/10	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR647/13	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR647/16	1021Leader	NORA _STU	1.10.1994Step-up	VCR
VR6490/57	1021Leader	INGRID	1.03.1992	VCR
VR6490/75	1021Leader	INGRID	1.09.1992	VCR
VR6491/08	1021Leader show view	INGRID	1.04.1992	VCR
VR6491/57	1021Step-up show view	INGRID	1.04.1992	VCR
VR6491/69	1021Leader show view	INGRID	1.03.1992	VCR
VR6491/75	1021Leader show view	INGRID	1.03.1992	VCR
VR6491/78	1021Leader show view	INGRID	1.06.1992	VCR
VR6491/93	1021Leader show view	INGRID	1.03.1992	VCR
VR652/02L	1021Leader	OLIVIA_STU	1.01.1996Step-up	VCR
VR653/50	1021High-end	VCR_INKOOOP	1.10.1993	VCR
VR654/50	1021High-end	VCR_INKOOOP	1.07.1994	VCR
VR654/75	1021High-end	VCR_INKOOOP	1.10.1994	VCR
VR654/78	1021Leader	VCR_INKOOOP	1.04.1995	VCR
VR6543/75A	1021Leader	VCR_INKOOOP	1.11.1992	VCR
VR6547/05	1021Leader	V07	1.04.1996	VCR
VR654705	1021Leader		1.11.1994	VCR

VR6548/56S	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR6549/57H	1021Leader	VCR_INKOOOP	1.07.1992	VCR
VR6549/79H	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR654L/78	1021Leader show view		1.08.1995	VCR
VR655/75	1021Leader	PAULIN_STN	1.09.1996Standard	VCR
VR6557/05	1021Leader	VCR_INKOOOP	1.01.1996	VCR
VR656/01	1021Leader	OLIVIA_STU	1.11.1995Step-up	VCR
VR656/02	1021Leader	OLIVIA_STU	1.11.1995Step-up	VCR
VR656/13	1021Leader	OLIVIA_STU	1.12.1995Step-up	VCR
VR656/16	1021Leader	OLIVIA_STU	1.11.1995Step-up	VCR
VR656/39	1021Leader	OLIVIA_STU	1.12.1995Step-up	VCR
VR656/58	1021Leader	OLIVIA_STU	1.01.1996Step-up	VCR
VR656/75	1021High-end	OLIVIA_STU	1.10.1996Step-up	VCR
VR657/01L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR657/02L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR657/05L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR657/06L	1021Leader	OLIVIA_STU	1.12.1995Step-up	VCR
VR657/13L	1021Leader	OLIVIA_STU	1.10.1995Step-up	VCR
VR657/16L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR657/39L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR658/55	1021High-end			VCR
VR6581/75	1021Leader		1.03.1992	VCR
VR6585/13	1021Leader	HARRY	1.03.1992	VCR
VR6589/02	1021Leader	HARRY	1.09.1992	VCR
VR6591/75	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR6595/97	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR6595/99	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR6605/99	1021Leader		1.10.1993	VCR
VR6615/76	1021Leader		1.01.1993	VCR
VR6615/99	1021Leader		1.10.1993	VCR
VR663/56	1021Leader	VCR_INKOOOP	1.12.1993	VCR
VR6648/00H	1021Leader	VCR_INKOOOP	1.12.1992	VCR
VR6648/57H	1021Leader	VCR_INKOOOP	1.07.1992	VCR
VR665/02	1021Leader	PAULIN_ECN	1.09.1996Economy	VCR
VR665/05	1021Leader	PAULIN_ECN	1.08.1996Economy	VCR
VR665/16	1021Leader	PAULIN_ECN	1.09.1996Economy	VCR
VR665/16L	1021Leader	PAULIN_ECN	1.03.1997Economy	VCR
VR665/39	1021Leader	PAULIN_ECN	1.11.1996Economy	VCR
VR665/58	1021Leader	PAULIN_ECN	1.10.1996Economy	VCR
VR666/02	1021Step-up	PAULIN_STU	1.11.1996Step-up	VCR
VR666/16	1021Step-up	PAULIN_STU	1.11.1996Step-up	VCR
VR666/39	1021Leader	PAULIN_STU	1.11.1996Step-up	VCR

VR6660	1021Step-up	ECHO	1.05.1998	VCR
VR668/02	1021High-end	PAULIN_STU	1.11.1996Step-up	VCR
VR668/02D	1021Leader	PAULIN_STU	1.10.1998Step-up	VCR
VR668/05	1021Leader	PAULIN_STU	1.12.1996Step-up	VCR
VR668/06	1021High-end	PAULIN_STU	1.12.1996Step-up	VCR
VR668/16	1021High-end	PAULIN_STU	1.12.1996Step-up	VCR
VR668/39	1021High-end	PAULIN_STU	1.12.1996Step-up	VCR
VR6691/57	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR670B/02	1021Leader	APOLLO13	1.06.2001	VCR
VR670B/07	1021Leader	APOLLO13	1.07.2001	VCR
VR670B/16	1021Leader	APOLLO13	1.06.2001	VCR
VR670B/39	1021Leader	APOLLO13	1.06.2001	VCR
VR670B/58	1021Leader	APOLLO13	1.05.2001	VCR
VR670B/GR	1021Leader	APOLLO13	1.07.2001	VCR
VR670B/XE	1021Leader	APOLLO13	1.06.2001	VCR
VR670W/02	1021Leader	APOLLO13	1.06.2001	VCR
VR670W/07	1021Leader	APOLLO13	1.07.2001	VCR
VR670W/16	1021Leader	APOLLO13	1.05.2001	VCR
VR670W/39	1021Leader	APOLLO13	1.07.2001	VCR
VR670W/58	1021Leader	APOLLO13	1.05.2001	VCR
VR670W/XE	Leader			VCR
VR6743/75A	1021Leader	VCR_INKOOOP	1.04.1992	VCR
VR675/02	1021Leader	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
VR675/02D	1021Leader	QUEEN_VLH	1.10.1998Volume Line Hifi	VCR
VR675/05	1021Leader	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
VR675/13	1021Leader	QUEEN_VLH	1.08.1997Volume Line Hifi	VCR
VR675/13G	1021Leader	QUEEN_VLH	1.06.1998Volume Line Hifi	VCR
VR675/16	1021Leader	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
VR675/39	1021Leader	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
VR675/58	1021Leader	QUEEN_VLH	1.08.1997Volume Line Hifi	VCR
VR6750/02	1021Leader	APOLLO20	1.10.1998	VCR
VR6750/02D	1021Leader	APOLLO20	1.10.1998	VCR
VR675CG/58	1021Leader	QUEEN_VLH	1.02.1998Volume Line Hifi	VCR
VR676/02	1021Step-up	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
VR676/02D	1021Leader	QUEEN_VLH	1.11.1998Volume Line Hifi	VCR
VR676/05	1021Step-up	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
VR676/13	1021Step-up	QUEEN_VLH	1.09.1997Volume Line Hifi	VCR
VR676/16	1021Step-up	QUEEN_VLH	1.08.1997Volume Line Hifi	VCR
VR676/39	1021Step-up	QUEEN_VLH	1.06.1997Volume Line Hifi	VCR
VR676CG/05	1021High-end	QUEEN_PL	1.12.1997Pro Line	VCR
VR678/02	1021High-end	QUEEN_PL	1.09.1997Pro Line	VCR
VR678/02A	1021High-end	QUEEN_PL	1.05.1998Pro Line	VCR

VR678/02D	1021High-end	QUEEN_PL	1.06.1998Pro Line	VCR
VR678/16	1021High-end	QUEEN_PL	1.09.1997Pro Line	VCR
VR678/39	1021High-end	QUEEN_PL	1.09.1997Pro Line	VCR
VR6785/13	1021Leader	HARRY	1.07.1992	VCR
VR678CG/02	1021Step-up	QUEEN_PL	1.11.1997Pro Line	VCR
VR678CG/02D	1021Leader	QUEEN_PL	1.10.1998Pro Line	VCR
VR678CG/16	1021High-end	QUEEN_PL	1.12.1997Pro Line	VCR
VR678CG/39	1021Step-up	QUEEN_PL	1.12.1997Pro Line	VCR
VR6800/99	1021Leader		1.03.1992	VCR
VR6843/56	1021Leader	VCR_INKOOOP	1.09.1992	VCR
VR685/02	1021Leader	APOLLO10	1.06.1998	VCR
VR685/02A	1021Leader	APOLLO10	1.10.1998	VCR
VR685/02D	1021Leader	APOLLO10	1.10.1998	VCR
VR685/07	1021Leader	APOLLO10	1.06.1998	VCR
VR685/13	1021Leader	APOLLO10	1.08.1998	VCR
VR685/13G	1021Leader	APOLLO10	1.12.1998	VCR
VR685/16	1021Leader	APOLLO10	1.07.1998	VCR
VR685/39	1021Leader	APOLLO10	1.07.1998	VCR
VR685/58	1021Leader	APOLLO10	1.08.1998	VCR
VR685/60	1021Leader	APOLLO10	1.10.1998	VCR
VR686/02	1021Leader	APOLLO10	1.05.1998	VCR
VR686/02D	1021Leader	APOLLO10	1.10.1998	VCR
VR686/07	1021Leader	APOLLO10	1.07.1998	VCR
VR686/13	1021Leader	APOLLO10	1.08.1998	VCR
VR686/39	1021Leader	APOLLO10	1.10.1998	VCR
VR6880/02	1021Leader	HARRY	1.01.1993	VCR
VR6880/05	1021Leader	HARRY	1.07.1992	VCR
VR689/02	1021Leader	APOLLO10	1.09.2000	VCR
VR6891/57	1021Leader	VCR_INKOOOP	1.03.1992	VCR
VR6891/67S	1021Leader	VCR_INKOOOP	1.04.1992	VCR
VR697/55	1021Step-up show view			VCR
VR700/02	1021Step-up	APOLLO20	1.05.1999	VCR
VR700/07	1021Step-up	APOLLO20	1.05.1999	VCR
VR700/16	1021Step-up	APOLLO20	1.05.1999	VCR
VR700/39	1021Step-up	APOLLO20	1.07.1999	VCR
VR700/58	1021Step-up	APOLLO20	1.04.1999	VCR
VR700DE	1021Step-up	APOLLO20	1.04.1999	VCR
VR700GR	1021Step-up	APOLLO20	1.12.1999	VCR
VR700XE	1021Step-up	APOLLO20	1.05.1999	VCR
VR702/13	1021Leader	JASMIN_STU	1.03.1992Step-up	VCR
VR703/02	1021Leader	JASMIN_STU	1.01.1993Step-up	VCR
VR703/16	1021Leader	JASMIN_STU	1.03.1992Step-up	VCR

VR705/02	1021Step-up	APOLLO21	1.09.2000	VCR
VR705/16	1021Step-up	APOLLO21	1.09.2000	VCR
VR705/39	1021Step-up	APOLLO21	1.09.2000	VCR
VR705/58	1021Step-up	APOLLO21	1.09.2000	VCR
VR708/02	1021Step-up	APOLLO20	1.11.1999	VCR
VR708/07	1021Step-up	APOLLO20	1.12.1999	VCR
VR708/16	1021Step-up	APOLLO20	1.12.1999	VCR
VR708/39	1021Step-up	APOLLO20	1.12.1999	VCR
VR708A/02	1021Step-up	APOLLO21	1.09.2000	VCR
VR708A/07	1021Step-up	APOLLO21	1.09.2000	VCR
VR708A/16	1021Step-up	APOLLO21	1.10.2000	VCR
VR708A/39	1021Step-up	APOLLO21	1.09.2000	VCR
VR708A/GR	1021Step-up	APOLLO21	1.11.2000	VCR
VR708A/XE	1021Step-up	APOLLO21	1.10.2000	VCR
VR708DE	1021Step-up	APOLLO20	1.12.1999	VCR
VR708GR	1021Step-up	APOLLO20	1.12.1999	VCR
VR708XE	1021Step-up	APOLLO20	1.12.1999	VCR
VR710/02	1021Step-up	APOLLO21	1.06.2000	VCR
VR710/07	1021Step-up	APOLLO21	1.07.2000	VCR
VR710/16	1021Step-up	APOLLO21	1.06.2000	VCR
VR710/39	1021Step-up	APOLLO21	1.06.2000	VCR
VR710/58	1021Step-up	APOLLO21	1.06.2000	VCR
VR710DE	1021Step-up	APOLLO21	1.06.2000	VCR
VR710GR	1021Step-up	APOLLO21	1.04.2000	VCR
VR710XE	1021Step-up	APOLLO21	1.06.2000	VCR
VR712/05	1021Leader	JASMIN_STU	1.06.1994Step-up	VCR
VR712/75	1021Leader	JASMIN_STU	1.05.1992Step-up	VCR
VR713/05	1021Leader	JASMIN_STU	1.03.1992Step-up	VCR
VR714/75	1021Leader	JASMIN_STU	1.11.1992Step-up	VCR
VR716/02	1021Leader	KATE _STU	1.01.1993Step-up	VCR
VR716/13	1021Leader	KATE _STU	1.01.1994Step-up	VCR
VR716/75	1021Leader	KATE _STU	1.11.1992Step-up	VCR
VR720/02	1021Standard	APOLLO13	1.06.2001	VCR
VR720/07	1021Standard	APOLLO13	1.06.2001	VCR
VR720/16	1021Standard	APOLLO13	1.06.2001	VCR
VR720/39	1021Standard	APOLLO13	1.06.2001	VCR
VR720/58	1021Standard	APOLLO13	1.06.2001	VCR
VR720/GR	1021Standard	APOLLO13	1.06.2001	VCR
VR720/XE	1021Standard	APOLLO13	1.06.2001	VCR
VR722/02	1021Leader	LUCY _STU	1.01.1994Step-up	VCR
VR722/08	1021Leader	LUCY _STU	1.03.1994Step-up	VCR
VR722/13	1021Leader	LUCY _STU	1.01.1994Step-up	VCR

VR722/15	1021Leader	LUCY _STU	1.01.1994Step-up	VCR
VR7225/05	1021Leader	LUCY _STU	1.01.1994Step-up	VCR
VR723/02	1021Leader	LUCY _STU	1.01.1994Step-up	VCR
VR723/05	1021Leader	LUCY _STU	1.06.1994Step-up	VCR
VR727/05	1021Leader	LUCY _STU	1.11.1994Step-up	VCR
VR730/58	Standard			VCR
VR732/01	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR732/02	1021Leader	MICHEL_STU	1.12.1994Step-up	VCR
VR732/16	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR732/58	Standard			VCR
VR733/02	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR737/02	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR737/13	1021Leader	MICHEL_STU	1.10.1994Step-up	VCR
VR7379/39N	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR742/55	1021Leader show view	NORA _STU	1.02.1993Step-up	VCR
VR742/57	1021Leader show view	NORA _STU	1.12.1992Step-up	VCR
VR743/75	1021High-end	NORA _STU	1.11.1993Step-up	VCR
VR747/01	1021Leader	NORA _STU	1.09.1994Step-up	VCR
VR747/02	1021Leader	NORA _STU	1.09.1994Step-up	VCR
VR747/05	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR747/08	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR747/10	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR747/13	1021Leader	NORA _STU	1.11.1994Step-up	VCR
VR747/16	1021Leader	NORA _STU	1.10.1994Step-up	VCR
VR755/50	1021High-end	OLIVIA_ECN	1.08.1995Economy	VCR
VR755/55	1021High-end	OLIVIA_ECN	1.01.1996Economy	VCR
VR755/61	1021Leader	OLIVIA_ECN	Economy	VCR
VR755/75	1021Leader	OLIVIA_ECN	1.10.1996Economy	VCR
VR755/77	1021Leader	OLIVIA_ECN	1.07.1996Economy	VCR
VR755/77A	1021High-end			VCR
VR755/77B	1021Leader	OLIVIA_ECN	1.04.1997Economy	VCR
VR755/78	1021Leader	OLIVIA_ECN	1.10.1995Economy	VCR
VR755/78B	1021Leader	OLIVIA_ECN	1.06.1996Economy	VCR
VR755/93	1021Leader	OLIVIA_ECN	1.09.1996Economy	VCR
VR755/97	1021High-end	OLIVIA_ECN	1.09.1996Economy	VCR
VR755L/78	1021Leader show view		1.10.1995	VCR
VR756/50	1021High-end	OLIVIA_ECN	1.10.1996Economy	VCR
VR756/55	1021High-end	OLIVIA_ECN	1.09.1996Economy	VCR
VR756/55S	1021Leader	OLIVIA_ECN	1.05.1997Economy	VCR
VR756/61	1021Leader	OLIVIA_ECN	Economy	VCR
VR756/78	1021Leader	OLIVIA_ECN	1.09.1996Economy	VCR
VR756/78B	1021Leader	OLIVIA_ECN	1.09.1996Economy	VCR

VR756/78F	1021Leader	OLIVIA_ECN	1.10.1996Economy	VCR
VR756/93	1021Leader	OLIVIA_ECN	1.09.1996Economy	VCR
VR757/01L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR757/02L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR757/05L	1021Leader	OLIVIA_STU	1.10.1995Step-up	VCR
VR757/13L	1021Leader	OLIVIA_STU	1.11.1995Step-up	VCR
VR757/16L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR757/39L	1021Leader	OLIVIA_STU	1.09.1995Step-up	VCR
VR757/50	1021High-end	OLIVIA_STU	1.08.1997Step-up	VCR
VR757/59L	1021High-end	OLIVIA_STU	1.11.1995Step-up	VCR
VR757/61	1021High-end	OLIVIA_STU	Step-up	VCR
VR757/75	1021High-end	OLIVIA_STU	1.10.1997Step-up	VCR
VR757/77	1021High-end			VCR
VR757/78	1021High-end	OLIVIA_STU	1.05.1997Step-up	VCR
VR757/97	1021High-end	OLIVIA_STU	1.02.1998Step-up	VCR
VR758/78	1021High-end	OLIVIA_ECN	Economy	VCR
VR765/02	1021Step-up	APOLLO21	1.09.2000	VCR
VR765/07	1021Step-up	APOLLO21	1.09.2000	VCR
VR765/16	1021Step-up	APOLLO21	1.09.2000	VCR
VR765/39	1021Step-up	APOLLO21	1.07.2000	VCR
VR765/58	1021Step-up	PAULIN_STU	1.11.1999Step-up	VCR
VR765DE	1021Step-up	APOLLO21		VCR
VR765GR	1021Step-up	APOLLO21	1.09.2000	VCR
VR765XE	1021Step-up	APOLLO21	1.07.2000	VCR
VR766/02	1021Step-up	APOLLO21	1.10.2000	VCR
VR766/07	1021Step-up	APOLLO21	1.11.2000	VCR
VR766/16	1021Step-up	APOLLO21	1.10.2000	VCR
VR766/39	1021Step-up	APOLLO21	1.11.2000	VCR
VR766/58	1021Step-up	APOLLO21	1.11.1999	VCR
VR766DE	1021Step-up			VCR
VR766GR	1021Step-up	APOLLO21	1.11.2000	VCR
VR766XE	1021Step-up			VCR
VR768/02	1021High-end edit	PAULIN_STU	1.10.1996Step-up	VCR
VR768/05	1021High-end edit	PAULIN_STU	1.12.1996Step-up	VCR
VR768/16	1021High-end edit	PAULIN_STU	1.12.1996Step-up	VCR
VR768/39	1021High-end edit	PAULIN_STU	1.12.1996Step-up	VCR
VR768/59	1021High-end edit	PAULIN_STU	1.12.1996Step-up	VCR
VR778/02	1021High-end edit	QUEEN_PL	1.11.1997Pro Line	VCR
VR778/02D	1021High-end edit	QUEEN_PL	1.06.1998Pro Line	VCR
VR778/05	1021High-end edit	QUEEN_PL	1.11.1997Pro Line	VCR
VR778/16	1021High-end edit	QUEEN_PL	1.12.1997Pro Line	VCR
VR778/39	1021High-end edit	QUEEN_PL	1.12.1997Pro Line	VCR

VR778/59	1021Leader	QUEEN _PL	Pro Line	VCR
VR788/50	1021High-end	PJVM	1.07.1998	VCR
VR788/55	1021High-end	PJVM	1.08.1998	VCR
VR788/61	1021High-end	PJVM		VCR
VR788/75	1021High-end	PJVM	1.08.1998	VCR
VR788/77	1021High-end			VCR
VR788/77A	1021High-end			VCR
VR797/55	1021High-end		1.09.1997	VCR
VR800/02	1021Step-up	APOLLO20	1.10.1998	VCR
VR800/02D	1021Leader	APOLLO20	1.10.1998	VCR
VR800/07	1021Step-up	APOLLO20	1.08.1998	VCR
VR800/16	1021Step-up	APOLLO20	1.10.1998	VCR
VR800/16G	1021Step-up	APOLLO20	1.10.1998	VCR
VR800/16N	1021Step-up	APOLLO20	1.11.1998	VCR
VR800/39	1021Step-up	APOLLO20	1.10.1998	VCR
VR800/58	1021Step-up	APOLLO20	1.09.1998	VCR
VR805/07	1021Step-up	APOLLO20	1.10.1998	VCR
VR805/16	1021Step-up	APOLLO20	1.10.1998	VCR
VR805/16D	1021Leader	APOLLO20	1.10.1998	VCR
VR805/16G	1021Step-up	APOLLO20	1.11.1998	VCR
VR805/16N	1021Step-up	APOLLO20	1.11.1998	VCR
VR805/39	1021Step-up	APOLLO20	1.10.1998	VCR
VR805/58	1021Step-up	APOLLO20	1.09.1999	VCR
VR806/07	1021Step-up	APOLLO20	1.01.1999	VCR
VR806/16	1021Step-up	APOLLO20	1.12.1998	VCR
VR806/16D	1021Leader	APOLLO20	1.01.1999	VCR
VR806/16G	1021Step-up		1.05.2000	VCR
VR806/39	1021Step-up	APOLLO20	1.01.1999	VCR
VR810/02	1021High-end	APOLLO21	1.06.2000	VCR
VR810/07	1021High-end	APOLLO21		VCR
VR810/16	1021High-end	APOLLO21	1.06.2000	VCR
VR810/39	1021High-end	APOLLO21	1.07.2000	VCR
VR810DE	1021High-end	APOLLO21	1.06.2000	VCR
VR810XE	1021High-end	APOLLO21	1.07.2000	VCR
VR813/02	1021Leader	KATE _STU	1.01.1993Step-up	VCR
VR813/02W	1021Leader	KATE _STU	1.01.1994Step-up	VCR
VR813/05	1021Leader	KATE _STU	1.01.1994Step-up	VCR
VR813/13	1021Leader	KATE _STU	1.01.1994Step-up	VCR
VR813/13W	1021Leader	KATE _STU	1.01.1994Step-up	VCR
VR820/02	1021High-end	APOLLO21	1.06.2001	VCR
VR820/16	High-end	APOLLO21		VCR
VR820/39	1021High-end	APOLLO21	1.07.2001	VCR

VR820/58	1021High-end	APOLLO21	1.07.2001	VCR
VR820/CH	1021High-end	APOLLO21	1.09.2001	VCR
VR820/GR	1021High-end	APOLLO21	1.08.2001	VCR
VR820/XE	1021High-end	APOLLO21	1.07.2001	VCR
VR830/58	Standard			VCR
VR833/02	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR833/13	1021Leader	MICHEL_STU	1.01.1994Step-up	VCR
VR838/02	1021Step-up	MICHEL_STU	1.03.1994Step-up	VCR
VR838/05	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR838/10	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR838/13	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR838/16	1021Leader	MICHEL_STU	1.08.1994Step-up	VCR
VR8389/39N	1021Leader	MICHEL_STU	1.10.1994Step-up	VCR
VR842/56	1021Leader	VCR_INKOOOP	1.02.1993	VCR
VR850/02	1021High-end	APOLLO20	1.10.1998	VCR
VR850/02D	1021Leader	APOLLO20	1.10.1998	VCR
VR850/02G	1021Step-up	APOLLO20	1.10.1998	VCR
VR850/07	1021High-end	APOLLO20	1.10.1998	VCR
VR850/16	1021High-end	APOLLO20	1.10.1998	VCR
VR850/16N	1021Step-up	APOLLO20	1.11.1998	VCR
VR850/39	1021High-end	APOLLO20	1.10.1998	VCR
VR850/58	1021High-end	APOLLO20	1.09.1998	VCR
VR856/75	1021High-end	PJVM	1.10.1996	VCR
VR857/75	1021High-end		1.10.1997	VCR
VR857/78	1021High-end			VCR
VR860/02	1021Step-up	APOLLO20	1.04.1999	VCR
VR860/07	1021Step-up	APOLLO20	1.05.1999	VCR
VR860/16	1021Step-up	APOLLO20	1.04.1999	VCR
VR860/39	1021Step-up	APOLLO20	1.05.1999	VCR
VR860DE	1021Step-up	APOLLO20	1.04.1999	VCR
VR860GR	1021Step-up	APOLLO20		VCR
VR860NL	1021Step-up	APOLLO20	1.09.1999	VCR
VR860XE	1021Step-up	APOLLO20	1.06.1999	VCR
VR863/56	1021High-end	VCR_INKOOOP	1.11.1993	VCR
VR870CC/02	1021Standard	APOLLO13	1.07.2001	VCR
VR870CC/07	1021Standard	APOLLO13	1.07.2001	VCR
VR870CC/16	1021Standard	APOLLO13	1.09.2001	VCR
VR870CC/39	1021Standard	APOLLO13	1.07.2001	VCR
VR870CC/58	1021Standard	APOLLO13	1.06.2001	VCR
VR870CC/GR	1021Standard	APOLLO13	1.08.2001	VCR
VR870CC/XE	1021Standard	APOLLO13	1.07.2001	VCR
VR870L/02	1021Standard	APOLLO13	1.06.2001	VCR

VR870L/07	1021Standard	APOLLO13	1.06.2001	VCR
VR870L/16	1021Standard	APOLLO13	1.06.2001	VCR
VR870L/39	1021Standard	APOLLO13	1.06.2001	VCR
VR870L/58	1021Standard	APOLLO13	1.07.2001	VCR
VR870L/GR	1021Standard	APOLLO13	1.09.2001	VCR
VR870L/XE	1021Standard	APOLLO13	1.08.2001	VCR
VR870P/02	1021Standard	APOLLO13	1.07.2001	VCR
VR870P/07	1021Standard	APOLLO13	1.07.2001	VCR
VR870P/16	1021Standard	APOLLO13	1.08.2001	VCR
VR870P/39	1021Standard	APOLLO13	1.07.2001	VCR
VR870P/58	1021Standard	APOLLO13	1.08.2001	VCR
VR870P/GR	1021Standard	APOLLO13	1.11.2001	VCR
VR870P/XE	1021Standard	APOLLO13	1.09.2001	VCR
VR874/55	1021High-end	VCR_INKOOOP	1.06.1995	VCR
VR874/56	1021Leader	VCR_INKOOOP	1.09.1996	VCR
VR888/55	1021Step-up	PJVM	1.07.1998	VCR
VR888/75	1021Step-up show view	PJVM	1.08.1998	VCR
VR8908/76	1021Leader	VCR_INKOOOP	1.06.1992	VCR
VR897/55	1021High-end	PJVM	1.09.1997	VCR
VR900/02	1021High-end	APOLLO20	1.07.1999	VCR
VR900/07	1021High-end	APOLLO20	1.06.1999	VCR
VR900/16	1021High-end	APOLLO20	1.06.1999	VCR
VR900/39	1021High-end	APOLLO20	1.07.1999	VCR
VR900/58	1021High-end	APOLLO20	1.05.1999	VCR
VR900DE	1021High-end	APOLLO20	1.06.1999	VCR
VR900GR	1021High-end	APOLLO20	1.10.1999	VCR
VR900XE	1021High-end	APOLLO20	1.08.1999	VCR
VR910/02	1021High-end edit	APOLLO21	1.07.2000	VCR
VR910/07	1021High-end	APOLLO21		VCR
VR910/16	1021High-end edit	APOLLO21	1.07.2000	VCR
VR910/39	1021High-end edit	APOLLO21	1.07.2000	VCR
VR910/58	1021High-end edit	APOLLO21	1.06.2000	VCR
VR910DE	1021High-end	APOLLO21	1.06.2000	VCR
VR910GR	1021High-end	APOLLO21	1.09.2000	VCR
VR910XE	1021High-end	APOLLO21	1.07.2000	VCR
VR948/02	1021Leader	MICHEL_STU	1.04.1994Step-up	VCR
VR948/02M	1021Leader	MICHEL_STU	1.12.1994Step-up	VCR
VR948/05	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR948/05M	1021Leader	MICHEL_STU	1.06.1995Step-up	VCR
VR948/10	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR948/10M	1021Leader	MICHEL_STU	1.02.1995Step-up	VCR
VR948/13	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR

VR948/13M	1021Leader	MICHEL_STU	1.12.1994Step-up	VCR
VR948/16	1021Leader	MICHEL_STU	1.07.1994Step-up	VCR
VR948/16M	1021Leader	MICHEL_STU	1.02.1995Step-up	VCR
VR9489/39N	1021Leader	MICHEL_STU	1.11.1994Step-up	VCR
VR955/55	1021High-end	PJVM	1.09.1996	VCR
VR955/93	1021Leader	PJVM	1.09.1996	VCR
VR958/78	1021High-end			VCR
VR960/02	1021Step-up	QUEEN_PL	1.03.1998Pro Line	VCR
VR960/02D	1021Step-up	QUEEN_PL	1.10.1998Pro Line	VCR
VR960/39	1021Step-up	QUEEN_PL	1.03.1998Pro Line	VCR
VR963/55	1021High-end	VCR_INKOOOP	1.04.1994	VCR
VR967/02	1021Step-up	PAULIN_STU	1.04.1997Step-up	VCR
VR967/16	1021Step-up	PAULIN_STU	1.05.1997Step-up	VCR
VR967/39	1021Step-up	PAULIN_STU	1.04.1997Step-up	VCR
VR967/58	1021Step-up	PAULIN_STU	1.05.1997Step-up	VCR
VR969/02	1021High-end	PAULIN_STU	1.06.1997Step-up	VCR
VR969/02D	1021Step-up	PAULIN_STU	1.10.1998Step-up	VCR
VR969/05	1021High-end	PAULIN_STU	1.10.1997Step-up	VCR
VR969/16	1021High-end	PAULIN_STU	1.07.1997Step-up	VCR
VR969/39	1021High-end	PAULIN_STU	1.07.1997Step-up	VCR
VR969/58	1021High-end	PAULIN_STU	1.09.1997Step-up	VCR
VR988/50	1021High-end	PJVM	1.09.1998	VCR
VR988/55	1021High-end	PJVM	1.10.1998	VCR
VR988/61	1021High-end	PJVM		VCR
VR988/75	1021High-end	PJVM	1.10.1998	VCR
VR997/55	1021High-end		1.10.1997	VCR
VRP25/97	1021Leader		1.04.1992	VCR
VRQ45/58	Standard			VCR
VRT362/99	1021Leader			VCR
VRT442/99	1021Leader show view			VCR
VRT462/99	1021Leader			VCR
VRT542/99	1021Leader show view			VCR
VRT562/99	1021Leader			VCR
VRU240/99	1021Leader show view			VCR
VRU442/99	1021Leader show view			VCR
VRU462/99	1021Leader			VCR
VRU464/99	1021Leader			VCR
VRU562/99	1021Leader		1.12.1999	VCR
VRX344/99	1021Leader show view			VCR
VRX363/99	1021Leader			VCR
VRX364/99	1021Leader			VCR
VRX442/99	1021Leader show view			VCR

VRX462/99	1021Leader		VCR
VRX463/99	1021Leader		VCR
VRZ244/99	1021Leader show view		VCR
VRZ255/99	1021Leader show view		VCR
VRZ264/99	1021Leader show view		VCR
VRZ340/99	1021Leader show view		VCR
VRZ344/99	1021Leader show view		VCR
VRZ360/99	1021Leader		VCR
VRZ364/99	1021Leader		VCR
VRZ464/99	1021Leader		VCR
VS22485R/,,	2010	VM4	OBSERVATION SYSTEMS
VS22605R/,,	2010		OBSERVATION SYSTEMS
VS22805T/,,	2010	VM8	OBSERVATION SYSTEMS
VS22815R/,,	2010	VM8	OBSERVATION SYSTEMS
VS22855T/,,	2010	VM8	OBSERVATION SYSTEMS
VS23605T/,,	2010		OBSERVATION SYSTEMS
VS23645P/,,	2010		OBSERVATION SYSTEMS
VS23645T/,,	2010		OBSERVATION SYSTEMS
VS23655T/,,	2010		OBSERVATION SYSTEMS
VS24415R/,,	2010	VM4	OBSERVATION SYSTEMS
VS290050/,,	2010		OBSERVATION SYSTEMS
VS29005T/,,	2010	ACC	OBSERVATION SYSTEMS
VS29039T/,,	2010		OBSERVATION SYSTEMS
VS32805T/,,	2010	VM8	OBSERVATION SYSTEMS
VS33405R/,,	2010		OBSERVATION SYSTEMS
VS33415R/,,	2010		OBSERVATION SYSTEMS
VS34405R/,,	2010	VM4	OBSERVATION SYSTEMS
VS39005R/,,	2010	ACC	OBSERVATION SYSTEMS
VS390150/,,	2010		OBSERVATION SYSTEMS
VS44405R/,,	2010	VM4	OBSERVATION SYSTEMS
VS44605T/,,	2010		OBSERVATION SYSTEMS
VS44805T/,,	2010	VM8	OBSERVATION SYSTEMS
VS73705P/,,	2010		OBSERVATION SYSTEMS
VS73705T/,,	2010	VM7	OBSERVATION SYSTEMS
VS73745P/,,	2010		OBSERVATION SYSTEMS
VS73745T/,,	2010	VM7	OBSERVATION SYSTEMS
VS79015T/,,	2010	ACC	OBSERVATION SYSTEMS
VS79025T/,,	2010	ACC	OBSERVATION SYSTEMS
VS79035T/,,	2010	ACC	OBSERVATION SYSTEMS
VS79055T/,,	2010	ACC	OBSERVATION SYSTEMS
VS82505T/,,	2010	VM5	OBSERVATION SYSTEMS
VS94515T/,,	2010	VM5	OBSERVATION SYSTEMS

VS94705T/.,	2010	VM7	OBSERVATION SYSTEMS
VS99005G/.,	2010	PTL-1	OBSERVATION SYSTEMS
VSS1601/00T	6010	ACC	OBSERVATION SYSTEMS
VSS2240/00T	2010	VM4	OBSERVATION SYSTEMS
VSS2240/01T	2010	VM4	OBSERVATION SYSTEMS
VSS2260/00R	2010		OBSERVATION SYSTEMS
VSS2282/00T	2010		OBSERVATION SYSTEMS
VSS2285/00T	2010	VM8	OBSERVATION SYSTEMS
VSS2286/00T	2010	VM8	OBSERVATION SYSTEMS
VSS2360/00T	2010	VM6	OBSERVATION SYSTEMS
VSS2360/C3T	2010	VM6	OBSERVATION SYSTEMS
VSS2364/00T	2010	VM6	OBSERVATION SYSTEMS
VSS2364/C4T	2010	VM6	OBSERVATION SYSTEMS
VSS2440/00T	2010	VM4	OBSERVATION SYSTEMS
VSS2440/01T	2010	VM4	OBSERVATION SYSTEMS
VSS2900/00	6010	VCM	OBSERVATION SYSTEMS
VSS2900/00T	6010	VCM	OBSERVATION SYSTEMS
VSS2900/01	6010	VCM	OBSERVATION SYSTEMS
VSS2900/01T	6010	VCM	OBSERVATION SYSTEMS
VSS2901/00	6010	ACC	OBSERVATION SYSTEMS
VSS2902/00	6010	ACC	OBSERVATION SYSTEMS
VSS2903/00	6010	ACC	OBSERVATION SYSTEMS
VSS2903/01	6010	ACC	OBSERVATION SYSTEMS
VSS2903/05	6010	ACC	OBSERVATION SYSTEMS
VSS2903/19T	6010	ACC	OBSERVATION SYSTEMS
VSS2904/00	6010	ACC	OBSERVATION SYSTEMS
VSS2904/01	6010	ACC	OBSERVATION SYSTEMS
VSS2904/05	6010	ACC	OBSERVATION SYSTEMS
VSS2905/00	6010	ACC	OBSERVATION SYSTEMS
VSS2906/00	6010	VCM	OBSERVATION SYSTEMS
VSS2907/00	6010	ACC	OBSERVATION SYSTEMS
VSS2907/01	6010	ACC	OBSERVATION SYSTEMS
VSS2913/05	2010	ACC	OBSERVATION SYSTEMS
VSS3240/00T	2010	VM4	OBSERVATION SYSTEMS
VSS3240/01T	2010	VM4	OBSERVATION SYSTEMS
VSS3280/00T	2010	VM8	OBSERVATION SYSTEMS
VSS3280/19T	2010	VM8	OBSERVATION SYSTEMS
VSS3440/00T	2010	VM4	OBSERVATION SYSTEMS
VSS3440/01T	2010	VM4	OBSERVATION SYSTEMS
VSS3900/00T	6010	ACC	OBSERVATION SYSTEMS
VSS3901/00	6010	ACC	OBSERVATION SYSTEMS
VSS4440/00T	2010	VM4	OBSERVATION SYSTEMS

VSS4440/01T	2010	VM4		OBSERVATION SYSTEMS
VSS4460/00T	2010	VM6		OBSERVATION SYSTEMS
VSS4480/00T	2010	VM8		OBSERVATION SYSTEMS
VSS7370/00T	2010	VM7		OBSERVATION SYSTEMS
VSS7370/54T	2010	VM7		OBSERVATION SYSTEMS
VSS7370/C3T	2010	VM7		OBSERVATION SYSTEMS
VSS7374/00T	2010	VM7		OBSERVATION SYSTEMS
VSS7374/54T	2010	VM7		OBSERVATION SYSTEMS
VSS7374/C4T	2010	VM7		OBSERVATION SYSTEMS
VSS7901/00T	6010	ACC		OBSERVATION SYSTEMS
VSS7902/00T	6010	ACC		OBSERVATION SYSTEMS
VSS7903/00T	6010	ACC		OBSERVATION SYSTEMS
VSS7905/00T	6010	ACC		OBSERVATION SYSTEMS
VSS8250/00T	2010	VM5		OBSERVATION SYSTEMS
VSS8250/19T	2010	VM5		OBSERVATION SYSTEMS
VSS9451/00T	2010	VM5		OBSERVATION SYSTEMS
VSS9459/00T	2010	VM5		OBSERVATION SYSTEMS
VSS9470/00T	2010	VM7		OBSERVATION SYSTEMS
VSS9900/00G	2010	PTL-1		OBSERVATION SYSTEMS
VT-M501EC/T	1021Leader		1.12.1996	VCR
VT-M530EC/T	1021Leader show view		1.12.1996	VCR
VWHSKP3/C	1021Leader show view		1.05.1994	VCR
VWHSMP1A	1021Leader		1.11.1994	VCR
WD100/00	1041Portable radio		1.03.1992	RADIO PORTABLE
WD300/00	1041Clock radio		1.07.1992	CLOCKRADIO
WD300/18	1041Clock radio		1.04.1992	CLOCKRADIO
WD800/00	1041Radio cassette recorders - mono		1.06.1992	RADIO MONO + STEREO
WK94/01	1021Leader	VCR_INKOOOP	1.05.1994	VCR
XC110/261	2010	VCM		OBSERVATION SYSTEMS
XC315/215	2010	X1-B/W		OBSERVATION SYSTEMS
XC319/215	2010	X9-B/W		OBSERVATION SYSTEMS
XC325/165	2010	X2-B/W		OBSERVATION SYSTEMS
XC325/215	2010	X2-B/W		OBSERVATION SYSTEMS
XC330/330	2010	X3-B/W		OBSERVATION SYSTEMS
XC339/215	2010			OBSERVATION SYSTEMS
XC425/165	2010	X2-COLOUR		OBSERVATION SYSTEMS
XC425/225	2010	X2-COLOUR		OBSERVATION SYSTEMS
XC445/370	2010			OBSERVATION SYSTEMS
XC611/150	2010	X1-B/W		OBSERVATION SYSTEMS
XC615/150	2010	X1-B/W		OBSERVATION SYSTEMS
XC625/135	2010	X2-B/W		OBSERVATION SYSTEMS
XC725/180	2010			OBSERVATION SYSTEMS

XS290/115

2010

VM4

OBSERVATION SYSTEMS