


Zikari Tunc

DODATAK

ZA

VEŠ MAŠINE

električne šeme i montažni nacrti



ELEKTRIČNA ŠEMA VEŠ MAŠINE PS 306 BM SA PROGRAMATOROM PG 1300

K U R L J I A V R	PROGRAMI	KONTAKT	NORMALNI														DELIKATNI													
			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
	PG 1300																													
14	PUŠ-PUL	A	1																											
13	PUŠ-PUL	A	22																											
12	KONDENZATOR PRANJA KONDENZATOR CENTRIF.	C	41																											
11	MT DIREKTNO TERMOSTAT 38	26	25																											
10	EL. VENTIL PREDPRANJA CENTRIFUGA	14	36																											
9	MT PREKO H	9	28																											
8	EL. VENTIL DIREKTNO NIVO II	14	25																											
7	TERMOSTAT 88 TERMOSTAT 50	28	37																											
6	EL. VENTIL PRANJA EL. VENTIL ADITIVA	14	34																											
5	PUMPA GREJAČ/TERMOSTAT 27	28	6																											
4	KONDENZATOR PRANJA KONDENZATOR CENTRIF.	C	42																											
3	PRANJE DELIKATNO PRANJE NORMALNO	28	44																											
	KORAK 2"																													
	KORAK 1"																													
2	PRANJE NORMALNO 9"-6"-9"	45	42																											
1	PRANJE DELIKATNO 4"-11"-4"	45	44																											

