




CIRCUIT DIAGRAM MAIN BOARD DTV 3

The components marked  conform to VDE or IEC guidelines and are essential for safe operation on the set, while those marked  are required for correct operation. Use specified parts only when replacing.

1	AUDIO IN R	11	GREEN
2	AUDIO OUT R	12	NC
3	NC	13	RED
4	AUDIO IN L	14	NC
5	NC	15	RED
6	AUDIO OUT L	16	NC
7	BLUE	17	NC
8	VCR-SWITCH	18	NC
9	NC	19	VIDEO IN
10	NC	20	NC
11	GREEN	21	NC
12	NC	22	NC
13	RED	23	NC
14	NC	24	NC
15	RED	25	NC
16	NC	26	NC
17	NC	27	NC
18	NC	28	NC
19	VIDEO IN	29	NC
20	NC	30	NC
21	NC	31	NC
22	NC	32	NC



Power - supply

Vomr. 1
Key number 1

VERTICAL