

● Remove the Heat Sink

1. Remove the four screws A and four screws B.
2. Remove the three screws C and then remove the heat sink.




Fig. 2

● Remove the Amp Unit

1. Remove the two screws D and a screw E.
2. Remove the panel.
3. Unbend the claw indicated by arrow until straight.
4. Remove the two screws F and then remove the amp unit.






Fig. 3

● ICs


TA8225L




UPC4570HA



UPC494C



TA8194Z



3. SCHEMATIC CIRCUIT DIAGRAM (GM-920/EW)




Fig. 4