SCHEMATIC DIAGRAM (PORTABLE HANDSET)



ORTABLE HANDSET)



KEY MATRIX

	TCC116R	TCC106R	TCC425	
I				
J				
K	SEND	SEND	SEND	
L	CLEAR	CLEAR	CLEAR	
M	TALK	TALK	TALK	
N	EXIT	EXIT	EXIT	
O	UP	UP	UP	
P	DOWN	DOWN	DOWN	
Q	DIRECTORY	DIRECTORY	DIRECTORY	
R	CALL_WAIT /FLASH	CALL_WAIT /FLASH	CALL_WAIT /FLASH	
S	VOLUME/ RINGER	VOLUME/ RINGER	VOLUME/ RINGER	
T	REDIAL /PAUSE	REDIAL	REDIAL /PAUSE	
U	INTERCOM	PAUSE	INTERCOM	
V	VOICE MAIL	VOICE MAIL	SCREEN/ PLAYBACK	
W	PROGRAM	PROGRAM	PROGRAM/ 2WAY_REC	
X	CH	CH	CH	

OPTION

	CONTENTS	OPEN	SHORT
A	TEST/ NORMAL	NORMAL	TEST MODE
B	TEST/ NORMAL	NORMAL	TEST MODE
C	TEST CH		
D	TEST CH		
E	CH	25CH	10CH
F	TEST CH		
G	PLL_UNLOCK	NORMAL	TCM420
H	DUMMY_MODE	NORMAL	DUMMY SET


CN1
CN201
MIC
GND
RXDATA
RXPOW
CS
EN
PLLDATA
CLOCK
TXPOW
DECTOUT
EXIN
TXDATA
DUP101
TXOUTVDD
TXIN
RF AMP
TX Signal
TX VCO
120mV
-SPKE
Voice
Data
LED Flashing
Nomal 3.9V
Reset
When pressing Key
High 3.9
Low 0
LCD ON 0
OFF 3.9
ON 3.9
OFF 0
ON 0
OFF 3.5
IC202
IC208
Vref
DE
CP
Q1
Q2
LED210
LED209
LED207
L201
0.68u
D203
R220
47K
R201 100K
R202 330K
C223 K0.1
C301 6.3470
R332 Z0.1
R331 100K
R333 100K
C302 10K
C303 Z0.1
R330 35K
C300 K0.1
R341 12K
R340 15K
R27 18K
R22 27K
R28 8.2K
C225 K1500P
Q2
Q1
3.6
SW201
SW202
SW203
SW204
SW205
SW206
SW207
SW208
SW209
SW210
SW211
SW212
SW213
SW214
SW215
SW216
SW217
SW218
SW219
SW220
SW221
SW222
SW223
SW224
SW225
SW226
SW227
SW228
D209 DA
D208 DB
D213 DE
D212 DF
D207 DC
D206 DD
D211 DG
D210 DH
CP_A
CP_B
CP_C
CP_D
CP_E
CP_F
CP_G
CP_H
CP_I
CP_J
CP_K
CP_Q
CP_R

OPTION

	CONTENTS	OPEN	SHORT
A	TEST/ NORMAL	NORMAL	TEST MODE
B	TEST/ NORMAL	NORMAL	TEST MODE
C	TEST CH		
D	TEST CH		
E	CH	25CH	10CH
F	TEST CH		
G	PLL_UNLOCK	NORMAL	TCM420
H	DUMMY_MODE	NORMAL	DUMMY SET

Vol	48	49
High	3.9	0
Mid	0	3.9
Low	3.9	3.9